# Onan

# Operator's Manual DGEA DGFA DGFB GenSets

# **Diesel Driven**



960-0137

# **Safety Precautions**

Before operating the generator set, read the Operator's Manual and become familiar with it and the equipment. Safe and efficient operation can be achieved only if the equipment is properly operated and maintained. Many accidents are caused by failure to follow fundamental rules and precautions.

The following symbols, found throughout this manual, alert you to potentially dangerous conditions to the operator, service personnel, or the equipment.

A DANGER This symbol warns of immediate hazards which will result in severe personal injury or death.

AWARNING This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.

A CAUTION This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.

# FUEL AND FUMES ARE FLAMMABLE. Fire and explosion can result from improper practices.

- DO NOT fill fuel tanks while engine is running, unless tanks are outside the engine compartment. Fuel contact with hot engine or exhaust is a potential fire hazard.
- DO NOT permit any flame, cigarette, pilot light, spark, or other ignition source near the generator set or fuel tank.
- Fuel lines must be adequately secured and free of leaks.
   Fuel connection at the engine should be made with an approved flexible line. Do not use copper piping on flexible lines as copper will become brittle if continuously vibrated or repeatedly bent.
- Be sure all fuel supplies have a positive shutoff valve.
- Do not smoke while servicing lead acid batteries. Lead acid batteries emit a highly explosive hydrogen gas that can be ignited by electrical arcing or by smoking.

## **EXHAUST GASES ARE DEADLY**

- Provide an adequate exhaust system to properly expel discharged gases. Visually and audibly inspect the exhaust daily for leaks per the maintenance schedule. Ensure that exhaust manifolds are secured and not warped. Do not use exhaust gases to heat a compartment.
- · Be sure the unit is well ventilated.

# MOVING PARTS CAN CAUSE SEVERE PERSONAL INJURY OR DEATH

- Keep your hands, clothing, and jewelry away from moving parts.
- Before starting work on the generator set, disconnect starting batteries, negative (-) cable first. This will prevent accidental starting.
- Make sure that fasteners on the generator set are secure.
   Tighten supports and clamps, keep guards in position over fans, drive belts, etc.

- Do not wear loose clothing or jewelry in the vicinity of moving parts, or while working on electrical equipment. Loose clothing and jewelry can become caught in moving parts.
   Jewelry can short out electrical contacts and cause shock or burning.
- If adjustment must be made while the unit is running, use extreme caution around hot manifolds, moving parts, etc.

# ELECTRICAL SHOCK CAN CAUSE SEVERE PER-SONAL INJURY OR DEATH

- Remove electric power before removing protective shields or touching electrical equipment. Use rubber insulative mats placed on dry wood platforms over floors that are metal or concrete when around electrical equipment. Do not wear damp clothing (particularly wet shoes) or allow skin surface to be damp when handling electrical equipment.
- Use extreme caution when working on electrical components. High voltages can cause injury or death. DO NOT tamper with interlocks.
- Follow all applicable state and local electrical codes. Have all electrical installations performed by a qualified licensed electrician. Tag open switches to avoid accidental closure.
- DO NOT CONNECT GENERATOR SET DIRECTLY TO ANY BUILDING ELECTRICAL SYSTEM. Hazardous voltages can flow from the generator set into the utility line. This creates a potential for electrocution or property damage. Connect only through an approved isolation switch or an approved paralleling device.

## **GENERAL SAFETY PRECAUTIONS**

- Coolants under pressure have a higher boiling point than water. DO NOT open a radiator or heat exchanger pressure cap while the engine is running. Allow the generator set to cool and bleed the system pressure first.
- Benzene and lead, found in some gasoline, have been identified by some state and federal agencies as causing cancer or reproductive toxicity. When checking, draining or adding gasoline, take care not to ingest, breathe the fumes, or contact gasoline.
- Used engine oils have been identified by some state or federal agencies as causing cancer or reproductive toxicity.
   When checking or changing engine oil, take care not to ingest, breathe the fumes, or contact used oil.
- Provide appropriate fire extinguishers and install them in convenient locations. Consult the local fire department for the correct type of extinguisher to use. Do not use foam on electrical fires. Use extinguishers rated ABC by NFPA.
- Make sure that rags are not left on or near the engine.
- Remove all unnecessary grease and oil from the unit. Accumulated grease and oil can cause overheating and engine damage which present a potential fire hazard.
- Keep the generator set and the surrounding area clean and free from obstructions. Remove any debris from the set and keep the floor clean and dry.
- Do not work on this equipment when mentally or physically fatigued, or after consuming any alcohol or drug that makes the operation of equipment unsafe.



# **Table of Contents**

SAFETY PRECAUTIONSINTRODUCTION	
About this Manual	ے
About this manual	?
How to Obtain Service	ے
SPECIFICATIONS	
OPERATION	+ ۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰۰
General	4
Prestart Checks	4
Control Panel	
Control Panel Interior	
Starting	
Stopping	
Break-In	
No-Load Operation	
Exercise Period	
High/Low Operating Temperatures	
Power Rating Factors	
TROUBLESHOOTING	
MAINTENANCE	14
Generator Set Inspection	
Lubrication System	15
Oil and Filter Change	16
Coolant System	
Fuel System	19
Air Cleaner	20
AC Generator	20
Batteries	21
ADJUSTMENTS	
Mechanical Governor	
Flectric Governor	



# Introduction

# **ABOUT THIS MANUAL**

This manual provides general information for operating and maintaining your Onan generator set. Study this manual carefully and observe all warnings and cautions. Using the generator set properly and following a regular maintenance schedule will contribute to longer unit life, better performance, and safer operation.

Included with the generator set literature package is a copy of the Cummins Manual for the engine. In case of conflicting information, the Generator Set Operator's Manual takes precedence over the engine manual.

# **HOW TO OBTAIN SERVICE**

When the generator set requires servicing, contact an Onan Distributor for assistance. Onan factory trained Parts and Service representatives are ready to handle all your service needs.

When contacting an Onan Distributor, always supply the complete Model number and Serial number as shown on the Onan nameplate (Figure 1). The Onan nameplate is located on the side of the generator control box.




FIGURE 1. ONAN NAMEPLATE

# **AWARNING**

INCORRECT SERVICE OR REPLACEMENT OF PARTS CAN RESULT IN SEVERE PERSONAL INJURY, DEATH AND/OR EQUIPMENT DAMAGE. SERVICE PERSONNEL MUST BE QUALIFIED TO PERFORM ELECTRICAL AND MECHANICAL SERVICE.



# **Specifications**

**TABLE 1. SPECIFICATIONS** 

		DGFA
SYSTEMS	DGEA	DGFB
Engine Cummins Diesel Series	6CTA8.3G	6CTA8.3G
Generator Onan 3 Phase 60 Hz UR	125 kW (156 kVA @ 0.8 PF)	150 kW (187.5 kVA @ 0.8 PF)
Onan 3 Phase 50 Hz UR	100 kW (125 kVA @ 0.8 PF)	135 kW (168.8 kVA @ 0.8 PF)
Electrical System Starting Voltage	24 Volts DC	24 Volts DC
Battery	Two, 12-Volt	Two, 12-Volt
Coolant System Capacity (Standard Radiator)	6.75 gallons (26 litres)	6.75 gallons (26 litres)
Lubricating System Oil Type 14°F -10°C) and above -10°F (-23°C) to 14°F (-10°C) Below -10°F (-23°C)	15W40 or 20W40 10W30 5 W (Synthetic Oil)	15W40 or 20W40 10W30 5 W (Synthetic Oil)
Oil Capacity (Filters, lines & Crankcase)	20 quarts (19 litres)	20 quarts (19 litres)



# Operation

# **GENERAL**

This section covers prestart checks, starting and stopping and operating the generator set. Each operator should read through this entire section before attempting to start the set. It is essential that the operator be completely familiar with the set for safe operation.

# PRESTART CHECKS

Before starting, be sure the following checks have been made and the unit is ready for operation. Refer to the *MAINTENANCE* section for the recommended procedures.

#### Lubrication

Check the engine oil level. Keep the oil level near as possible to the dipstick high mark without overfilling.

#### Coolant

Check the engine coolant level. The coolant should be about two inches below the radiator cap opening. Do not check while the engine is hot.

AWARNING Contact with hot coolant can result in serious burns. Do not bleed hot, pressurized coolant from a closed cooling system.

#### Fuel

Make sure the fuel tanks have sufficient fuel and fuel system is primed. See the MAINTENANCE section for recommended fuel.

# **CONTROL PANEL**

The following describes the function and operation of the standard Detector 7 and optional Detector 12 generator set control. All instruments and control switches are located on the face of the control panel as illustrated in Figure 2. The control panel is separated into a DC panel for monitoring the engine and an AC panel for monitoring the generator.

**▲WARNING** 

# **EXHAUST GAS IS DEADLY!**

Exhaust gases contain carbon monoxide, an odorless and colorless gas. Carbon monoxide is poisonous and can cause unconsciousness and death. Symptoms of carbon monoxide poisoning can include:

- Dizziness
- Nausea
- Headache
- Weakness and \$leepiness
- Throbbing in Temples
- Muscular Twitching
- Vomiting
- Inability to Think Coherently

IF YOU OR ANYONE ELSE EXPERIENCE ANY OF THESE SYMPTOMS, GET OUT INTO THE FRESH AIR IMMEDIATELY. If symptoms persist, seek medical attention. Shut down the unit and do not operate until it has been inspected and repaired.

Protection against carbon monoxide inhalation includes proper installation and regular, frequent visual and audible inspections of the complete exhaust system.

1-P/EM






FIGURE 2. DETECTOR 12 CONTROL PANEL

## DC Panel

Panel Lamp: Illuminates control panel.

Oil Pressure Gauge: Indicates pressure of lubricating oil in engine (wired to a sensor unit located on the engine).

Coolant Temperature Gauge: Indicates temperature of circulating coolant in engine (wired to a sensor unit located on the engine).

**DC Voltmeter:** Indicates the battery charging system voltage.

**Run/Stop/Remote Switch:** Starts and stops the unit locally, or from a remote location wired to the control engine monitor board.

**Running Time Meter:** Registers the total number of hours the unit has run. Use it to keep a record of periodic servicing. Time is cumulative; meter cannot be reset.

Reset/Lamp Test/Panel Lamp Switch: Resets the fault circuit only when the Run/Stop/Remote switch is in the Stop (Reset) position. Tests fault lamps and turns on the control panel lamp.

**Tachometer (Optional):** Provides constant monitoring of engine r/min.

**Speed Adjusting Rheostat (Optional):** Used in conjunction with an optional electronic governor to adjust engine speed.

Oil Temperature Gauge (Optional): Indicates temperature of lubricating oil in engine (wired to a sensor unit located on the engine).

**Emergency Stop Button (Optional):** Push-in switch for emergency shut down of the engine.

**Detector 7-Indicator Lamps:** The standard control panel has seven indicator lamps which are described as follows:

- RUN (green) lamp comes on when both starter circuits are opened after unit starting.
- PRE LO OIL PRES (yellow) indicates engine oil pressure is marginally low.
- PRE HI ENG TEMP (yellow) indicates engine temper-
- a ture is marginally high.
- LO OIL PRES (red) indicates engine has shut down because of critically low oil pressure.
- HI ENG TEMP (red) indicates engine has shut down because of critically high temperature.
- OVERSPEED (red) indicates engine has shut down because of excessive speed.
- OVERCRANK (red) indicates engine has shut down because of a failure to start during the cranking period.



**Detector 12-Indicator Lamps:** The optional twelvelamp control version included all features of the sevenlamp version plus the following:

- FAULT 1 (red) an undedicated fault. May be factory programmed as a shutdown or non-shutdown, and as a timed or non-timed fault. (Normally set for timed shutdown).
- FAULT 2 (red) Same features as Fault 1 (Normally set for timed shutdown).
- LOW ENG TEMP (yellow) engine temperature is marginaly low for starting. Indicates inoperative coolant heater.
- LO FUEL (yellow) indicates fuel supply is marginally low.
- SWITCH OFF (flashing red) indicates generator set is not in automatic start operation mode.

ACAUTION Yellow lamps indicate potential problems that could damage the genset. Refer to Troubleshooting, Table 2.

## **AC Panel**

AC Voltmeter (Optional): Dual range instrument indicating AC voltage. Measurement range in use shown on indicator light.

AC Ammeter (Optional): Dual range instrument indicates AC generator line current.

**Wattmeter (Optional):** Continuously gives reading of the generator output in kilowatts.

**Power Factor Meter (Optional):** Indicates percent power factor of AC output.

Frequency Meter (Optional): Indicates generator output frequency in hertz. It can be used to check engine speed (each hertz equals 30 r/min).

**Voltage Adjusting Rheostat (Optional):** Provides approximately plus or minus five percent adjustment of the rated output voltage.

Upper and Lower Scale Indicator Lamps (Optional): Indicates which scale to use on the AC voltmeter and ammeter.

**Phase Selector Switch (Optional):** Selects phases of generator output to be measured by AC voltmeter and AC ammeter.

**Engine Pyrometers (Optional):** Indicate engine exhaust and inlet air temperatures.

**Field Breaker:** Provides generator exciter and regulator protection from overheating in the event of certain failure modes of generator, exciter and voltage regulator.

# **CONTROL PANEL INTERIOR**

# **Generator AC Voltage Regulator**

The solid-state regulator (VRAS-2) controls AC output voltage from the generator at a predetermined level regardless of load. Voltage regulation is plus or minus two percent from no load to full load. Random voltage variation is plus or minus one percent for constant loads.

# **Engine Control Module**

Electronic and relay components of the engine monitoring circuit are on a circuit board assembly. Sensor inputs (Figure 4) are connected by the wiring harness to plug connectors on the board. The control module shuts down the engine under any of the following conditions.

- Overcrank Limits engine cranking to 75 seconds. If engine fails to start, the module lights a fault lamp and opens the cranking circuit. The cycle cranking option allows three 15-second cranking cycles with two 15-second rest periods on the 12-lamp control.
- Overspeed Shuts down the engine immediately if overspeed occurs and lights a fault lamp. The sensor switch is mounted in the end bell on the generator shaft. It is factory adjusted to shut down 60 hertz units at 2100 ± 90 r/min, 50 hertz units at 1850 ± 50 r/min.
- Low Oil Pressure Shuts down the engine immediately if oil pressure drops below 14 psi (97 kPa) and lights a fault lamp. The fault is time-delayed about 10 seconds following starter disconnect and inhibited during cranking. The delay allows oil pressure to rise to normal before the electronic control module monitors this system.

A pre-low oil pressure sensor and lamp provides an alarm that oil pressure is marginally low, 20 psi (137 kPa) or less. The cause should be found and corrected as soon as possible.

High Engine Temperature - shuts down the engine immediately if coolant temperature rises above 230°F (110°C) and lights a fault lamp. The fault is time-delayed about 10 seconds following starter disconnect and inhibited during cranking. This delay allows coolant in a hot engine time to circulate and return the water jacket to normal before the electronic control module monitors this system.

A pre-high engine temperature sensor and lamp provides an alarm that engine temperature is marginally high, 220°F (105°C). The cause should be found and corrected as soon as possible.






FIGURE 3. CONTROL PANEL INTERIOR

The high engine temperature shutdown system will not operate if the coolant level is too low. The high engine temperature sensor monitors coolant temperature. Loss of coolant will prevent sensor operation and allow the engine to overheat causing severe damage to the engine. Therefore, maintain adequate coolant level for proper operation of the high engine temperature shutdown system.

Low Coolant Level Shutdown (Optional) - A submerged sensor in the top portion of the radiator shuts down the engine and lights the Hi Engine Temp fault lamp when the coolant level falls below the level of the sensor.

## STARTING

The following sections cover the three systems used to start the generator set.

# **Starting at Control Panel**

Move the Run-Stop-Remote switch on the DC panel (Figure 2) to the RUN position. This will activate the engine control system and the starting system. The starter will begin cranking and after a few seconds the engine should start. The starter will disconnect when the engine reaches a speed of 450 to 570 r/min.

If the engine does not start, the starter will disengage after a specified period of time and the control will indicate an overcrank fault. Generator sets with the standard overcrank control will crank continuously for up to 75 seconds before disengaging the starter. Generator sets with the cycle cranking option will crank for 15 seconds and then stop for 15 seconds until 3 cycles have been completed. To clear an overcrank fault, place the Run-Stop-Remote switch in the STOP position and momentarily depress the Reset switch. Wait two minutes for the starter motor to cool and then repeat the starting procedure. If the engine does not run after a second attempt at starting, refer to the Troubleshooting section.



# **Starting From Remote Location**

Move the Run/Stop/Remote switch on the generator set DC panel to the REMOTE position. This allows the generator set to be started from a remote switch. Closing the remote switch initiates the starting sequence described in the previous section.

# **Automatic Starting**

Place the Run/Stop/Remote switch on the generator set DC panel in the REMOTE position if an automatic transfer switch is used. This allows the transfer switch to start the generator set if a power outage occurs and stop it when the power returns.

# **STOPPING**

# **Before Stopping**

Run the generator set at no load for three to five minutes before stopping. This allows the lubricating oil and engine coolant to carry heat away from the combustion chamber and bearings.

# To Stop

If the set was started at the set control panel or at a remote control panel, move the Run/Stop/Remote switch or remote starting switch to the STOP position. If the set was started by an automatic transfer switch, the set will automatically stop about 15 minutes after the normal power source returns.

# **BREAK-IN**

Drain and replace the crankcase oil after the first 50 hours of operation on new generator sets. Refer to the MAINTENANCE section of this manual for the recommended procedures.

## NO-LOAD OPERATION

Periods of no load operation should be held to a minimum. If it is necessary to keep the engine running for long periods of time when no electric output is required, best engine performance will be obtained by connecting a "dummy" electrical load. Such a load could consist of heater element, etc.

# **EXERCISE PERIOD**

Generator sets on continuous standby must be able to go from a cold start to being fully operational in a matter of seconds. This can impose a severe burden on engine parts.

Regular exercising keeps engine parts lubricated, prevents oxidation of electrical contacts and in general helps provide reliable engine starting. Exercise the generator set at least once a week for a minimum of 30 minutes with load so the engine reaches normal operating temperatures.

Onan automatic transfer switches have as an option an exerciser that can be preset to provide regular exercise periods. Typically the exerciser can be set for time of start, length of run, and day of week.

# **HIGH/LOW OPERATING TEMPERATURES**

Use a coolant heater if a separate source of power is available. The optional heater available from Onan will help provide reliable starting under adverse weather conditions. Be sure the voltage of the separate power source is correct for the heater element rating.

ACAUTION

To avoid damage to heater, be sure the cooling system is full before applying power to the heater.

# **POWER RATING FACTORS**

The generator set power rating applies to sets used in standby applications. The set will operate at the stated rating for the duration of normal utility power interruptions. The rating was established for a standard radiator cooled set running on diesel fuel and operating at an altitude of 300 feet (92 m) with an ambient temperature of 81°F (27°C). For a rating relative to other applications, altitudes, cooling systems, or ambient temperatures, contact an authorized Onan Distributor.



# **Troubleshooting**

The generator set has a number of sensor units (Figure 4) that continuously monitor the engine for abnormal conditions such as low oil pressure or high coolant temperature. If an abnormal condition does occur, the engine monitor will activate a fault lamp and may also stop the engine depending on the condition. If the generator set does shut down, the operator may be able to restart the set after making certain adjustments or corrections. This section describes the operation of the fault condition system and suggested troubleshooting (Table 2) procedures for the operator.

The standard seven light control has a single green light to indicate RUN, two amber pre-fault lights and four red fault lights. The optional twelve light control has a single green light to indicate RUN, four amber lights and seven red fault lights. Both controls also have a terminal connection for an audible alarm which will sound when a fault occurs.

# **Safety Considerations**

High voltages are present within the control box and generator output box when the generator is running. Do not open the control box or generator output box while set is running.

AWARNING Contacting high voltage components can cause serious personal injury or death. Keep control and output box covers in place during troubleshooting.

Generator set installations are normally designed for automatic starting or remote starting. When troubleshooting a set that is shut down, make certain the generator set cannot be accidentally restarted. Place the Run/Stop/Remote switch in the STOP position and remove the negative battery cable from the set starting battery.

AWARNING Accidental starting of the generator set during troubleshooting can cause severe personal injury or death. Disable the generator set before troubleshooting.

When a fault comes on during operation, follow the procedures in Table 2 to locate and correct the problem. For any symptom not listed, contact an Onan Distributor for service.

# **Resetting the Control**

The external alarm and fault lamp can be deactivated by placing the Run/Stop/Remote switch in the Stop position and pressing the Reset/Lamp Test switch. Locate the problem and make the necessary corrections before restarting the generator set. While pressing the Reset/Lamp Test switch, observe that all lamps light.

# Line Circuit Breaker (Optional)

The optional line circuit breaker mounts on the generator output box. If the load exceeds the generator current rating, the line circuit breaker will open to prevent the generator from being overloaded. If the circuit breaker trips, locate the source of the overload and correct as required. Manually reset the breaker to reconnect the load to the generator.






FIGURE 4. ENGINE SENSORS



# **TABLE 2. TROUBLESHOOTING**

**AWARNING**Many troubleshooting procedures present hazards which can result in severe personal injury or death. Only qualified service personnel with knowledge of fuels, electricity, and machinery hazards should perform service procedures. Review safety precautions on inside cover page.

SYMPTOM	CORRECTIVE ACTION
Green RUN lamp lights following engine start-up.	Indicates all engine systems are normal. No corrective action required.
PRE HI ENGINE TEMP lamp lights. Engine continues to operate.	<ol> <li>Indicates engine has begun to overheat and engine temperature has risen to approximately 220°F (105°C). If generator is powering non-critical and critical loads and cannot be shutdown, use the following:         <ol> <li>Reduce load if possible by turning off non-critical loads.</li> <li>Check air inlets and outlets and remove any obstructions to airflow.</li> <li>Open doors or windows in generator area to increase ventilation.</li> <li>If engine can be stopped, follow procedure in step 3.</li> </ol> </li> </ol>
HI ENG TEMP lamp lights. Engine shuts down.	3. Indicates engine has overheated (engine temperature has risen above 230°F/110°C) or coolant level is low (sets with coolant level sensor).  Allow engine to cool down completely before proceeding with the following checks:  a. Check coolant level and replenish if low.  Look for possible coolant leakage points and repair
	<ul><li>if necessary.</li><li>b. Check for obstructions to cooling airflow and correct as necessary.</li></ul>
	c. Check for a slipping fan belt and tighten if loose.
	<ul> <li>d. Reset control and restart after locating and correcting problem. Contact an Onan Dealer or Distributor if none of the above.</li> </ul>
PRE LO OIL PRES lamp lights. Engine continues to operate.	4. Indicates engine oil pressure has dropped to 20 psi (138 kPa). If generator is powering critical loads and cannot be shut down, wait until next shutdown period and then follow step 5 procedure. If engine can be stopped, follow procedures in step 5.
5. LO OIL PRES lamp lights. Engine shuts down NOTE: See also step 6.	5. Indicates engine oil pressure has dropped to 14 psi (97 kPa). Check oil level, lines and filters. If oil system is okay but oil level is low, replenish. Reset control and restart. Contact an Onan Dealer or Distributor if oil pressure is not in the range of 35 to 55 psi (241 to 379 kPa).



# **TABLE 2. TROUBLESHOOTING (Continued)**

**AWARNING**Many troubleshooting procedures present hazards which can result in severe personal injury or death. Only qualified service personnel will knowledge of fuels, electricity, and machinery hazards should perform service procedures. Review safety precautions on inside cover page.

SYMPTOM	CORRECTIVE ACTION
OVERCRANK lamp lights and engine stops cranking.      or     Engine runs, shuts down, and LO OIL PRES lamp lights.	Indicates possible fuel system problem.     a. Check for empty fuel tank, fuel leaks, or plugged fuel lines and correct as required.     b. Check for dirty fuel filter and replace if necessary (see MAINTENANCE section).     c. Check for dirty or plugged air filter and
	replace if necessary (see MAINTENANCE section).
	<ul> <li>d. Refer to Step 5.</li> <li>e. Reset the control and restart after correcting the problem. Contact an Onan Dealer or Distributor for service if none of the above.</li> </ul>
Engine runs and then shuts down,     OVERSPEED lamp lights.	Indicates engine has exceeded normal operating speed. Contact an Onan Dealer or Distributor for service.
8. SWITCH OFF lamp flashes.	8. Indicates Run/Stop/Remote switch is in the Stop position which will prevent automatic starting if an automatic transfer switch is used. Move the Run/Stop/Remote switch to the Remote position for automatic starting.
LO FUEL lamp lights. Engine continues to run.	Indicates diesel fuel supply is     running low. Check fuel supply and     replenish as required.
LO FUEL lamp lights.     Engine shuts down and LO OIL PRES lamp lights.	Indicates engine has run out of fuel.     Check fuel level and replenish     as required.
*11. LO ENG TEMP lamp lights. Set is in standby mode but is not operating.  (Lamp lights when engine coolant temperature is 70°F (21°C) or lower. Since the lamp goes out after the engine warms up, there should be no cause for alarm even during initial generator set operation.)	<ul> <li>11. Indicates engine coolant heater is not operating or is not circulating coolant. Check for the following conditions: <ul> <li>a. Coolant heater not connected to power supply. Check for blown fuse or disconnected heater cord and correct as required.</li> <li>b. Check for low coolant level and replenish if required. Look for possible coolant leakage points and repair as required.</li> <li>c. Contact an Onan Dealer or Distributor</li> </ul> </li> </ul>

<sup>\*12-</sup>Light Panel Only.



# **TABLE 2. TROUBLESHOOTING (Continued)**

**AWARNING**Many troubleshooting procedures present hazards which can result in severe personal injury or death. Only qualified service personnel with knowledge of fuels, electricity, and machinery hazards should perform service procedures. Review safety precautions on inside cover page.

SYMPTOM	CORRECTIVE ACTION
*12. The FAULT 1 or FAULT 2 fault lamp lights. Engine shuts down immediately, engine runs for several seconds and then shuts down, or engine continues to run.	12. The standard undesignated fault functions are programmed to shut down the set when a fault is sensed. Fault 1 is time delayed while Fault 2 is immediate. The nature of the fault is an optional selection that is determined when the set installation is designed. The undesignated fault functions may also be programmed for non-shutdown or non-time delay.
Fault lamp lights but no fault exists. Engine gauges show oil pressure, engine temperature, and frequency (speed) are within normal limits.	The monitor board or a sensor may be at fault.     Contact an Onan Dealer or Distributor for service.
<ol> <li>Engine starts from generator control panel but will not start automatically or from a remote panel. (Note: The Run/Stop/Remote switch must be in the Remote position for automatic or remote starting).</li> </ol>	Remote circuit breaker is tripped, Reset breaker and restart. Contact an Onan Dealer or Distributor if breaker trips after resetting.
15. Engine will not crank.	Indicates possible fault with control or starting system. Check for the following conditions:     a. Fault lamp on. Correct fault and reset control.     b. Poor battery cable connections. Clean the
	<ul> <li>battery cable terminals and tighten all connections.</li> <li>c. Discharged or defective battery. Recharge or replace the battery.</li> </ul>
	d. Contact an Onan Dealer or Distributor for assistance if none of the above.
16. No AC output voltage.	Field breaker is tripped. Reset breaker.     Contact an Onan Dealer or Distributor if voltage build up causes breaker to trip.
17. Green RUN lamp does not light following engine start-up.	Indicates possible Start/Disconnect relay failure. Contact an Onan Dealer or Distributor for assistance.

<sup>\* - 12-</sup>Light Panel Only.



# **Maintenance**

Establish and adhere to a definite schedule for maintenance and service based on the application and severity of the environment. The table below covers the recommended service intervals for a generator set on STANDBY service. If the set will be subjected to extreme operating conditions, the service intervals should be reduced accordingly. Some of the factors that can affect the maintenance schedule are the following:

- Use for continuous duty (prime power)
- · Extremes in ambient temperature
- Exposure to elements
- Exposure to salt water
- Exposure to windblown dust or sand.

Consult with an authorized Onan Distributor if the generator set will be subjected to any extreme operating conditions and determine a suitable schedule of maintenance. Use the running time meter to keep an accurate log of all service performed for warranty support. Perform all service at the time period indicated or after the number of operating hours indicated, whichever comes first. Use Table 3 to determine the maintenance required and then refer to the sections that follow for the correct service procedures.

AWARNING Accidental starting of the set can cause severe personal injury or death. Disconnect the battery cables (ground cable first) when repairs are made to the engine, controls, or generator.

# **TABLE 3. MAINTENANCE SCHEDULE**

	SERVICE TIME				
MAINTENANCE CHECKS	Daily or after 8 hours	Weekly or after 50 hours	Monthly or after 100 hours	3 Months or after 250 hours	6 Months or after 500 hours
Inspect Set	X <sup>1</sup>				
Check Coolant Heater	x	}			
Check Oil Level	х				
Check Coolant Level	x				
Drain Water from Fuel Filter	X <sup>4</sup>				
Check Air Cleaner (clean if required)		X <sup>2</sup>			
Check Battery Charging System		х			
Drain Water and Sediment from Fuel Tanks		X <sup>4</sup>			
Check Anti-freeze and DCA Concentration			х		
Check Drive Belt Tension			х <sup>3</sup>		
Check Fuel Level			×		
Drain Exhaust Condensate Trap			×		
Check Battery Level and Specific Gravity			×		
Check Generator Air Outlet			×		
Clean Generator Assembly				×	
Change Crankcase Oil and Filter				X <sup>2</sup>	
Check Heat Exchanger Plugs (if equipped)				x	
Check Governor Adjustment				x	
Change Air Cleaner Element					X <sup>2</sup>
Change Fuel Filters					х
Clean Cooling System					x
Adjust Valve Lash		A	fter 1000 hour	'S <sup>5</sup>	

<sup>1 -</sup> Check for oil, fuel, cooling, and exhaust system leaks. Check exhaust system audibly and visually with set running. Shut unit down and repair any leaks immediately.

2 - Perform more often in extremely dusty conditions.

3 - Visually check belts for evidence of slippage.

4 - Drain 1 cup or more of fuel to remove water and sediment.

5 - Contact an authorized service center for service.



# GENERATOR SET INSPECTION

During operation, be alert for mechanical problems that could create unsafe or hazardous conditions. The following sections cover several areas that should be frequently inspected for continued safe operation.

# **Exhaust System**

With the generator set operating, inspect the entire exhaust system visually and audibly, including the exhaust manifold, turbocharger, muffler, and exhaust pipe. Check for leaks at all connections, welds, gaskets, and joints and also make sure that exhaust pipes are not heating surrounding areas excessively. If any leaks are detected, shut down the generator set and have leaks corrected immediately.

AWARNING result in serious personal injury or Inhalation of exhaust gases can death. Be sure deadly exhaust gas is piped outside and away from windows, doors or other inlets to building.

# Fuel System

With the generator set operating, inspect the fuel supply lines, return lines, filters, and fittings for leaks. Check any flexible sections for cuts, cracks and abrasions and make sure they are not rubbing against anything that could cause breakage. If any leaks are detected, have them corrected immediately.

Ignition of fuel can cause serious AWARNING personal injury or death by fire or explosion. Do not permit any flame, cigarette, pilot light spark, or other ignition source near the fuel system.

# **AC Electric System**

Check the following while the generator set is operating: otherwise measure load lines L1, L2, and L3 using the appropriate AC meter.

Frequency Meter: The generator frequency should be stable and the reading should be the same as the nameplate rating.

AC Voltmeter: Turn the phase selector switch to each line-to-line phase selection shown on the volts scale (L1-L2, L2-L3, and L3-L1). Read the AC voltmeter using the upper or lower scale as indicated by the scale indicator light. At no load, the line-to-line voltage(s) should be the same as the set nameplate rating.

AC Ammeter: Turn the phase selector switch to each phase selection shown on the amps scale (L1, L2, and L3). Read the ammeter using the upper or lower scale as indicated by the scale indicator light. At no load, the current readings should be zero. With a load applied, each line current should be about the same.

Fault Lamps: Push the Reset/Lamp switch on the control panel. All indicator lamps should light. Verify that all of the bulbs are on and then release the switch. Replace any bulbs that are burned out.

# **DC Electrical System**

Check the terminals on the battery for clean and tight connections. Loose or corroded connections create resistance which can hinder starting. Clean and reconnect the battery cables if loose. Always disconnect both ends of the negative battery cable. Reconnect one end of the cable to the negative battery terminal and the other end to ground. Following this sequence will help to reduce arcing at the battery.

**▲WARNING** 

Ignition of explosive battery gases can cause severe personal injury. Do not smoke while servicing batteries.

**▲WARNING** 

Accidental starting of the generator set can cause severe personal injury or death. Place the control switch in STOP position and disconnect the negative (-) battery cable before inspecting generator set.

With the generator set stopped, check for loose belts and fittings, leaking gaskets and hoses, or any signs of mechanical damage. If any problems are found, have them corrected immediately. With the set running, listen for any unusual noises that may indicate mechanical problems and check the oil pressure frequently. Investigate anything that indicates possible mechanical problems.

# **LUBRICATION SYSTEM**

The engine lubrication system must be primed and filled with oil of the recommended classification and viscosity. Refer to the SPECIFICATIONS section for the lubricating oil capacity.

## Oil API Classification

The lubricating oil recommended for turbocharged diesel engines is API (American Petroleum Institute) Class CC/CD with a maximum sulphated ash content of 1.85 percent. Oils in this class satisfy the engine manufacturer's recommendations for satisfactory operation under most conditions. A book entitled "Lubricating Oils Data Book" is available from EMA (Engine Manufacturers Association) that lists the commercially available oils by brand name and the corresponding API classification. Once an oil is selected, do not mix it with oils of another classification or brand.

# Oil Viscosity

The viscosity of an oil is a measure of its resistance to flow at certain specified temperatures. Oils that can meet both low (0°F or -18°C) and high (212°F or 100°C) temperature flow requirements are labeled as multigrade or multiviscosity oils. Multigrade oils that meet the API classification requirements are recommended for use in the engine by the engine manufacturer. The use of a multigrade oil will improve oil control, improve engine cranking in cold weather, maintain adequate lubrication, and can also contribute to improved fuel economy.



Table 4 shows the oil viscosity grades that are recommended for various ambient temperatures. Use only the viscosity grades shown in the table. The engine manufacturer does not recommend the use of a single grade oil.

**TABLE 4** 

AMBIENT TEMPERATURE	SAE VISCOSITY GRADE
-10°F (-23°C) and below	See following section
-10°F (-23°C) to 14°F (-10°C)	10W-30
14°F (-10°C) and above	15W-40
32°F (0°C) and above	20W-40

When selecting the oil viscosity, pick the grade that is right for the lowest temperature expected. Oil that is too thick may result in a lack of lubrication when the engine is started. Use a lower grade of oil as the ambient temperature reaches the lower end of the scale.

# Oil Viscosity for Extreme Cold

The engine manufacturer recommends using a *synthetic* lubricating oil when the ambient temperature is consistently below -10° *F* (-23°C) and there is no provision to keep the engine warm. Use an SAE5W grade *synthetic* oil provided it meets the following requirements:

- API class CC/CD
- Sulphated ash content does not exceed 1.85 percent.
- Pour point is 9°F (5°C) below the lowest expected temperature (minimum).
- Viscosity is 10,000 mPa●s (maximum) at -31°F (-35°C) and 4.1 mm²/s (minimum) at 212°F (100°C).


Do not use a petroleum base 5W grade oil for extreme cold since it usually will not perform satisfactorily.

# **Engine Oil Level**

Check the engine oil level during engine shutdown periods at the intervals specified in the Maintenance Table. The oil filter location is shown in Figure 5. The dipstick is stamped with high and low marks to indicate the level of oil in the crankcase. For accurate readings, shut off the engine and wait approximately 15 minutes before checking the oil level. This allows oil in the upper portion of the engine to drain back into the crankcase. The dipstick and oil fill are located on the same side of the engine as shown in Figure 6.

AWARNING Crankcase pressure can blow out hot oil and cause serious burns. Do NOT check oil while the generator set is operating.

Keep the oil level as near as possible to the high mark on the dipstick. Remove the oil fill cap (see Figure 5) and add oil of the same API and brand when necessary.




LS-1174

FIGURE 5. OIL FILTER

ACAUTION

Do not operate the engine with the oil level below the low mark or above the high mark. Overfilling can cause foaming or aeration of the oil while operation below the low mark may cause loss of oil pressure.



FS-1764-1

FIGURE 6. OIL FILL AND DIPSTICK LOCATIONS

# **OIL AND FILTER CHANGE**

Change the oil and filter at the intervals recommended in the maintenance table. Use oil that meets the engine manufacturer's API Classification and viscosity requirements.



# **Engine Oil Change**

- Bring the engine up to operating temperature and then shut it off.
- Open the drain valve and collect the engine oil in a pan. When the crankcase is drained close the drain valve.
- 3. Fill the crankcase to the full mark on the dipstick. Allow for oil filters when drained or if changed.
- 4. Start the engine and check for oil leaks.
- 5. Shut off the engine and wait 15 minutes before checking the oil level. Add oil if required.

AWARNING Crankcase pressure can blow out hot oil and cause serious burns. Do NOT check oil while the generator set is operating.

# Oil Filter Change

Replace the oil filter every time the oil is changed.

- 1. Clean around the filter head.
- 2. Using a filter wrench, remove the oil filter.
- Fill the filter with clean oil as recommended in Table
- 4. Apply a light film of lubricating oil to the gasket sealing surface before installing the filter.
- Install the filter until hand tight then turn an additional 1/2 turn.
- Start engine to verify that filter is tight and does not leak.

# **COOLANT SYSTEM**

The coolant system must be refilled (radiator and heat exchanger) before being operated. The cooling system capacity of the standard unit with set mounted radiator is shown in the SPECIFICATIONS section.

The heater must not be operated while the cooling system is empty or when the engine is running or damage to the heater will occur.

# **Coolant Level**

Check the coolant level during shutdown periods at the intervals specified in the Maintenance Table. Remove the radiator cap after allowing the engine to cool and if necessary, add coolant until the level is near the top of the radiator. Use a coolant solution that meets the engine manufacturer's coolant requirements.

AWARNING

Contact with hot coolant can result in serious burns. Allow cooling system to cool before releasing pressure and removing radiator cap.

ACAUTION High Engine Temperature Cutoff will shut down engine in an overheat condition only if coolant is sufficiently high to physically contact shutdown switch. Loss of coolant will allow engine to overheat without protection of shutdown device and cause severe damage to the engine. It is therefore imperative that adequate coolant levels be maintained to provide operational integrity of the cooling system and for engine coolant overheat shutdown protection.

# Coolant Requirements

The water used for engine coolant should be clean, low in mineral content, and free of any corrosive chemicals such as chloride, sulphate, or acid. Generally, any water that is suitable for drinking can be treated for use as engine coolant.

Cooling systems that are subject to freezing conditions must also be protected with a permanent type antifreeze. Mix the water and antifreeze in the proportion recommended by the supplier for the lowest expected ambient temperature. Do not use an antifreeze that contains anti-leak additives.

AWARNING Contact with hot coolant can result in serious burns. Do not bleed hot, pressurized coolant from a closed cooling system.

# Filling the Cooling System (Standard Radiator and Heat Exchanger Sets)

Remove the cooling system pressure cap and fill the system with water or a water/antifreeze mixture.

When the engine is first started, remove the pressure cap and monitor the coolant level. As trapped air is expelled from the system, the coolant level will drop and additional coolant should be added. Replace the pressure cap when the coolant level is stable.

ACAUTION

Be sure the electric solenoid valve used with city water cooled sets is open before initial starting of unit to allow coolant chambers to fill. Otherwise overheating and damage to the engine can result.

# Flushing and Cleaning

The cooling system must be clean and free of rust and scale if it is to perform properly. Use only coolant that meets the engine manufacturer's requirements.

Chemical Cleaning: Thoroughly clean the cooling system if rust and scale have collected on the engine water jacket or in the radiator. Rust and scale slow down heat absorption and can block the coolant flow. Use a good cooling system cleaner such as sodium bisulphate or oxalic acid and follow the instructions provided by the supplier. Follow up by neutralizing and flushing with clean water.



Flushing: Flush the radiator and block after cleaning or before refilling the system with new coolant. Open the upper and lower radiator hose connections and install the radiator cap. Attach a flushing gun nozzle to the lower radiator hose connection and let the water run until the radiator is full. When full, gradually apply air pressure to avoid damaging the core.

ACAUTION Excessive air pressure while starting the water flow could split the radiator core. Apply air pressure gradually to avoid damage.

Shut off the air and allow the radiator to refill. Repeat flushing procedure until the water coming from the radiator is clean.


To flush the engine block, first remove the thermostat to allow the water to fill the block. Attach the flushing gun

to the upper radiator hose and fill the block with water. Restrict the lower radiator hose opening until the block is filled. Apply air pressure and force water from the lower opening. Repeat until the water coming from lower radiator hose is clean.

Replace the thermostat and all hoses and refill cooling system.

# **Heat Exchanger Plugs**

Check the zinc plugs in the heat exchanger and replace if they are eroded to less than half their original length. The frequency of replacement is dependent on the chemical reaction that occurs when the plugs are in contact with the raw water.



CS-1320-1

FIGURE 7. COOLANT HEATER



# **FUEL SYSTEM**

The engine has been primarily designed to operate on No. 2 diesel fuels since such fuels have a higher energy content and are generally lower in cost. The engine will also operate satisfactorily on No. 1 fuel or other similar fuels if they meet certain specifications. Consult the engine manufacturer for the specific requirements if using a non-standard fuel.

# **Fuel Handling Precautions**

Take appropriate precautions to prevent the entrance of dirt, water, or other contaminants into the fuel system. Filter or strain the fuel as the tank is filled.

AWARNING Ignition of fuel can cause serious personal injury or death by fire or explosion. Do not permit any flame, cigarette, pilot light spark, or other igniter near the fuel system.

To avoid condensation problems, keep fuel supply tanks as full as possible by filling up each time the engine is used. In cold weather, warm fuel returning from the injectors heats the fuel in the supply tank. If the fuel level is low, the upper portion of the tank tends to form condensation. In warm weather, both the fuel and the tank will be warm during the daytime. At night, cool air tends to lower the temperature of the tank more rapidly than the temperature of the fuel. If the fuel level is low, the upper portion of the tank will cool more rapidly and tend to form condensation.

Condensation (water) can cause clogging of fuel filters as well as freezing problems. In addition, water mixing with the sulphur in the fuel forms acid which can corrode and damage engine parts.

## **Fuel Filters**

The filters (see Figure 8) are spin-off throw-away units. A water drain is situated at the bottom of one filter case. This should be used to drain off moisture either daily or at the end of every exercise period, depending on unit application. Fill the new filters with diesel fuel and put a light coat of fuel on the sealing gasket. Install and tighten by hand until the gasket just touches the filter head. Tighten an additional one-half to three-fourths of a turn. The fuel system will need bleeding if:

- The fuel filters are not filled prior to installation.
- The injection pump is replaced.
- High pressure fuel lines are replaced.

Refer to Cummins Operation Manual.




FIGURE 8. FUEL FILTERS



# **AIR CLEANER**

The filter element should be replaced yearly or sooner if the service indicator button pops up indicating air restriction.

The vacuator valve dumps collected dust automatically.


The following procedure should be followed when replacing the element:

- Remove the air cleaner cover.
- 2. Remove thumb screw and gasket washer, then remove the element from air cleaner.
- Wipe out the interior of the air cleaner housing and cover with a clean, damp cloth.
- Install new element and secure with gasket washer and thumb screw.
- 5. Put on the air cleaner cover and secure.

On some housed units it will be necessary to loosen the air cleaner bands and move the air cleaner to access the element.

Inspect all components of the air filtering system including all ducts and hoses. Verify that all connections and clamps are tight and inspect each component for cracks, dents, or other damage. Repair or service as required.

ACAUTION Filters should be handled with care to prevent damage. If the filter does become damaged, install recommended replacement part.



#### M-1738

# FIGURE 9. AIR CLEANER

## **AC GENERATOR**

#### General

These generators require very little servicing. Periodic inspections, to coincide with engine oil changes, will help to provide good performance.

Remove the grill section and inspect the rotating rectifier assembly to make sure the diodes (see Figure 10) are free of dust, dirt, and grease. Excessive foreign matter on these diodes and heat sinks will cause the diodes to overheat and will result in their failure. Blow out the assembly periodically with filtered low pressure air.

Check generator voltage. It may be necessary to make a slight readjustment to obtain the preferred voltage at average load. Refer to Installation manual for adjustment procedure.

# **Generator Bearing**

Have the bearing inspected for wear every 1000 hours by an Onan Distributor. If the unit is used for "prime power," have the bearing replaced every 10,000 hours or after two years. If the unit is used for "standby power," have the bearing replaced every five years.




FIGURE 10. RECTIFIER ASSEMBLY

# **BATTERIES**

Check the condition of the starting batteries (see Figure 11) at the interval specified in the Maintenance Table. See that connections are clean and tight. A light coating of non-conductive grease will retard corrosion at terminals. Keep the electrolyte at the proper level above the plates by adding distilled water. Check specific gravity using a hydrometer and recharge if below 1.260.

AWARNING Ignition of explosive battery gases can cause severe personal injury. Do not smoke. Wear goggles and protective, rubber gloves and apron when servicing batteries.




FIGURE 11. CHECKING BATTERY



# Adjustments

# **MECHANICAL GOVERNOR ADJUSTMENTS**

At engine running-time intervals of 250 hours, check governor performance. Droop\* should be within 5%, and the governor should not hunt\*\*. Output frequency limits within specified droop are as follows:

Nominal (Full-Load) Hz	Maximum (No-Load) Hz
50	52.5
60	63

Using an accurate frequency meter, measure frequency under no-load, partial-load (if possible) and full-load. Observe droop and hunt. If necessary, make the following adjustments:

- Refer to Figure 12. Adjust the throttle lever (1) if the nominal, full-load frequency is not correct. To do this, first back-off the throttle set screw (2) and then readjust the throttle stop screw (3) to position the throttle lever for the correct frequency. Tighten the throttle set screw (2) and the lock nuts if no further adjustments are necessary.
- 2. If droop is greater than specified, loosen the locknut for the bumper spring screw (4) and back-out the screw in quarter-turn increments until the droop is within specifications. Note the number of turns the screw was backed out. Check for hunt at various loads. If the governor does not hunt, further adjustments are not necessary and the locknut should be tightened. If the adjustment results in hunting, turn the screw clockwise in quarter-turn increments until hunting stops. Then tighten the locknut. If the bumper spring screw does not afford enough adjustment for droop or hunt go to Step 3.
- If excessive droop or hunt persist, it will be necessary to adjust the governor spring lever arm screw inside the governor housing. Follow the steps below to make adjustments:
  - A. Remove the screw access plug (5).
  - B. To align the screw with the access opening allow the throttle lever to rotate clockwise by fully backing-off the throttle set screw (2) and the idle adjustment screw (6).

- C. For Model DGEA genset governors use a flatbladed screwdriver, and for Model DGFA genset governors use a 3/16 inch ball point driver (Onan Part Number 420-0342) to turn the screw
- D. The screw "clicks" every quarter turn. Turn the screw clockwise and count the number of "clicks" until it bottoms. Write the number down. Turn the screw out (counterclockwise) the same number of clicks to return the adjustment to the original position.

If the problem is too much droop, turn the screw clockwise one "click" and check for droop. Continue the procedure until droop is within specifications. If the governor hunts, turn the screw counterclockwise, one "click" at a time. Readjust the frequency as in Step 1 after each adjustment of the screw.

- If hunting occurs only at light loads, adjust the bumper spring screw (4) clockwise in quarter-turn increments until hunting stops. Then check the droop.
- If satisfactory adjustments for droop or hunt cannot be made, call an Onan Distributor.





FIGURE 12. BOSCH RSV GOVERNOR

- Droop is the change in frequency (as a percentage of nominal frequency) as the genset is loaded from no-load to full-load.
- \*\* Hunt is pulsation in frequency caused by the governor when it is adjusted so that cyclical over-correction of speed occurs.



# ELECTRIC GOVERNOR CONTROLLER ADJUSTMENTS

- 1. Move the RUN/STOP/REMOTE switch to RUN position, and operate the generator set at no load.
- Refer to Figure 13 and adjust the governor control as follows:
- Confirm that DROOP potentiometer adjust is set at "0" (zero) position. If not, turn pointer fully counterclockwise to "0".



ES-1697

FIGURE 13. ELECTRIC GOVERNOR CONTROLLER

- Set speed by adjusting the SPEED potentiometer. Turn clockwise to increase and counterclockwise to decrease. Set to 50 or 60 Hz.
- Adjust the GAIN potentiometer by turning it clockwise until the engine starts to hunt. (It may be necessary to push the linkage off speed to get the engine to hunt). Turn GAIN potentiometer counterclockwise until the engine speed is once again stable (i.e., no audible hunting).

- Adjust the "D" potentiometer the same as step 5 GAIN.
- 7. Adjust the "I" potentiometer by pulling back the fuel injection pump lever to its minimum position and maintain in position until the engine speed slows. Release the lever and observe the frequency meter for overshoot above rated speed. Turn the "I" potentiometer counterclockwise a slight amount to decrease overshoot. A slight amount of overshoot is acceptable.
- 8. Apply 1/4 load and adjust the GAIN potentiometer again per step 5.
- 9. From no load, apply full load to be certain that generator set will carry it. If generator set will NOT accept full load, stop generator set and lengthen the governor actuator linkage (stud and rod ends) by half turns and repeat full load operation until the generator set will accept full load. Check generator set operation at varying load levels for stability.
- 10. Move the RUN/STOP/REMOTE switch to STOP position to stop generator set. The generator set should come to a complete stop within 15 seconds. If not, then stop the generator set by removing one end of the linkage and repeat calibration procedure. If the generator set stops correctly, leave generator set off for 30 seconds to allow the turbo charger to coast down.
- 11. Move the RUN/STOP/REMOTE switch to RUN position and check for overshoot of engine speed.
- If generator set shuts down on overspeed, check for binding linkage, repair and repeat the calibration procedure. Tighten all jam nuts and set screws. Replace all seals removed during these procedures.







1400 73rd Avenue N.E. Minneapolis, MN 55432 Phone 612-574-5000 Telex 275477 Fax 574-5298

Onan Corporation Printed in U.S.A.

