

The following catalog  
has gaps in its page  
numbers, or doesn't  
have any numbers.  
We have chosen to  
leave the page  
numbering in the  
order that Acrobat  
assigns it.



SPECIAL PARTS LIST FOR MODEL 2.5 DJA-53CR SPEC 14928U  
FOR STANDARD PARTS REFER TO CATALOG 967-0224 KEY NO. 1  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
WIRING DIAGRAM NO. (ENG) 610-0328-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
High Air Temperature Cut Off					
102-0547	1	Base, Oil			
309-0196	1	Switch, High Air Temperature			

SPECIAL PARTS LIST FOR MODEL 3.0 DJA-3CR SPEC 14928U  
FOR STANDARD PARTS REFER TO CATALOG 967-0224 KEY NO. 1  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
WIRING DIAGRAM NO. (ENG) 610-0328-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
----------	------	-------------	----------	------	-------------

• High Air Temperature Cut Off

309-0196	1	Switch, High Air Temperature
102-0547	1	Base, Oil

SPECIAL PARTS LIST FOR MODEL 3.0 DJA-3CR SPEC 15494T  
FOR STANDARD PARTS REFER TO CATALOG 967-0224 KEY NO. 1  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
WIRING DIAGRAM NO. (ENG) 610-0328-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
----------	------	-------------	----------	------	-------------

High Air Temperature Cut Off

509-0112	1	Seal, Crankshaft Rear			
509-0111	1	Seal, Oil - Gearcase			
103-0454	1	Gearcase Assembly, Complete			
134-1806	1	Duct, Air			
309-0196	1	Switch, High Air Temperature			

SPECIAL PARTS LIST FOR MODEL 3.0 DJA-3CR SPEC 15494U  
FOR STANDARD PARTS REFER TO CATALOG 967-0224 KEY NO. 1  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
WIRING DIAGRAM NO. (ENG) 610-0328-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
----------	------	-------------	----------	------	-------------

High Air Temperature Cut Off

509-0112	1	Seal, Crankshaft Rear			
509-0111	1	Seal, Oil - Gearcase			
103-0454	1	Gearcase Assembly, Complete			
134-1806	1	Duct, Air			
309-0196	1	Switch, High Air Temperature			

SPECIAL PARTS LIST FOR MODEL 3.0 DJA-3R

SPEC

16524U

FOR STANDARD PARTS REFER TO CATALOG 967-0224

KEY NO. 1

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 610-0353-01 (AC) SAME

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
----------	------	-------------	----------	------	-------------

Housed

Meter Panel

Mounted Fuel Tank

High Air Temperature Cut Off.

102-0547	1	Base, Oil
154-0704	1	Manifold, Exhaust
309-0196	1	Switch, High Air Temperature
155-0951	1	Tube, Exhaust
201-1235	1	Armature Assembly
212-0350	1	Rig Assembly, Brush
212-1105	8	Spring, Brush
214-0056	4	Brush, Collector Ring (AC)
312-0058	3	Condenser, AC - .1 MFD
204-0092	1	Ring, Collector
305-0235	1	Rectifier - 10 Amp 100 Volt Peak
305-0254	1	Bracket, Rectifier Mounting
320-0002	2	Breaker, Circuit - 15 Amp, 120/240 Volt
302-0460	2	Ammeter, AC - 0-20
332-0142	1	Terminal
301-2288	1	Panel, Meter
302-0465	1	Meter, Running Time - 120 Volt

SPECIAL PARTS LIST FOR MODEL 3.0 DJA-3R SPEC 16853U  
 FOR STANDARD PARTS REFER TO CATALOG 967-0224 KEY NO. 1  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 610-0353-01 (AC) 610-0353

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Air Duct And Shutter					
Meter Panel					
High Air Temperature Cut Off					
309-0196	1	Switch, High Air Temperature			
201-1235	1	Armature Assembly			
212-0350	1	Rig Assembly, Brush			
212-1105	8	Spring, Brush			
214-0056	4	Brush, Collector Ring (AC)			
312-0058	3	Condenser, AC - .1 MFD.			
204-0092	1	Ring, Collector			
305-0235	1	Rectifier - 10 Amp 100 Volt Peak			
305-0254	1	Bracket, Rectifier Mounting			
320-0002	2	Breaker, Circuit - 15 Amp, 120/240 Volt			
32-0460	2	Ammeter, AC - 0-20			
32-0142	1	Terminal			
301-0288	1	Panel, Meter			
302-0105	1	Meter, Running Time - 120 Volt			
155-0951	1	Tube, Exhaust			



SPECIAL PARTS LIST FOR MODEL

3.0 DJA-3CR

SPEC

16938U

FOR STANDARD PARTS REFER TO CATALOG

967-0224

KEY NO. 1

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO.

(ENG) 610-0328-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed			
		Air Duct and Shutter			
		High Air Temperature Cut Off			
309-0196	1	Switch, High Air Temperature			
155-0360	1	Muffler, Exhaust - Critical			
155-0951	1	Tube, Exhaust			
140-0078	2	Band, Muffler Mounting			
505-0100	2	Nipple, Half - Oil Drain			
		1/2 x 1 1/8"			



3.0 DJA-3CR

**SPEC**

17264U

FOR STANDARD PARTS REFER TO **CATALOG** 967-0224

KEY NO. 1

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO.

(ENG) 610-0328-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Mounted Fuel Tank					
High Air Temperature Cut Off					
Oil Base Heater					
309-0196	1	Switch, High Air Temperature			
134-1806	1	Duct, Air			
155-0951	1	Tube, Exhaust			

SPECIAL PARTS LIST FOR MODEL 3.0 DJA-3CR SPEC 17989U  
FOR STANDARD PARTS REFER TO CATALOG 967-0224 KEY NO. 1  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 610-0328-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
----------	------	-------------	----------	------	-------------

NOTE: Fungus Treated Control and  
Environmentally Protected Generator

212-0350	1	Rig Assembly, Brush
212-1105	12	Spring, Brush
214-0050	8	Brush, Collector Ring (AC)
201-2539	1	Armature Assembly

SPECIAL PARTS LIST FOR MODEL 3.0 DJA-3R

SPEC

18229U

FOR STANDARD PARTS REFER TO CATALOG 967-0224

KEY NO. 1

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 610-0361-01 (AC) 610-0361

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed			332-1043	1	Jumper, Ground
Meter Panel			508-0001	2	Grommet, Rubber - 1 1/1
High Air Temperature Cut Off			508-0002	1	Grommet, Rubber - 1/2"
502-0058	1	Tee, Street Pipe - Oil	501-3423	1	Panel, Control Box
		Pressure Switch Mounting	320-0002	2	Breaker, Circuit - 15 A
509-0113	1	Switch, Low Oil Pressure			120/240 Volt
102-0547	1	Base, Oil	302-0460	2	Ammeter, AC - 0-20
154-0704	1	Manifold, Exhaust	332-0142	1	Terminal
309-0206	1	Switch, High Air Temperature	301-2288	1	Panel, Meter
160-0773	1	Spring, Thrust Plunger	302-0465	1	Meter, Running Time - 1
160-0774	1	Plunger, Thrust			Volt
160-0720	1	Spacer, Switch Plate			
309-0134	1	Switch Assembly (Only) For			
		Start Disconnect			
309-0152	1	Plunger, Switch			
160-0382	1	Diaphragm, Switch Plunger			
191-0496	1	Plate, Start Disconnect			
191-0392	1	Cover, Start Disconnect			
191-0388	1	Control Assembly, Start			
		Disconnect Switch			
338-0258	1	Harness, Wiring - Start			
		Disconnect Switch to			
		Control			
160-0721	1	Gasket, Start Disconnect			
		Plate			
160-0806	1	Disc, Start Disconnect			
		Thrust Plunger			
160-0711	2	Spring, Weight (Included In			
		191-0388 Start Disconnect			
		Switch Control Assembly)			
154-1806	1	Duct, Air			
155-0951	1	Tube, Exhaust			
201-1235	1	Armature Assembly			
212-0330	1	Rig Assembly, Brush			
212-1105	8	Spring, Brush			
214-0056	4	Brush, Collector Ring (AC)			
312-0058	5	Condenser, AC - .1 MFD			
204-0092	1	Ring, Collector			
322-0069	2	Receptacle, Panel Light			
320-0221	1	Limiter, Cranking - For Low			
		Oil Pressure			
307-0655	1	Relay, Latching - For High			
		Air Temperature			
302-0060	1	Ammeter, Charge - 20-0-20			
304-0217	1	Resistor, Fixed - 1 OHM,			
		10 Watt			
332-0706	1	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker (For 8 Place			
		Terminal Block)			

SPECIAL PARTS LIST FOR MODEL

3.0 DJA-3CE

SPEC

18336U

FOR STANDARD PARTS REFER TO CATALOG 967-0224

KEY NO. -

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 605-0101-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
----------	------	-------------	----------	------	-------------

Contractor Model

212-0350	1	Rig Assembly, Brush
214-0050	8	Brush, Collector Ring (AC)
212-1105	12	Spring, Brush

## SPECIAL PARTS LIST FOR MODEL 3.0 DJA-3CR

SPEC 23356V

FOR STANDARD PARTS REFER TO CATALOG 967-0224 KEY NO. 1

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

WIRING DIAGRAM NO. 610-0367-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
123-0649	1	Tube, Oil Fill	502-0001	1	Tee, Inverted (Brass)
123-1350	1	Cap and Indicator - Oil Fill Tube			Oil Pressure Gauge Mounting
102-1090	1	Base, Oil (6 Quart)	502-0053	2	Elbow, Street Pipe (45°)
102-1052	2	Bracket, Mounting - Oil Base			Brass - Oil Pressure Gauge Mounting & Fuel Pump Outlet
505-0007	1	Bushing, Reducer - Pipe (1/4" x 1/8")	505-0049	1	Elbow, Street (90°) Pipe
		Oil Line to Oil Base Tee			Oil Pressure Switch to Lube Filter Oil Line
505-0100	1	Nipple, Close - Pipe (1/2" x 1-1/8") Oil	505-0059	1	Tee, Pipe - Oil Pressure
		Base Tee to Oil Base			Switch Mounting
505-0229	1	Tee, Reducing - Pipe (1/2" x 1/4" x 1/2")	505-0104	1	Nipple, Pipe - Oil
		Oil Line to Oil Base			Filter Adapter to Oil Pressure Switch Mounting Tee
505-0130	2	Plug, Pipe - Square Head - Oil Base	309-0105	1	Switch, Oil Pressure
		(3/4")	501-0005	1	Line, Flex - Oil
505-0056	1	Plug, Pipe - Square Head - Oil Base Tee	103-0366	1	Gearcase (Less Stator)
		(1/2")			(Includes Parts Marked *
191-1393	1	Flywheel Assembly - Includes Ring Gear and Magnets	150-0838	1	*Shaft, Governor
104-0423	1	Gear, Ring	150-0777	1	*Yoke, Governor
191-1256	1	Stator, Alternator - Includes Connector Body (G1)	518-0129	1	*Ring, Retaining
338-1509	1	Harness, Wiring - Stator Leads to Regulator (26") (W17)	516-0111	1	*Pin, Roll
323-0853	1	Body, Connector - Wiring Harness to Voltage Regulator	509-0087	1	*Seal, Oil (1-1/2" Dia.)
191-0886	1	Regulator, Voltage (Alternator) (VR1)	509-0088	1	*Seal, Oil (1/2" Dia.)
120-1001	1	Pump, Oil	510-0048	1	*Bearing, Needle (.49975 ID)
120-0755	1	Cup, Oil Pump Intake	510-0082	1	*Bearing, Needle (.25 ID)
			510-0043	1	*Ball, Steel
			146-0083	1	*Cup, Restricting
			191-1256	1	Stator (Replacement Kit)
			103-0271	1	Backplate
			134-2679	1	Panel, Cylinder Air Housing - Bottom
			508-0021	4	Grommet, Rubber (3/4" Hole)

SPECIAL PARTS LIST FOR MODEL 3.0 DJA-3CR SPEC 23356V  
 FOR STANDARD PARTS REFER TO CATALOG 967-0224 KEY NO. 1  
 OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.  
 WIRING DIAGRAM NO. 610-0367-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
191-0324	1	Starter (Includes Parts Marked +)	160-0382	1	Diaphragm, Switch Plunger
191-0712	1	+Armature	160-0720	1	Spacer, Switch Plate
191-0432	1	+Clutch	160-0721	1	Gasket, Plate
191-1023	1	+Head Assembly, Commutator End	191-0392	1	Cover, Switch Plate
191-1024	1	+Coil Package, Field	191-0388	1	Control Assembly, Switch
191-1025	1	+Plate Assembly, Brush	160-0711	2	Spring, Weight (Included in Switch Control Assembly)
191-1020	1	+Spring Set, Brush (Set of 4)	160-0806	1	Disc, Thrust Plunger
191-1263	1	+Connector Package	160-0774	1	Plunger, Thrust
191-0497	1	+Bearing (Bronze), Drive End	160-0773	1	Spring, Thrust Plunger
191-1027	1	+Spring, Plunger	520-0347	1	Stud, Plate Cover (Special)
191-1028	1	+Core Assembly, Moving	338-0258	1	Harness, Wiring - Switch to Control
191-0433	1	+Switch, Solenoid	122-0552	1	Bracket, Oil and Fuel Filter Mounting
191-1029	1	+Yoke Parts Package	502-0003	2	Connector, Inverted Male - Brass
191-1030	1	+Stop and Lock Ring Package, Pinion	122-0553	1	Filter, Lube Oil
191-1031	1	+Thrust Washer Package, Armature (Use as Required)	122-0037	1	Element, Lube Oil Filter
191-0434	1	+Brush Set, Service	502-0094	1	Fitting, Restriction - Brass
191-1032	1	+Yoke	122-0326	1	Filter, Secondary Fuel
191-0468	1	+Cover, Solenoid	501-0005	2	Line, Oil - Flexible
191-1134	1	+Boot, Rubber - Part of Moving Core Assembly	122-0325	1	Filter, Primary Fuel
191-0311	1	Spacer, Starter	149-1185	1	Adapter, Fuel Filter
191-1400	1	Flange, Starter	501-0103	1	Line, Fuel - Flexible - 13-3/4" Long
191-1419	1	Bracket, Starter Support	502-0002	2	Elbow, Inverted Male (90°)
134-1532	1	Baffle, Starter Hole	501-0015	1	Line, Fuel - Flexible - 16" Long
416-0633	2	Cable, Battery (54")	501-0163	1	Line, Fuel - Flexible - 28" Long
416-0133	1	Cable, Battery Jumper (7-1/2")	501-0164	1	Line, Fuel - Flexible - 24" Long
338-1519	1	Harness, Wiring - Starter	122-0561	1	Bracket, Oil Filter Mounting
191-0496	1	Plate, Start Disconnect	502-0080	2	Plug, Fuel Filter Drain
309-0134	1	Switch Assembly (Includes Leads)	301-6433	1	Mounting, Control - Saddle
309-0152	1	Plunger, Switch	140-0645	1	Adapter, Air Cleaner Hose



SPECIAL PARTS LIST FOR MODEL 3.0 DJA-3CR

SPEC 23356V

FOR STANDARD PARTS REFER TO CATALOG 967-0224 KEY NO. 1

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

WIRING DIAGRAM NO. 610-0367-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
503-1141	4	Clamp, Hose	309-0085	1	Element, Vernatherm
503-0330	1	Hose, Connector (Rubber) - 2" Long	134-2473	2	Spring, Shutter (Left Hand)
140-1762	1	Tube, Air Induction	134-3432	2	Spring, Shutter (Right Hand)
503-0419	1	Elbow (Rubber)	309-0447	1	Bracket, Mounting - High Air Temperature Switch
140-0721	1	Cleaner, Air (Includes Element and Baffle)	309-0196	1	Switch, High Air Temperature
140-0722	2	Band, Air Cleaner Mounting	508-0127	1	Sleeve, Teflon
140-1271	1	Bracket, Air Cleaner Mounting	134-0658	1	Spring, Vernatherm Element
140-1559	1	Hood, Air Inlet	220-2014	1	Stator, Generator
140-0765	1	Element, Air Cleaner	201-2154	1	Rotor Assembly, Generator (Includes Parts Marked †)
140-1267	1	Baffle, Air Cleaner	510-0112	1	†Bearing, Rotor
134-4147	1	Duct, Air	232-2398	1	†Spacer, Bearing
134-3428	2	Bracket and Pivot - Shutter	201-2151	1	†Rotor, Wound - Exciter
134-3429	1	Bracket and Pivot - Shutter and Rod (Upper)	515-0094	1	†Key, Exciter Rotor
134-3430	1	Bracket and Pivot - Shutter and Rod (Lower)	205-0105	1	†Fan, Generator
134-1808	2	Shutter, Air	515-0006	1	Key, Fan to Crankshaft
150-1358	1	Joint, Ball	358-0069	1	†Rectifier Assembly - Positive
134-1606	1	Rod, Control - Upper	358-0070	1	†Rectifier Assembly - Negative
518-0006	2	Clip, Rod	515-0103	1	†Key, Fan to Rotor
518-0004	1	Clip, Rod - Actuating Arm (Lower)	220-2009	1	Stator, Wound - Exciter
134-1604	1	Arm, Actuating	234-0185	1	Cover, End Bell
134-1607	1	Rod, Control - Lower	509-0094	1	Seal, Bearing ("O" Ring)
134-1248	2	Bearing, Actuating Arm	520-0794	4	Stud, Generator Through
134-2474	1	Bracket and Guide - Vernatherm Element (Includes Washer, Element and Spring)	520-0786	1	Stud, Rotor Through
134-1605	1	Shaft, Actuating Arm	234-0462	1	Baffle, Air
134-2478	1	Washer - Vernatherm Bracket and Guide, Mounting	508-0112	1	Grommet, Rubber - Generator Adapter (2-3/4" x 1-7/8")
134-3431	4	Bearing, Shutter	211-0237	1	Bell, End
508-0002	2	Grommet, Rubber	232-2418	1	Board, Connection
			231-0259	1	Adapter, Generator
			234-0493-01	1	Cover Assembly, Air Outlet
			508-0095	1	Grommet, Rubber - Air Baffle (25/32" x 21/32")

SPECIAL PARTS LIST FOR MODEL 3.0 DJA-3CR SPEC 23356V  
 FOR STANDARD PARTS REFER TO CATALOG 967-0224 KEY NO. 1  
 OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.  
 WIRING DIAGRAM NO. 610-0367-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
518-0011	2	Ring, Retaining	357-0028	3	Rectifier, Diode
232-2847	2	Spacer, Generator Adapter	365-0002	2	Rectifier, Gate Control
301-3714	1	Cover, Voltage Regulator	361-0003	1	Transistor, Unijunction
305-0589	1	Regulator, Voltage (Includes Parts Marked °) (VR22)	350-0423	1	Resistor (33,000-Ohm, 1/2 Watt)
300-1540	1	°Board, Voltage Regulator (See Below for Components)	350-0443	1	Resistor (220,000-Ohm, 1/2 Watt)
320-0505	1	°Breaker, Circuit	350-0447	1	Resistor (330,000-Ohm, 1/2 Watt)
315-0391	1	°Reactor	350-0398	1	Resistor (3,000-Ohm, 1/2 Watt)
315-0386	1	°Transformer, Voltage	350-0466	1	Resistor (2,000,000-Ohm, 1/2 Watt)
517-0045	1	°Plug, Dot Button	351-0202	1	Resistor (1,240-Ohm, 1/4 Watt)
332-1647	1	°Strip, Terminal	350-0445	1	Resistor (270,000-Ohm, 1/2 Watt)
301-3713	1	°Panel, Mounting	350-0435	2	Resistor (100,000-Ohm, 1/4 Watt)
338-0744	1	Harness, Wiring - Voltage Regulator to Exciter Stator (W9)	350-0459	1	Resistor (1,000,000-Ohm, 1/2 Watt)
300-1540	1	Board, Voltage Regulator - Complete (Consists of Parts Listed Below)	353-0048	2	Resistor (4,000-Ohm, 5 Watt)
356-0039	1	Capacitor (100 Mfd, 10 Volt)	351-0293	1	Resistor (11,000-Ohm, 1/4 Watt)
355-0044	2	Capacitor (.47 Mfd, 250 VDC)	350-0363	1	Resistor (100-Ohm, 1/2 Watt)
355-0043	2	Capacitor (.22 Mfd, 250 VDC)	350-0351	2	Resistor (33-Ohm, 1/2 Watt)
355-0045	3	Capacitor (.1 Mfd, 250 VDC)	350-0851	1	Resistor (18,000-Ohm, 1 Watt)
355-0046	1	Capacitor (1.0 Mfd, 100 VDC)	351-0332	1	Resistor (28,000-Ohm, 1/4 Watt)
355-0051	1	Capacitor (.39 Mfd, 250 VDC)	351-0240	1	Resistor (3,090-Ohm, 1/4 Watt)
355-0047	1	Capacitor (.47 Mfd, 400 VDC)	351-0211	1	Resistor (1,530-Ohm, 1/4 Watt)
359-0036	1	Diode - Zener (5-6 V)	351-0234	1	Resistor (2,670-Ohm, 1/4 Watt)
359-0025	1	Diode - Zener (20 V)	350-0973	1	Resistor (270-Ohm, 2 Watt)
357-0004	8	Rectifier, Diode (1 Amp, 400 Volt)	350-0512	1	Resistor (10-Ohm, 1/2 Watt)
359-0026	1	Diode, Zener (18 V)			

SPECIAL PARTS LIST FOR MODEL 3.0 DJA-3CR SPEC 23356V  
 FOR STANDARD PARTS REFER TO CATALOG 967-0224 KEY NO. 1  
 OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.  
 WIRING DIAGRAM NO. 610-0367-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
351-0353	1	Resistor (46,400-Ohm, 1/4 Watt)	332-0604	1	Block, Terminal
351-0349	1	Resistor (42,200-Ohm, 1/4 Watt)	332-0706	1	5 Place (TB11)
303-0210	1	Potentiometer (5,000-Ohm)	332-0503	1	8 Place (TB12)
303-0211	1	Potentiometer (100,000-Ohm)	332-0516	1	8 Place (TB13)
350-0355	1	Resistor (47-Ohm, 1/2 Watt)	332-0739	1	Strip, Marker
363-0069	2	Sink, Heat	332-2461	1	5 Place (TB11)
362-0017	1	Transistor (NPN)	508-0015	4	8 Place (TB12)
367-0005	1	Integrated Circuit	508-0015	4	8 Place (TB13)
332-1511	14	Terminals	508-0015	4	Washer, Fiber -
301-6447	1	Box, Control	402-0078	4	Resistor Mounting
301-6452	1	Panel, Control Box	402-0078	4	Mount, Rubber - Control
301-6433	1	Bracket, Control Box Mounting	337-0036	1	Box Mounting
301-6448	1	Box, Output	337-0036	1	Strap, Ground
301-6453	1	Cover, Output Box Relay	321-0175	1	Holder, Fuse (F4)
307-0845	1	Start Solenoid (K11)	321-0146	1	Fuse - 10 Amp (F1)
307-0052	1	Start Disconnect (K12)	305-0589	1	Regulator, Voltage
307-1046	1	Manifold Heater (K13)	304-0003	1	Resistor, Fixed
320-0104	1	Cranking Limiter (K14)	304-0003	1	(5-Ohm, 50 Watt) (R1)
307-1529	1	Cutout (K15)	304-0292	1	Insulator, Resistor
301-6432	2	Bracket, Relay Mounting (K11 and K13)	304-0292	1	Mounting
308-0154	1	Switch, Start-Stop (S11)	304-0427	2	Washer, Centering -
308-0220	1	Switch, Run-off - Remote (S13)	304-0427	2	Resistor Mounting
308-0037	1	Switch, Manifold Heater (S12)	508-0001	2	Grommet, Rubber
302-0446	1	Ammeter, Charge (5-0-5) (M11)	508-0001	2	1-1/16" Hole
304-0217	1	Resistor, Fixed (1-Ohm, 10 Watt) (R11)	508-0183	1	1-3/4" Hole
			508-0009	1	1-3/8" Hole
			332-0052	1	Clip, Wire
			336-7817	1	Jumper
			323-0853	1	Connector, Regulator Body
			The following parts refer to the Remote Control Assembly (A1):		
			301-3492	1	Box Control
			301-3493	1	Panel, Control
			308-0029	2	Switch, Push - Preheat and Start
			308-0069	1	Switch, Toggle - On-Off