

The following catalog  
has gaps in its page  
numbers, or doesn't  
have any numbers.  
We have chosen to  
leave the page  
numbering in the  
order that Acrobat  
assigns it.

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 13937T  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 611-0807-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Housed					
Low Oil Pressure Cut Off					
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
416-0004	1	Cable, Battery Jumper			
220-0596	1	Stator Assembly, Wound			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 13948U  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. 611-0863-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Cut Off					
Skid And Battery Rack					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0196	1	Switch, High Air Temperature			
416-0004	1	Cable, Battery Jumper			
220-0854	1	Stator Assembly, Wound			
211-0152	1	Bell, End			
150-0956	1	Switch Assembly, Overspeed			
150-0958	1	Bracket And Point Assembly, Overspeed			
322-0004	1	Lamp, Indicator - Overspeed			
322-0069	1	Holder, Indicator Lamp			
320-0104	1	Relay, Low Oil Pressure			
307-0655	1	Relay, Overspeed			
301-2376	1	Panel, Control			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 13950U  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 611-0807-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Skid And Battery Rack					
Low Oil Pressure Cut Off					
102-0620	1	Base, Oil			
220-0596	1	Stator Assembly, Wound			

SPECIAL PARTS LIST FOR MODEL 7.5JB-4R SPEC 13961AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-4793-10(AC) 612-1469-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Housed					
Meter Panel					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2204	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
332-0566	1	Strip, Marker - B+,1,2,3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-5DR **SPEC** 13961AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW  
 (ENG)  
**WIRING DIAGRAM NO.** 612-4793-10 (AC) 612-1556-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System Housed Meter Panel					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0183	1	Elbow, Reducer - 1½ To 1¼ (Exhaust)			
301-2204	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-1R SPEC 13961U  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 611-0806-01 (AC) 612-3291.

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Housed					
Meter Panel					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
416-0004	1	Cable, Battery Jumper			
220-0596	1	Stator Assembly, Wound			
320-0148	1	Breaker, Circuit - 70 Amp.			
301-1641	1	Panel, Meter			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-4XR **SPEC** 13985U  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** 611-0806-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			



SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 14008U  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 611-1041-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
LPG Fuel System					
Low Oil Pressure Cut Off					
Mounted Fuel Tank (Note: Tank Is Being Used As An Oil Reserve)					
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
110-1742	1	Head Assembly, Cylinder (Also Includes 502-0274 Connector Assembly And 502-0082 Hex Nipple)			
520-0526	2	Stud, Carburetor Mounting			
502-0082	1	Nipple, Hex - Cyl Block			
115-0189	2	Stud Package, Rocker Arm (Each Package Contains Two Studs And One Lock)			
148-0367	1	Switch, Vacuum			
502-0053	1	Elbow, Vacuum Switch			
502-0046	1	Nipple, Vacuum Switch			
502-0051	1	Coupling, Vacuum Switch			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0100	2	Nipple, Oil Drain			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
220-0596	1	Stator Assembly, Wound			
416-0004	1	Cable, Battery Jumper			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-4R **SPEC** 14052U  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG) 611-0873-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Cut Off					
Gas Fuel System					
112-0106	2	Piston and Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0206	1	Switch, High Air Temperature			
220-0973	1	Stator Assembly, Wound			
211-0152	1	Bell, End			
150-0956	1	Switch Assembly, Overspeed			
150-0958	1	Bracket and Point Assembly, Overspeed			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
332-0751	1	Block, Terminal - 10 Place			
332-1235	1	Strip, Marker - 10 Place			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 14079AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** 612-5558-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Housed					
Mounted Fuel Tank					
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0183	1	Elbow, Reducer - 1½ To 1¼ (Exhaust)			
505-0100	2	Nipple, Oil Drain			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 14081AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** 612-4794-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Housed					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
505-0100	2	Nipple, Oil Drain			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	1	Washer, Fiber-Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 14093AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5559-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Skid And Battery Rack					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Gas Fuel System					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0196	1	Switch, High Air Temperature			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 14097U  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** 611-0806-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Housed					
Air Duct And Shutter					
102-0620	1	Base, Oil			
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
416-0C04	1	Cable, Battery Jumper			
220-0596	1	Stator Assembly, Wound			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 14109T  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** 611-0807-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System Housed Low Oil Pressure Cut Off High Air Temperature Cut Off					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0196	1	Switch, High Air Temperature			
307-1203	1	Coil, Choke Solenoid			
155-0391	1	Core, Choke Solenoid			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
416-0004	1	Cable, Battery Jumper			
220-0596	1	Stator Assembly, Wound			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-5DE **SPEC** 14113T  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** 611-1087-01 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Vacu-Flo Cooling (See Air Housing)					
Mobile Unit Air Cleaner					
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
415-0128	1	Tank Package, Fuel - 5 Gal. (Includes Parts Marked *)			
415-0126	1	*Tank, Fuel			
415-0124	1	*Cap, Rain			
501-0081	1	*Line, Fuel - 48"			
220-1836	1	Stator Assembly, Wound			
201-1958	1	Rotor Assembly, Wound			
211-0151	1	Bell, End			
212-0285	1	Rig Assembly, Brush			
212-1188	2	Block, Brush - Extends Farthermost From Brush Rig Ring			
212-1176	2	Block, Brush - Mounts Closest To Brush Rig Ring			
212-1105	4	Spring, Brush			
214-0072	4	Brush, Collector Ring			
234-0200	1	Cover, Generator Air Outlet			
209-0047	1	Exciter, Complete (Less Cover) (Exciter Stamped Number 06SX/32) For Replacement Parts Use Column "F" In Exciter Portion Of Parts Catalog Except Part Marked #.			
234-0234	1	#Cover, Exciter			
308-0028	1	Switch, Start			
308-0069	1	Switch, Ignition			
332-0254	1	Block, Terminal - 4 Place			
332-0869	1	Strip, Marker - 4 Place			
301-2092	1	Panel, Control Box			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			

Parts Not Furnished By Onan  
 Pre-Cleaner



SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3R **SPEC** 14148AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** (ENG) 612-4848-13(AC) 612-1559-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Low Oil Pressure Cutoff					
High Air Temperature Cutoff					
Housed					
Meter Panel					
Overspeed Cutoff					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0196	1	Switch, High Air Temperature			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2288	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
338-0917	1	Harness, Wiring - Voltage Regulator to Exciter Stator			
322-0004	1	Lamp, Indicator - Overspeed			
322-0069	1	Holder, Indicator Lamp			
320-0104	1	Relay, Low Oil Pressure			
307-1129	1	Relay, Overspeed			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 14161U  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO. (ENG) 611-0883-01**

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Housed					
Low Oil Pressure Cut Off					
102-0620	1	Base, Oil			
220-0596	1	Stator Assembly, Wound			
322-0004	1	Lamp, Indicator - Low Oil Pressure			
301-2376	1	Panel, Control			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 14178U  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** 611-0806-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Housed					
High Air Temperature Cut Off					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0196	1	Switch, High Air Temperature			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
416-0004	1	Cable, Battery Jumper			
220-0596	1	Stator Assembly, Wound			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 14180U  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. 611-1041-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Vacu-Flo Cooling (See Air Housing)					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
309-0196	1	Switch, High Air Temperature			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
110-1742	1	Head Assembly, Cylinder (Also Includes 502-0274 Connector Assembly And 502-0082 Hex Nipple)			
520-0526	2	Stud, Carburetor Mounting			
502-0082	1	Nipple, Hex - Cyl Block			
115-0189	2	Stud Package, Rocker Arm (Each Package Contains Two Studs And One Lock)			
148-0367	1	Switch, Vacuum			
502-0053	1	Elbow, Vacuum Switch			
502-0046	1	Nipple, Vacuum Switch			
502-0051	1	Coupling, Vacuum Switch			
416-0021	2	Cable, Battery			
220-0596	1	Stator Assembly, Wound			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3R **SPEC** 14229AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-4793-09 (AC) 612-1559-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank					
Housed					
Meter Panel					
Air Duct and Shutter					
102-0620	1	Base, Oil			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2288	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-4XR **SPEC** 14248U  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** 611-1034-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
110-1742	1	Head Assembly, Cylinder (Also Includes 502-0274 Connector Assembly And 502-0082 Hex Nipple)			
520-0526	2	Stud, Carburetor Mounting			
502-0082	1	Nipple, Hex - Cyl. Block			
115-0189	2	Stud Package, Rocker Arm (Each Package Contains Two Studs And One Lock)			
148-0367	1	Switch, Vacuum			
502-0053	1	Elbow, Vacuum Switch			
502-0046	1	Nipple, Vacuum Switch			
502-0051	1	Coupling, Vacuum Switch			
134-1804	1	Duct, Air			
211-0152	1	Bell, End			
150-0956	1	Switch Assembly, Overspeed			
150-0958	1	Bracket And Point Assembly, Overspeed			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R131 **SPEC** 14302AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Air Duct And Shutter					
LPG Fuel System					
Note: Pennsylvania Approved					
102-0620	1	Base, Oil			
112-0092	2	Piston And Pin			
113-0089	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
416-0325	1	Hydrometer			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0100	2	Nipple, Oil Drain			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-4R SPEC 14303U  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 611-0806-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Housed					
Air Duct and Shutter					
102-0620	1	Base, Oil			
112-0106	2	Piston and Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0100	2	Nipple, Oil Drain			
416-0004	1	Cable, Battery Jumper			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			



SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 14303AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** 612-5558-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Housed					
Air Duct And Shutter					
102-0620	1	Base, Oil			
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-C100	2	Nipple, Oil Drain			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 14304T  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** 611-0807-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Oil Bath Air Cleaner Housed Low Oil Pressure Cut Off High Air Temperature Cut Off					
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0100	2	Nipple, Oil Drain			
140-0645	1	Adapter, Oil Bath Air Clnr.			
416-0004	1	Cable, Battery Jumper			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
503-0576	1	Hose, Air Cleaner (2" ID X 8" Long) (Elbow)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
220-0596	1	Stator Assembly, Wound			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 14305T  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** 611-0841-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Cut Off					
102-0620	1	Base, Oil			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0206	1	Switch, High Air Temperature			
220-0854	1	Stator Assembly, Wound			
211-0152	1	Bell, End			
150-0956	1	Switch Assembly, Overspeed			
150-0958	1	Bracket And Point Assembly, Overspeed			
322-0004	2	Lamp, Indicator - Low Oil Pressure (1) Overspeed And High Air Temp. (1)			
307-1129	1	Relay, High Air Temperature And Overspeed			
332-0751	1	Block, Terminal - 10 Place			
332-1235	1	Strip, Marker - 10 Place			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-4R **SPEC** 14326U  
**FOR STANDARD PARTS REFER TO CATALOG** 967-0223 **KEY NO.** 4  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 611-1112-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off			332-0609	1	Block, Terminal - 2 Place
High Air Temperature Cut Off			332-0610	1	Strip, Marker - 2 Place
Overspeed Cut Off			301-3567	1	Panel, Control Box
Gas Fuel System			508-0009	1	Grommet, Rubber - 1-3/8" Hole (Control Box)
Skid and Battery Rack			301-1964	1	Bracket, Control Box - L
112-0106	2	Piston and Pin	301-1965	1	Bracket, Control Box - R
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0206	1	Switch, High Air Temperature			
110-1742	1	Head Assembly, Cylinder (Also Includes 502-0274 Connector Assembly and 502-0082 Hex Nipple)			
520-0526	2	Stud, Carburetor Mounting			
502-0082	1	Nipple, Hex - Cyl Block			
115-0189	2	Stud Package, Rocker Arm (Each Package Contains Two Studs and One Lock)			
148-0367	1	Switch, Vacuum			
502-0053	1	Elbow, Vacuum Switch			
502-0046	1	Nipple, Vacuum Switch			
502-0051	1	Coupling, Vacuum Switch			
134-1804	1	Duct, Air			
416-0004	1	Cable, Battery Jumper			
220-1960	1	Stator Assembly, Wound			
211-0152	1	Bell, End			
150-0956	1	Switch Assembly, Overspeed			
150-0958	1	Bracket and Point Assembly, Overspeed			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switches)			
307-1129	2	Relay, High Air Temperature and Overspeed			
307-1143	1	Relay, Generating (DPDT)			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temp			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			

SPECIAL PARTS LIST FOR **MODEL** 6.0JB-518E **SPEC** 14364AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** 612-4921-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing) Low Oil Pressure Cut Off High Air Temperature Cut Off Mobile Unit Air Cleaner					
338-0408	1	Harness, Wiring - Breaker to Control			
338-0975	1	Harness, Wiring - Starter			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
140-1271	1	Bracket, Air Cleaner Mtg.			
503-0274	4	Clamp, Air Cleaner Hose			
503-0330	1	Hose, Air Cleaner - 2" Long			
220-2049	1	Stator Assembly, Wound-Gen.			
201-2156	1	Rotor Assembly - Generator			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
308-0028	1	Switch, Start - Push			
308-0069	1	Switch, Ignition - Toggle			
301-2092	1	Panel, Control			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18E **SPEC** 14364AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** 612-4921-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Vacu-Flo Cooling (See Air Housing)					
Mobile Unit Air Cleaner					
338-0408	1	Harness, Wiring - Breaker To Control			
338-0975	1	Harness, Wiring - Starter			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0961	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
308-0028	1	Switch, Start			
308-0069	1	Switch, Ignition			
301-2092	1	Panel, Control Box			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18E SPEC 14364AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. 612-5626-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mobile Unit Air Cleaner					
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
338-0408	1	Harness, Wiring - Breaker To Control			
338-0975	1	Harness, Wiring - Starter			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
308-0028	1	Switch, Start			
308-0069	1	Switch, Ignition			
301-2092	1	Panel, Control Box			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 14421AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** 612-4844-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Vacu-Flo Cooling (See Air Housing)					
115-0173	1	Cover, Rocker - Includes Oil Line			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0206	1	Switch, High Air Temperature			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
338-0917	1	Harress, Wiring - Voltage Regulator To Exciter Stator			
322-0004	2	Lamp, Indicator - Low Oil Pressure (1) Overspeed And High Air Temp. (1)			
307-1129	1	Relay, High Air Temperature And Overspeed			



SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 14421AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4844-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
LPG Fuel System					
Overspeed Cut Off					
Vacu-Flo Cooling (See Air Housing)					
115-0173	1	Cover, Rocker - Includes Oil Line			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0206	1	Switch, High Air Temperature			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	2	Lamp, Indicator - Low Oil Pressure (1) Overspeed And High Air Temp. (1)			
307-1129	1	Relay, High Air Temperature And Overspeed			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 14422AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** 612-4844-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Cut Off					
Housed					
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0206	1	Switch, High Air Temperature			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	2	Lamp, Indicator - Low Oil Pressure (1) Overspeed And High Air Temp. (1)			
307-1129	1	Relay, High Air Temperature And Overspeed			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 14436AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Skid And Battery Rack					
102-0620	1	Base, Oil			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
332-0566	1	Strip, Marker - E+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 14461AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. 612-4794-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Skid And Battery Rack					
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
309-0196	1	Switch, High Air Temperature			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 14480AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELC  
**WIRING DIAGRAM NO.** 612-4860-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Gas Fuel System					
Vacu-Flo Cooling (See Air Housing)					
Skid And Battery Rack					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0206	1	Switch, High Air Temperature			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
322-0004	2	Lamp, Indicator - High Air Temp. And Low Oil Pressure			
307-1129	1	Relay, High Air Temperature			
301-2376	1	Panel, Control			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 14519AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** 612-4851-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cut Off Gas Fuel System					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
538-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	1	Lamp, Indicator - Overspeed			
322-0069	1	Holder, Indicator Lamp			

**WIRING DIAGRAM NO. (ENG) 612-5558-10**

220-2049	1	Stator Assembly, Wound
201-2156	1	Rotor Assembly
520-0796	4	Stud, Generator Through
520-0788	1	Stud, Rotor Through

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 14531AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** 612-4848-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0196	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	1	Lamp, Indicator - Overspeed			
322-0069	1	Holder, Indicator Lamp			
320-0104	1	Relay, Low Oil Pressure			
307-1129	1	Relay, Overspeed			



SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 14531AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4848-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Cut Off					
Gas Fuel System					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0196	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	1	Lamp, Indicator - Overspeed			
322-0069	1	Holder, Indicator Lamp			
320-0104	1	Relay, Low Oil Pressure			
307-1129	1	Relay, Overspeed			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 14543AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4794-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Housed					
Air Duct And Shutter					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 14560AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 (ENG) WIRING DIAGRAM NO. 612-4794-13 (Output Panel) 61

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Housed					
Air Duct And Shutter					
102-0620	1	Base, Oil			
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0196	1	Switch, High Air Temperature			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
301-3021	1	Panel, Output			
301-2727	1	Handle, Output Panel			
320-0020	2	Breaker, Circuit			
323-0184	1	Receptacle, Duplex			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 14603AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4858-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Cut Off					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
134-1804	1	Duct, Air			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Assembly Includes Two Each Of 307-0655 Relay And All Leads)			
307-1143	1	Relay, Generating (DPDT)			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Hold Down			
309-0270	1	Thermostat, Low Engine Temp.			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18E SPEC 14643AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. 612-4921-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off High Air Temperature Cut Off Vacu-Flo Cooling (See Air Housing) Mobile Unit Air Cleaner LPG Fuel System					
338-0408	1	Harness, Wiring - Breaker To Control			
338-0975	1	Harness, Wiring - Starter			
115-0173	1	Cover, Rocker - Includes Oil Line			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
308-0028	1	Switch, Start			
308-0069	1	Switch, Ignition			
301-2092	1	Panel, Control Box			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18E **SPEC** 14643AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** 612-5626-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Mobile Unit Air Cleaner					
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
338-0408	1	Harness, Wiring - Breaker To Control			
338-0975	1	Harness, Wiring - Starter			
115-0173	1	Cover, Rocker - Includes Oil Line			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
308-0028	1	Switch, Start			
308-0069	1	Switch, Ignition			
301-2092	1	Panel, Control Box			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 14668AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELC

**WIRING DIAGRAM NO.** 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 14668AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. 612-5558-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			



SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 14669AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Vacu-Flo Cooling (See Air Housing)					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 14669AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. 612-5558-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Vacu-Flo Cooling (See Air Housing)					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R31 **SPEC** 14670AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Note: Pennsylvania Approved					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
416-0325	1	Hydrometer			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18R31 SPEC 14670AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5558-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Note: Pennsylvania Approved					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
416-0325	1	Hydrometer			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3R **SPEC** 14716AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-4858-13 (AC) 612-1559-0

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Gas - Gasoline Fuel System					
Day Tank (One Quart)					
Housed					
Meter Panel					
309-0206	1	Switch, High Air Temperature			
102-0620	1	Base, Oil			
134-1949	1	Cover, Air Housing			
331-0103	1	Bushing, Snap - Gas Hose			
502-0053	1	Elbow, Street Pipe - Valve			
		To Carburetor Fuel Line			
501-0005	1	Line, Fuel - Valve To Carb.			
508-0021	2	Grommet, Rubber - Air Hsg.			
		Cover (3/4" Hole)			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0183	1	Elbow, Reducer - 1-1/2 To			
		1-1/4 (Exhaust)			
301-2288	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0917	1	Harness, Wiring - Voltage			
		Regulator To Exciter Stator			
322-0004	5	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay And Lead Assembly -			
		High Air Temperature And			
		Overspeed (Assembly			
		Includes Two Each Of			
		307-0655 Relay And All			
		Leads)			
307-1143	1	Relay, Generating (DPDT)			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temp.			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With			
		332-0706 Terminal Block			

SPECIAL PARTS LIST FOR MODEL 7.5JB-4R SPEC 14734AB  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-5564-14 (AC) 612-1469-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Air Duct and Shutter					
Meter Panel					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Cut Off					
Mounted Fuel Tank					
102-0620	1	Base, Oil			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2204	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
338-0917	1	Harness, Wiring - Voltage Regulator to Exciter Stator			
322-0904	1	Lamp, Indicator - Overspeed			
322-0069	1	Holder, Indicator Lamp			
320-0104	1	Relay, Low Oil Pressure			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 14757AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELC  
**WIRING DIAGRAM NO.** 612-4794-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Gas-Gasoline Fuel System					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
309-0196	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			

**WIRING DIAGRAM NO. (ENG) 612-5559-14**

Gas - Gasoline Fuel System  
Low Oil Pressure Cut Off  
High Air Temperature Cut Off

309-0196	1	Switch, High Air Temperature
134-1804	1	Duct, Air
220-2041	1	Stator Assembly, Generator
201-2156	1	Rotor Assembly, Generator
520-0796	4	Stud, Generator Through
520-0788	1	Stud, Rotor Through



SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 14758AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. 612-4795-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
134-1804	1	Duct, Air			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 14758AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** 612-5558-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
134-1804	1	Duct, Air			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
532-0566	1	Strip, Marker - B+, 1, 2, 3			
532-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-4R SPEC 14786AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4997-16(AC) 612-1469-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off High Air Temperature Cut Off Overspeed Cut Off Housed Air Duct and Shutter Meter Panel LPG Fuel System Adjustable Voltage Regulator					
102-0620	.1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0206	1	Switch, High Air Temperature			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2204	1	Panel, Meter			
338-0917	1	Harness, Wiring - Voltage Regulator to Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switches)			
307-1519	1	Relay and Lead Assembly - High Air Temperature and Overspeed (Assembly Includes Two Each of 307- 0655 Relay and All Leads)			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+,1,2,3			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 14795AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** 612-4794-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Skid And Battery Rack			
		Low Oil Pressure Cut Off			
		Day Tank (One Quart)			
102-0620	1	Base, Oil			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
397-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
134-1843	1	Cover, Air Housing			
502-0053	1	Elbow, Street Pipe - Valve To Carburetor Fuel Line			
501-0005	1	Line, Fuel - Valve To Carb.			
508-0021	2	Grommet, Rubber - Air Hsg. Cover (3/4" Hole)			
134-1804	1	Duct, Air			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-9537	1	Block, Terminal - 4 Place			
332-9566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR MODEL 7.5JB-4R SPEC 14842AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4858-16 (AC) 612-1469-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Cut Off					
Gas Fuel System					
Adjustable Voltage Regulator					
Meter Panel					
112-0106	2	Piston and Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0206	1	Switch, High Air Temperature			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2204	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
338-0917	1	Harness, Wiring - Voltage Regulator to Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay and Lead Assembly - High Air Temperature and Overspeed (Assembly Includes Two Each of 307- 0655 Relay and All Leads)			
307-1143	1	Relay, Generating (DPDT)			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temp			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 14858AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 14858AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** 612-5558-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
332-0566	1	Strip, Marker - B+, 1, 2, 5			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3R SPEC 14901AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4794-13(AC) 612-1559-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cutoff					
High Air Temperature Cutoff					
Housed					
Air Duct and Shutter					
Meter Panel					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
505-0100	2	Nipple, Oil Drain			
301-2288	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			



SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 14940AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** 612-4794-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cut Off					
231-0171	1	Adapter, Generator			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
234-0492	1	Cover, Generator Air Outlet			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 14940AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** 612-5559-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cut Off					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
231-0171	1	Adapter, Generator			
234-0492	1	Cover, Generator Air Outlet			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 14992AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** 612-4858-13 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0206	1	Switch, High Air Temperature			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Assembly Includes Two Each Of 307-0655 Relay And All Leads)			
307-1143	1	Relay, Generating (DPDT)			
325-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Hold Down			
309-0270	1	Thermostat, Low Engine Temp			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 15012AB  
FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5569-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Housed					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
102-0620	1	Base, Oil			
309-0206	1	Switch, High Air Temperature			
155-0360	1	Muffler, Critical			
322-0004	2	Lamp, Indicator - Low Oil Pressure And High Air Temperature			
307-1129	1	Relay, High Air Temperature			
332-0604	1	Block, Terminal - 5 Place			
332-0616	1	Strip, Marker - 5 Place			
301-2376	1	Panel, Control			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3R SPEC 15019AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG)612-4794-13(AC)612-1559-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank Housed Low Oil Pressure Cutoff Meter Panel					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2288	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 15024AB  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-5559-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
134-1804	1	Duct, Air			
220-2041	1	Stator Assembly, Generator			
201-2156	1	Rotor Assembly, Generator			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 15032AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** 612-4997-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
LPG Fuel System					
Overspeed Cut Off					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0206	1	Switch, High Air Temperature			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switches)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Assembly Includes Two Each Of 307-0655 Relay And All Leads)			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 15125AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** 612-4794-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
		Mounted Fuel Tank			
		Housed			
		Air Duct And Shutter			
102-0620	1	Duct, Air			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0100	2	Nipple, Oil Drain			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			



SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 15144AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** 612-4794-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Housed					
Low Oil Pressure Cut Off					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 15144AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4794-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Housed					
Low Oil Pressure Cut Off					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0105	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1½ To 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 15175AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
**WIRING DIAGRAM NO.** 612-4794-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System:					
Housed					
Low Oil Pressure Cut Off					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0100	2	Nipple, Oil Drain			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 15186AB  
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO. (ENG) 612-5559-14**

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling Low Oil Pressure Cut Off High Air Temperature Cut Off Gas - Gasoline Fuel System					
102-0620	1	Base, Oil			
309-0196	1	Switch, High Air Temperature			
220-2041	1	Stator Assembly, Generator			
201-2156	1	Rotor Assembly, Generator			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3R SPEC 15190AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. (ENG) 612-4793-09 (AC) 612-4793-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Housed					
Meter Panel					
Air Duct and Shutter					
Oil Bath Air Cleaner					
High Air Temperature Cutoff					
102-0620	1	Base, Oil			
112-0106	2	Piston and Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0196	1	Switch, High Air Temperature			
140-0645	1	Adapter, Oil Bath Air Cleaner			
405-1651	1	Panel, Upper (Engine End)			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
505-0100	2	Nipple, Oil Drain			
301-1554	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
333-0495	1	Harness, Wiring - Control to Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			



SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 15254AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** 612-4794-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Housed					
Air Duct And Shutter					
Low Oil Pressure Cut Off					
102-0620	1	Base, Oil			
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0100	2	Nipple, Oil Drain			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 15260AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System Housed					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1½ To 1½ (Exhaust)			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			



SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 15276AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4794-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off Gas-Gasoline Fuel System Vacu-Flö Cooling (See Air Housing)					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 15276AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** 612-5559-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
Gas-Gasoline Fuel System					
Vacu-Flo Cooling (See Air Housing)					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CE SPEC 15346AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5030-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
Mobile Unit Air Cleaner					
338-0975	1	Harness, Wiring - Starter			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
503-0274	4	Clamp, Air Cleaner Hose			
140-1271	1	Bracket, Air Cleaner Mtg.			
220-2015	1	Stator Assembly, Wound			
308-0028	1	Switch, Start - Push			
308-0069	1	Switch, Ignition - Toggle			
323-0856	2	Receptacle, Twistlock			
323-0857	2	Plug, Twistlock Receptacle			
323-0184	2	Receptacle, Duplex			
332-1695	2	Tab, Terminal - Output Box			
301-2092	1	Panel, Control			
301-3682	1	Box, Output			
301-1170	1	Cover, Output Box			
517-0045	1	Button, Dot - 9/32" Hole			
503-0330	1	Hose, Air Cleaner - 2" Long			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 15355AB  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** 612-5558-11

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Vacu-Flo Cooling (See Air Housing)					
Adjustable Voltage Regulator					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

**WIRING DIAGRAM NO. (ENG) 612-5558-10**

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
220-2041	1	Stator Assembly, Generator			
201-2156	1	Rotor Assembly, Generator			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 15427AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)  
 WIRING DIAGRAM NO. 612-4794-13

PART NO	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Housed					
Mounted Fuel Tank					
102-0620	1	Base, Oil			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0591	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 15432AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELC  
**WIRING DIAGRAM NO.** 612-4794-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Skid And Battery Rack Low Oil Pressure Cut Off Gas-Gasoline Fuel System Vacu-Flo Cooling (See Air Housing)					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-4R **SPEC** 15439AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

**WIRING DIAGRAM NO.** (ENG) 612-4793-10(AC) 612-1469-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Housed					
Air Duct and Shutter					
Meter Panel					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2204	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
332-0566	1	Strip, Marker - B+,1,2,3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			



SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 15446AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank Housed High Air Temperature Cut Off					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0183	1	Elbow, Reducer - 1½ To 1¼ (Exhaust)			
505-0100	2	Nipple, Oil Drain			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

**WIRING DIAGRAM NO. (ENG)612-5559-14**

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas - Gasoline Fuel System					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
102-0620	1	Base, Oil			
309-0196	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
220-2041	1	Stator Assembly, Generator			
201-2156	1	Rotor Assembly, Generator			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3R SPEC 15486AA  
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4793-09 (AC) 612-1559-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank					
Housed					
Air Duct and Shutter					
High Air Temperature Cutoff					
Meter Panel					
102-0620	1	Base, Oil			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
505-0100	2	Nipple, Oil Drain			
301-2288	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 15487AA  
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4  
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELC  
**WIRING DIAGRAM NO.** 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing)					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Det - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			