

The following catalog
has gaps in its page
numbers, or doesn't
have any numbers.
We have chosen to
leave the page
numbering in the
order that Acrobat
assigns it.

SPECIAL PARTS LIST FOR MODEL 7.5JB-5DR SPEC 15496AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 (ENG) 612-4997-14
 WIRING DIAGRAM NO. (AC) 612-1556-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Air Duct And Shutter					
Meter Panel					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Cut Off					
Mounted Fuel Tank					
102-0620	1	Base, Oil			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0206	1	Switch, High Air Temperature			
505-0183	1	Elbow, Reducer - 1½ To 1¼ (Exhaust)			
301-2204	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switches)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Assembly Includes Two Each of 307-0655 Relay And All Leads)			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 15500AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. 612-4997-14 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
LPG Fuel System					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0206	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switches)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Assembly Includes Two Each Of 307-0655 Relay And All Leads)			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 15500AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5573-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cut Off					
LPG Fuel System					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0206	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Assembly Includes Two Each Of 307-0655 Relay And All Leads)			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 15544AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELC

WIRING DIAGRAM NO. 612-4843-14 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Gas Fuel System					
Overspeed Cut Off					
102-0620	1	Base, Oil			
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1½ To 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	2	Lamp, Indicator - Overspeed And Low Oil Pressure			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 15552AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4858-13 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Cut Off					
Vacu-Flo Cooling (See Air Housing)					
115-0173	1	Cover, Rocker - Includes Oil Line			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0206	1	Switch, High Air Temperature			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Assembly Includes two each of 307-0655 Relay And All Leads)			
307-1143	1	Relay, Generating (DPDT)			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Hold Down			
309-0270	1	Thermostat, Low Engine Temp			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 15569AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4794-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
102-0620	1	Base, Oil			
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0196	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 15569AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4794-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Gas Fuel System					
102-0620	1	Base, Oil			
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0196	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 15571AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4794-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off High Air Temperature Cut Off Gas-Gasoline Fuel System Vacu-Flo Cooling (See Air Housing)					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 15571AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5559-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas - Gasoline Fuel System					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Vacu-Flo Cooling					
309-0196	1	Switch, High Air Temperature			
220-2041	1	Stator Assembly, Generator			
201-2156	1	Rotor Assembly, Generator			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 15601AB
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5573-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Gas-Gasoline Fuel System					
Air Duct And Shutter					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0206	1	Switch, High Air Temperature			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Assembly Includes Two Each of 307-0655 Relay And All Leads)			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 15615AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. 612-4858-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0206	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Assembly Includes Two Each Of 307-0655 Relay And All Leads)			
307-1143	1	Relay, Generating (DPDT)			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Hold Down			
309-0270	1	Thermostat, Low Engine Temp.			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 15681AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4883-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed LPG Fuel System Mounted Fuel Tank (Note: Tank Is Being Used An An Oil Reserve)					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
110-1742	1	Head Assembly, Cylinder (Also Includes 502-0274 Connector Assembly And 502-0082 Hex Nipple)			
520-0526	2	Stud, Carburetor Mounting			
502-0082	1	Nipple, Hex - Cyl Block			
115-0189	2	Stud Package, Rocker Arm (Each Package Contains Two Studs And One Lock)			
148-0367	1	Switch, Vacuum			
502-0053	1	Elbow, Vacuum Switch			
502-0046	1	Nipple, Vacuum Switch			
502-0051	1	Coupling, Vacuum Switch			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 15715AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4997-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
LPG Fuel System					
Vacu-Flo Cooling (See Air Housing)					
Skid And Battery Rack					
115-0173	1	Cover, Rocker - Includes Oil Line			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0206	1	Switch, High Air Temperature			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switches)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Assembly Includes Two Each of 307-0655 Relay And All Leads)			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 15717AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4860-16

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Adjustable Voltage Regulator					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0206	1	Switch, High Air Temperature			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
322-0004	2	Lamp, Indicator - High Air Temp. And Low Oil Pressure			
307-1129	1	Relay, High Air Temperature			
301-2376	1	Panel, Control			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 15719AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4843-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cut Off					
Overspeed Cut Off					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	2	Lamp, Indicator - Overspeed And Low Oil Pressure			

SPECIAL PARTS LIST FOR MODEL 6.0JB-518E SPEC 15730AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4921-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank					
Housed					
Meter Panel (Blank)					
Low Oil Pressure Cut Off					
338-0975	1	Harness, Wiring - Starter			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
220-2048	1	Stator Assembly, Wound			
301-1195	1	Panel, Meter			
308-0028	1	Switch, Start - Push			
308-0069	1	Switch, Ignition - Toggle			
301-2092	1	Panel, Control			
Parts not Furnished by Onan					
Associated Meter Panel Parts (Meters, Breakers, etc.)					

SPECIAL PARTS LIST FOR MODEL 6.0JB-518R SPEC 15730AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank Housed Meter Panel (Blank)					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
220-2048	1	Stator Assembly, Wound			
301-1195	1	Panel, Meter			
332-0566	1	Strip, Block Marker - 4 Place			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot (11/16" Hole)			
508-0015	2	Washer, Fiber - Control Panel Resistor			
Parts not Furnished by Onan Associated Meter Panel Parts (Meters, Breakers, etc.)					

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R31 **SPEC** 15762AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4909-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off High Air Temperature Cut Off Overspeed Cut Off Gas Fuel System Note: Pennsylvania Approved					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0206	1	Switch, High Air Temperature			
416-0325	1	Hydrometer			
134-1804	1	Duct, Air			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 15772AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4794-15

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing) Low Oil Pressure Cut Off High Air Temperature Cut Off Gas-Gasoline Fuel System Adjustable Voltage Regulator					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 6.0JB-53CR **SPEC** 15798AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW
WIRING DIAGRAM NO. (ENG) 612-4794-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
505-0098	1	Nipple, Close - Fuel Pump to Fuel Solenoid Valve			
502-0020	1	Elbow, Street - Fuel Pump to Fuel Solenoid Valve			
307-1279	1	Valve, Fuel Solenoid			
502-0003	1	Connector, Inverted Male - Fuel Solenoid Valve Inlet			
307-1293	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1,2,3			

SPECIAL PARTS LIST FOR MODEL 7. JB-3CR SPEC 15798AB
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5559-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
505-0098	1	Nipple, Close - Fuel Pump Inlet			
502-0020	1	Elbow, Street - Fuel Pump To Fuel Solenoid Valve			
502-0003	1	Connector, Inverted Male - Fuel Solenoid Valve Inlet			
307-1279	1	Valve, Fuel Solenoid			
309-0196	1	Switch, High Air Temperature			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 15802AA
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Skid And Battery Rack					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-4XR SPEC 15806AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 (ENG)
 WIRING DIAGRAM NO. 612-4848-14 (AC) 612-1859-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Cut Off					
Gas Fuel System					
Housed					
Air Duct And Shutter					
Meter Panel					
102-0620	1	Base, Oil			
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0196	1	Switch, High Air Temperature			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0100	2	Nipple, Oil Drain			
505-0183	1	Elbow, Reducer - 1½ To 1¼ (Exhaust)			
301-2373	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	1	Lamp, Indicator - Overspeed			
322-0069	1	Holder, Indicator Lamp			
320-0104	1	Relay, Low Oil Pressure			
307-1129	1	Relay, Overspeed			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 15812AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
102-0620	1	Base, Oil			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
505-0183	1	Elbow, Reducer - 1½ To 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3R **SPEC** 15833AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5568-13 (AC)612-1559-C

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off High Air Temperature Cut Off Overspeed Cut Off Housed Gas - Gasoline Fuel System AC Meter Panel					
309-0206	1	Switch, High Air Temperature			
301-2288	1	Panel, Meter			
322-0004	3	Lamp, Indicator - Low Oil Pressure, Overspeed And High Air Temperature			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay And Lead Assembly - Overspeed And High Air Temperature (Assembly Includes Two Each Of 307-0655 Relay And Leads)			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			
301-3567	1	Panel, Control			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3R **SPEC** 15874AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5564-13 (AC) 612-1559-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Gas - Gasoline Fuel System					
Housed					
AC Meter Panel					
Air Duct And Shutter					
102-0620	1	Base, Oil			
309-0196	1	Switch, High Air Temperature			
301-2288	1	Panel, Meter			
322-0004	1	Lamp, Indicator - Overspeed			
320-0104	1	Relay, Low Oil Pressure			
332-0604	1	Block, Terminal - 5 Place			
332-0616	1	Strip, Marker - 5 Place			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3R **SPEC** 15948AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4848-13(AC) 612-1559-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cutoff					
Low Oil Pressure Cutoff					
High Air Temperature Cutoff					
LPG Fuel System					
Housed					
Air Duct and Shutter					
Meter Panel					
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0196	1	Switch, High Air Temperature			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2288	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
338-0917	1	Harness, Wiring - Voltage Regulator to Exciter Stator			
322-0004	1	Lamp, Indicator - Overspeed			
322-0069	1	Holder, Indicator Lamp			
320-0104	1	Relay, Low Oil Pressure			
307-1129	1	Relay, Overspeed			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR31 **SPEC** 15950AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4997-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Low Oil Pressure Cutoff					
High Air Temperature Cutoff					
Overspeed Cutoff					
Note: Pennsylvania Approved					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0206	1	Switch, High Air Temperature			
416-0325	1	Hydrometer			
338-0917	1	Harness, Wiring - Voltage Regulator to Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switches)			
307-1519	1	Relay and Lead Assembly - High Air Temperature and Overspeed (Assembly Includes Two Each of 307-0655 Relay and All Leads)			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 15982AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4883-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Housed					
Mounted Fuel Tank		(Note: Tank Is Being Used As An Oil Reserve)			
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
110-1742	1	Head Assembly, Cylinder (Also Includes 502-0274 Connector Assembly And 502-C082 Hex Nipple)			
520-0526	2	Stud, Carburetor Mounting			
502-0082	1	Nipple, Hex - Cyl Block			
115-0189	2	Stud Package, Rocker Arm (Each Package Contains Two Studs And One Lock)			
148-0367	1	Switch, Vacuum			
502-0053	1	Elbow, Vacuum Switch			
502-0046	1	Nipple, Vacuum Switch			
502-0051	1	Coupling, Vacuum Switch			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
332-0566	1	Strip, Marker - B+ 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 16028AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4793-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Mounted Fuel Tank					
Housed					
Air Duct and Shutter					
High Air Temperature Cut Off					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
309-0196	1	Switch, High Air Temperature			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0100	2	Nipple, Oil Drain			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 16088AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Housed					
Air Duct And Shutter					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1½ To 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 16095AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4794-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Low Oil Pressure Cut Off					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - Br, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 16095AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5559-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas - Gasoline Fuel System					
Low Oil Pressure Cut Off					
220-2041	1	Stator Assembly, Generator			
201-2156	1	Rotor Assembly, Generator			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 16165AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4860-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Air Duct and Shutter					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
LPG Fuel System					
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0206	1	Switch, High Air Temperature			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
322-0004	2	Lamp, Indicator - High Air Temp. And Low Oil Pressure			
307-1129	1	Relay, High Air Temperature			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3R **SPEC** 16206AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5559-13 (AC) 612-1559-0

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank					
Housed					
Air Duct And Shutter					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
AC Meter Panel					
102-0620	1	Base, Oil			
309-0196	1	Switch, High Air Temperature			
155-0360	1	Muffler, Critical			
301-2288	1	Panel, Meter			

SPECIAL PARTS LIST FOR MODEL 7.5 JB-3CR SPEC 16223AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4794-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System Housed Low Oil Pressure Cut Off Mounted Fuel Tank Air Duct And Shutter					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-4R **SPEC** 16229AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4850-14 (AC) 612-1469-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System Housed Low Oil Pressure Cut Off Meter Panel					
123-1306	1	Cap and Indicator-Includes Chain			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2204	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
322-0004	1	Lamp, Indicator - Low Oil Pressure			
322-0069	1	Holder, Indicator Lamp			

SPECIAL PARTS LIST FOR MODEL 6.0JB-518E SPEC 16253AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4921-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cutoff					
High Air Temperature Cutoff					
Note: Manual Choke					
104-0429	1	Crankdog			
338-0975	1	Harness, Wiring - Starter			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
141-0693	1	Carburetor, Gasoline			
153-0327	1	Bracket, Choke			
518-0176	1	Clamp, Choke			
153-0328	1	Choke, Manual			
309-0196	1	Switch, High Air Temperature			
134-1091	1	Grille, Air Housing			
220-2048	1	Stator Assembly, Wound			
308-0028	1	Switch, Start - Push			
308-0069	1	Switch, Ignition - Toggle			
301-2092	1	Panel, Control			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 16315AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4794-14 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Gas Fuel System					
Air Duct And Shutter					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0196	1	Switch, High Air Temperature			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-4R **SPEC** 16331AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4997-14 (AC) 612-1469-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Cut Off					
Mounted Fuel Tank					
Housed					
Meter Panel					
102-0620	1	Base, Oil			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0206	1	Switch, High Air Temperature			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2204	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
338-0917	1	Harness, Wiring - Voltage Regulator to Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switches)			
307-1519	1	Relay and Lead Assembly - High Air Temperature and Overspeed (Assembly Includes Two Each of 307-0655 Relay and All Leads)			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+,1,2,3			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 16364AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4850-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cutoff					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
322-0004	1	Lamp, Indicator - Low Oil Pressure			
322-0069	1	Holder, Indicator Lamp			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 16367AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4794-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Skid and Battery Rack					
Low Oil Pressure Cutoff					
High Air Temperature Cutoff					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
309-0128	1	Thermostat, Adjustable - Generator End Bell			
232-2458	1	Plate, Thermostat Mounting - Generator End Bell			
232-2457	1	Bracket, Heater Mounting - Generator End Bell			
333-0059	1	Ring Heater - Generator End Bell			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 16369AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5559-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 16387AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4997-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Low Oil Pressure Cutoff					
High Air Temperature Cutoff					
Overspeed Cutoff					
Vacu-Flo Cooling (See Air Housing)					
115-0173	1	Cover, Rocker - Includes Oil Line			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0206	1	Switch, High Air Temperature			
338-0917	1	Harness, Wiring - Voltage Regulator to Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switches)			
307-1519	1	Relay and Lead Assembly - High Air Temperature and Overspeed (Assembly Includes Two Each of 307-0655 Relay and All Leads)			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 16402AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4794-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cutoff					
High Air Temperature Cutoff					
Day Tank (One Quart)					
102-0620	1	Base, Oil			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
134-1843	1	Cover, Air Housing			
505-0008	2	Plug, Slotted - Day Tank			
502-0082	1	Nipple, Solenoid Valve to Day Tank			
159-1062	1	Bracket, Day Tank Mounting			
501-0005	1	Line, Fuel - Solenoid Valve to Carburetor			
309-0196	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 16402AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4794-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
High Air Temperature Cut Off					
Low Oil Pressure Cut Off					
Day Tank (One Quart)					
102-0620	1	Base, Oil			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
134-1843	1	Cover, Air Housing			
505-0008	2	Plug, Slotted - Day Tank			
502-0082	1	Nipple, Solenoid Valve To Day Tank			
159-1062	1	Bracket, Day Tank Mounting			
501-0005	1	Line, Fuel - Solenoid Valve To Carburetor			
309-0196	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 16422AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4860-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Oil Bath Air Cleaner					
Vacu-Flo Cooling					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
309-0206	1	Switch, High Air Temperature			
102-0620	1	Base, Oil			
140-0645	1	Adapter, Oil Bath Air Cleaner Hose			
322-0004	2	Lamp, Indicator - High Air Temperature And Low Oil Pressure			
307-1129	1	Relay, High Air Temperature			
301-2376	1	Panel, Control			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 16425AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Vacu-Flo Cooling (See Air Housing)					
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 16425AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5558-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Vacu-Flo Cooling (See Air Housing)					
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 16457AA
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4794-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Housed					
Low Oil Pressure Cut Off					
Voltage Regulator Filter					
102-0620	1	Base, Oil			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3R SPEC 16478AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG)612-4997-13(AC)612-1559-0

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cutoff					
Low Oil Pressure Cutoff					
High Air Temperature Cutoff					
Mounted Fuel Tank					
Housed					
Meter Panel					
102-0620	1	Base, Oil			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0206	1	Switch, High Air Temperature			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2288	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
338-0917	1	Harness, Wiring - Voltage Regulator to Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switches)			
307-1519	1	Relay and Lead Assembly - High Air Temperature and Overspeed (Assembly Includes Two Each of 307-0655 Relay and All Leads)			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			

SPECIAL PARTS LIST FOR MODEL 7.5JB-4R SPEC 16478AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4997-14 (AC) 612-1400-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Cut Off					
Mounted Fuel Tank					
Housed					
Meter Panel					
102-0620	1	Base, Oil			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0206	1	Switch, High Air Temperature			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2204	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
338-0917	1	Harness, Wiring - Voltage Regulator to Exciter Stator			
322-0004	5	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switches)			
307-1519	1	Relay and Lead Assembly - High Air Temperature and Overspeed (Assembly Includes Two Each of 307-0655 Relay and All Leads)			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - R+, 1, 2, 3			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 16479AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4858-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Cut Off					
Housed					
102-0620	1	Base, Oil			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0206	1	Switch, High Air Temperature			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0183	1	Elbow, Reducer - 1½ To 1¼ (Exhaust)			
505-0100	2	Nipple, Oil Drain			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Assembly Includes Two Each Of 307-0655 Relay And All Leads)			
307-1143	1	Relay, Generating (DPDT)			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Hold Down			
309-0270	1	Thermostat, Low Engine Temp.			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			

SPECIAL PARTS LIST FOR MODEL 7.5JB-4R SPEC 16565AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4997-14 (AC) 612-1469-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Housed					
Meter Panel					
Overspeed Cut Off					
Mounted Fuel Tank					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0206	1	Switch, High Air Temperature			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2204	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
338-0917	1	Harness, Wiring - Voltage Regulator to Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switches)			
307-1519	1	Relay and Lead Assembly - High Air Temperature and Overspeed (Assembly Includes Two Each of 307-0655 Relay and All Leads)			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+,1,2,3			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			

SPECIAL PARTS LIST FOR MODEL 7.5JB-4XR SPEC 16565AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW
 (ENG)
 WIRING DIAGRAM NO. 612-4997-14 (AC) 612-1851-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off High Air Temperature Cut Off Overspeed Cut Off Housed Mounted Fuel Tank Meter Panel					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0206	1	Switch, High Air Temperature			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0183	1	Elbow, Reducer - 1½ To 1½ (Exhaust)			
301-2308	1	Panel, Meter			
304-0305	1	Resistor, Fixed-Meter Panel (45,000 Ohm, 10 Watt)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switches)			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Assembly Includes Two Each of 307-0655 Relay And All Leads)			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-4R **SPEC** 16565AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (Eng) 612-5573-14 (AC) 612-1469-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Meter Panel					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Cut Off					
Mounted Fuel Tank					
Housed					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0206	1	Switch, High Air Temperature			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2204	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
338-0917	1	Harness, Wiring - Voltage Regulator to Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay and Lead Assembly - High Air Temperature and Overspeed (Assembly Includes Two Each of 307-0655 Relay and All Leads)			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			
301-3567	1	Panel, Control Box			

SPECIAL PARTS LIST FOR **MODEL** 6.0JB-53R **SPEC** 16574AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4793-09 (AC) 612-1559

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Meter Panel					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
301-2288	1	Panel, Meter			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-4R SPEC 16575AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (Eng) 612-4997-14(AC) 612-1469-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Gas-Gasoline Fuel System					
Housed					
Meter Panel					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0206	1	Switch, High Air Temperature			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2204	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
338-0917	1	Harness, Wiring - Voltage Regulator to Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switches)			
307-1519	1	Relay and Lead Assembly - High Air Temperature and Overspeed (Assembly Includes Two Each of 307-0655 Relay and All Leads)			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+,1,2,3			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 16581AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4794-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Gas-Gasoline Fuel System					
102-0880	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0196	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 16581AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5559-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas - Gasoline Fuel System					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
102-0880	1	Base, Oil			
309-0196	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
220-2041	1	Stator Assembly, Generator			
201-2156	1	Rotor Assembly, Generator			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 16584AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4858-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Overspeed Cutoff					
Low Oil Pressure Cutoff					
High Air Temperature Cutoff					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0206	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
338-0917	1	Harness, Wiring - Voltage Regulator to Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay and Lead Assembly - High Air Temperature and Overspeed (Assembly Includes Two Each of 307-0655 Relay and All Leads)			
307-1143	1	Relay, Generating (DPDT)			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 16584AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5568-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Cut Off					
134-1804	1	Duct, Air			
309-0206	1	Switch, High Air Temperature			
322-0004	3	Lamp, Indicator - Low Oil Pressure, Overspeed And High Air Temperature			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay And Lead Assembly - Overspeed And High Air Temperature (Assembly Includes Two Each Of 307-0655 Relay And Leads)			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			
301-3567	1	Panel, Control			

SPECIAL PARTS LIST FOR **MODEL** 6.0JB-53CR **SPEC** 16671AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4848-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing) Low Oil Pressure Cut Off High Air Temperature Cut Off Overspeed Cut Off					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
338-0917	1	Harness, Wiring - Voltage Regulator to Exciter Stator			
322-0004	1	Lamp, Indicator - Overspeed			
322-0069	1	Holder, Indicator Lamp			
320-0104	1	Relay, Low Oil Pressure			
307-1129	1	Relay, Overspeed			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 16687AB
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5559-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cutoff					
High Air Temperature Cutoff					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 16710AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
High Air Temperature Cut Off LPG Fuel System Housed					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0196	1	Switch, High Air Temperature			
505-0183	1	Elbow, Reducer - 1½ To 1¼ (Exhaust)			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3R **SPEC** 1679QAA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4794-13 (AC) 612-1786-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cutoff					
High Air Temperature Cutoff					
Mounted Fuel Tank					
Housed					
Meter Panel					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-1554	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3R SPEC 16819AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 612-4848-13(AC) 612-1559-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cutoff					
Mounted Fuel Tank					
Housed					
Low Oil Pressure Cutoff					
Meter Panel					
102-0620	1	Base, Oil			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2288	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
338-0917	1	Harness, Wiring - Voltage Regulator to Exciter Stator			
322-0004	1	Lamp, Indicator - Overspeed			
322-0069	1	Holder, Indicator Lamp			
320-0104	1	Relay, Low Oil Pressure			
307-1129	1	Relay, Overspeed			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3R**SPEC** 16847AAFOR STANDARD PARTS REFER TO **CATALOG** 967-0223**KEY NO.** 4

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4794-13(AC)612-1559-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Day Tank (One Quart)					
Housed					
Air Duct And Shutter					
Meter Panel					
102-0620	1	Base, Oil			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
134-1843	1	Cover, Air Housing			
505-0008	2	Plug, Slotted - Day Tank			
502-0082	1	Nipple, Solenoid Valve To Day Tank			
159-1062	1	Bracket, Day Tank Mounting			
501-0005	1	Line, Fuel - Solenoid Valve To Carburetor			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0183	1	Elbow, Reducer - 1-1/2 To 1-1/4 (Exhaust)			
505-0100	2	Nipple, Oil Drain			
301-2288	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+,1,2,3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 16877AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5196-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off High Air Temperature Cut Off Overspeed Cut Off Gas Fuel System Vacu-Flo Cooling (See Air Housing)					
112-0106	2	Piston And Pin			
115-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
110-1742	1	Head Assembly, Cylinder (Also Includes 502-0274 Connector Assembly And 502-0082 Hex Nipple)			
520-0526	2	Stud, Carburetor Mounting			
502-0082	1	Nipple, Hex - Cyl. Block			
115-0189	2	Stud Package, Rocker Arm (Each Package Contains Two Studs And One Lock)			
148-0367	1	Switch, Vacuum			
502-0053	1	Elbow, Vacuum Switch			
502-0046	1	Nipple, Vacuum Switch			
502-0051	1	Coupling, Vacuum Switch			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	1	Lamp, Indicator - Overspeed			
322-0069	1	Holder, Indicator Lamp			
320-0104	1	Relay, Low Oil Pressure			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 16912AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Voltage Regulator Filter					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 16947AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4794-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Low Oil Pressure Cut Off					
Air Duct And Shutter					
102-0620	1	Base, Oil			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0100	2	Nipple, Oil Drain			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 16947AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5559-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed			
		Low Oil Pressure Cut Off			
		Air Duct And Shutter			
102-0620	1	Base, Oil			
155-0360	1	Muffler, Critical			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 17031AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG)612-4997-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cutoff					
Low Oil Pressure Cutoff					
High Air Temperature Cutoff					
Day Tank (One Quart)					
102-0620	1	Base, Oil	508-0015	4	Washer, Fiber - Contro
502-0020	1	Elbow, Street - Fuel Pump			Panel Resistors
		Inlet	332-0537	1	Block, Terminal - 4 P1
505-0061	1	Nipple, Pipe - Fuel Pump	332-0566	1	Strip, Marker - B+, 1,
		Inlet			2, 3
502-0017	1	Connector, Female - Fuel	332-0706	2	Block, Terminal - 8 P1
		Pump Inlet	332-0707	1	Strip, Marker - Use Wi
307-1203	1	Coil, Choke Solenoid			332-0706 Terminal B1
153-0391	1	Core, Choke Solenoid			
134-3322	1	Cover, Air Housing			
166-0382	1	Coil, Ignition (Includes			
		Capacitor)			
312-0083	1	Capacitor, Ignition Coil			
509-0102	1	"O" Ring - Capacitor to Coil			
134-2342	1	Housing, Air - Bottom			
166-0388	1	Bracket, Coil Mounting			
503-0465	1	Clamp, Coil Mounting			
812-0091	1	Screw, RHSMS - 8-32 X 2-1/2			
		(Coil Resistor Mounting)			
336-1506	1	Lead Assembly - Points to			
		Coil			
167-1479	2	Cable, Spark Plug			
337-0070	1	Strap, Ground - Ignition			
		Coil			
508-0002	2	Grommet, Rubber - 1/2" Hole			
		(Coil Leads Thru Air			
		Housing)			
502-0053	1	Elbow, Street Pipe - Valve			
		to Carburetor Fuel Line			
501-0005	1	Line, Fuel - Valve to			
		Carburetor			
167-0199	2	Plug, Spark			
309-0206	1	Switch, High Air Temperature			
338-0917	1	Harness, Wiring - Voltage			
		Regulator to Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure			
		(Includes Micro Switches)			
307-1519	1	Relay and Lead Assembly -			
		High Air Temperature and			
		Overspeed (Assembly			
		Includes Two Each of 307-			
		0655 Relay and All Leads)			
508-0001	1	Grommet, Rubber - Control Box			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 17046AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4795-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Housed					
Voltage Regulator Filter					
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1½ To 1¼ (Exhaust)			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 17075AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4793-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Housed					
Voltage Regulator Filter					
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0100	2	Nipple, Oil Drain			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 17106AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4794-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Skid and Battery Rack					
Low Oil Pressure Cutoff					
High Air Temperature Cutoff					
102-0620	1	Base, Oil			
112-0106	2	Piston and Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0196	1	Switch, High Air Temperature			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2,3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 17113AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4858-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off High Air Temperature Cut Off Overspeed Cut Off Gas-Gasoline Fuel System Day Tank (One Quart)					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
309-0206	1	Switch, High Air Temperature			
134-1949	1	Cover, Air Housing			
502-0053	1	Elbow, Street Pipe - Valve To Carburetor Fuel Line			
501-0005	1	Line, Fuel - Valve To Carb.			
508-0021	2	Grommet, Rubber - Air HSG. Cover (3/4" Hole)			
338-0917	1	Harness, Wiring - Voltage Regulator To Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay And Lead Assembly - High Air Temperature And Overspeed (Assembly Includes Two Each Of 307-0655 Relay And All Leads)			
307-1143	1	Relay, Generating (DPDT)			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Hold Down			
309-0270	1	Thermostat, Low Engine Temp.			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block.			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 17136AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4794-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Gas-Gasoline Fuel System					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
331-0103	1	Bushing, Snap - Gas Hose			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR31 **SPEC** 17145AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4850-13

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 17152AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4860-15

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cutoff					
Oil Bath Air Cleaner					
Adjustable Voltage Regulator					
High Air Temperature Cutoff					
112-0106	2	Piston and Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0206	1	Switch, High Air Temperature			
140-0645	1	Adapter, Oil Bath Air Cleaner			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
322-0004	2	Lamp, Indicator - High Air Temperature and Low Oil Pressure			
307-1129	1	Relay, High Air Temperature			
301-2376	1	Panel, Control			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 17177AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG)612-4858-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cutoff High Air Temperature Cutoff Overspeed Cutoff Vacu-Flo Cooling (See Air Housing) Gas Fuel System Skid and Battery Rack					
112-0106	2	Piston and Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0206	1	Switch, High Air Temperature			
338-0917	1	Harness, Wiring - Voltage Regulator to Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay and Lead Assembly - High Air Temperature and Overspeed (Assembly Includes Two Each of 307-0655 Relay and All Leads)			
307-1143	1	Relay, Generating (DPDT)			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			

SPECIAL PARTS LIST FOR **MODEL** 6.0JB-52R **SPEC** 17179AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4794-14 (AC) 612-4729-11

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Low Oil Pressure Cut Off High Air Temperature Cut Off Meter Panel					
505-0183	1	Elbow, Reducer - 1 1/2 to 1 1/4 (Exhaust)			
338-0495	1	Harness, Wiring - Control to Output Box			
322-0072	2	Receptacle, Panel Light			
301-1641	1	Panel, Meter			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1,2,3			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
309-0196	1	Switch, High Air Temperature			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 17204AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Housed					
Voltage Regulator Filter					
102-0620	1	Base, Oil			
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1½ To 1¼ (Exhaust)			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 17205AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG)612-4794-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Housed					
Low Oil Pressure Cutoff					
Voltage Regulator Filter					
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0100	2	Nipple, Oil Drain			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3R**SPEC** 17207AAFOR STANDARD PARTS REFER TO **CATALOG** 967-0223**KEY NO.** 4

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4794-13(AC)612-1786-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
LPG Fuel System					
Housed					
Air Duct And Shutter					
Meter Panel					
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
309-0196	1	Switch, High Air Temperature			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1-1/2 To 1-1/4 (Exhaust)			
301-1554	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+,1,2,3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 17225AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG)612-4794-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cutoff					
102-0620	1	Base, Oil			
112-0106	2	Piston and Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 17229AB
 FOR STANDARD PARTS REFER TO CATALOG 967-0225 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5559-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Air Duct And Shutter					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
309-0196	1	Switch, High Air Temperature			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 17230AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG)612-4858-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cutoff			
		Low Oil Pressure Cutoff			
		High Air Temperature Cutoff			
		Voltage Regulator Filter			
102-0620	1	Base, Oil			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
134-1804	1	Duct, Air			
309-0206	1	Switch, High Air Temperature			
338-0917	1	Harness, Wiring - Voltage Regulator to Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay and Lead Assembly - High Air Temperature and Overspeed (Assembly Includes Two Each of 307-0655 Relay and All Leads)			
307-1143	1	Relay, Generating (DPDT)			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			