

The following catalog
has gaps in its page
numbers, or doesn't
have any numbers.
We have chosen to
leave the page
numbering in the
order that Acrobat
assigns it.

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR31 **SPEC** 19985AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5568-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cutoff					
High Air Temperature Cutoff					
Overspeed Cutoff					
Gas Fuel System					
Skid and Battery Rack					
Note: Pennsylvania Approved					
115-0173	1	Cover, Rocker - Includes Oil Line			
508-0109	1	Grommet, Rubber - 1" Hole Governor Adjusting Nut			
309-0206	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
416-0325	1	Hydrometer			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
338-0917	1	Harness, Wiring - Voltage Regulator to Exciter Stator			
322-0004	3	Lamp, Indicator			
322-0069	3	Holder, Indicator Lamp			
320-0259	1	Relay, Low Oil Pressure (Includes Micro Switches)			
307-1519	1	Relay and Lead Assembly - High Air Temperature and Overspeed (Assembly includes two each of 307-0655 Relay and All Leads)			
307-1143	1	Relay, Generating (DPDT)			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 20055AB
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5559-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
High Air Temperature Cut Off					
Low Oil Pressure Cut Off					
Mounted Fuel Tank					
Housed					
Gas-Gasoline Fuel System					
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
309-0196	1	Switch, High Air Temperature			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0183	1	Elbow, Reducer - 1½ To 1½ (Exhaust)			
505-0100	2	Nipple, Oil Drain			
220-2041	1	Stator Assembly, Wound			
201-2156	1	Rotor Assembly			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 20115AB
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG)612-5558-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing)					
High Air Temperature Cutoff					
231-0171	1	Adapter, Generator			
502-0020	1	Elbow, Street -- Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
234-0492	1	Cover, Generator Air Outlet			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5IB-18R SPEC 20198AB
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5559-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Gas Fuel System					
Air Duct And Shutter					
Voltage Regulator Filter					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0175	1	Cover, Rocker - Includes Oil Line			
351-0103	1	Bushing, Snap - Gas Hose			
309-0196	1	Switch, High Air Temperature			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 5			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 20332AB
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5642-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Low Oil Pressure Cut Off					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
110-1742	1	Head Assembly, Cylinder - Includes Valves			
110-1741	1	Head, Cylinder - Without Valves			
520-0526	2	Stud, Carburetor Mounting			
502-0082	1	Nipple, Hex - Vacuum Switch			
502-0053	1	Elbow, Vacuum Switch			
502-0046	1	Nipple, Close - Vacuum Switch			
502-0051	1	Coupling, Vacuum Switch			
148-0367	1	Switch, Vacuum			
332-0604	1	Block, Terminal - 5 Place			
332-0616	1	Strip, Marker - 5 Place			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 20354AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5559-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Gas - Gasoline Fuel System			
		Vacu-Flo Cooling			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
		Skid And Battery Rack			
3C9-0196	1	Switch, High Air Temperature			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 20601AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5569-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
309-0206	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
322-0004	2	Lamp, Indicator - Low Oil Pressure And High Air Temperature			
307-1129	1	Relay, High Air Temperature			
322-0604	1	Block, Terminal - 5 Place			
332-0616	1	Strip, Marker - 5 Place			
301-2376	1	Panel, Control			

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5559-14

Skid And Battery Rack		
Low Oil Pressure Cut Off		
High Air Temperature Cut Off		
102-0620	1	Base, Oil
309-0196	1	Switch, High Air Temperature
134-1804	1	Duct, Air
220-2041	1	Stator Assembly, Generator
201-2156	1	Rotor Assembly, Generator
520-0796	4	Stud, Generator Through
520-0788	1	Stud, Rotor Through

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 20710AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-5559-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Low Oil Pressure Cut Off					
Air Duct And Shutter					
155-0369	1	Muffler, Critical			
220-2041	1	Stator Assembly, Generator			
201-2156	1	Rotor Assembly, Generator			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 20742AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5559-13

PART NO	QTY	DESCRIPTION	PART NO	QTY	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
309-0196	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
220-2668	1	Stator Assembly, Generator			
201-2310	1	Rotor Assembly, Generator			
201-2299	1	Rotor, Exciter			
234-0532	1	Baffle, Air - Generator			
220-2308	1	Stator, Exciter			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 20810AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5568-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Cut Off					
Housed					
Gas - Gasoline Fuel System					
155-0360	1	Muffler, Critical			
309-0206	1	Switch, High Air Temperature			
322-0004	3	Lamp, Indicator - Low Oil Pressure, Overspeed And High Air Temperature			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay And Lead Assembly - Overspeed And High Air Temperature (Assembly Includes Two Each Of 307-0655 Relay And Leads)			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			
301-3567	1	Panel, Control			

SPECIAL PARTS LIST FOR **MODEL** 6.0JB-53CR **SPEC** 20861AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-5559-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
		Gas Fuel System			
		Voltage Regulator Filter			
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
309-0196	1	Switch, High Air Temperature			

SPECIAL PARTS LIST FOR **MODEL** 7,5JB-3CR **SPEC** 20999AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5569-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Vacu-Flo Cooling					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Voltage Regulator Filter					
309-0206	1	Switch, High Air Temperature			
322-0004	2	Lamp, Indicator - Low Oil Pressure And High Air Temperature			
307-1129	1	Relay, High Air Temperature			
332-0604	1	Block, Terminal - 5 Place			
332-0516	1	Strip, Marker - 5 Place			
301-2376	1	Panel, Control			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 21018AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5559-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas - Gasoline Fuel System					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Air Duct And Shutter					
102-0620	1	Base, Oil			
309-0196	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
220-2041	1	Stator Assembly, Generator			
201-2156	1	Rotor Assembly, Generator			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 21107AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5564-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cut Off					
LPG Fuel System					
Low Oil Pressure Cut Off					
322-0004	1	Lamp, Indicator - Overspeed			
320-0104	1	Relay, Low Oil Pressure			
332-0604	1	Block, Terminal - 5 Place			
332-0616	1	Strip, Marker - 5 Place			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3R **SPEC** 21113AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5559-13 (AC) 612-1559-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Mounted Fuel Tank			
		Housed			
		Low Oil Pressure Cut Off			
		AC Meter Panel			
		High Air Temperature Cut Off			
309-0196	1	Switch, High Air Temperature			
155-0360	1	Muffler, Critical			
301-2288	1	Panel, Meter			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3R **SPEC** 21221AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5559-13 (AC)612-1559-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Voltage Regulator Filter			
		Low Oil Pressure Cut Off			
		Higl. Air Temperature Cut Off			
		LPG Fuel System			
		Housed			
		Air Duct And Shutter			
		AC Meter Panel			
102-0620	1	Base, Oil			
309-0196	1	Switch, High Air Temperature			
155-0360	1	Muffler, Critical			
301-2288	1	Panel, Meter			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 21268AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5559-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas - Gasoline Fuel System					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Skid And Battery Rack					
309-0196	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
220-2041	1	Stator Assembly, Generator			
201-2156	1	Rotor Assembly, Generator			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 21285AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5559-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Gas Fuel System					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
102-0620	1	Base, Oil			
309-0196	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
220-2041	1	Stator Assembly, Generator			
201-2156	1	Rotor Assembly, Generator			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 21346AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5559-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Gas - Gasoline Fuel System			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
		Mounted Fuel Tank			
		Housed			
		Air Duct And Shutter			
102-0620	1	Base, Oil			
309-0196	1	Switch, High Air Temperature			

SPECIAL PARTS LIST FOR **MODEL** 6.0JB-53R **SPEC** 21349AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5559-13 (AC) 612-1559-08

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Mounted Fuel Tank			
		Housed			
		Low Oil Pressure Cut Off			
		AC Meter Panel			
		Air Duct And Shutter			
301-2288	1	Panel, Meter			

SPECIAL PARTS LIST FOR **MODEL** 6.0JB-53CR **SPEC** 21365AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5568-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling					
Voltage Regulator Filter					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Cut Off					
309-0206	1	Switch, High Air Temperature			
322-0004	3	Lamp, Indicator - Low Oil Pressure, Overspeed And High Air Temperature			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay And Lead Assembly - Overspeed And High Air Temperature (Assembly Includes Two Each of 307-0655 Relay And Leads)			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			
301-3567	1	Panel, Control			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 21401AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5559-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Gas Fuel System					
Housed					
Voltage Regulator Filter					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
102-0620	1	Base, Oil			
155-0360	1	Muffler, Critical			
309-0196	1	Switch, High Air Temperature			
220-2041	1	Stator Assembly, Generator			
201-2156	1	Rotor Assembly, Generator			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR31 **SPEC** 21477AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5568-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
NOTE: Pennsylvania Approved Gas Fuel System Low Oil Pressure Cut Off High Air Temperature Cut Off Overspeed Cut Off					
416-0325	1	Hydrometer			
309-0206	1	Switch, High Air Temperature			
322-0004	3	Lamp, Indicator - Low Oil Pressure, Overspeed And High Air Temperature			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay And Lead Assembly - Overspeed And High Air Temperature (Assembly Includes Two Each Of 307-0655 Relay And Leads)			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			
301-3567	1	Panel, Control			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 21537AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5568-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Cut Off					
110-1742	1	Head Assembly, Cylinder - Includes Valves			
110-1741	1	Head, Cylinder - Without Valves			
520-0526	2	Stud, Carburetor Mounting			
502-0082	1	Nipple, Hex - Vacuum Switch			
502-0053	1	Elbow, Vacuum Switch			
502-0046	1	Nipple, Close - Vacuum Switch			
502-0051	1	Coupling, Vacuum Switch			
148-0367	1	Switch, Vacuum			
134-1804	1	Duct, Air			
309-0206	1	Switch, High Air Temperature			
322-0004	3	Lamp, Indicator - Low Oil Pressure, Overspeed And High Air Temperature			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay And Lead Assembly - Overspeed And High Air Temperature (Assembly Includes Two Each Of 307-0655 Relay And Leads)			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			
301-3567	1	Panel, Control			

WIRING DIAGRAM NO. (ENG) 612-5559-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Gas Fuel System			
		Housed			
		Air Duct And Shutter			
		Low Oil Pressure Cut Off			
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 21705AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5573-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Housed					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Cut Off					
Air Duct And Shutter					
102-0620	1	Base, Oil			
309-0206	1	Switch, High Air Temperature			
110-1742	1	Head Assembly, Cylinder -			
		Includes Valves			
110-1741	1	Head, Cylinder - Without			
		Valves			
520-0526	2	Stud, Carburetor Mounting			
502-0082	1	Nipple, Hex - Vacuum Switch			
502-0053	1	Elbow, Vacuum Switch			
502-0046	1	Nipple, Close - Vacuum Switch			
502-0051	1	Coupling, Vacuum Switch			
148-0367	1	Switch, Vacuum			
155-0360	1	Muffler, Critical			
234-0541	1	Cover, End Bell			
333-0184	1	Heater, Immersion - End Bell			
322-0004	3	Lamp, Indicator - Low Oil			
		Pressure, Overspeed And			
		High Air Temperature			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay And Lead Assembly -			
		Overspeed And High Air			
		Temperature (Assembly			
		Includes Two Each Of			
		307-0655 Relay And Leads)			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With			
		332-0706 Terminal Block			
301-3567	1	Panel, Control			

WIRING DIAGRAM NO. (ENG) 612-5558-09 (AC) 612-1559-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
AC Meter Panel					
155-0360	1	Muffler, Critical			
301-2288	1	Panel, Meter			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 21710AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5564-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Vacu-Flo Cooling					
231-0171	1	Adapter, Generator			
234-0492	1	Cover, Generator Air Outlet			
505-0098	1	Nipple, Close - Fuel Pump Inlet			
502-0020	1	Elbow, Street - Fuel Pump To Fuel Solenoid Valve			
502-0003	1	Connector, Inverted Male - Fuel Solenoid Valve Inlet			
307-1279	1	Valve, Fuel Solenoid			
309-0196	1	Switch, High Air Temperature			
322-0004	1	Lamp, Indicator - Overspeed			
320-0104	1	Relay, Low Oil Pressure			
332-0604	1	Block, Terminal - 5 Place			
332-0616	1	Strip, Marker - 5 Place			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 21730AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5558-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed			
		High Air Temperature Cut Off			
		Mounted Fuel Tank			
		Air Duct And Shutter			
309-0196	1	Switch, High Air Temperature			
155-0360	1	Muffler, Critical			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 21739AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5759-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cut Off					
Gas Fuel System					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
110-1742	1	Head Assembly, Cylinder - Includes Valves			
110-1741	1	Head, Cylinder - Without Valves			
520-0526	2	Stud, Carburetor Mounting			
502-0082	1	Nipple, Hex - Vacuum Switch			
502-0053	1	Elbow, Vacuum Switch			
502-0046	1	Nipple, Close - Vacuum Switch			
502-0051	1	Coupling, Vacuum Switch			
148-0367	1	Switch, Vacuum			
309-0196	1	Switch, High Air Temperature			
322-0004	1	Lamp, Indicator - Overspeed			
332-0604	1	Block, Terminal - 5 Place			
332-0616	1	Strip, Marker - 5 Place			
301-2376	1	Panel, Control			

WIRING DIAGRAM NO. (ENG) 612-5559-14

220-2041	1	Stator Assembly, Generator
201-2156	1	Rotor Assembly, Generator
520-0796	4	Stud, Generator Through
520-0788	1	Stud, Rotor Through

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3R **SPEC** 21752AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5558-09 (AC) 612-1786-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed			
		Air Duct And Shutter			
		AC Meter Panel			
		Voltage Regulator Filter			
155-0360	1	Muffler, Critical			
301-1554	1	Panel, Meter			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 21784AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5559-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Gas Fuel System					
Air Duct And Shutter					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
102-0620	1	Base, Oil			
309-0196	1	Switch, High Air Temperature			
220-2041	1	Stator Assembly, Generator			
201-2156	1	Rotor Assembly, Generator			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 21859AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5568-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Cut Off					
Gas - Gasoline Fuel System					
102-0620	1	Base, Oil			
309-0206	1	Switch, High Air Temperature			
220-2041	1	Stator Assembly, Generator			
201-2156	1	Rotor Assembly, Generator			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
322-0004	3	Lamp, Indicator - Low Oil Pressure, Overspeed And High Air Temperature			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay And Lead Assembly - Overspeed And High Air Temperature (Assembly Includes Two Each Of 307-0655 Relay And Leads)			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			
301-3567	1	Panel, Control			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 21876AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5573-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Cut Off					
Air Duct And Shutter					
Gas Fuel System					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
309-0206	1	Switch, High Air Temperature			
322-0004	3	Lamp, Indicator - Low Oil Pressure, Overspeed And High Air Temperature			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay And Lead Assembly - Overspeed And High Air Temperature (Assembly Includes Two Each Of 307-0655 Relay And Leads)			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			
301-3567	1	Panel, Control			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 21924AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG)612-5559-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas - Gasoline Fuel System					
Vacu-Flo Cooling					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Skid And Battery Rack					
309-0196	1	Switch, High Air Temperature			
220-2041	1	Stator Assembly, Generator			
201-2156	1	Rotor Assembly, Generator			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 21982AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5559-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas - Gasoline Fuel System					
Housed					
Low Oil Pressure Cut Off					
102-0620	1	Base, Oil			
220-2041	1	Stator Assembly, Generator			
201-2156	1	Rotor Assembly, Generator			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 22080AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5568-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas - Gasoline Fuel System					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Overspeed Cut Off					
309-0206	1	Switch, High Air Temperature			
134-1804	1	Duct, Air			
220-2041	1	Stator Assembly, Generator			
201-2156	1	Rotor Assembly, Generator			
520-0796	4	Stud, Generator Through			
520-0788	1	Stud, Rotor Through			
322-0004	3	Lamp, Indicator - Low Oil Pressure, Overspeed And High Air Temperature			
320-0259	1	Relay, Low Oil Pressure			
307-1519	1	Relay And Lead Assembly - Overspeed And High Air Temperature (Assembly Includes Two Each Of 307-0655 Relay And Leads)			
307-1143	1	Relay, Generating			
323-0760	1	Socket, Generating Relay			
332-0943	2	Spacer, Generating Relay			
307-1157	1	Spring, Relay Holddown			
309-0270	1	Thermostat, Low Engine Temperature			
332-0706	2	Block, Terminal - 8 Place			
332-0707	1	Strip, Marker - Use With 332-0706 Terminal Block			
301-3567	1	Panel, Control			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 22141AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5559-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas - Gasoline Fuel System					
Vacu-Flo Cooling					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
505-0098	1	Nipple, Close - Fuel Pump Inlet			
502-0020	1	Elbow, Street - Fuel Pump To Fuel Solenoid Valve			
502-0003	1	Connector, Inverted Male - Fuel Solenoid Valve Inlet			
307-1279	1	Valve, Fuel Solenoid			
309-0196	1	Switch, High Air Temperature			

WIRING DIAGRAM NO. (ENG)612-5559-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
102-0880	1	Base, Oil			
309-0196	1	Switch, High Air Temperature			
155-0360	1	Muffler, Critical			

SPECIAL PARTS LIST FOR **MODEL** 6.0JB-518R **SPEC** 23966AC
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5898-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Low Oil Pressure Switch			501-0110	1	Line, Oil (16") Oil Cooler
High Air Temperature Switch					to Oil Filter Adapter
AC Meter Panel (Blank)			104-0429	1	Crankdog, Flywheel
Carburetor Air Heater (Late Models)			192-0350	1	Crank, Flywheel
Mounted Fuel Tank			134-1406	1	Flywheel Assembly (Includes
					Parts Marked *)
800-0028	2	Screw, Cap - Hex Head	104-0423	1	*Gear, Ring
		(5/16-18 x 1") Fuel Pump	801-0054	4	*#Screw, Flywheel Hub Mounting
		Mounting			(3/8-24 x 2")
149-1307	2	Stiffener-Fuel Pump	134-1401	1	*Hub, Flywheel
		Mounting	526-0187	4	*#Washer, Flat-Hub to Flywheel
850-0045	2	Washer, Lock-Spring (5/16")	104-0543	4	*#Spacer and Washer-Hub to
		Fuel Pump Mounting			Flywheel
505-0061	1	Nipple, Pipe (1/8" x 2")	870-0352	4	*#Nut, Locking-Hub to Flywheel
		Fuel Pump Inlet			(Special)
502-0017	1	Connector-Fuel Pump Inlet	134-3960	1	Hardware Kit, Hub Mounting
103-0272	1	Backplate, Gearcase			(Includes Parts Marked #)
167-0215	2	Plug, Spark	166-0382	1	Coil, Ignition-Includes
141-0881	1	Carburetor, Gasoline-Includes			Capacitor
		Mounting Gasket (Manual Choke)	312-0083	1	Capacitor (Mounted on
153-0327	1	Bracket, Manual Choke			Ignition Coil)
518-0176	1	Clamp, Choke Cable	134-4246	1	Housing, Air-Bottom
153-0550	1	Cable, Manual Choke	166-0388	1	Bracket, Coil Mounting
150-1110	1	Bracket, Governor	503-0465	1	Clamp, Coil
150-1083	1	Stud, Governor Adjusting	336-9029	1	Lead-to Resistor (32")
122-0245	1	Adapter, Oil Filter			Marked #4
122-0246	1	Gasket, Oil Filter Adapter	336-1506	1	Lead-Points to Ignition
309-0130	1	Thermostat, Oil Filter			Coil (Low Tension) (18")
		Adapter	167-1480	2	Lead-High Tension (17")
122-0242	1	Spring, Oil By-Pass (Oil	812-0091	1	Screw, Machine-Round Head
		Filter Adapter)			(#8-32 x 2½") Resistor
122-0243	1	Gasket, Oil By-Pass Plate			Mounting
		(Oil Filter Adapter)	337-0070	1	Strap, Ground (5") Ignition
122-0244	1	Plate, Oil By-Pass (Oil			Coil
		Filter Adapter)	508-0005	2	Grommet, Rubber (9/16" Ho
800-0005	3	Screw, Cap-Hex Head (1/4-20 x			Air Housing Bottom
		3/4") Oil By-Pass Plate	336-7878	1	Lead-to Ignition Coil
		Mounting (Oil Filter			Capacitor (27") Marked #
		Adapter)	134-1449	1	Housing, Air-Front
850-0040	3	Washer, Lock-Spring (1/4")	508-0117	1	Grommet, Rubber (1-3/8"
		Oil By-Pass Plate Mounting			Hole)
		(Oil Filter Adapter)	134-1447	1	Housing, Blower
505-0274	1	Plug, Pipe (1/8") Oil By-Pass	134-1908	1	Cover, Air Housing
		(Oil Filter Adapter)	134-1091	1	Grille
502-0277	2	Elbow, Male (90°) Oil Filter	309-0196	1	Switch, High Air Temperat
		Adapter to Oil Cooler Oil	336-1348	1	Lead-Low Oil Pressure Swi
		Lines			(32")
102-0518	1	Plate, Oil Cooler Mounting	503-0311	2	Clamp, Hose-Carburetor Ai
102-0843	1	Cooler, Oil			Heater
501-0109	1	Line, Oil (17-3/8") Oil Filter	405-2943	1	Panel, Rear Housing-Gener
		Adapter to Oil Cooler			End

SPECIAL PARTS LIST FOR MODEL 6.0JB-518R SPEC 23966AC
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. 612-5898-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
402-0327	1	Hardware Package-Mounting (Set of 4)			
155-0360	1	Muffler, Exhaust			
140-0078	2	Clamp, Muffler Mounting			
154-0133	1	Gasket, Exhaust Manifold Outlet			
155-0170	1	Flange, Exhaust Manifold Outlet (Oval Shaped)			
155-1925	1	Flange, Exhaust Manifold Outlet (With Half Nipple)			
301-1195	1	Panel, AC Meter			
332-0537	1	Block, Terminal (4 Place)			
332-0566	1	Strip, Marker (4 Place)			
517-0019	1	Button, Dot ($\frac{1}{2}$ " Hole)			
508-0015	4	Washer, Fiber-Resistor Mounting (Two Used Per Resistor)			
357-0030	1	Rectifier (Ignition Relay)			

Parts Not Furnished by Onan:

Wiring Harness - Generator Control to
Housing Control Panel