

The following catalog
has gaps in its page
numbers, or doesn't
have any numbers.
We have chosen to
leave the page
numbering in the
order that Acrobat
assigns it.

SPECIAL PARTS LIST FOR **MODEL** 6.0JB-53CR **SPEC** 8347AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4793-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Skid and Battery Rack					
508-0001	1	Grommet, Rubber-Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
332-0566	1	Strip, Block Marker - 4 Place			
332-0537	1	Block, Terminal - 4 Place			
517-0139	1	Button, Dot (11/16" Hole)			

SPECIAL PARTS LIST FOR **MODEL** 6.0JB-518R **SPEC** 8347AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Skid and Battery Rack					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
220-2048	1	Stator Assembly, Wound			
332-0566	1	Strip, Block Marker - 4 Place			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot (11/16" Hole)			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 8347AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4793-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Skid and Battery Rack					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 8347AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Skid And Battery Rack					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-1R **SPEC** 8375AA
FOR STANDARD PARTS REFER TO CATALOG 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4793-09 (ENG) 612-3291-02 (AC

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank Housed Meter Panel					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
220-2015	1	Stator Assembly, Wound			
320-0148	1	Breaker, Circuit - 70 Amp.			
301-1641	1	Panel, Meter			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3R SPEC 8375AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG)612-4793-09(AC)612-1559-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank Housed Meter Panel					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2288	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-4R **SPEC** 8375AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4793-10(AC) 612-1469-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank Housed Meter Panel					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2204	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-4XR SPEC 8375AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (Eng.) 612-4793-10(AC) 612-1851-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank					
Housed					
Meter Panel					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2308	1	Panel, Meter			
304-0305	1	Resistor, Fixed - Meter Panel (45,000 Ohm, 10 Watt)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-4XR SPEC 8388T
FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 611-0807-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
416-0021	2	Cable, Battery			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			

SPECIAL PARTS LIST FOR MODEL 6.0JB-53CR SPEC 8388AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 612-4794-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1,2,3			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 8388AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4794-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing) Low Oil Pressure Cut Off High Air Temperature Cut Off					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 8388AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4794-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Vacu-Flo Cooling (See Air Housing)					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 6.0JB-53CR **SPEC** 8388AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5559-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Vacu-Flo Cooling (See Air Housing)					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1293	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
508-0001	1	Grommet, Rubber-Control Lox			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 8388AB
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5559-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
509-0196	1	Switch, High Air Temperature			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R**SPEC** 8388ABFOR STANDARD PARTS REFER TO **CATALOG** 967-0223**KEY NO.** 4

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5559-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Vacu-Flo Cooling (See Air Housing)					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-9XR **SPEC** 8389T
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 611-0806-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Vacu-Flo Cooling (See Air Housing)					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
416-0021	2	Cable, Battery			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 8389AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4793-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Vacu-Flo Cooling (See Air Housing)					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 8389AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Vacu-Flo Cooling (See Air Housing)					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole Governor Adjusting Nut			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 8389AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5558-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Gas - Gasoline Fuel System			
		Vacu-Flo Cooling			

SPECIAL PARTS LIST FOR MODEL 7.5JB-4R31 SPEC 8390U
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 611-0905-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Vacu-Flo Cooling (See Air Housing)					
NOTE: Pennsylvania Approved					
115-0173	1	Cover, Rocker - Includes Oil Line			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
307-0845	1	Solenoid, Start			
306-0196	1	Bracket, Start Solenoid Mtg			
338-0470	1	Harness, Wiring - Starter			
416-0325	1	Hydrometer			
332-0751	1	Block, Terminal - 10 Place			
332-1235	1	Strip, Marker - 10 Place			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 8390AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4793-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing)					
Gas Fuel System					
115-0173	1	Cover, Rocker - Includes Oil Line			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR31 **SPEC** 8390AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG)612-4793-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Vacu-Flo Cooling (See Air Housing)					
Note: Pennsylvania Approved					
115-0173	1	Cover, Rocker - Includes Oil Line			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
416-0325	1	Hydrometer			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

WIRING DIAGRAM NO. (ENG) 612-5558-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
NOTE: Pennsylvania Approved Gas Fuel System Vacu-Flo Cooling					
416-0325	1	Hydrometer			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3R **SPEC** 8430AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4794-13(AC) 612-1559-C

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Low Oil Pressure Cutoff					
Meter Panel					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2288	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-5DR **SPEC** 8457T
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 611-0807-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cut Off					
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
416-0021	2	Cable, Battery			
220-0629	1	Stator Assembly, Wound			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			

SPECIAL PARTS LIST FOR MODEL 6.0JB-53CR SPEC 8457AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 612-4794-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cut Off					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			
332-0557	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1,2,3			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 8457AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG)612-4794-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cutoff					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 8457AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4794-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cut Off					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 8457AB
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5559-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cutoff					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 8489AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Skid And Battery Rack			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
134-1804	1	Duct, Air			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 8505AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4794-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
115-0173	1	Cover, Rocker - Includes Oil Line			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R31 **SPEC** 8505AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4794-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Vacu-Flo Cooling (See Air Housing)					
Note: Pennsylvania Approved					
112-0106	2	Piston And Pin			
113-0107	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
416-0325	1	Hydrometer			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 8525AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. 612-4794-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cut Off					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 8525AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4794-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Low Oil Pressure Cut Off					
Vacu-Flo Cooling (See Air Housing)					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 8525AB
FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5559-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cut Off					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 8561AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4794-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 8561AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. 612-4794-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 6.0JB-53CR **SPEC** 8561AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5559-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Gas-Gasoline Fuel System			
		Vacu-Flo Cooling			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
309-0196	1	Switch, High Air Temperature			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 8561AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5559-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 8582AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4793-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing)					
High Air Temperature Cut Off					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 8645AB
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5558-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System					
Housed					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1½ To 1¼ (Exhaust)			
505-0100	2	Nipple, Oil Drain			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 6.0JB-599R SPEC 8663T
FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 611-1004-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing)					
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
416-0021	2	Cable, Battery			
304-0512	1	Resistor, Exciter			
315-0105	1	Reactor, Voltage Control			
315-0104	2	Reactor, Gate			
220-0965	1	Stator Assembly, Wound			
301-1964	1	Bracket, Control Box - L. H.			
301-1965	1	Bracket, Control Box - R. H.			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-99R **SPEC** 8663AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5087-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing)					
Adjustable Voltage Regulator					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
220-2515	1	Stator Assembly, Wound			
305-0558	1	Regulator Assembly, Voltage (Adjustable) For Component Parts Use Parts Listed For 305-0533 Voltage Regulator Plus Part Marked *.			
351-0222	1	*Resistor -2,000 Ohm- $\frac{1}{4}$ Watt			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-99R **SPEC** 8663AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-5617-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing)					
Adjustable Voltage Regulator					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
220-2515	1	Stator Assembly, Wound			
305-0587	1	Regulator Assembly, Voltage (Adjustable) For Component Parts Use Parts Listed For 305-0590 Voltage Regulator Plus Part Marked *			
351-0222	1	*Resistor -2,000 Ohm- $\frac{1}{4}$ Watt			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R31 **SPEC** 8689AA
FOR STANDARD PARTS REFER TO CATALOG 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4794-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas Fuel System					
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cut Off					
Note: Pennsylvania Approved					
112-0092	2	Piston And Pin			
113-0089	2	Ring Set, Piston			
115-0173	1	Cover, Rocker - Includes Oil Line			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
416-0325	1	Hydrometer			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-4R **SPEC** 8706AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4794-14 (AC) 612-1469-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Low Oil Pressure Cutoff					
Meter Panel					
High Air Temperature Cutoff					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2204	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR MODEL 7.5JB-5DR SPEC 8706AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR AIR OR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. 612-4794-14 (AC) 612-1556-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Housed					
Meter Panel					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
507-1205	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
505-0183	1	Elbow, Reducer - 1/2 To 1/4 (Exhaust)			
501-2204	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0565	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-4R **SPEC** 8706AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5559-14 (AC)612-1469-0

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Low Oil Pressure Cut Off High Air Temperature Cut Off AC Meter Panel 309-0196 1 Switch, High Air Temperature 301-2204 1 Panel, Meter					

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-5DR **SPEC** 8706AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5559-14 (AC) 612-1556.

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Low Oil Pressure Cut Off High Air Temperature Cut Off AC Meter Panel					
309-0196	1	Switch, High Air Temperature			
301-2204	1	Panel, Meter			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 8727T
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 611-0806-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank					
Housed					
Air Duct and Shutter					
High Air Temperature Cut Off					
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
416-0004	1	Cable, Battery Jumper			
220-0596	1	Stator Assembly, Wound			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
301-1964	1	Bracket, Control Box - L. H.			
301-1965	1	Bracket, Control Box - R. H.			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-4R **SPEC** 8803T
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 611-0807-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cutoff					
High Air Temperature Cutoff					
Day Tank (One Quart)					
Vacu-Flo Cooling (See Air Housing)					
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
134-1843	1	Cover, Air Housing			
502-0053	1	Elbow, Street Pipe - Valve to Carburetor Fuel Line			
508-0021	2	Grommet, Rubber - Air Housing Cover (3/4" Hole)			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			
416-0021	2	Cable, Battery			
501-0005	1	Line, Fuel - Valve To Carb.			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-9XR **SPEC** 8803AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4891-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Vacu-Flo Cooling (See Air Housing) Low Oil Pressure Cut Off High Air Temperature Cut Off Day Tank (One Quart)					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
502-0053	1	Elbow, Street Pipe - Valve To Carburetor Fuel Line			
501-0005	1	Line, Fuel - Valve To Carb.			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 8803AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5559-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Vacu-Flo Cooling			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
		Day Tank (One Quart)			
309-0196	1	Switch, High Air Temperature			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 8809T
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW
WIRING DIAGRAM NO. 611-0807-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
Vacu-Flo Cooling (See Air Housing)					
Mobile Unit Air Cleaner					
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
503-0330	1	Hose, Air Cleaner - 2" Long			
416-0021	2	Cable, Battery			
220-0596	1	Stator Assembly, Wound			
301-1964	1	Bracket, Control Box - L. H.			
301-1965	1	Bracket, Control Box - R. H.			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 8809AA
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4794-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mobile Unit Air Cleaner Vacu-Flo Cooling Low Oil Pressure Cut Off					
502-0002	1	Elbow, Fuel Pump Inlet			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 8812AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4860-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Vacu-Flo Cooling (See Air Housing)					
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0206	1	Switch, High Air Temperature			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
322-0004	2	Lamp, Indicator - High Air Temp. And Low Oil Pressure			
307-1129	1	Relay, High Air Temperature			
301-2376	1	Panel, Control			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 8898AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. 612-4794-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Air Temperature Cut Off					
Housed					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
155-0360	1	Muffler			
140-0078	2	Band, Muffler			
155-0951	1	Tube, Flexible Exhaust			
505-0183	1	Elbow, Reducer - 1½ To 1¼ (Exhaust)			
505-0100	2	Nipple, Oil Drain			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 5			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 8898AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5559-14

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
155-0360	1	Muffler, Critical			

SPECIAL PARTS LIST FOR MODEL 7.5JB-1R SPEC 8941AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4795-09 (AC) 612-3291

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Meter Panel					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
220-2015	1	Stator Assembly, Wound			
320-0148	1	Breaker, Circuit - 70 Amp.			
301-1641	1	Panel, Meter			
332-0566	1	Strip, Marker - B+, 1, 2, 5			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3R **SPEC** 8941AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4793-09 (AC) 612-1559-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Meter Panel					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2288	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-4R**SPEC** 8941AAFOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4793-10(AC) 612-1469-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Meter Panel					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2204	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 6.0JB-52R SPEC 8969AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 612-4793-10 (AC) 612-4729-

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank Housed Air Duct and Shutter Meter Panel					
505-0183	1	Elbow, Reducer - 1 1/2 to 1 1/4 (Exhaust)			
338-0495	1	Harness, Wiring - Control to Output Box			
322-0072	2	Receptacle, Panel Light			
301-1641	1	Panel, Meter			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
332-0566	1	Strip, Block Marker - 4 Place			
332-0537	1	Block, Terminal - 4 Place			
517-0139	1	Button, Dot (11/16" Hole)			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 9220AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4848-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Vacu-Flo Cooling (See Air Housing)			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
338-0917	1	Harness, Wiring - Voltage Regulator to Exciter Stator			
322-0004	1	Lamp, Indicator - Overspeed			
322-0069	1	Holder, Indicator Lamp			
320-0104	1	Relay, Low Oil Pressure			
307-1129	1	Relay, Overspeed			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 9220AB
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5564-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Vacu-Flo Cooling (See Air Housing)			
		Low Oil Pressure Cut Off			
		High Air Temperature Cut Off			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
508-0109	1	Grommet, Rubber - 1" Hole - Governor Adjusting Nut			
309-0196	1	Switch, High Air Temperature			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
338-0917	1	Harness, Wiring - Voltage Regulator to Exciter Stator			
322-0004	1	Lamp, Indicator - Overspeed			
322-0069	1	Holder, Indicator Lamp			
320-0104	1	Relay, Low Oil Pressure			
307-1129	1	Relay, Overspeed			

SPECIAL PARTS LIST FOR MODEL 7.5JB-4R SPEC 9234U
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 611-0806-02(AC) 612-1486-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System Housed Meter Panel					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
416-0004	1	Cable, Battery Jumper			
301-2088	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-4R **SPEC** 9269U
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG)611-0806-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System Housed					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
416-0004	1	Cable, Battery Jumper			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-9XR **SPEC** 9269U
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 611-0806-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System Housed					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
416-0004	1	Cable, Battery Jumper			
505-0183	1	Elbow, Reducer - 1½ To 1½ (Exhaust)			
522-0072	2	Receptacle, Panel Light			
538-0495	1	Harness, Wiring - Control To Output Box			
501-1964	1	Bracket, Control Box - L.H.			
501-1965	1	Bracket, Control Box - R.H.			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 9269AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4793-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System Housed					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 9269AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System Housed					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1½ To 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 9269AB
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. 612-5558-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System Housed					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 9269AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-5558-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
LPG Fuel System Housed					
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1½ To 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 6.0JB-53R SPEC 9279T
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 611-0807-01 (AC) 612-1559-

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank Housed Air Duct And Shutter Low Oil Pressure Cut Off High Air Temperature Cut Off Meter Panel					
309-0196	1	Switch, High Air Temperature			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
220-0693	1	Stator Assembly, Wound			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
301-2288	1	Panel, Meter			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			
416-0004	1	Cable, Battery Jumper			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3R SPEC 9279AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4794-13 (AC) 612-1559-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed					
Air Duct and Shutter					
Mounted Fuel Tank					
Low Oil Pressure Cutoff					
High Air Temperature Cutoff					
Meter Panel					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
309-0196	1	Switch, High Air Temperature			
301-2288	1	Panel, Meter			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harress, Wiring - Control to Output Box			
508-0001	1	Grommet, Rubber - Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0565	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 9331AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-5559-13 (AC) 612-1559-0.

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank Housed Low Oil Pressure Cut Off Meter Panel					
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
505-0183	1	Elbow, Reducer - 1½ To 1¼ (Exhaust)			
301-2288	1	Panel, Meter			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
508-0001	1	Grommet, Rubber-Control Box			
508-0015	4	Washer, Fiber - Control Panel Resistors			
332-0537	1	Block, Terminal - 4 Place			
332-0566	1	Strip, Marker - B+, 1, 2, 3			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3R **SPEC** 9331AB
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BEL

WIRING DIAGRAM NO. (ENG)612-5559-13 (AC)612-1559

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Mounted Fuel Tank			
		Housed			
		Low Oil Pressure Cut Off			
		AC Meter Panel			
301-2288	1	Panel, Meter			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 9549AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. 612-4793-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-4XR SPEC 9578AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (Eng.) 612-4793-10(AC) 612-1851-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Housed					
Mounted Fuel Tank					
Meter Panel					
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1-1/2 to 1-1/4 (Exhaust)			
301-2308	1	Panel, Meter			
304-0305	1	Resistor, Fixed - Meter Panel (45,000 Ohm, 10 Watt)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
332-0566	1	Strip, Marker - B+,1,2,3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 9582AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4793-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank					
Housed					
102-0620	1	Base, Oil			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
522-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 9582AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank Housed					
102-0620	1	Base, Oil			
502-0020	1	Elbow, Street - Fuel Pump Inlet			
505-0061	1	Nipple, Pipe - Fuel Pump Inlet			
502-0017	1	Connector, Female - Fuel Pump Inlet			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
505-0183	1	Elbow, Reducer - 1½ To 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control To Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 9582AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5558-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank Housed					
102-0620	1	Base, Oil			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 9582AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5558-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Mounted Fuel Tank Housed					
102-0620	1	Base, Oil			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-3CR **SPEC** 9597T
FOR STANDARD PARTS REFER TO **CATALOG** 967-0225 **KEY NO.** 4
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 611-0806-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
154-1804	1	Duct, Air			
220-0596	1	Stator Assembly, Wound			
301-1964	1	Bracket, Control Box - L.H.			
301-1965	1	Bracket, Control Box - R.H.			

SPECIAL PARTS LIST FOR MODEL 7.5JB-18R SPEC 9597AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4793-10

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
134-1804	1	Duct, Air			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 9597AB
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. 612-5558-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
331-0103	1	Bushing, Snap - Gas Hose			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
134-1804	1	Duct, Air			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR MODEL 7.5JB-3CR SPEC 9616AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0223 KEY NO. 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4795-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System					
Housed					
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1½ to 1¼ (Exhaust)			
322-0072	2	Receptacle, Panel Light			
338-0495	1	Harness, Wiring - Control to Output Box			
332-0566	1	Strip, Marker - B+, 1, 2, 3			
332-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber - Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			

SPECIAL PARTS LIST FOR **MODEL** 7.5JB-18R **SPEC** 9616AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0223 **KEY NO.** 4
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 612-4793-10 (ENG)

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Gas-Gasoline Fuel System Housed					
102-0620	1	Base, Oil			
115-0173	1	Cover, Rocker - Includes Oil Line			
307-1203	1	Coil, Choke Solenoid			
153-0391	1	Core, Choke Solenoid			
331-0103	1	Bushing, Snap - Gas Hose			
505-0183	1	Elbow, Reducer - 1½ To 1½ (Exhaust)			
522-0072	2	Receptacle, Panel Light			
538-0495	1	Harness, Wiring - Control To Output Box			
532-0566	1	Strip, Marker - B+, 1, 2, 3			
532-0537	1	Block, Terminal - 4 Place			
508-0001	1	Grommet, Rubber-Control Box			
517-0139	1	Button, Dot - Control Box			
508-0015	2	Washer, Fiber - Control Panel Resistor			