

The following catalog
has gaps in its page
numbers, or doesn't
have any numbers.
We have chosen to
leave the page
numbering in the
order that Acrobat
assigns it.

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-4XR **SPEC** 16345AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4997-02 (AC) 612-1851-05

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--|------|---|----------|------|-------------|
| Low Oil Pressure Cut Off High Air Temperature Cut Off Overspeed Cut Off Housed Meter Panel | | | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 301-2308 | 1 | Panel, Meter | | | |
| 304-0305 | 1 | Resistor, Fixed-Meter Panel | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 3 | Lamp, Indicator - Low Oil Pressure (1) High Air Temp. (1) Overspeed (1) | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-0655 | 2 | Relay, Latching - High Air Temp. (1) Overspeed (1) | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker (Blank) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR MODEL 12.5JC-4R SPEC 16349AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4794-02 (AC) 612-1469-0

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|---|----------|------|-------------|
| Housed | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Meter Panel | | | | | |
| Gas Fuel System | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 155-0360 | 1 | Muffler | | | |
| 140-0078 | 2 | Band, Muffler Mounting | | | |
| 155-0949 | 1 | Tube, Exhaust - Flexible | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 333-0151 | 1 | Heater - Control | | | |
| 309-0128 | 1 | Thermostat, Adjustable - Control | | | |
| 301-1886 | 1 | Cover, Thermostat - Control | | | |
| 335-0110 | 1 | Cable Assembly, Heater - Control | | | |
| 301-2204 | 1 | Panel, Meter | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 320-0104 | 1 | Relay, Low Oil Pressure | | | |

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-4R **SPEC** 16363AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4793-02 (AC) 612-1486-05

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--|------|---|----------|------|-------------|
| Gas - Gasoline Fuel System Housed Air Shutter Meter Panel | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 301-2088 | 1 | Panel, Meter | | | |

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4794-02

| | | |
|----------|---|-----------------------------|
| 134-3756 | 1 | Duct, Air |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover |
| 220-2044 | 1 | Stator, Generator |
| 201-2159 | 1 | Rotor Assembly, Generator |
| 520-0799 | 4 | Stud, Generator Through |
| 520-0791 | 1 | Stud, Rotor Through |

SPECIAL PARTS LIST FOR MODEL 12.5JC-3R SPEC 16380AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4997-05 (SWBD) 615-0373-

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|---|----------|------|-------------|
| Overspeed Cut Off | | | | | |
| Gas Fuel System | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Switchboard Control | | | | | |
| 112-0106 | 4 | Piston and Pin | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 134-1805 | 1 | Duct, Air | | | |
| 302-0458 | 2 | Ammeter, AC | | | |
| 301-2086 | 1 | Panel, Instrument | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 3 | Lamp, Indicator - Low Oil Pressure (1) High Air Temp. (1) Overspeed (1) | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-0655 | 2 | Relay, Latching - High Air Temp. (1) Overspeed (1) | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker (Blank) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-4R SPEC 16380AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4997-06 (SWBD) 615-0371

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|---|----------|------|-------------|
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Overspeed Cut Off | | | | | |
| Gas Fuel System | | | | | |
| Switchboard Control | | | | | |
| 112-0106 | 4 | Piston and Pin | | | |
| 351-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 134-1805 | 1 | Duct, Air | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 302-0458 | 3 | Ammeter, AC | | | |
| 301-2099 | 1 | Panel, Instrument | | | |
| 301-0500 | 1 | Box Assembly, Meter - Includes Box, Cover and Grommet | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 3 | Lamp, Indicator - Low Oil Pressure (1) High Air Temp. (1) Overspeed (1) | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-0655 | 2 | Relay, Latching - High Air Temp. (1) Overspeed (1) | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker (Blank) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR **MODEL** 12.5JC-4XR **SPEC** 16385AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4794-06 (SWBD) 615-0381-0

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--|------|-----------------------------|----------|------|-------------|
| Vacu - Flo Cooling (See Air Housing) Skid and Battery Rack (See Housing Option) Low Oil Pressure Cut Off High Air Temperature Cut Off Gas Fuel System Switchboard Control | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 309-0162 | 1 | Switch, High Air Temp. | | | |
| 508-0002 | 1 | Grommet, Rubber - High Air | | | |
| | | Temp. Switch Harness | | | |
| 338-0337 | 1 | Harness, Wiring - High Air | | | |
| | | Temperature Switch | | | |
| 508-0109 | 1 | Grommet, Rubber - 1" Hole | | | |
| 134-3081 | 1 | Guard, Scroll Outlet | | | |
| 505-0002 | 2 | Nipple, Oil Drain | | | |
| 402-0364 | 1 | Hardware Set, Generator Set | | | |
| | | Mounting (Set of Four) | | | |
| 416-0522 | 1 | Plate, Battery Mounting | | | |
| 301-2116 | 1 | Panel, Instrument | | | |
| 301-0994 | 1 | Box Assembly, Meter - | | | |
| | | Includes Box, Cover and | | | |
| | | Grommet | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 320-0104 | 1 | Relay, Low Oil Pressure | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-3CR SPEC 16387AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4997-01

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--------------------------------------|------|------------------------------|----------|------|-------------|
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Overspeed Cut Off | | | | | |
| LPG Fuel System | | | | | |
| Vacu - Flo Cooling (See Air Housing) | | | | | |
| 309-0171 | 1 | Switch, High Air Temperature | | | |
| 508-0002 | 1 | Grommet, Rubber - High Air | | | |
| | | Temp. Switch Harness | | | |
| 338-0337 | 1 | Harness, Wiring - High Air | | | |
| | | Temperature Switch | | | |
| 508-0109 | 1 | Grommet, Rubber - 1" Hole | | | |
| 134-3081 | 1 | Guard, Scroll Outlet | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage | | | |
| | | Regulator to Exciter | | | |
| | | Stator | | | |
| 322-0004 | 3 | Lamp, Indicator - Low Oil | | | |
| | | Pressure (1) High Air | | | |
| | | Temp. (1) Overspeed (1) | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil | | | |
| | | Pressure | | | |
| 307-0655 | 2 | Relay, Latching - High Air | | | |
| | | Temp. (1) Overspeed (1) | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker (Blank) | | | |
| 321-0146 | 1 | Fuse -10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-18R SPEC 16387AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. _____ (ENG) 612-4997-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--------------------------------------|------|------------------------------|----------|------|-------------|
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Overspeed Cut Off | | | | | |
| Vacu - Flo Cooling (See Air Housing) | | | | | |
| LPG Fuel System | | | | | |
| 309-0171 | 1 | Switch, High Air Temperature | | | |
| 508-0002 | 1 | Grommet, Rubber - High Air | | | |
| | | Temp. Switch Harness | | | |
| 338-0337 | 1 | Harness, Wiring - High Air | | | |
| | | Temperature Switch | | | |
| 508-0109 | 1 | Grommet, Rubber - 1" Hole | | | |
| 134-3081 | 1 | Guard, Scroll Outlet | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage | | | |
| | | Regulator to Exciter | | | |
| | | Stator | | | |
| 322-0004 | 3 | Lamp, Indicator - Low Oil | | | |
| | | Pressure (1) High Air | | | |
| | | Temp. (1) Overspeed (1) | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil | | | |
| | | Pressure | | | |
| 307-0655 | 2 | Relay, Latching - High Air | | | |
| | | Temp. (1) Overspeed (1) | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker (Blank) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-3CR SPEC 16388AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. _____ (ENG) 612-4851-01

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|---|----------|------|-------------|
| High Air Temperature Cut Off | | | | | |
| Overspeed Cut Off | | | | | |
| Air Shutter | | | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 1 | Lamp, Indicator - Overspeed | | | |
| 322-0069 | 1 | Holder, Indicator Lamp | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 307-0655 | 1 | Relay, Overspeed | | | |
| 332-0604 | 1 | Block, Terminal - 5 Place | | | |
| 332-0616 | 1 | Strip, Marker - 5 Place | | | |

SPECIAL PARTS LIST FOR **MODEL** 12.5JC-3CR **SPEC** 16389AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4860-01

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--|------|---|----------|------|-------------|
| LPG Fuel System | | | | | |
| Skid and Battery Rack (See Housing Option) | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 505-0002 | 2 | Nipple, Oil Drain | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 322-0004 | 2 | Lamp, Indicator - High Air Temperature (1) Low Oil Pressure (1) | | | |
| 322-0069 | 2 | Holder, Indicator Lamp | | | |
| 320-0221 | 1 | Relay, Low Oil Pressure | | | |
| 307-0655 | 1 | Relay, Latching - High Air Temperature | | | |
| 332-0604 | 1 | Block, Terminal - 5 Place | | | |
| 332-0616 | 1 | Strip, Marker - 5 Place | | | |
| 301-2376 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-18R SPEC 16389AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4860-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--|------|---|----------|------|-------------|
| Skid and Battery Rack (See Housing Option) | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| LPG Fuel System | | | | | |
| High Air Temperature Cut Off | | | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 505-0002 | 2 | Nipple, Oil Drain | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 322-0004 | 2 | Lamp, Indicator - High Air Temperature (1) Low Oil Pressure (1) | | | |
| 322-0069 | 2 | Holder, Indicator Lamp | | | |
| 320-0221 | 1 | Relay, Low Oil Pressure | | | |
| 307-0655 | 1 | Relay, Latching - High Air Temperature | | | |
| 332-0604 | 1 | Block, Terminal - 5 Place | | | |
| 332-0616 | 1 | Strip, Marker - 5 Place | | | |
| 301-2376 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-3R **SPEC** 16391AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (Eng) 612-4997-07 (SWBD) 615-0373-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|---|----------|------|-------------|
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Overspeed Cut Off | | | | | |
| LPG Fuel System | | | | | |
| Switchboard Control | | | | | |
| Adjustable Voltage Regulator | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 302-0458 | 2 | Ammeter, AC | | | |
| 301-2086 | 1 | Panel, Instrument | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 3 | Lamp, Indicator - Low Oil Pressure (1) High Air Temp. (1) Overspeed (1) | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-0655 | 2 | Relay, Latching - High Air Temp. (1) Overspeed (1) | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker (Blank) | | | |
| 321-0146 | 1 | Fuse - 10 Amp | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR **MODEL** 12.5JC-3CR **SPEC** 16393AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4794-01

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--------------------------------------|------|--|----------|------|-------------|
| Vacu - Flo Cooling (See Air Housing) | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| 231-0171 | 1 | Adapter, Generator | | | |
| 141-0686 | 1 | Carburetor, Gasoline (Manual Choke) | | | |
| 141-0747 | 1 | Kit, Carburetor Repair | | | |
| 141-0748 | 1 | Kit, Carburetor Gasket | | | |
| 141-0741 | 1 | Plate, Choke | | | |
| 141-0742 | 1 | Shaft, Choke | | | |
| 141-0699 | 1 | Washer, Choke Shaft | | | |
| 141-0697 | 1 | Seal, Felt - Choke Shaft | | | |
| 141-0203 | 1 | Retainer, Seal - Choke Shaft | | | |
| 153-0327 | 1 | Bracket, Manual Choke | | | |
| 518-0176 | 1 | Clamp, Manual Choke Cable | | | |
| 140-0645 | 1 | Adapter, Oil Bath Air Cleaner Type | | | |
| 140-0721 | 1 | Cleaner, Air - Includes Element and Baffle | | | |
| 140-0765 | 1 | Element, Air Cleaner | | | |
| 140-1267 | 1 | Baffle, Air Cleaner | | | |
| 140-0722 | 2 | Band, Air Cleaner Mounting | | | |
| 503-0274 | 4 | Clamp, Hose - Air Cleaner | | | |
| 503-0419 | 1 | Elbow, Rubber - Air Cleaner | | | |
| 140-1271 | 1 | Bracket, Air Cleaner Mtg. | | | |
| 140-0740 | 1 | Tube, Intake - Air Cleaner | | | |
| 140-0723 | 1 | Pre-Cleaner - Air Cleaner | | | |
| 191-0506 | 1 | Seal, Dirt - Starter Motor | | | |
| 191-0505 | 1 | Plate, Cover - Starter Motor | | | |
| 134-1532 | 1 | Baffle, Starter Motor Hole | | | |
| 332-1554 | 1 | Clamp, Loop - Starter Harness | | | |
| 309-0162 | 1 | Switch, High Air Temperature | | | |
| 134-3081 | 1 | Guard, Scroll Outlet | | | |
| 508-0002 | 1 | Grommet, Rubber - High Air Temp. Switch Harness | | | |
| 338-0337 | 1 | Harness, Wiring - High Air Temperature Switch | | | |
| 508-0109 | 1 | Grommet, Rubber - 1" Hole | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 320-0104 | 1 | Relay, Low Oil Pressure | | | |
| Parts Not Furnished by Onan | | | | | |
| Manual Choke Cable | | | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-18R SPEC 16402AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4794-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|--|----------|------|-------------|
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Day Tank (One Quart) | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 502-0020 | 1 | Elbow, Street - Fuel Pump Inlet | | | |
| 504-0007 | 1 | Valve, Fuel Pump Inlet | | | |
| 502-0002 | 2 | Elbow, Inverted Flare - Day Tank Fuel Line to Fuel Pump Inlet Valve (1) And Day Tank Fuel Line to Carburetor Inlet (1) | | | |
| 134-1805 | 1 | Duct, Air | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 320-0104 | 1 | Relay, Low Oil Pressure | | | |

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-4R **SPEC** 16414AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO(ENG) 612-4794-02 (AC) 612-1486-05

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|--|----------|------|-------------|
| Gas Fuel System | | | | | |
| Housed | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Meter Panel | | | | | |
| Air Shutter | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 112-0106 | 4 | Piston and Pin | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 301-2088 | 1 | Panel, Meter | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 320-0104 | 1 | Relay, Low Oil Pressure | | | |

SPECIAL PARTS LIST FOR MODEL 12.5JC-18R SPEC 16416AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 612-4793-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|----------|------|-------------|----------|------|-------------|
|----------|------|-------------|----------|------|-------------|

Gas Fuel System

Vacu - Flo Cooling (See Air Housing)

Skid and Battery Rack (See Housing Option)

| | | |
|----------|---|---|
| 134-3081 | 1 | Guard, Scroll Outlet |
| 508-0109 | 1 | Grommet, Rubber - 1" Hole |
| 505-0002 | 2 | Nipple, Oil Drain |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) |

The following parts refer to the regulator
filter assembly:

| | | |
|----------|---|---|
| 232-2589 | 1 | Regulator Filter Package - (for Complete Replacement) includes drawings and unlisted miscellaneous hardware items |
| 232-2462 | 1 | Box, Mounting |
| 232-2463 | 1 | Cover, Mounting Box |
| 312-0197 | 1 | Capacitor |
| 312-0198 | 2 | Bracket, Capacitor Mounting |
| 508-0071 | 1 | Grommet, Rubber - 7/8" Hole |
| 304-0120 | 2 | Resistor, Fixed - 2 Ohm, 25 Watts |
| 304-0015 | 4 | Washer, Resistor Centering |
| 304-0292 | 2 | Insulator, Resistor |
| 813-0112 | 2 | Screw - RHM (10-32 x 2½") Resistor Mounting |
| 338-1165 | 1 | Harness, Wiring |
| 625-1304 | - | Wiring Diagram |

SPECIAL PARTS LIST FOR MODEL 15.0JC-3R SPEC 16418AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (Eng) 612-4851-05 (SWBD) 615-0373-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--|------|---|----------|------|-------------|
| High Air Temperature Cut Off | | | | | |
| Overspeed Cut Off | | | | | |
| Skid and Battery Rack (See Housing Option) | | | | | |
| LPG Fuel System | | | | | |
| Switchboard Control | | | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 505-0002 | 2 | Nipple, Oil Drain | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 416-0522 | 1 | Plate, Battery Mounting | | | |
| 302-0458 | 2 | Ammeter, AC | | | |
| 301-2086 | 1 | Panel, Instrument | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-9004 | 1 | Lamp, Indicator - Overspeed | | | |
| 322-0069 | 1 | Holder, Indicator Lamp | | | |
| 321-0146 | 1 | Fuse - 10 Amp | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 307-0655 | 1 | Relay, Overspeed | | | |
| 332-0604 | 1 | Block, Terminal - 5 Place | | | |
| 332-0616 | 1 | Strip, Marker - 5 Place | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-4R SPEC 16421AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4793-08 (SWBD) 615-0371

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|---|----------|------|-------------|
| Gas - Gasoline Fuel System | | | | | |
| Switchboard Control | | | | | |
| Adjustable Voltage Regulator | | | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 302-0458 | 3 | Ammeter, AC | | | |
| 301-2099 | 1 | Panel, Instrument | | | |
| 301-0500 | 1 | Box Assembly, Meter - Includes Box, Cover and Grommet | | | |

SPECIAL PARTS LIST FOR **MODEL** 12.5JC-18R **SPEC** 16425AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. _____ **(ENG)** 612-4793-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--------------------------------------|------|-----------------------------------|----------|------|-------------|
| Vacu - Flo Cooling (See Air Housing) | | | | | |
| Gas - Gasoline Fuel System | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 134-3081 | 1 | Guard, Scroll Outlet | | | |
| 508-0109 | 1 | Grommet, Rubber - 1" Hole | | | |
| 220-2043 | 1 | Stator, Wound - Generator | | | |
| 201-2158 | 1 | Rotor Assembly, Wound - Generator | | | |
| 520-0798 | 4 | Stud, Generator Through | | | |
| 520-0790 | 1 | Stud, Rotor Through | | | |

FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. _____ (ENG) 612-4793-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--------------------------------------|------|-----------------------------------|----------|------|-------------|
| Vacu - Flo Cooling (See Air Housing) | | | | | |
| Gas - Gasoline Fuel System | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 134-3081 | 1 | Guard, Scroll Outlet | | | |
| 508-0109 | 1 | Grommet, Rubber - 1" Hole | | | |
| 220-2044 | 1 | Stator, Wound - Generator | | | |
| 201-2159 | 1 | Rotor Assembly, Wound - Generator | | | |
| 520-0799 | 4 | Stud, Generator Through | | | |
| 520-0791 | 1 | Stud, Rotor Through | | | |

SPECIAL PARTS LIST FOR **MODEL** 12.5JC-18R **SPEC** 16425AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 1
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5558-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|----------------------------|------|---------------------------|----------|------|-------------|
| Gas - Gasoline Fuel System | | | | | |
| Vacu-Flo Cooling | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 220-2043 | 1 | Stator, Generator | | | |
| 201-2158 | 1 | Rotor Assembly, Generator | | | |
| 520-0798 | 4 | Stud, Generator Through | | | |
| 520-0790 | 1 | Stud, Rotor Through | | | |

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-18R **SPEC** 16425AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 2
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5558-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|----------------------------|------|---------------------------|----------|------|-------------|
| Gas - Gasoline Fuel System | | | | | |
| Vacu-Flo Cooling | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 220-2044 | 1 | Stator, Generator | | | |
| 201-2159 | 1 | Rotor Assembly, Generator | | | |
| 520-0799 | 4 | Stud, Generator Through | | | |
| 520-0791 | 1 | Stud, Rotor Through | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-18R SPEC 16441AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4860-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|---|----------|------|-------------|
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Housed | | | | | |
| LPG Fuel System | | | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 322-0004 | 2 | Lamp, Indicator - High Air Temperature (1) Low Oil Pressure (1) | | | |
| 322-0069 | 2 | Holder, Indicator Lamp | | | |
| 320-0221 | 1 | Relay, Low Oil Pressure | | | |
| 307-0655 | 1 | Relay, Latching - High Air Temperature | | | |
| 332-0604 | 1 | Block, Terminal - 5 Place | | | |
| 332-0616 | 1 | Strip, Marker - 5 Place | | | |
| 301-2376 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR **MODEL** 12.5JC-3CR **SPEC** 16444AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4997-01

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|----------|------|--|----------|------|-------------|
| | | Overspeed Cut Off | | | |
| | | Low Oil Pressure Cut Off | | | |
| | | High Air Temperature Cut Off | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 322-0004 | 3 | Lamp, Indicator | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-1519 | 1 | Relay - High Air Temperature and Overspeed | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker - Blank | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR **MODEL** 12.5JC-18R **SPEC** 16444AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG)612-4997-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|--|----------|------|-------------|
| Overspeed Cut Off | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 322-0004 | 3 | Lamp, Indicator | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limitter, Cranking - Low Oil Pressure | | | |
| 307-1519 | 1 | Relay - High Air Temperature And Overspeed | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 532-0707 | 1 | Strip, Marker - Blank | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-3CR SPEC 16444AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4997-01

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|----------|------|--|----------|------|-------------|
| | | Overspeed Cut Off | | | |
| | | Low Oil Pressure Cut Off | | | |
| | | High Air Temperature Cut Off | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 322-0004 | 3 | Lamp, Indicator | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-1519 | 1 | Relay - High Air Temperature And Overspeed | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker - Blank | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-18R SPEC 16444AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4997-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|--|----------|------|-------------|
| Overspeed Cut Off | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 322-0004 | 3 | Lamp, Indicator | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-1519 | 1 | Relay - High Air Temperature And Overspeed | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker - Blank | | | |
| 301-3567 | 1 | Panel, Control | | | |

FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 1
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4793-02 (AC)612-1469-04

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|-----------------|------|--------------|----------|------|-------------|
| LPG Fuel System | | | | | |
| Housed | | | | | |
| AC Meter Panel | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 301-2204 | 1 | Panel, Meter | | | |

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-3R **SPEC** 16445AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (Eng) 612-4793-01 (AC) 612-1559-05

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|-----------------|------|--|----------|------|-------------|
| LPG Fuel System | | | | | |
| Housed | | | | | |
| Meter Panel | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 301-2288 | 1 | Panel, Meter | | | |

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-4XR **SPEC** 16445AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO(ENG) 612-4793-02 (AC) 612-1851-05

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--|------|---|----------|------|-------------|
| LPG Fuel System Housed Meter Panel | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 301-2308 | 1 | Panel, Meter | | | |
| 304-0305 | 1 | Resistor, Fixed-Meter Panel | | | |

SPECIAL PARTS LIST FOR **MODEL** 12.5JC-3CR **SPEC** 16455AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4794-01

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|---|------|-------------|----------|------|-------------|
| Vacu - Flo Cooling (See Air Housing) Low Oil Pressure Cut Off High Air Temperature Cut Off 309-0162 1 Switch, High Air Temperature 508-0002 1 Grommet, Rubber - High Air Temp. Switch Harness 338-0337 1 Harness, Wiring - High Air Temperature Switch 508-0109 1 Grommet, Rubber - 1" Hole 321-0146 1 Fuse - 10 Amp. 321-0175 1 Holder, Fuse 320-0104 1 Relay, Low Oil Pressure 134-3081 1 Guard, Scroll Outlet The following parts refer to the regulator filter assembly: 232-2589 1 Regulator Filter Package - (For Complete Replacement) Includes Drawings and Unlisted Miscellaneous Hardware Items 232-2462 1 Box, Mounting 232-2463 1 Cover, Mounting Box 312-0197 1 Capacitor 312-0198 2 Bracket, Capacitor Mounting 508-0071 1 Grommet, Rubber - 7/8" Hole 304-0120 2 Resistor, Fixed - 2 OHM, 25 Watts 304-0015 4 Washer, Resistor Centering 304-0292 2 Insulator, Resistor 813-0112 2 Screw - RHM (10-32 x 2 1/2") Resistor Mounting 338-1165 1 Harness, Wiring 625-1304 - Wiring Diagram | | | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-3CR SPEC 16455AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4794-01

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--|------|---|----------|------|-------------|
| Vacu - Flo Cooling (See Air Housing) Low Oil Pressure Cut Off High Air Temperature Cut Off | | | | | |
| 134-3081 | 1 | Guard, Scroll Outlet | | | |
| 309-0162 | 1 | Switch, High Air Temperature | | | |
| 508-0002 | 1 | Grommet, Rubber - High Air Temp. Switch Harness | | | |
| 338-0337 | 1 | Harness, Wiring - High Air Temperature Switch | | | |
| 508-0109 | 1 | Grommet, Rubber - 1" Hole | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 320-0104 | 1 | Relay, Low Oil Pressure | | | |
| The following Parts refer to the regulator filter assembly: | | | | | |
| 232-2589 | 1 | Regulator filter package - (for complete replacement) includes drawings and unlisted miscellaneous hardware items | | | |
| 232-2462 | 1 | Box, Mounting | | | |
| 232-2463 | 1 | Cover, Mounting Box | | | |
| 312-0197 | 1 | Capacitor | | | |
| 312-0198 | 2 | Bracket, Capacitor Mounting | | | |
| 508-0071 | 1 | Grommet, Rubber - 7/8" Hole | | | |
| 304-0120 | 2 | Resistor, Fixed - 2 OHM, 25 Watts | | | |
| 304-0015 | 4 | Washer, Resistor Centering | | | |
| 304-0292 | 2 | Insulator, Resistor | | | |
| 813-0112 | 2 | Screw-RHM (10-32 x 2½") Resistor Mounting | | | |
| 338-1165 | 1 | Harness, Wiring | | | |
| 625-1304 | - | Wiring Diagram | | | |

WIRING DIAGRAM NO. (ENG) 612-5559-01

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|----------|------|------------------------------|----------|------|-------------|
| | | Vacu-Flo Cooling | | | |
| | | Low Oil Pressure Cut Off | | | |
| | | High Air Temperature Cut Off | | | |
| | | Voltage Regulator Filter | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-3CR SPEC 16457AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4794-01

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--|------|---|----------|------|-------------|
| Housed | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| LPG Fuel System | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 320-0104 | 1 | Relay, Low Oil Pressure | | | |
| The following parts refer to the regulator | | | | | |
| Filter Assembly: | | | | | |
| 232-2589 | 1 | Regulator Filter Package - (for complete replacement) includes drawings and unlisted miscellaneous hardware items | | | |
| 232-2462 | 1 | Box, Mounting | | | |
| 232-2463 | 1 | Cover, Mounting Box | | | |
| 312-0197 | 1 | Capacitor | | | |
| 312-0198 | 2 | Bracket, Capacitor Mounting | | | |
| 508-0071 | 1 | Grommet, Rubber - 7/8" Hole | | | |
| 304-0120 | 2 | Resistor, Fixed - 2 Ohm, 25 Watts | | | |
| 304-0015 | 4 | Washer, Resistor Centering | | | |
| 304-0292 | 2 | Insulator, Resistor | | | |
| 813-0112 | 2 | Screw-RHM (10-32 x 2½") Resistor Mounting | | | |
| 338-1165 | 1 | Harness, Wiring | | | |
| 625-1304 | - | Wiring Diagram | | | |

SPECIAL PARTS LIST FOR **MODEL** 12.5JC-3CR **SPEC** 16457AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 1
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5559-01

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|---|------|-------------|----------|------|-------------|
| LPG Fuel System Housed Low Oil Pressure Cut Off Voltage Regulator Filter | | | | | |
| 102-0549 | 1 | Base, Oil | | | |

SPECIAL PARTS LIST FOR MODEL 12.5JC-18R SPEC 16464AA
FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 1
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4794-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--------------------------|------|--|----------|------|-------------|
| LPG Fuel System | | | | | |
| Housed | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 155-0360 | 1 | Muffler | | | |
| 140-0078 | 2 | Band, Muffler Mounting | | | |
| 155-0949 | 1 | Tube, Exhaust - Flexible | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 320-0104 | 1 | Relay, Low Oil Pressure | | | |

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-3CR **SPEC** 16464AA
FOR STANDARD PARTS REFER TO CATALOG 967-0220 **KEY NO.** 2
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4794-01

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--------------------------|------|--|----------|------|-------------|
| LPG Fuel System | | | | | |
| Housed | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 155-0360 | 1 | Muffler | | | |
| 140-0078 | 2 | Band, Muffler Mounting | | | |
| 155-0949 | 1 | Tube, Exhaust - Flexible | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 320-0104 | 1 | Relay, Low Oil Pressure | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-18R SPEC 16464AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4794-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--------------------------|------|--|----------|------|-------------|
| LPG Fuel System | | | | | |
| Housed | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 155-0360 | 1 | Muffler | | | |
| 140-0078 | 2 | Band, Muffler Mounting | | | |
| 155-0949 | 1 | Tube, Exhaust - Flexible | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 320-0104 | 1 | Relay, Low Oil Pressure | | | |

SPECIAL PARTS LIST FOR MODEL 12.5JC-3R SPEC 16468AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4858-01 (AC) 612-1559-0

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|--|----------|------|-------------|
| LPG Fuel System | | | | | |
| Housed | | | | | |
| Meter Panel | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Overspeed Cut Off | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 309-0206 | 1 | Switch, High Air Temp. | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 155-0360 | 1 | Muffler | | | |
| 140-0078 | 2 | Band, Muffler Mounting | | | |
| 155-0949 | 1 | Tube, Exhaust - Flexible | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 301-2288 | 1 | Panel, Meter | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 3 | Lamp, Indicator - Low Oil Pressure (1) High Air Temp (1) Overspeed (1) | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-0655 | 2 | Relay, Latching - High Air Temp (1) Overspeed (1) | | | |
| 307-1143 | 1 | Relay, Generating | | | |
| 323-0760 | 1 | Socket, Generating Relay | | | |
| 332-0943 | 2 | Spacer, Generating Relay | | | |
| 307-1157 | 1 | Spring, Generating Relay | | | |
| 309-0270 | 1 | Thermostat - Low Engine Temperature | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker (Blank) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-4XR **SPEC** 16468AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO(ENG) 612-4858-02 (AC) 612-1851-05

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|---|----------|------|-------------|
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Overspeed Cut Off | | | | | |
| LPG Fuel System | | | | | |
| Housed | | | | | |
| Meter Panel | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 309-0106 | 1 | Switch, High Air Temperature | | | |
| 155-0360 | 1 | Muffler | | | |
| 140-0078 | 2 | Band, Muffler Mounting | | | |
| 155-0949 | 1 | Tube, Exhaust - Flexible | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 301-2308 | 1 | Panel, Meter | | | |
| 304-0305 | 1 | Resistor, Fixed - Meter Panel | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 3 | Lamp, Indicator - Low Oil Pressure (1) High Air Temp. (1) Overspeed (1) | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-0655 | 2 | Relay, Latching - High Air Temp. (1) Overspeed (1) | | | |
| 307-1143 | 1 | Relay, Generating | | | |
| 323-0760 | 1 | Socket, Generating Relay | | | |
| 332-0943 | 2 | Spacer, Generating Relay | | | |
| 307-1157 | 1 | Spring, Generating Relay | | | |
| 309-0270 | 1 | Thermostat - Low Engine Temp. | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker (Blank) | | | |
| 331-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 301-0507 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR MODEL 12.5JC-3R SPEC 16478AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4997-01 (AC) 612-1559-04

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|---|----------|------|-------------|
| Overspeed Cut Off | | | | | |
| Fuel Tank | | | | | |
| Housed | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Meter Panel | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 309-0206 | 1 | Switch, High Air Temp. | | | |
| 155-0360 | 1 | Muffler | | | |
| 140-0078 | 2 | Band, Muffler Mounting | | | |
| 155-0949 | 1 | Tube, Exhaust - Flexible | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 301-2288 | 1 | Panel, Meter | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 3 | Lamp, Indicator - Low Oil Pressure (1) High Air Temp. (1) Overspeed (1) | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-0655 | 2 | Relay, Latching - High Air Temp. (1) Overspeed (1) | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker (Blank) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR **MODEL** 12.5JC-4R **SPEC** 16478AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO.(ENG) 612-4997-02 (AC) 612-1469-C

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|---|----------|------|-------------|
| Overspeed Cut Off | | | | | |
| Fuel Tank | | | | | |
| Housed | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Meter Panel | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 155-0360 | 1 | Muffler | | | |
| 140-0078 | 2 | Band, Muffler Mounting | | | |
| 155-0949 | 1 | Tube, Exhaust - Flexible | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 301-2204 | 1 | Panel, Meter | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 3 | Lamp, Indicator - Low Oil Pressure (1) High Air Temp. (1) Overspeed (1) | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-0655 | 2 | Relay, Latching - High Air Temp. (1) Overspeed (1) | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker (Blank) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-5DR SPEC 16478AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4997-02 (AC) 612-1556-

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|------------------------------|----------|------|-------------|
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Overspeed Cut Off | | | | | |
| Fuel Tank | | | | | |
| Housed | | | | | |
| Meter Panel | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 155-0360 | 1 | Muffler | | | |
| 140-0078 | 2 | Band, Muffler Mounting | | | |
| 155-0949 | 1 | Tube, Exhaust - Flexible | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set | | | |
| | | Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 301-2204 | 1 | Panel, Meter | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage | | | |
| | | Regulator to Exciter | | | |
| | | Stator | | | |
| 322-0004 | 3 | Lamp, Indicator - Low Oil | | | |
| | | Pressure (1) High Air | | | |
| | | Temp. (1) Overspeed (1) | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil | | | |
| | | Pressure | | | |
| 307-0655 | 2 | Relay, Latching - High Air | | | |
| | | Temp. (1) Overspeed (1) | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker (Blank) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR MODEL 12.5JC-3CR SPEC 16483AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4794-01

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|---|------|---|----------|------|-------------|
| LPG Fuel System | | | | | |
| Vacu - Flo Cooling (See Air Housing) | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| 309-0162 | 1 | Switch, High Air Temperature | | | |
| 508-0002 | 1 | Grommet, Rubber - High Air Temp. Switch Harness | | | |
| 338-0337 | 1 | Harness, Wiring - High Air Temperature Switch | | | |
| 508-0109 | 1 | Grommet, Rubber - 1" Hole | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 320-0104 | 1 | Relay, Low Oil Pressure | | | |
| 134-3081 | 1 | Guard, Scroll Outlet | | | |
| The following parts refer to the regulator filter assembly: | | | | | |
| 232-2589 | 1 | Regulator Filter Package - (for complete replacement) includes drawings and unlisted miscellaneous hardware items | | | |
| 232-2462 | 1 | Box, Mounting | | | |
| 232-2463 | 1 | Cover, Mounting Box | | | |
| 312-0197 | 1 | Capacitor | | | |
| 312-0198 | 2 | Bracket, Capacitor Mounting | | | |
| 508-0071 | 1 | Grommet, Rubber - 7/8" Hole | | | |
| 304-0120 | 2 | Resistor, Fixed - 2 OHM, 25 Watts | | | |
| 304-0015 | 4 | Washer, Resistor Centering | | | |
| 304-0292 | 2 | Insulator, Resistor | | | |
| 813-0112 | 2 | Screw - RHM (10-32 x 2 1/2") Resistor Mounting | | | |
| 338-1165 | 1 | Harness, Wiring | | | |
| 625-1304 | - | Wiring Diagram | | | |

SPECIAL PARTS LIST FOR MODEL 12.5JC-3CR SPEC 16486AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4794-01

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|---|------|---|----------|------|-------------|
| Gas Fuel System | | | | | |
| Vacu - Flo Cooling (See Air Housing) | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| 309-0162 | 1 | Switch, High Air Temperature | | | |
| 508-0002 | 1 | Grommet, Rubber - High Air Temp. Switch Harness | | | |
| 338-0337 | 1 | Harness, Wiring - High Air Temperature Switch | | | |
| 508-0109 | 1 | Grommet, Rubber - 1" Hole | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 320-0104 | 1 | Relay, Low Oil Pressure | | | |
| 134-3081 | 1 | Guard, Scroll Outlet | | | |
| The following parts refer to the regulator filter assembly: | | | | | |
| 232-2589 | 1 | Regulator Filter Package - (for complete replacement) includes drawings and unlisted miscellaneous hardware items | | | |
| 232-2462 | 1 | Box, Mounting | | | |
| 232-2463 | 1 | Cover, Mounting Box | | | |
| 312-0197 | 1 | Capacitor | | | |
| 312-0198 | 2 | Bracket, Capacitor Mounting | | | |
| 508-0071 | 1 | Grommet, Rubber - 7/8" Hole | | | |
| 304-0120 | 2 | Resistor, Fixed - 2 OHM, 25 Watts | | | |
| 304-0015 | 4 | Washer, Resistor Centering | | | |
| 304-0292 | 2 | Insulator, Resistor | | | |
| 813-0112 | 2 | Screw - RHM (10-32 x 2½") Resistor Mounting | | | |
| 338-1165 | 1 | Harness, Wiring | | | |
| 625-1304 | - | Wiring Diagram | | | |

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-18R **SPEC** 16495AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4997-06 (SWBD) 615-0373

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|---|------|---|----------|------|--------------------------|
| Low Oil Pressure Cut Off | | | 304-0015 | 1 | Washer, Resistor Centeri |
| High Air Temperature Cut Off | | | 304-0292 | 2 | Insulator, Resistor |
| Overspeed Cut Off | | | 813-0112 | 2 | Screw - RHM (10-32 x 2) |
| Gas - Gasoline Fuel System | | | | | Resistor Mounting |
| Switchboard Control | | | 338-1165 | 1 | Harness, Wiring |
| | | | 625-1304 | - | Wiring Diagram |
| 102-0818 | 1 | Base, Oil | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 134-1805 | 1 | Duct, Air | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 220-2044 | 1 | Stator, Wound - Generator | | | |
| 201-2159 | 1 | Rotor Assembly, Wound - Generator | | | |
| 520-0799 | 4 | Stud, Generator Through | | | |
| 520-0791 | 1 | Stud, Rotor Through | | | |
| 302-0458 | 2 | Ammeter, AC | | | |
| 301-2086 | 1 | Panel, Instrument | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 3 | Lamp, Indicator - Low Oil Pressure (1) High Air Temp. (1) Overspeed (1) | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-0655 | 2 | Relay, Latching - High Air Temp. (1) Overspeed (1) | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker (Blank) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 301-3567 | 1 | Panel, Control | | | |
| The following parts refer to the regulator filter assembly: | | | | | |
| 232-2589 | 1 | Regulator Filter Package - (For Complete Replacement) Includes Drawings and Unlisted Miscellaneous Hardware Items | | | |
| 232-2462 | 1 | Box, Mounting | | | |
| 232-2463 | 1 | Cover, Mounting Box | | | |
| 312-0197 | 1 | Capacitor | | | |
| 312-0198 | 2 | Bracket, Capacitor Mounting | | | |
| 508-0071 | 1 | Grommet, Rubber - 7/8" Hole | | | |
| 304-0120 | 2 | Resistor, Fixed - 2 OHM, 25 Watts | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-18R31 SPEC 16512AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4793-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|-----------------------------|------|--|----------|------|-------------|
| Gas Fuel System | | | | | |
| Housed | | | | | |
| NOTE: Pennsylvania Approved | | | | | |
| 112-0106 | 4 | Piston and Pin | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 149-0558 | 1 | Strainer | | | |
| 307-0312 | 1 | Valve, Fuel | | | |
| 416-0325 | 1 | Hydrometer | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 220-2044 | 1 | Stator, Wound - Generator | | | |
| 201-2159 | 1 | Rotor Assembly, Wound - Generator | | | |
| 520-0799 | 4 | Stud, Generator Through | | | |
| 520-0791 | 1 | Stud, Rotor Through | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-18R SPEC 16513AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO(ENG) 612-4997-02 (AC) 612-4895-03

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|----------|------|------------------------------|----------|------|---------------------------|
| | | Low Oil Pressure Cut Off | 232-2589 | 1 | Regulator Filter Package |
| | | High Air Temperature Cut Off | | | (For Complete Replaceme |
| | | Overspeed Cut Off | | | Includes Drawings and |
| | | Housed | | | Unlisted Miscellaneous |
| | | Air Shutter | | | Hardware Items |
| | | Meter Panel | 232-2462 | 1 | Box, Mounting |
| | | | 232-2463 | 1 | Cover, Mounting Box |
| 102-0549 | 1 | Base, Oil | 312-0197 | 1 | Capacitor |
| 309-0206 | 1 | Switch, High Air Temperature | 312-0198 | 2 | Bracket, Capacitor Mounti |
| 155-0360 | 1 | Muffler | 508-0071 | 1 | Grommet, Rubber - 7/8" Ho |
| 140-0078 | 2 | Band, Muffler Mounting | 304-0120 | 2 | Resistor, Fixed - 2 OHM, |
| 155-0949 | 1 | Tube, Exhaust - Flexible | | | 25 Watts |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | 304-0015 | 4 | Washer, Resistor Centerin |
| 402-0364 | 1 | Hardware Set, Generator Set | 304-0292 | 2 | Insulator, Resistor |
| | | Mounting (Set of Four) | 813-0112 | 2 | Screw - RHM (10-32 x 2 1, |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | Resistor Mounting |
| 220-2044 | 1 | Stator, Wound - Generator | 338-1165 | 1 | Harness, Wiring |
| 201-2159 | 1 | Rotor Assembly, Wound - | 625-1304 | - | Wiring Diagram |
| | | Generator | | | |
| 520-0799 | 4 | Stud, Generator Through | | | |
| 520-0791 | 1 | Stud, Rotor Through | | | |
| 322-0044 | 2 | Light, Pilot - Meter Panel | | | |
| 302-0465 | 1 | Meter, Running Time | | | |
| 308-0203 | 1 | Switch, Output Phase | | | |
| | | Selector | | | |
| 301-3732 | 1 | Panel, Meter | | | |
| 301-2395 | 1 | Bracket, Meter Panel Stop | | | |
| 301-2727 | 1 | Handle, Meter Panel | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage | | | |
| | | Regulator to Exciter | | | |
| | | Stator | | | |
| 322-0004 | 3 | Lamp, Indicator - Low Oil | | | |
| | | Pressure (1) High Air | | | |
| | | Temp. (1) Overspeed (1) | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil | | | |
| | | Pressure | | | |
| 307-0655 | 2 | Relay, Latching - High Air | | | |
| | | Temp. (1) Overspeed (1) | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker (Blank) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 301-3567 | 1 | Panel, Control | | | |

The following parts refer to the regulator
 filter assembly:

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-4R **SPEC** 16541AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4793-08 (SWBD) 615-0571

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|--|----------|------|-------------|
| LPG Fuel System | | | | | |
| Switchboard Control | | | | | |
| Adjustable Voltage Regulator | | | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 134-1805 | 1 | Duct, Air | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 302-0458 | 3 | Ammeter, AC | | | |
| 301-2099 | 1 | Panel, Instrument | | | |
| 301-0500 | 1 | Box Assembly, Meter - Includes Box, Cover and Grommet | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-3R SPEC 16553AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (Eng)612-4793-01(AC)612-1559-05

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|-------------|------|-----------------------------|----------|------|-------------|
| Fuel Tank | | | | | |
| Housed | | | | | |
| Air Shutter | | | | | |
| Meter Panel | | | | | |
| 155-0360 | 1 | Muffler | | | |
| 140-0078 | 2 | Band, Muffler Mounting | | | |
| 155-0949 | 1 | Tube, Exhaust - Flexible | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set | | | |
| | | Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 301-2288 | 1 | Panel, Meter | | | |

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-4R **SPEC** 16553AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4793-02 (AC) 612-1469-05

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|-------------|------|-----------------------------|----------|------|-------------|
| Fuel Tank | | | | | |
| Housed | | | | | |
| Air Shutter | | | | | |
| Meter Panel | | | | | |
| 155-0360 | 1 | Muffler | | | |
| 140-0078 | 2 | Band, Muffler Mounting | | | |
| 155-0949 | 1 | Tube, Exhaust - Flexible | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set | | | |
| | | Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 301-2204 | 1 | Panel, Meter | | | |

SPECIAL PARTS LIST FOR **MODEL** 12.5JC-3R **SPEC** 16560AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4997-05 (SWBD) 615-0373-

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--------------------------------------|------|---|----------|------|-------------|
| Overspeed Cut Off | | | | | |
| LPG Fuel System | | | | | |
| Vacu - Flo Cooling (See Air Housing) | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Switchboard Control | | | | | |
| 309-0171 | 1 | Switch, High Air Temperature | | | |
| 508-0092 | 1 | Grommet, Rubber - High Air Temp. Switch Harness | | | |
| 338-0337 | 1 | Harness, Wiring - High Air Temperature Switch | | | |
| 508-0109 | 1 | Grommet, Rubber - 1" Hole | | | |
| 134-3081 | 1 | Guard, Scroll Outlet | | | |
| 332-0216 | 1 | Lug, Solderless Ground | | | |
| 302-0458 | 2 | Ammeter, AC | | | |
| 301-2086 | 1 | Panel, Instrument | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 3 | Lamp, Indicator - Low Oil Pressure (1) High Air Temp. (1) Overspeed (1) | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-0655 | 2 | Relay, Latching - High Air Temp. (1) Overspeed (1) | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker (Blank) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 301-3567 | 1 | Panel, Control | | | |
| Part not furnished by Onan | | | | | |
| Muffler | | | | | |

SPECIAL PARTS LIST FOR MODEL 12.5JC-3R31 SPEC 16562AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4851-05 (SWBD) 615-0373

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--------------------------------------|------|---|----------|------|-------------|
| Overspeed Cut Off | | | | | |
| Gas Fuel System | | | | | |
| Vacu - Flo Cooling (See Air Housing) | | | | | |
| Switchboard Control | | | | | |
| NOTE: Pennsylvania Approved | | | | | |
| 134-3081 | 1 | Guard, Scroll Outlet | | | |
| 508-0109 | 1 | Grommet, Rubber - 1" Hole | | | |
| 332-0216 | 1 | Lug, Solderless Ground | | | |
| 302-0458 | 2 | Ammeter, AC | | | |
| 301-2086 | 1 | Panel, Instrument | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 1 | Lamp, Indicator - Overspeed | | | |
| 322-0069 | 1 | Holder, Indicator Lamp | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 307-0655 | 1 | Relay, Overspeed | | | |
| 332-0604 | 1 | Block, Terminal - 5 Place | | | |
| 332-0616 | 1 | Strip, Marker - 5 Place | | | |
| 149-0558 | 1 | Strainer | | | |
| 307-0312 | 1 | Valve, Fuel | | | |
| 416-0325 | 1 | Hydrometer | | | |
| 402-0287 | 2 | Cushion, Vibration - Gener- ator End | | | |

SPECIAL PARTS LIST FOR **MODEL** 12.5JC-4R **SPEC** 16564AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4997-06 (SWBD) 615-0371-(

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|---|------|---|----------|------|-------------|
| Vacu - Flo Cooling (See Air Housing) Skid and Battery Rack (See Housing Option) Low Oil Pressure Cut Off High Air Temperature Cut Off Overspeed Cut Off Gas Fuel System Switchboard Control | | | | | |
| 309-0171 | 1 | Switch, High Air Temperature | | | |
| 5C8-0002 | 1 | Grommet, Rubber - High Air Temp. Switch Harness | | | |
| 338-0337 | 1 | Harness, Wiring - High Air Temperature Switch | | | |
| 508-0109 | 1 | Grommet, Rubber - 1" Hole | | | |
| 505-0002 | 2 | Nipple, Oil Drain | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 416-0522 | 1 | Plate, Battery Mounting | | | |
| 332-0216 | 1 | Lug, Solderless Ground | | | |
| 301-2099 | 1 | Panel, Instrument | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 3 | Lamp, Indicator - Low Oil Pressure (1) High Air Temp. (1) Overspeed (1) | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-0655 | 2 | Relay, Latching - High Air Temp. (1) Overspeed (1) | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker (Blank) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 301-3567 | 1 | Panel, Control | | | |
| 301-0500 | 1 | Box Assembly, Meter - Includes Box, Cover and Grommet | | | |

SPECIAL PARTS LIST FOR **MODEL** 12.5JC-3R **SPEC** 16565AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO.(ENG) 612-4997-01 (AC) 612-1559-04

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|------------------------------|----------|------|-------------|
| Overspeed Cut Off | | | | | |
| Fuel Tank | | | | | |
| Housed | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Meter Panel | | | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 155-0360 | 1 | Muffler | | | |
| 140-0078 | 2 | Band, Muffler Mounting | | | |
| 155-0949 | 1 | Tube, Exhaust - Flexible | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set | | | |
| | | Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 301-2288 | 1 | Panel, Meter | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage | | | |
| | | Regulator to Exciter | | | |
| | | Stator | | | |
| 322-0004 | 3 | Lamp, Indicator - Low Oil | | | |
| | | Pressure (1) High Air | | | |
| | | Temp. (1) Overspeed (1) | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil | | | |
| | | Pressure | | | |
| 307-0655 | 2 | Relay, Latching - High Air | | | |
| | | Temp. (1) Overspeed (1) | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker (Blank) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR MODEL 12.5JC-4R SPEC 16565AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4997-02 (AC)612-1469-04

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|----------|------|---|----------|------|-------------|
| | | Overspeed Cut Off | | | |
| | | Fuel Tank | | | |
| | | Housed | | | |
| | | Low Oil Pressure Cut Off | | | |
| | | High Air Temperature Cut Off | | | |
| | | AC Meter Panel | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 155-0360 | 1 | Muffler, Critical | | | |
| 301-2204 | 1 | Panel, Meter | | | |
| 322-0004 | 3 | Lamp, Indicator | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-1519 | 1 | Relay - High Air Temperature And Overspeed | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker - Blank | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-4R **SPEC** 16565AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4997-02 (AC) 612-1469-05

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|----------|------|--|----------|------|-------------|
| | | Overspeed Cut Off | | | |
| | | Low Oil Pressure Cut Off | | | |
| | | High Air Temperature Cut Off | | | |
| | | Fuel Tank | | | |
| | | Housed | | | |
| | | AC Meter Panel | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 155-0360 | 1 | Muffler, Critical | | | |
| 301-2204 | 1 | Panel, Meter | | | |
| 322-0004 | 3 | Lamp, Indicator | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-1519 | 1 | Relay - High Air Temperature And Overspeed | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker - Blank | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-4R31 SPEC 16566AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO(ENG) 612-4851-02 (AC) 612-2129-0

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|---|------|---|----------|------|-------------|
| Overspeed Cut Off Gas Fuel System Housed Meter Panel | | | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 332-0216 | 1 | Lug, Solderless Ground | | | |
| 155-0360 | 1 | Muffler | | | |
| 140-0078 | 2 | Band, Muffler Mounting | | | |
| 155-0949 | 1 | Tube, Exhaust - Flexible | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 301-2129 | 1 | Panel, Meter | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 1 | Lamp, Indicator - Overspeed | | | |
| 322-0069 | 1 | Holder, Indicator Lamp | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 307-0655 | 1 | Relay, Overspeed | | | |
| 332-0604 | 1 | Block, Terminal - 5 Place | | | |
| 332-0616 | 1 | Strip, Marker - 5 Place | | | |

SPECIAL PARTS LIST FOR **MODEL** 12.5JC-3R **SPEC** 16574AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4793-01 (AC) 612-1559-01

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|-------------|------|-----------------------------|----------|------|-------------|
| Housed | | | | | |
| Meter Panel | | | | | |
| 155-0360 | 1 | Muffler | | | |
| 140-0078 | 2 | Band, Muffler Mounting | | | |
| 155-0949 | 1 | Tube, Exhaust - Flexible | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set | | | |
| | | Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 301-2288 | 1 | Panel, Meter | | | |

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-3CR **SPEC** 16580AA
FOR STANDARD PARTS REFER TO CATALOG 967-0220 **KEY NO.** 2
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4793-01

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--|------|--|----------|------|-------------|
| Skid and Battery Rack (See Housing Option) | | | | | |
| LPG Fuel System | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 134-1805 | 1 | Duct, Air | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 505-0002 | 2 | Nipple, Oil Drain | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |

SPECIAL PARTS LIST FOR **MODEL** 12.5JC-18R **SPEC** 16581AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4794-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|---|----------|------|-------------|
| Gas - Gasoline Fuel System | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| 102-0622 | 1 | Base, Oil | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 134-1805 | 1 | Duct, Air | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 220-2043 | 1 | Stator, Wound - Generator | | | |
| 201-2158 | 1 | Rotor Assembly, Wound - Generator | | | |
| 520-0798 | 1 | Stud, Generator Through | | | |
| 520-0790 | 1 | Stud, Rotor Through | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 320-0104 | 1 | Relay, Low Oil Pressure | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-18R SPEC 16581AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4794-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|---|----------|------|-------------|
| LPG Fuel System | | | | | |
| High Air Temperature Cut Off | | | | | |
| Gas - Gasoline Fuel System | | | | | |
| 102-0622 | 1 | Base, Oil | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 134-1805 | 1 | Duct, Air | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 220-2044 | 1 | Stator, Wound - Generator | | | |
| 201-2159 | 1 | Rotor Assembly, Wound - Generator | | | |
| 520-0799 | 4 | Stud, Generator Through | | | |
| 520-0791 | 1 | Stud, Rotor Through | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 320-0104 | 1 | Relay, Low Oil Pressure | | | |

SPECIAL PARTS LIST FOR MODEL 12.5JC-18R SPEC 16584AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4858-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|---|----------|------|-------------|
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Overspeed Cut Off | | | | | |
| LPG Fuel System | | | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 134-1805 | 1 | Duct, Air | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 3 | Lamp, Indicator - Low Oil Pressure (1) High Air Temp. (1) Overspeed (1) | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-0655 | 2 | Relay, Latching - High Air Temp. (1) Overspeed (1) | | | |
| 307-1143 | 1 | Relay, Generating | | | |
| 323-0760 | 1 | Socket, Generating Relay | | | |
| 332-0943 | 2 | Spacer, Generating Relay | | | |
| 307-1157 | 1 | Spring, Generating Relay | | | |
| 309-0270 | 1 | Thermostat - Low Engine Temperature | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker (Blank) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-3CR SPEC 16584AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4858-01

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|--|----------|------|-------------|
| LPG Fuel System | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Overspeed Cut Off | | | | | |
| 134-3756 | 1 | Duct, Air | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 322-0004 | 3 | Lamp, Indicator | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-1519 | 1 | Relay - High Air Temperature And Overspeed | | | |
| 307-1143 | 1 | Relay, Generating | | | |
| 323-0760 | 1 | Socket, Generating Relay | | | |
| 332-0943 | 2 | Spacer, Generating Relay | | | |
| 307-1157 | 1 | Spring, Generating Relay | | | |
| 309-0270 | 1 | Thermostat, Low Engine Temperature | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker - Blank | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-18R **SPEC** 16584AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4858-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|-----------------------------|------|---|----------|------|-------------|
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature CutOff | | | | | |
| Overspeed Cut Off | | | | | |
| LPG Fuel System | | | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 134-1805 | 1 | Duct, Air | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 3 | Lamp, Indicator - Low Oil Pressure (1) High Air Temp. (1) Overspeed (1) | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-0655 | 2 | Relay, Latching - High Air Temp. (1) Overspeed (1) | | | |
| 307-1143 | 1 | Relay, Generating | | | |
| 323-0760 | 1 | Socket, Generating Relay | | | |
| 332-0943 | 2 | Spacer, Generating Relay | | | |
| 307-1157 | 1 | Spring, Generating Relay | | | |
| 309-0270 | 1 | Thermostat - Low Engine Temp. | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker (Blank) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-18R131 SPEC 16584AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4858-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|---|------|---|----------|------|-------------|
| Note: Pennsylvania Approved LPG Fuel System Low Oil Pressure Cut Off High Air Temperature Cut Off Overspeed Cut Off | | | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 134-3756 | 1 | Duct, Air | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 149-0558 | 1 | Strainer | | | |
| 307-0312 | 1 | Valve, Fuel | | | |
| 416-0325 | 1 | Hydrometer | | | |
| 402-0287 | 2 | Cushion, Vibration - Generator End | | | |
| 322-0004 | 3 | Lamp, Indicator | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-1519 | 1 | Relay - High Air Temperature And Overspeed | | | |
| 307-1143 | 1 | Relay, Generating | | | |
| 323-0760 | 1 | Socket, Generating Relay | | | |
| 332-0943 | 2 | Spacer, Generating Relay | | | |
| 307-1157 | 1 | Spring, Generating Relay | | | |
| 309-0270 | 1 | Thermostat, Low Engine Temperature | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker - Blank | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR **MODEL** 12.5JC-5DR **SPEC** 16586AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO.(ENG) 612-4843-06 (SWBD) 615-0376-

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--|------|---|----------|------|-------------|
| Vacu - Flo Cooling (See Air Housing) Low Oil Pressure Cut Off Overspeed Cut Off Switchboard Control | | | | | |
| 134-3081 | 1 | Guard, Scroll Outlet | | | |
| 508-0109 | 1 | Grommet, Rubber - 1" Hole | | | |
| 301-2116 | 1 | Panel, Instrument | | | |
| 301-0994 | 1 | Box Assembly, Meter - Includes Box, Cover and Grommet | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 2 | Lamp, Indicator - Low Oil Pressure (1) Overspeed (1) | | | |
| 322-0069 | 2 | Holder, Indicator Lamp | | | |
| 320-0221 | 1 | Relay, Low Oil Pressure | | | |
| 307-0655 | 1 | Relay, Latching - Overspeed | | | |
| 332-0604 | 1 | Block, Terminal - 5 Place | | | |
| 332-0616 | 1 | Strip, Marker - 5 Place | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-3R SPEC 16591AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (Eng) 612-4794-07(SWBD)615-0373-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--|------|--|----------|------|-------------|
| Low Oil Pressure Cut Off High Air Temperature Cut Off Air Shutter Switchboard Control Adjustable Voltage Regulator | | | | | |
| 309-0128 | 1 | Thermostat, Adjustable - Generator End Bell | | | |
| 232-2458 | 1 | Plate, Thermostat Mounting - Generator End Bell | | | |
| 232-2457 | 1 | Bracket, Heater Mounting - Generator End Bell | | | |
| 333-0059 | 1 | Heater Ring - Generator End Bell | | | |
| 302-0458 | 2 | Ammeter, AC | | | |
| 301-2086 | 1 | Panel, Instrument | | | |
| 321-0146 | 1 | Fuse - 10 Amp | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 320-0104 | 1 | Relay, Low Oil Pressure | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-4XR SPEC 16598AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4794-06 (SWBD) 615-0377-1

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|----------|------|--|----------|------|-------------|
| | | Switchboard Control | | | |
| | | Low Oil Pressure Cut Off | | | |
| | | High Air Temperature Cut Off | | | |
| | | Air Shutter | | | |
| | | Day Tank (One Quart) | | | |
| 502-0020 | 1 | Elbow, Street - Fuel Pump Inlet | | | |
| 504-0007 | 1 | Valve, Fuel Pump Inlet | | | |
| 502-0002 | 2 | Elbow, Inverted Flare - Day Tank Fuel Line to Fuel Pump Inlet Valve (1) And Day Tank Fuel Line to Carburetor Inlet (1) | | | |
| 301-2116 | 1 | Panel, Instrument | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 320-0104 | 1 | Relay, Low Oil Pressure | | | |

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-5DR **SPEC** 16606AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4997-02 (AC) 612-1556-03

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|----------|------|--|----------|------|-------------|
| | | Overspeed Cut Off | | | |
| | | Low Oil Pressure Cut Off | | | |
| | | High Air Temperature Cut Off | | | |
| | | Housed | | | |
| | | AC Meter Panel | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 155-0360 | 1 | Muffler, Critical | | | |
| 301-2204 | 1 | Panel, Meter | | | |
| 322-0004 | 3 | Lamp, Indicator | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-1519 | 1 | Relay - High Air Temperature And Overspeed | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker - Blank | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR **MODEL** 12.5JC-4XR **SPEC** 16611AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4858-08 (SWBD) 615-0381

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--|------|---|----------|------|-------------|
| Skid and Battery Rack (See Housing Option) | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Gas Fuel System | | | | | |
| Switchboard Control | | | | | |
| Adjustable Voltage Regulator | | | | | |
| Overspeed Cut Off | | | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 505-0002 | 2 | Nipple, Oil Drain | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 416-0522 | 1 | Plate, Battery Mounting | | | |
| 301-2116 | 1 | Panel, Instrument | | | |
| 301-0994 | 1 | Box Assembly, Meter - Includes Box, Cover And Grommet | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 3 | Lamp, Indicator - Low Oil Pressure (1) High Air Temp. (1) Overspeed (1) | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-0655 | 2 | Relay, Latching - High Air Temp. (1) Overspeed (1) | | | |
| 307-1143 | 1 | Relay, Generating | | | |
| 323-0760 | 1 | Socket, Generating Relay | | | |
| 332-0943 | 2 | Spacer, Generating Relay | | | |
| 307-1157 | 1 | Spring, Generating Relay | | | |
| 309-0270 | 1 | Thermostat - Low Engine Temperature | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker (Blank) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-3R **SPEC** 16620AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (Eng) 612-4848-05 (SWBD) 615-0373-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|----------|------|---|----------|------|-------------|
| | | Skid and Battery Rack (See Housing Option) | | | |
| | | Low Oil Pressure Cut Off | | | |
| | | High Air Temperature Cut Off | | | |
| | | Overspeed Cut Off | | | |
| | | Air Shutter | | | |
| | | Switchboard Control | | | |
| 505-0002 | 2 | Nipple, Oil Drain | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 302-0458 | 2 | Ammeter, AC | | | |
| 301-2086 | 1 | Panel, Instrument | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 1 | Lamp, Indicator - Overspeed | | | |
| 322-0069 | 1 | Holder, Indicator Lamp | | | |
| 321-0146 | 1 | Fuse - 10 Amp | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 320-0104 | 1 | Relay, Low Oil Pressure | | | |
| 307-0655 | 1 | Relay, Overspeed | | | |
| 332-0604 | 1 | Block, Terminal - 5 Place | | | |
| 332-0616 | 1 | Strip, Marker - 5 Place | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-4R SPEC 16620AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 612-4848-06 (SWBD) 615-037

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|----------|------|---|----------|------|-------------|
| | | Low Oil Pressure Cut Off | | | |
| | | High Air Temperature Cut Off | | | |
| | | Overspeed Cut Off | | | |
| | | Skid And Battery Rack (See Housing Option) | | | |
| | | Air Shutter | | | |
| | | Switchboard Control | | | |
| 505-0002 | 2 | Nipple, Oil Drain | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 302-0458 | 3 | Ammeter, AC | | | |
| 301-2099 | 1 | Panel, Instrument | | | |
| 301-0500 | 1 | Box Assembly, Meter - Includes Box, Cover and Grommet | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 1 | Lamp, Indicator - Overspeed | | | |
| 322-0069 | 1 | Holder, Indicator Lamp | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 320-0104 | 1 | Relay, Low Oil Pressure | | | |
| 307-0655 | 1 | Relay, Overspeed | | | |
| 332-0604 | 1 | Block, Terminal - 5 Place | | | |
| 332-0616 | 1 | Strip, Marker - 5 Place | | | |

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-3CR **SPEC** 16621AA
FOR STANDARD PARTS REFER TO CATALOG 967-0220 **KEY NO.** 2
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4858-01

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--|------|--|----------|------|-------------|
| Skid and Battery Rack (See Housing Option) | | | | | |
| Day Tank (One Quart) | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Overspeed Cut Off | | | | | |
| 502-0020 | 1 | Elbow, Street - Fuel Pump Inlet | | | |
| 504-0007 | 1 | Valve, Fuel Pump Inlet | | | |
| 502-0002 | 2 | Elbow, Inverted Flare - Day Tank Fuel Line to Fuel Pump Inlet Valve (1) And Day Tank Fuel Line to Carburetor Inlet (1) | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 505-0002 | 2 | Nipple, Oil Drain | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 3 | Lamp, Indicator - Low Oil Pressure (1) High Air Temp. (1) Overspeed (1) | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-0655 | 2 | Relay, Latching - High Air Temp. (1) Overspeed (1) | | | |
| 307-1143 | 1 | Relay, Generating | | | |
| 323-0760 | 1 | Socket, Generating Relay | | | |
| 332-0943 | 2 | Spacer, Generating Relay | | | |
| 307-1157 | 1 | Spring, Generating Relay | | | |
| 309-0270 | 1 | Thermostat - Low Engine Temperature | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker (Blank) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-3CR **SPEC** 16638AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 **KEY NO.** 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4794-01

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--------------------------|------|---|----------|------|-------------|
| Gas Fuel System | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 112-0106 | 4 | Piston and Pin | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 134-1805 | 1 | Duct, Air | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 320-0104 | 1 | Relay, Low Oil Pressure | | | |

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-18R **SPEC** 16638AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4794-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--------------------------|------|---|----------|------|-------------|
| Gas Fuel System | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 112-0106 | 4 | Piston and Pin | | | |
| 33i-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 134-1805 | 1 | Duct, Air | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 149-0558 | 1 | Strainer | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 320-0104 | 1 | Relay, Low Oil Pressure | | | |

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-18R **SPEC** 16638AB
FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 2
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-5559-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--------------------------|------|-----------------------------|----------|------|-------------|
| Gas Fuel System | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 112-0106 | 4 | Piston And Pin | | | |
| 134-3756 | 1 | Duct, Air | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |

SPECIAL PARTS LIST FOR MODEL 12.5JC-3CR SPEC 16640AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4860-01

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|------------------------------|----------|------|-------------|
| Fuel Tank | | | | | |
| Housed | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 309-0162 | 1 | Switch, High Air Temperature | | | |
| 155-0360 | 1 | Muffler | | | |
| 140-0078 | 2 | Band, Muffler Mounting | | | |
| 155-0949 | 1 | Tube, Exhaust - Flexible | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set | | | |
| | | Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 322-0004 | 2 | Lamp, Indicator - High Air | | | |
| | | Temperature (1) Low Oil | | | |
| | | Pressure (1) | | | |
| 322-0069 | 2 | Holder, Indicator Lamp | | | |
| 320-0221 | 1 | Relay, Low Oil Pressure | | | |
| 307-0655 | 1 | Relay, Latching - High Air | | | |
| | | Temperature | | | |
| 332-0604 | 1 | Block, Terminal - 5 Place | | | |
| 332-0616 | 1 | Strip, Marker - 5 Place | | | |
| 301-2376 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR **MODEL** 12.5JC-18R **SPEC** 16640AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. _____ **(ENG)** 612-4860-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|------------------------------|----------|------|-------------|
| Fuel Tank | | | | | |
| Housed | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 155-0360 | 1 | Muffler | | | |
| 140-0078 | 2 | Band, Muffler Mounting | | | |
| 155-0949 | 1 | Tube, Exhaust - Flexible | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set | | | |
| | | Mounting (set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 322-0004 | 2 | Lamp, Indicator - High Air | | | |
| | | Temperature (1) Low Oil | | | |
| | | Pressure (1) | | | |
| 322-0069 | 2 | Holder, Indicator Lamp | | | |
| 320-0221 | 1 | Relay, Low Oil Pressure | | | |
| 307-0655 | 1 | Relay, Latching - High Air | | | |
| | | Temperature | | | |
| 332-0604 | 1 | Block, Terminal - 5 Place | | | |
| 332-0616 | 1 | Strip, Marker - 5 Place | | | |
| 301-2376 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR MODEL 15.0JC-4R SPEC 1664/AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4794-02 (AC) 612-1469-(

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|--|----------|------|-------------|
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Gas Fuel System | | | | | |
| Housed | | | | | |
| Air Shutter | | | | | |
| Meter Panel | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 112-0106 | 4 | Piston and Pin | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 155-0360 | 1 | Muffler | | | |
| 140-0078 | 2 | Band, Muffler Mounting | | | |
| 155-0949 | 1 | Tube, Exhaust - Flexible | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 301-2204 | 1 | Panel, Meter | | | |
| 333-0151 | 1 | Heater - Control | | | |
| 309-0128 | 1 | Thermostat, Adjustable - Control | | | |
| 301-1886 | 1 | Cover, Thermostat - Control | | | |
| 335-0110 | 1 | Cable Assembly, Heater - Control | | | |
| 309-0128 | 1 | Thermostat, Adjustable - Generator End Bell | | | |
| 232-2458 | 1 | Plate, Thermostat Mounting - Generator End Bell | | | |
| 232-2457 | 1 | Bracket, Heater Mounting - Generator End Bell | | | |
| 333-0059 | 1 | Heater Ring - Generator End Bell | | | |
| 301-2204 | 1 | Panel, Meter | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 320-0104 | 1 | Relay, Low Oil Pressure | | | |

FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 2
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. _____ **(ENG) 612-4794-02**

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|-----------------------------------|----------|------|-------------|
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| 220-2044 | 1 | Stator, Wound - Generator | | | |
| 201-2159 | 1 | Rotor Assembly, Wound - Generator | | | |
| 520-0799 | 4 | Stud, Generator Through | | | |
| 520-0791 | 1 | Stud, Rotor Through | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 320-0104 | 1 | Relay, Low Oil Pressure | | | |

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-4XR **SPEC** 16650AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO(ENG) 612-4851-06 (SWBD) 615-0381-

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--|------|---|----------|------|-------------|
| Gas Fuel System | | | | | |
| Vacu - Flo Cooling (See Air Housing) | | | | | |
| Skid and Battery Rack (See Housing Option) | | | | | |
| Overspeed Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Switchboard Control | | | | | |
| 112-0106 | 4 | Piston and Pin | | | |
| 134-3081 | 1 | Guard, Scroll Outlet | | | |
| 309-0162 | 1 | Switch, High Air Temperature | | | |
| 508-0002 | 1 | Grommet, Rubber - High Air Temp. Switch Harness | | | |
| 338-0337 | 1 | Harness, Wiring - High Air Temperature Switch | | | |
| 508-0109 | 1 | Grommet, Rubber - 1" Hole | | | |
| 301-2116 | 1 | Panel, Instrument | | | |
| 301-0994 | 1 | Box Assembly, Meter - Includes Box, Cover and Grommet | | | |
| 505-0002 | 2 | Nipple, Oil Drain | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 1 | Lamp, Indicator - Overspeed | | | |
| 322-0069 | 1 | Holder, Indicator Lamp | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 307-0655 | 1 | Relay, Overspeed | | | |
| 332-0604 | 1 | Block, Terminal - 5 Place | | | |
| 332-0616 | 1 | Strip, Marker - 5 Place | | | |

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-18R **SPEC** 16654AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4794-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--------------------------------------|------|-----------------------------------|----------|------|-------------|
| Vacu - Flo Cooling (See Air Housing) | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| 134-3081 | 1 | Guard, Scroll Outlet | | | |
| 508-0109 | 1 | Grommet, Rubber - 1" Hole | | | |
| 220-2044 | 1 | Stator, Wound - Generator | | | |
| 201-2159 | 1 | Rotor Assembly, Wound - Generator | | | |
| 520-0799 | 4 | Stud, Generator Through | | | |
| 520-0791 | 1 | Stud, Rotor Through | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 320-0104 | 1 | Relay, Low Oil Pressure | | | |

FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 1
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5559-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--------------------------|------|---------------------------|----------|------|-------------|
| Vacu-Flo Cooling | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| 220-2043 | 1 | Stator, Generator | | | |
| 201-2158 | 1 | Rotor Assembly, Generator | | | |
| 520-0798 | 4 | Stud, Generator Through | | | |
| 520-0790 | 1 | Stud, Rotor Through | | | |

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-3R **SPEC** 16662AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (Eng)612-4793-01 (AC)612-1786-05

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|-----------------|------|---|----------|------|-------------|
| Gas Fuel System | | | | | |
| Housed | | | | | |
| Meter Panel | | | | | |
| 102-0549 | 1 | Base, Oil | | | |
| 112-0106 | 4 | Piston and Pin | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |
| 134-1375 | 1 | Plate, Exhaust Outlet Cover | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 405-1674 | 1 | Shield, Rain (Top Panel) | | | |
| 301-1554 | 1 | Panel, Meter | | | |

SPECIAL PARTS LIST FOR MODEL 12.5JC-3R SPEC 16666AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4997-01 (SWBD) 615-037

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|---|----------|------|-------------|
| Air Shutter | | | | | |
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Overspeed Cut Off | | | | | |
| Switchboard Control | | | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 302-0458 | 2 | Ammeter, AC | | | |
| 301-2086 | 1 | Panel, Instrument | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 3 | Lamp, Indicator - Low Oil Pressure (1) High Air Temp. (1) Overspeed (1) | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-0655 | 2 | Relay, Latching - High Air Temp. (1) Overspeed (1) | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker (Blank) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 301-3567 | 1 | Panel, Control | | | |

SPECIAL PARTS LIST FOR **MODEL** 15.0JC-4XR **SPEC** 16666AA
 FOR STANDARD PARTS REFER TO **CATALOG** 967-0220 **KEY NO.** 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO(ENG) 612-4997-06 (SWBD) 615-0381-(

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|---|----------|------|-------------|
| Low Oil Pressure Cut Off | | | | | |
| High Air Temperature Cut Off | | | | | |
| Overspeed Cut Off | | | | | |
| Air Shutter | | | | | |
| Switchboard Control | | | | | |
| 309-0206 | 1 | Switch, High Air Temperature | | | |
| 301-2116 | 1 | Panel, Instrument | | | |
| 301-0994 | 1 | Box Assembly, Meter - Includes Box, Cover and Grommet | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 3 | Lamp, Indicator - Low Oil Pressure (1) High Air Temp. (1) Overspeed (1) | | | |
| 322-0069 | 3 | Holder, Indicator Lamp | | | |
| 320-0259 | 1 | Limiter, Cranking - Low Oil Pressure | | | |
| 307-0655 | 2 | Relay, Latching - High Air Temp. (1) Overspeed (1) | | | |
| 332-0706 | 2 | Block, Terminal - 8 Place | | | |
| 332-0707 | 1 | Strip, Marker (Blank) | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 301-3567 | 1 | Panel, Control | | | |

Sept 1, 1978

SPECIAL PARTS LIST FOR **MODEL** 12.5JC-18R **SPEC** 16668AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-4793-02

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|------------------------------|------|---|----------|------|-------------|
| LPG Fuel System | | | | | |
| High Air Temperature Cut Off | | | | | |
| 331-0103 | 1 | Grommet, Hose (Regulator to Carburetor) | | | |

SPECIAL PARTS LIST FOR MODEL 12.5JC-3R31 SPEC 16689AA
 FOR STANDARD PARTS REFER TO CATALOG 967-0220 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 612-4851-05 (SWBD) 615-0373-

| PART NO. | QTY. | DESCRIPTION | PART NO. | QTY. | DESCRIPTION |
|--|------|---|----------|------|-------------|
| Overspeed Cut Off | | | | | |
| Gas Fuel System | | | | | |
| Vacu - Flo Cooling (See Air Housing) | | | | | |
| Switchboard Control | | | | | |
| Skid and Battery Rack (See Housing Option) | | | | | |
| NOTE: Pennsylvania Approved | | | | | |
| 134-3081 | 1 | Guard, Scroll Outlet | | | |
| 508-0109 | 1 | Grommet, Rubber - 1" Hole | | | |
| 332-0216 | 1 | Lug, Solderless Ground | | | |
| 505-0002 | 2 | Nipple, Oil Drain | | | |
| 402-0364 | 1 | Hardware Set, Generator Set Mounting (Set of Four) | | | |
| 416-0522 | 1 | Plate, Battery Mounting | | | |
| 149-0558 | 1 | Strainer | | | |
| 307-0312 | 1 | Valve, Fuel | | | |
| 416-0325 | 1 | Hydrometer | | | |
| 402-0287 | 2 | Cushion, Vibration - Generator End | | | |
| 338-0917 | 1 | Harness, Wiring - Voltage Regulator to Exciter Stator | | | |
| 322-0004 | 1 | Lamp, Indicator - Overspeed | | | |
| 322-0069 | 1 | Holder, Indicator Lamp | | | |
| 321-0146 | 1 | Fuse - 10 Amp. | | | |
| 321-0175 | 1 | Holder, Fuse | | | |
| 307-0655 | 1 | Relay, Overspeed | | | |
| 332-0604 | 1 | Block, Terminal - 5 Place | | | |
| 332-0616 | 1 | Strip, Marker - 5 Place | | | |