

The following catalog
has gaps in its page
numbers, or doesn't
have any numbers.
We have chosen to
leave the page
numbering in the
order that Acrobat
assigns it.

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4R SPEC 13943AB
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 612-5505-01 (AC) 612-5500-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off - Dual Senders			
		High Water Temperature Cut Off - Dual Senders			
		Overcrank Cut Off			
154-0840	1	Manifold, intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
309-0178	1	Switch, High Water Temperature Alarm			
110-1282	1	Bolt, Low Engine Temperature Switch			
309-0064	1	Switch, Low Oil Pressure Cut Off			
502-0058	1	Tee, Street Pipe - Oil Filter Adapter			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
307-0848	1	Relay, Oil Pressure - Time Delay 15 Seconds			
332-1006	1	Strip, Marker (20 Place)			
307-0819	3	Relay, Pre-Alarm - Low Oil Pressure & High Water Temperature, & Low Engine Temperature			
301-2393	1	Bracket, Mounting			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0612	1	Strip, Marker (3 Place)			
332-0943	2	Spacer			
332-0611	2	Block, Terminal (3 Place)			
332-1043	1	Jumper			
307-0778	3	Spring, Hold-Down			
405-1157	1	Flange, Air Duct Adapter			

SPECIAL PARTS LIST FOR **MODEL** 17.5RDJF-4R **SPEC** 13983AA
 FOR STANDARD PARTS REFER TO **CATALOG** 974-0222 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-3843-01(AC) 612-4816-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Water Temperature Cut Off			
		Overcrank Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			

SPECIAL PARTS LIST FOR MODEL 17.5RDJE-4R SPEC 13988AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 612-3136-01 (AC) 612-4816-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2204	1	Panel, Control - Upper			
320-0259	1	Relay, Cranking Limiter			
307-0696	1	Relay, Time Delay - 10 Second			
307-0734	1	Relay, Time Delay - 5 Second			
332-0795	1	Block, Terminal (16 Terminal)			
332-0862	1	Strip, Marker - (Use With 332-0795)			
338-0768	1	Harness, Wiring - Overspeed			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4R SPEC 14004AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 612-2730-01(AC) 612-4816-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Engine Coolant Heater					
Oil Base Heater					
Voltage Regulator Filter					
Overspeed Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
		Voltage Regulator Filter			
		Assembly - Consists Of			
		Following: (Parts			
		Marked With *)			
232-2589	1	Regulator Filter Package -			
		Complete			
232-2462	1	*Box, Mounting			
232-2463	1	*Cover, Mounting Box			
312-0197	1	*Capacitor			
312-0198	2	*Bracket, Capacitor Mounting			
508-0071	1	*Grommet, Rubber - 7/8" Hole			
304-0120	2	*Resistor, Fixed - 2 Ohm,			
		25 Watts			
304-0015	4	*Washer, Resistor Centering			
304-0292	2	*Insulator, Resistor			
813-0112	2	*Screw - RHM (10-32 X 2-1/2")			
		Resistor Mounting			
338-1165	1	*Harness, Wiring			
625-1304	-	Wiring Diagram			
405-1157	1	Flange, Air Duct Adapter			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4R SPEC 14035AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG)612-2730-01(AC)612-4816-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
City Water Cooled					
Water Cooled Manifold					
Heat Exchanger					
Overspeed Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Thorough			
505-0266	1	Plug, Pipe - Recess Head, Exhaust Manifold (3/8")			
504-0006	1	Cock, Drain - Exhaust Manifold (1/8" Pipe)			
517-0059	1	Plug, Expansion - Exhaust Manifold (Brass 1-7/16" OD)			
103-0228	1	Backplate, Gearcase			
306-0195	1	Plate, Relay Mounting			
503-0478	1	Hose, Cylinder #1 & 2 To Cylinder #3 & 4 (3/4" ID X 9" Long)			
130-0892	1	Stiffener, Filler Neck - Expansion Chamber			
503-0679	1	Hose, Overflow - Expansion Chamber			
504-0003	1	Cock, Drain - Heat Exchanger			
526-0158	4	Washer, Flat - Heat Exchanger			
503-0711	1	Hose, Pump Outlet To Block (3/4" ID X 6" Long)			
503-0460	1	Hose, Heat Exchanger To Pump Inlet (3/4" ID X 7" Long)			
503-0461	1	Hose, Heat Exchanger Inlet To Top Of Exchanger Chamber (3/4" ID X 13-1/4" Long)			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4R SPEC 14044AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 612-3843-01(AC) 612-4816-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Water Temperature Cut Off			
		Overcrank Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
405-1157	1	Flange, Air Duct Adapter			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4R SPEC 14108AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-3136-01 (AC) 612-4816-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Muffler Mounted On Housing			
		Engine Coolant Heater			
		Oil Base Heater			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Water Temperature Cut Off			
		Overcrank Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
307-0696	1	Relay, Time Delay - 10 Second			
307-0734	1	Relay, Time Delay - 5 Second			
332-0795	1	Block, Terminal (16 Terminal)			
332-0862	1	Strip, Marker (Use With 332-0795 Block)			
405-1889	1	Shield, Rain - Muffler			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4R SPEC 14108AB
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5548-01 (AC) 612-5500-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Muffler Mounted On Housing					
Engine Coolant Heater					
Oil Base Heater					
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2204	1	Panel, Control - Upper			
332-0943	2	Spacer			
332-1043	1	Jumper			
332-1006	1	Strip, Marker (20 Place)			
320-0259	1	Relay, Cranking Limiter			
332-0612	1	Strip, Marker (3 Place)			
307-0597	1	Relay - Pilot			
307-0696	1	Relay, Cycle Cranker - Time Delay 10 Seconds			
307-0734	1	Relay, Cycle Cranker - Time Delay 5 Seconds			
301-2393	1	Bracket, Relay Mounting			
338-0768	1	Harness, Wiring - Overspeed			
405-1889	1	Shield, Rain - Muffler			
332-0611	2	Block, Terminal (3 Place)			

SPECIAL PARTS LIST FOR MODEL 14.5RDJF-53R SPEC 14114AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG)612-4880-01(AC)612-4815-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
110-1282	1	Bolt, Low Engine Temperature Switch			
301-2288	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
307-0819	1	Relay, Pre-Alarm - Low Engine Temperature			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0943	2	Spacer			
332-0611	1	Block, Terminal (3 Place)			
320-0259	1	Relay, Cranking Limiter			
332-1006	1	Strip, Marker (20 Place)			
150-1046	1	Switch Assembly, Overspeed			
405-1157	1	Flange, Air Duct Adapter			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-3R SPEC 14114AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG)612-4880-01(AC)612-4815-0

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Water Temperature Cut Off			
		Overcrank Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
110-1282	1	Bolt, Low Engine Temperature Switch			
301-2288	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
307-0819	1	Relay, Pre-Alarm - Low Engine Temperature			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0943	2	Spacer			
332-0611	1	Block, Terminal (3 Place)			
320-0259	1	Relay, Cranking Limiter			
332-1006	1	Strip, Marker (20 Place)			
405-1157	1	Flange, Air Duct Adapter			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4R SPEC 14114AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 612-4880-01 (AC) 612-4816-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Water Temperature Cut Off			
		Overcrank Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
110-1282	1	Bolt, Low Engine Temperature Switch			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
307-0819	1	Relay, Pre-Alarm - Low Engine Temperature			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0943	2	Spacer			
332-0611	1	Block, Terminal (3 Place)			
320-0259	1	Relay, Cranking Limiter			
332-1006	1	Strip, Marker (20 Place)			
405-1157	1	Flange, Air Duct Adapter			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-5DR SPEC 14114AB
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 612-5516-01 (AC) 612-5502-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Water Temperature Cut Off			
		Overcrank Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
110-1282	1	Bolt, Low Engine Temperature Switch			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
307-0819	1	Relay, Pre-Alarm - Low Engine Temperature			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
332-0943	2	Spacer			
332-0611	1	Block, Terminal (3 Place)			
320-0259	1	Relay, Cranking Limiter			
332-1006	1	Strip, Marker (20 Place)			
332-1043	1	Jumper			
307-0778	1	Spring, Hold-Down			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
405-1157	1	Flange, Air Duct Adapter			

SPECIAL PARTS LIST FOR MODEL 17.5RDJE-4R SPEC 14142AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-2896-01 (AC) 612-4816-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Water Temperature Cut Off			
		Overcrank Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2204	1	Panel, Control - Upper			
301-2574	1	Panel, Control - Lower			
307-0696	1	Relay, Time Delay - 10 Second			
307-0734	1	Relay, Time Delay - 5 Second			
307-1149	1	Relay, Time Delay - Cranking Periods, 1 To 300 Seconds On Energization			
332-0532	1	Block, Terminal (10 Terminal)			
332-0533	1	Strip, Marker - (Use With 332-0532)			
332-0795	1	Block, Terminal - Engine (16 Terminal)			
332-0862	1	Strip, Marker - (Use With 332-0795)			
338-0768	1	Harness, Wiring - Overspeed			
405-1157	1	Flange, Air Duct Adapter			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4R SPEC 14151AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4842-01 (AC) 612-4816-08

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Mounted Fuel Tank			
		Muffler Mounted On Housing			
		Engine Coolant Heater			
		Oil Base Heater			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off - Dual Senders			
		High Water Temperature Cut Off - Dual Senders			
		Overcrank Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
309-0178	1	Switch, High Water Temperature Alarm			
110-1282	1	Bolt, Low Engine Temperature Switch			
309-0064	1	Switch, Low Oil Pressure Cut Off			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
307-0848	1	Relay, Oil Pressure - Time Delay 15 Seconds			
332-1006	1	Strip, Marker (20 Place)			
307-0819	3	Relay, Pre-Alarm - Low Oil Pressure & High Water Temperature, & Low Engine Temperature			
301-2393	1	Bracket, Mounting			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0612	1	Strip, Marker (3 Place)			
332-0943	2	Spacer			
332-0611	2	Block, Terminal (3 Place)			
405-1889	1	Shield, Rain - Muffler			

SPECIAL PARTS LIST FOR MODEL 14.5RDJF-57R SPEC 14183AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-2749-01(AC)612-4922-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Water Temperature Cut Off			
		Overcrank Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2308	1	Panel, Control - Upper			
302-0612	1	Voltmeter, AC (0-500 Volt)			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-0795	1	Block, Terminal (16 Terminal)			
332-0862	1	Strip, Marker - (Use With 332-0795)			
338-0768	1	Harness, Wiring - Overspeed			
150-1046	1	Switch Assembly - Overspeed			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-3R SPEC 14183AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-2749-01(AC) 612-4815-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Water Temperature Cut Off			
		Overcrank Cut Off			
140-1194	1	Cover, Air Cleaner			
154-0840	1	Manifold, Intake			
232-0200	1	Washer, Rotor Through			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-0795	1	Block, Terminal (16 Terminal)			
332-0862	1	Strip, Marker - (Use With 332-0795)			
301-2288	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			

SPECIAL PARTS LIST FOR MODEL 17.5RDJE-4R SPEC 14183AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-2749-01(AC) 612-4816-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-0795	1	Block, Terminal (16 Terminal)			
332-0862	1	Strip, Marker - (Use With 332-0795)			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4XR SPEC 14183AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-2749-01 (AC) 612-4817-0

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2308	1	Panel, Control - Upper			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-0795	1	Block, Terminal (16 Terminal)			
332-0862	1	Strip, Marker - (Use With 332-0795)			
338-0768	1	Harness, Wiring - Overspeed			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-5DR SPEC 14183AA
FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-2749-01(AC)612-4818-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Water Temperature Cut Off			
		Overcrank Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2204	1	Panel, Control - Upper			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-0795	1	Block, Terminal (16 Terminal)			
332-0862	1	Strip, Marker - (Use With 332-0795)			
338-0768	1	Harness, Wiring - Overspeed			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-9XR SPEC 14183AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-2749-01(AC) 612-4892-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overspeed Cut Off					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
220-2287	1	Stator, Wound			
301-3736	1	Panel, Control - Upper			
320-0551	1	Breaker, Circuit - 25 Amp			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-0795	1	Block, Terminal (16 Terminal)			
332-0862	1	Strip, Marker - (Use With 332-0795)			
338-0768	1	Harness, Wiring - Overspeed			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-3R SPEC 14183AB
FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5506-01(AC) 612-5486-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Water Temperature Cut Off			
		Overcrank Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2288	1	Panel, Control - Upper			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-1043	1	Jumper			
332-1006	1	Strip, Marker (20 Place)			
338-0768	1	Harness, Wiring - Overspeed			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4R SPEC 14183AB
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5506-01(AC) 612-5500-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Water Temperature Cut Off			
		Overcrank Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2204	1	Panel, Control - Upper			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-1043	1	Jumper			
332-1006	1	Strip, Marker (20 Place)			
338-0768	1	Harness, Wiring - Overspeed			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-9XR SPEC 14183AB
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5506-01 (AC) 612-5511-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overspeed Cut Off					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
220-2287	1	Stator, Wound			
301-3736	1	Panel, Control - Upper			
320-0551	1	Circuit Breaker, 25 Amp			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-1043	1	Jumper			
332-1006	1	Strip, Marker (20 Place)			
338-0768	1	Harness, Wiring - Overspeed			

SPECIAL PARTS LIST FOR **MODEL** 17.5RDJF-4XR **SPEC** 14234AA
FOR STANDARD PARTS REFER TO CATALOG 974-0222 **KEY NO.** 2
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4445-01(AC)612-4817-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
City Water Cooled			505-0075	1	Nipple (3/8 X 2-1/2" Long)
Water Cooled Manifold			301-2308	1	Panel, Control - Upper
Heat Exchanger			338-0768	1	Harness, Wiring - Overspee
Overspeed Cut Off			320-0259	1	Relay, Cranking Limiter
Low Oil Pressure Cut Off - Dual Senders			307-0848	1	Relay, Oil Pressure - Time
High Water Temperature Cut Off - Dual Senders					Delay 15 Seconds
Overcrank Cut Off			332-1006	1	Strip, Marker (20 Place)
			307-0819	2	Relay, Pre-Alarm - Low Oil
154-0840	1	Manifold, Intake			Pressure & High Water
140-1194	1	Cover, Air Cleaner			Temperature
232-0200	1	Washer, Rotor Through	301-2393	1	Bracket, Mounting
505-0266	1	Plug, Pipe - Recess Head,	332-0943	2	Spacer
		Exhaust Manifold (3/8")	332-0611	2	Block, Terminal (3 Place)
504-0006	1	Cock, Drain - Exhaust Manifold			
		1/8" Pipe			
517-0059	1	Plug, Expansion - Exhaust			
		Manifold (Brass			
		1-7/16" OD)			
502-0245	1	Tee, Inverted Flared -			
		Manifold (Brass			
		1-7/8" X 7/8")			
103-0228	1	Backplate, Gearcase			
306-0195	1	Plate, Relay Mounting			
503-0478	1	Hose, Cylinder #1 & 2 To			
		Cylinder #3 & 4			
		(3/4" ID X 9" Long)			
130-0892	1	Stiffener, Filler Neck -			
		Expansion Chamber			
503-0679	1	Hose, Overflow - Expansion			
		Chamber			
504-0003	1	Cock, Drain - Heat Exchanger			
526-0158	4	Washer, Flat - Heat Exchanger			
503-0711	1	Hose, Pump Outlet To Block			
		(3/4" ID X 6" Long)			
503-0460	1	Hose, Heat Exchanger To Pump			
		Inlet (3/4" ID X 7" Long)			
503-0461	1	Hose, Heat Exchanger Inlet			
		To Top Of Exchanger Chamber			
		(3/4" ID X 13-1/4" Long)			
505-0101	3	Nipple, Close (3/8" X 1")			
309-0064	1	Switch (Lopko)			
503-0478	1	Hose, Heat Exchanger To			
		Engine Water Pump			
309-0179	1	Thermostat, Open 190° - Close			
		215°			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4XR SPEC 14255AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4880-01 (AC)612-4817-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Engine Coolant Heater					
Oil Base Heater					
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
Muffler Mounted On Housing					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
110-1282	1	Bolt, Low Engine Temperature Switch			
301-2308	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
307-0819	1	Relay, Pre-Alarm - Low Engine Temperature			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0943	2	Spacer			
332-0611	1	Block, Terminal (3 Place)			
320-0259	1	Relay, Cranking Limiter			
332-1006	1	Strip, Marker (20 Place)			
405-1889	1	Shield, Rain - Muffler			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-5DR SPEC 14255AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4880-01 (AC) 612-4818-08

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Engine Coolant Heater					
Oil Base Heater					
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
Muffler Mounted On Housing					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
110-1282	1	Bolt, Low Engine Temperature Switch			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
307-0819	1	Relay, Pre-Alarm - Low Engine Temperature			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0943	2	Spacer			
332-0611	1	Block, Terminal (3 Place)			
320-0259	1	Relay, Cranking Limiter			
332-1006	1	Strip, Marker (20 Place)			
405-1889	1	Shield, Rain - Muffler			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-3R SPEC 14255AB
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5516-01(AC)612-5486-08

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Engine Coolant Heater			
		Oil Base Heater			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Water Temperature Cut Off			
		Overcrank Cut Off			
		Muffler Mounted On Housing			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
110-1282	1	Bolt, Low Engine Temperature Switch			
301-2288	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
307-0819	1	Relay, Pre-Alarm - Low Engine Temperature			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
332-0943	2	Spacer			
332-0611	1	Block, Terminal (3 Place)			
320-0259	1	Relay, Cranking Limiter			
332-1006	1	Strip, Marker (20 Place)			
332-1043	1	Jumper			
307-0778	1	Spring, Hold-Down			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
405-1889	1	Shield, Rain - Muffler			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-3R SPEC 14380AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-2749-01(AC)612-4815-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Water Temperature Cut Off			
		Overcrank Cut Off			
140-1194	1	Cover, Air Cleaner			
154-0840	1	Manifold, Intake			
232-0200	1	Washer, Rotor Through			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-0795	1	Block, Terminal (16 Terminal)			
332-0862	1	Strip, Marker - (Use With 332-0795)			
301-2288	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			

Dated Sept. 1, 1979

Revised

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4R SPEC 14380AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-2749-01(AC) 612-4816-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Water Temperature Cut Off			
		Overcrank Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-0795	1	Block, Terminal (16 Terminal)			
332-0862	1	Strip, Marker - (Use With 332-0795)			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-9XR SPEC 14380AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-2749-01(AC)612-4892-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Water Temperature Cut Off			
		Overcrank Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
220-2287	1	Stator, Wound			
301-3736	1	Panel, Control - Upper			
320-0551	1	Breaker, Circuit - 25 Amp			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-0795	1	Block, Terminal (16 Terminal)			
332-0862	1	Strip, Marker - (Use With 332-0795)			
338-0768	1	Harness, Wiring - Overspeed			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4R SPEC 14380AB
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 612-5506-01(AC) 612-5500-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Water Temperature Cut Off			
		Overcrank Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2204	1	Panel, Control - Upper			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-1043	1	Jumper			
332-1006	1	Strip, Marker (20 Place)			
338-0768	1	Harness, Wiring - Overspeed			

SPECIAL PARTS LIST FOR MODEL 14.5RDJF-57R SPEC 14412AB
FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5488-01 (AC) 612-5512-08

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Muffler Mounted On Housing					
Mounted Fuel Tank					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2308	1	Panel, Control - Upper			
302-0612	1	Voltmeter, AC (0-500 Volt)			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-1043	1	Jumper			
405-1889	1	Shield, Rain - Muffler			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-3R SPEC 14475AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 612-2749-01 (AC) 612-4815-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Engine Coolant Heater					
Oil Base Heater					
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-0795	1	Block, Terminal (16 Terminal)			
332-0862	1	Strip, Marker (Use With 332-0795 Block)			
301-2288	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
405-1157	1	Flange, Air Duct Adapter			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4R SPEC 14475AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-2749-01(AC)612-4816-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Engine Coolant Heater					
Oil Base Heater					
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2204	1	Panel, Control - Upper			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-0795	1	Block, Terminal (16 Terminal)			
332-0862	1	Strip, Marker (Use With 332-0795)			
338-0768	1	Harness, Wiring - Overspeed			
405-1157	1	Flange, Air Duct Adapter			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4XR SPEC 14475AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-2749-01 (AC) 612-4817-09

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Engine Coolant Heater					
Oil Base Heater					
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2308	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-0795	1	Block, Terminal (16 Terminal)			
332-0862	1	Strip, Marker (Use With 332-0795 Block)			
405-1157	1	Flange, Air Duct Adapter			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4R SPEC 14475AB
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 612-5506-01 (AC) 612-5500-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Engine Coolant Heater					
Oil Base Heater					
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2204	1	Panel, Control - Upper			
332-0943	2	Spacer			
332-1043	1	Jumper			
332-1006	1	Strip, Marker (20 Place)			
338-0768	1	Harness, Wiring - Overspeed			
405-1157	1	Flange, Air Duct Adapter			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-5DR SPEC 14475AB
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG)612-5506-01(AC)612-5502-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Engine Coolant Heater					
Oil Base Heater					
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2204	1	Panel, Control - Upper			
332-0943	2	Spacer			
332-1043	1	Jumper			
332-1006	1	Strip, Marker (20 Place)			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			

SPECIAL PARTS LIST FOR **MODEL** 17.5RDJF-3R **SPEC** 14533AA
 FOR STANDARD PARTS REFER TO **CATALOG** 974-0222 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-2730-01(AC) 612-4815-18

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Muffler Mounted On Housing			
		Engine Coolant Heater			
		Oil Base Heater			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2288	1	Panel, Control - Upper			
405-1889	1	Shield, Rain - Muffler			

Dated Sept. 1, 1979

Revised

Page 1

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4XR SPEC 14533AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 612-2730-01 (AC) 612-4817-12

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Muffler Mounted On Housing					
Engine Coolant Heater					
Oil Base Heater					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2308	1	Panel, Control - Upper			
405-1889	1	Shield, Rain - Muffler			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-3R SPEC 14569AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 612-4880-01 (AC) 612-4815-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Water Temperature Cut Off			
		Overcrank Cut Off			
		Voltage Regulator Filter			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
110-1282	1	Bolt, Low Engine Temperature Switch			
301-2288	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
307-0819	1	Relay, Pre-Alarm - Low Engine Temperature			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0943	2	Spacer			
332-0611	1	Block, Terminal (3 Place)			
320-0259	1	Relay, Cranking Limiter			
332-1006	1	Strip, Marker (20 Place)			
405-1157	1	Flange, Air Duct Adapter			
		Voltage Regulator Filter Assembly - Consists Of Following: (Parts Marked With *)			
232-2589	1	Regulator Filter Package - Complete			
232-2462	1	*Box, Mounting			
232-2463	1	*Cover, Mounting Box			
312-0197	1	*Capacitor			
312-0198	2	*Bracket, Capacitor Mounting			
508-0071	1	*Grommet, Rubber - 7/8" Hole			
304-0120	2	*Resistor, Fixed - 2 Ohm, 25 Watts			
304-0015	4	*Washer, Resistor Centering			
304-0292	2	*Insulator, Resistor			
813-0112	2	*Screw - RHM (10-32 X 2-1/2") Resistor Mounting			
338-1165	1	*Harness, Wiring			
625-1304	-	Wiring Diagram			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4R SPEC 14572AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4445-01 (AC)612-4816-08

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Muffler Mounted On Housing			
		Engine Coolant Heater			
		Oil Base Heater			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off - Dual Senders			
		High Water Temperature Cut Off - Dual Senders			
		Overcrank Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
309-0178	1	Switch, High Water Temperature Alarm			
309-0064	1	Switch, Low Oil Pressure Cut Off			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
307-0848	1	Relay, Oil Pressure - Time Delay 15 Seconds			
332-1006	1	Strip, Marker (20 Place)			
307-0819	2	Relay, Pre-Alarm - Low Oil Pressure & High Water Temperature			
301-2393	1	Bracket, Mounting			
332-0943	2	Spacer			
332-0611	1	Block, Terminal (3 Place)			
405-1889	1	Shield, Rain - Muffler			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4XR SPEC 14572AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4445-01(AC)612-4817-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Muffler Mounted On Housing			
		Engine Coolant Heater			
		Oil Base Heater			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off - Dual Senders			
		High Water Temperature Cut Off - Dual Senders			
		Overcrank Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
309-0178	1	Switch, High Water Temperature Alarm			
309-0064	1	Switch, Low Oil Pressure Cut Off			
301-2308	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
307-0848	1	Relay, Oil Pressure - Time Delay 15 Seconds			
332-1006	1	Strip, Marker (20 Place)			
307-0819	2	Relay, Pre-Alarm - Low Oil Pressure & High Water Temperature			
301-2393	1	Bracket, Mounting			
332-0943	2	Spacer			
332-0611	1	Block, Terminal (3 Place)			
405-1889	1	Shield, Rain - Muffler			

SPECIAL PARTS LIST FOR **MODEL** 17.5RDJF-5DR **SPEC** 14572AA
 FOR STANDARD PARTS REFER TO **CATALOG** 974-0222 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4445-01 (AC)612-4818-08

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Engine Coolant Heater					
Oil Base Heater					
Overspeed Cut Off					
Low Oil Pressure Cut Off - Dual Senders					
High Water Temperature Cut Off - Dual Senders					
Overcrank Cut Off					
Muffler Mounted On Housing					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
309-0178	1	Switch, High Water Temperature Alarm			
309-0064	1	Switch, Low Oil Pressure Cut Off			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
307-0848	1	Relay, Oil Pressure - Time Delay 15 Seconds			
332-1006	1	Strip, Marker (20 Place)			
307-0819	2	Relay, Pre-Alarm - Low Oil Pressure & High Water Temperature			
301-2393	1	Bracket, Mounting			
332-0943	2	Spacer			
332-0611	1	Block, Terminal (3 Place)			
405-1889	1	Shield, Rain - Muffler			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-3R SPEC 14585AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4880-01 (AC) 612-4815-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Engine Coolant Heater					
Oil Base Heater					
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
110-1282	1	Bolt, Low Engine Temperature Switch			
301-2288	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
307-0819	1	Relay, Pre-Alarm - Low Engine Temperature			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0943	2	Spacer			
332-0611	1	Block, Terminal (3 Place)			
320-0259	1	Relay, Cranking Limiter			
332-1006	1	Strip, Marker (20 Place)			

SPECIAL PARTS LIST FOR **MODEL** 17.5RDJF-4R **SPEC** 14585AA
 FOR STANDARD PARTS REFER TO **CATALOG** 974-0222 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4880-01(AC)612-4816-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Engine Coolant Heater					
Oil Base Heater					
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
110-1282	1	Bolt, Low Engine Temperature Switch			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
307-0819	1	Relay, Pre-Alarm - Low Engine Temperature			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0943	2	Spacer			
332-0611	1	Block, Terminal (3 Place)			
320-0259	1	Relay, Cranking Limiter			
332-1006	1	Strip, Marker (20 Place)			

SPECIAL PARTS LIST FOR **MODEL** 17.5RD.IF-4R **SPEC** 14587AB
 FOR STANDARD PARTS REFER TO **CATALOG** 974-0222 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5505-01 (AC)612-5500-08

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Muffler Mounted On Housing					
Engine Coolant Heater					
Oil Base Heater					
Overspeed Cut Off					
Low Oil Pressure Cut Off - Dual Senders					
High Water Temperature Cut Off - Dual Senders					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
309-0178	1	Switch, High Water Temperature Alarm			
110-1282	1	Bolt, Low Engine Temperature Switch			
309-0064	1	Switch, Low Oil Pressure Cut Off			
502-0058	1	Tee, Street Pipe - Oil Filter Adapter			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
307-0848	1	Relay, Oil Pressure - Time Delay 15 Seconds			
332-1006	1	Strip, Marker (20 Place)			
307-0819	3	Relay, Pre-Alarm - Low Oil Pressure & High Water Temperature, & Low Engine Temperature			
301-2393	1	Bracket, Mounting			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0612	1	Strip, Marker (3 Place)			
332-0943	2	Spacer			
332-0611	2	Block, Terminal (3 Place)			
332-1043	1	Jumper			
307-0778	3	Spring, Hold-Down			
405-1889	1	Shield, Rain - Muffler			

SPECIAL PARTS LIST FOR MODEL 14.5RDJF-57R SPEC 14592AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-2749-01(AC)612-4922-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2308	1	Panel, Control - Upper			
302-0612	1	Voltmeter, AC - 0-500 Volt			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-0795	1	Block, Terminal (16 Terminal)			
332-0862	1	Strip, Marker - (Use With 332-0795)			
338-0768	1	Harness, Wiring - Overspeed			
150-1046	1	Switch Assembly - Overspeed			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-3R SPEC 14592AA
FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-2749-01(AC)612-4815-08

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Water Temperature Cut Off			
		Overcrank Cut Off			
140-1194	1	Cover, Air Cleaner			
154-0840	1	Manifold, Intake			
232-0200	1	Washer, Rotor Through			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-0795	1	Block, Terminal (16 Terminal)			
332-0862	1	Strip, Marker - (Use With 332-0795)			
301-2288	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			

SPECIAL PARTS LIST FOR MODEL 17.5RDJE-5DR SPEC 14592AB
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5506-01 (AC) 612-5502-08

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2204	1	Panel, Control - Upper			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-1043	1	Jumper			
332-1006	1	Strip, Marker - (Use With 332-1005 Block)			
338-0768	1	Harness, Wiring - Overspeed			

SPECIAL PARTS LIST FOR **MODEL** 17.5RDJF-4R **SPEC** 14817AA
 FOR STANDARD PARTS REFER TO **CATALOG** 974-0222 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-2730-01(AC) 612-4816-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Engine Coolant Heater					
Oil Base Heater					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2204	1	Panel, Control - Upper			
201-2160	1	Rotor Assembly, Wound			
220-2045	1	Stator, Wound			
520-0792	1	Stud, Rotor Through			
520-0800	4	Stud, Generator Through			
405-1157	1	Flange, Air Duct Adapter			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-8R SPEC 14831AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG)612-2749-01(AC)612-4979-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Engine Coolant Heater					
Oil Base Heater					
Control Box Heater					
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
332-0795	1	Block, Terminal (16 Terminal)			
332-0862	1	Strip, Marker (Use With 332-0795 Block)			
332-0943	2	Spacer			
		Control Box Heater - Consists Of Following: (Parts Marked With ++)			
333-0151	1	++Heater, 300 Watt, 240 Volt (75 Watt At 120 Volt)			
309-0128	1	++Thermostat - Open At 105°±5°			
301-1886	1	++Cover, Thermostat			
335-0110	1	++Cord Assembly			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4R SPEC 14956AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-3136-01(AC) 612-4816-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Water Temperature Cut Off			
		Overcrank Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
320-0259	1	Relay, Cranking Limiter			
307-0696	1	Relay, Time Delay - 10 Second			
307-0734	1	Relay, Time Delay - 5 Second			
332-0795	1	Block, Terminal (16 Terminal)			
332-0862	1	Strip, Marker - (Use With 332-0795)			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
405-1157	1	Flange, Air Duct Adapter			

SPECIAL PARTS LIST FOR **MODEL** 16.ORDJF-4R50 **SPEC** 14957AA
 FOR STANDARD PARTS REFER TO **CATALOG** 974-0222 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4875-01 (AC) 612-4816-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Note: Pennsylvania Approved Engine Coolant Heater Oil Base Heater Overspeed Cut Off Low Oil Pressure Cut Off - Dual Senders High Water Temperature Cut Off - Dual Senders Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
309-0178	1	Switch, High Water Temperature Alarm			
110-1282	1	Bolt, Low Engine Temperature Switch			
309-0064	1	Switch, Low Oil Pressure Cut Off			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
307-0848	1	Relay, Oil Pressure - Time Delay 15 Seconds			
332-1006	1	Strip, Marker (20 Place)			
307-0819	3	Relay, Pre-Alarm - Low Oil Pressure & High Water Temperature, & Low Engine Temperature			
301-2393	1	Bracket, Mounting			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0612	1	Strip, Marker (3 Place)			
332-0943	2	Spacer			
332-0611	2	Block, Terminal (3 Place)			

SPECIAL PARTS LIST FOR **MODEL** 16.0RDJF-4R50 **SPEC** 14957AB
 FOR STANDARD PARTS REFER TO **CATALOG** 974-0222 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5503-01(AC)612-5500-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Note: Pennsylvania Approved Engine Coolant Heater Oil Base Heater Overspeed Cut Off Low Oil Pressure Cut Off - Dual Senders High Water Temperature Cut Off - Dual Senders Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
309-0178	1	Switch, High Water Temperature Alarm			
110-1282	1	Bolt, Low Engine Temperature Switch			
309-0064	1	Switch, Low Oil Pressure Cut Off			
502-0058	1	Tee, Street Pipe - Oil Filter Adapter			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
307-0848	1	Relay, Oil Pressure - Time Delay 15 Seconds			
332-1006	1	Strip, Marker (20 Place)			
307-0819	3	Relay, Pre-Alarm - Low Oil Pressure & High Water Temperature, & Low Engine Temperature			
301-2393	1	Bracket, Mounting			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
308-0005	1	Switch, Selector			
332-0612	1	Strip, Marker (3 Place)			
332-0611	2	Block, Terminal (3 Place)			
332-1043	1	Jumper			
307-0778	3	Spring, Hold-Down			

SPECIAL PARTS LIST FOR **MODEL** 17.5RDJF-4R **SPEC** 14968AA
 FOR STANDARD PARTS REFER TO **CATALOG** 974-0222 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-2905-01 (AC) 612-4816-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Engine Coolant Heater					
Oil Base Heater					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2204	1	Panel, Control - Upper			
353-0015	1	Resistor, 3.5 Ohm - 10 Watt			
307-0696	1	Relay, Time Delay - 10 Second			
307-0734	1	Relay, Time Delay - 5 Second			

SPECIAL PARTS LIST FOR **MODEL** 17.5RDJF-4XR **SPEC** 14968AA
 FOR STANDARD PARTS REFER TO **CATALOG** 974-0222 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG) 612-2905-01 (AC) 612-4817-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Engine Coolant Heater					
Oil Base Heater					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2308	1	Panel, Control - Upper			
353-0015	1	Resistor, 3.5 Ohm - 10 Watt			
307-0696	1	Relay, Time Delay - 10 Second			
307-0734	1	Relay, Time Delay - 5 Second			

SPECIAL PARTS LIST FOR **MODEL** 17.5RDJF-18R **SPEC** 15147AA
 FOR STANDARD PARTS REFER TO **CATALOG** 974-0222 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-2730-01 (AC) 612-4814-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Engine Coolant Heater			
		Oil Base Heater			
		Overspeed Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2019	1	Panel, Control - Upper			
338-0936	1	Harness, Wiring - Voltage Regulator To Running Time Meter			
338-0768	1	Harness, Wiring - Overspeed			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-5DR SPEC 15180AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4842-01 (AC)612-4818-08

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Muffler Mounted On Housing					
Overspeed Cut Off					
Low Oil Pressure Cut Off - Dual Senders					
High Water Temperature Cut Off - Dual Senders					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
309-0178	1	Switch, High Water Temperature Alarm			
110-1282	1	Bolt, Low Engine Temperature Switch			
309-0064	1	Switch, Low Oil Pressure Cut Off			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
307-0848	1	Relay, Oil Pressure - Time Delay 15 Seconds			
332-1006	1	Strip, Marker (20 Place)			
307-0819	3	Relay, Pre-Alarm - Low Oil Pressure & High Water Temperature, & Low Engine Temperature			
301-2393	1	Bracket, Mounting			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0943	2	Spacer			
332-0611	2	Block, Terminal (3 Place)			
332-0612	1	Strip, Marker (3 Place)			
405-1889	1	Shield, Rain - Muffler			

SPECIAL PARTS LIST FOR MODEL 15.0RDJF-4R50 SPEC 15193AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4873-01(AC)612-4816-12

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Note: Pennsylvania Approved Engine Coolant Heater Oil Base Heater					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
201-2158	1	Rotor Assembly - Wound			
220-2043	1	Stator, Wound			
520-0790	1	Stud, Rotor Through			
520-0798	4	Stud, Generator Through			
332-0943	2	Spacer			
301-2204	1	Panel, Control - Upper			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-3R SPEC 15193AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG)612-2730-01(AC)612-4815-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Engine Coolant Heater					
Oil Base Heater					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2288	1	Panel, Control - Upper			

SPECIAL PARTS LIST FOR MODEL 17.5RDJE-5DR SPEC 15266AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4880-01(AC)612-4818-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Engine Coolant Heater					
Oil Base Heater					
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
110-1282	1	Bolt, Low Engine Temperature Switch			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
307-0819	1	Relay, Pre-Alarm - Low Engine Temperature			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0943	2	Spacer			
332-0611	1	Block, Terminal (3 Place)			
320-0259	1	Relay, Cranking Limiter			
332-1006	1	Strip, Marker (20 Place)			
405-1157	1	Flange, Air Duct Adapter			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-3CR SPEC 15303AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-2730-01(AC) 612-4814-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Muffler Mounted On Housing					
Mounted Fuel Tank					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2019	1	Panel, Control - Upper			
338-0936	1	Harness, Wiring - Voltage			
		Regulator To Running Time			
		Meter			
405-1889	1	Shield, Rain - Muffler			
405-1157	1	Flange, Air Duct Adapter			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-18R SPEC 15303AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-2730-01 (AC) 612-4814-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Muffler Mounted On Housing					
Mounted Fuel Tank					
140-1194	1	Cover, Air Cleaner			
154-0840	1	Manifold, Intake			
232-0200	1	Washer, Rotor Through			
301-2019	1	Panel, Control - Upper			
338-0936	1	Harness, Wiring - Voltage			
		Regulator To Running Time			
		Meter			
405-1889	1	Shield, Rain - Muffler			
405-1157	1	Flange, Air Duct Adapter			

SPECIAL PARTS LIST FOR **MODEL** 17.5RDJF-18R **SPEC** 15313AA
 FOR STANDARD PARTS REFER TO **CATALOG** 974-0222 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4445-01 (AC)612-4814-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Engine Coolant Heater					
Oil Base Heater					
Overspeed Cut Off					
Low Oil Pressure Cut Off - Dual Senders					
High Water Temperature Cut Off - Dual Senders					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
309-0178	1	Switch, High Water Temperature Alarm			
309-0064	1	Switch, Low Oil Pressure Cut Off			
301-2019	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
338-0936	1	Harness, Wiring - Voltage Regulator To Running Time Meter			
320-0259	1	Relay, Cranking Limiter			
307-0848	1	Relay, Oil Pressure - Time Delay 15 Seconds			
332-1006	1	Strip, Marker (20 Place)			
307-0819	2	Relay, Pre-Alarm - Low Oil Pressure & High Water Temperature			
301-2393	1	Bracket, Mounting			
332-0943	2	Spacer			
332-0611	1	Block, Terminal (3 Place)			

SPECIAL PARTS LIST FOR MODEL 14.5R JF-57R SPEC 15370AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 612-2730-01 (AC) 612-4922-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2308	1	Panel, Control - Upper			
302-0612	1	Voltmeter, AC - 0-500 Volt			

SPECIAL PARTS LIST FOR **MODEL** 17.5RDJE-5DR **SPEC** 15374AA
 FOR STANDARD PARTS REFER TO **CATALOG** 974-0222 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-5036-01 (AC) 612-4818-08

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit Muffler Mounted On Housing Engine Coolant Heater Oil Base Heater Overspeed Cut Off Low Oil Pressure Cut Off - Dual Senders High Water Temperature Cut Off - Dual Senders Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
309-0178	1	Switch, High Water Temperature Alarm			
110-1282	1	Bolt, Low Engine Temperature Switch			
309-0064	1	Switch, Low Oil Pressure Cut Off			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
307-0848	1	Relay, Oil Pressure - Time Delay 15 Seconds			
307-0819	3	Relay, Pre-Alarm - Low Oil Pressure & High Water Temperature, & Low Engine Temperature			
301-2393	1	Bracket, Mounting			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0612	2	Strip, Marker (3 Place)			
332-0943	4	Spacer			
332-0611	3	Block, Terminal (3 Place)			
405-1889	1	Shield, Rain - Muffler			

SPECIAL PARTS LIST FOR **MODEL** 17.5RDJF-18R **SPEC** 15403AA
 FOR STANDARD PARTS REFER TO **CATALOG** 974-0222 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-2730-01 (AC) 612-4814-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Muffler Mounted On Housing			
		Engine Coolant Heater			
		Oil Base Heater			
		Overspeed Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2019	1	Panel, Control - Upper			
201-2160	1	Rotor Assembly, Wound			
220-2045	1	Stator, Wound			
520-0792	1	Stud, Rotor Through			
520-0800	4	Stud, Generator Through			
338-0936	1	Harness, Wiring - Voltage Regulator To Running Time Meter			
338-0768	1	Harness, Wiring - Overspeed			
405-1889	1	Shield, Rain - Muffler			

SPECIAL PARTS LIST FOR **MODEL** 17.5RDJF-4R **SPEC** 15404AA
 FOR STANDARD PARTS REFER TO **CATALOG** 974-0222 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-2730-01(AC)612-4816-08

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Muffler Mounted On Housing					
Mounted Fuel Tank					
Engine Coolant Heater					
Oil Base Heater					
Overspeed Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
405-1889	1	Shield, Rain - Muffler			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-3R SPEC 15404AB
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5488-01(AC)612-5486-08

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Muffler Mounted On Housing					
Engine Coolant Heater					
Mounted Fuel Tank					
Oil Base Heater					
Overspeed Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2288	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-1043	1	Jumper			
405-1889	1	Shield, Rain - Muffler			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-5DR SPEC 15467AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG)612-5036-01(AC)612-4818-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Engine Coolant Heater					
Oil Base Heater					
Overspeed Cut Off					
Low Oil Pressure Cut Off - Dual Senders					
High Water Temperature Cut Off - Dual Senders					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
309-0178	1	Switch, High Water Temperature Alarm			
110-1282	1	Bolt, Low Engine Temperature Switch			
309-0064	1	Switch, Low Oil Pressure Cut Off			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
307-0848	1	Relay, Oil Pressure - Time Delay 15 Seconds			
307-0819	3	Relay, Pre-Alarm - Low Oil Pressure & High Water Temperature, & Low Engine Temperature			
301-2393	1	Bracket, Mounting			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0612	1	Strip, Marker (3 Place)			
332-0943	2	Spacer			
332-0611	3	Block, Terminal (3 Place)			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-18R SPEC 15469AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-2730-01(AC)612-4814-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Muffler Mounted On Housing					
Engine Coolant Heater					
Oil Base Heater					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
201-2160	1	Rotor Assembly, Wound			
220-2045	1	Stator, Wound			
520-0792	1	Stud, Rotor Through			
520-0800	4	Stud, Generator Through			
301-2019	1	Panel, Control - Upper			
338-0936	1	Harness, Wiring - Voltage Regulator To Running Time Meter			
405-1889	1	Shield, Rain - Muffler			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4R SPEC 15470AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-2749-01 (AC) 612-4816-08

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Muffler Mounted On Housing					
Engine Coolant Heater					
Mounted Fuel Tank					
Oil Base Heater					
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2204	1	Panel, Control - Upper			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-0795	1	Block, Terminal (16 Terminal)			
332-0862	1	Strip, Marker (Use With 332-0795)			
338-0768	1	Harness, Wiring - Overspeed			
405-1889	1	Shield, Rain - Muffler			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-18R SPEC 15492AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-2730-01(AC) 612-4814-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Muffler Mounted On Housing					
Engine Coolant Heater					
Oil Base Heater					
Voltage Regulator Filter					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2019	1	Panel, Control - Upper			
338-0936	1	Harness, Wiring - Voltage Regulator To Running Time Meter			
405-1889	1	Shield, Rain - Muffler			
		Voltage Regulator Filter Assembly - Consists Of Following: (Parts Marked With *)			
232-2589	1	Regulator Filter Package - Complete			
232-2462	1	*Box, Mounting			
232-2463	1	*Cover, Mounting Box			
312-0197	1	*Capacitor			
312-0198	2	*Bracket, Capacitor Mounting			
508-0071	1	*Grommet, Rubber - 7/8" Hole			
304-0120	2	*Resistor, Fixed - 2 Ohm, 25 Watts			
304-0015	4	*Washer, Resistor Centering			
304-0292	2	*Insulator, Resistor			
813-0112	2	*Screw - RHM (10-32 X 2-1/2") Resistor Mounting			
338-1165	1	*Harness, Wiring			
625-1304	-	Wiring Diagram			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-3R SPEC 15536AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4842-01(AC)612-4815-08

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Overspeed Cut Off					
Low Oil Pressure Cut Off - Dual Senders					
High Water Temperature Cut Off - Dual Senders					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
309-0178	1	Switch, High Water Temperature Alarm			
110-1282	1	Bolt, Low Engine Temperature Switch			
309-0064	1	Switch, Low Oil Pressure Cut Off			
301-2288	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
307-0848	1	Relay, Oil Pressure - Time Delay 15 Seconds			
332-1006	1	Strip, Marker (20 Place)			
307-0819	3	Relay, Pre-Alarm - Low Oil Pressure & High Water Temperature, & Low Engine Temperature			
301-2393	1	Bracket, Mounting			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0943	2	Spacer			
332-0611	2	Block, Terminal (3 Place)			
332-0612	1	Strip, Marker (3 Place)			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-5DR SPEC 15536AB
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5505-01(AC)612-5502-08

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Overspeed Cut Off					
Low Oil Pressure Cut Off - Dual Senders					
High Water Temperature Cut Off - Dual Senders					
Overcrank Cut Off					
154-0840	1	Manifold, intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
309-0178	1	Switch, High Water Temperature Alarm			
110-1282	1	Bolt, Low Engine Temperature Switch			
309-0064	1	Switch, Low Oil Pressure Cut Off			
502-0058	1	Tee, Street Pipe - Oil Filter Adapter			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
307-0848	1	Relay, Oil Pressure - Time Delay 15 Seconds			
332-1006	1	Strip, Marker (20 Place)			
307-0819	3	Relay, Pre-Alarm - Low Oil Pressure & High Water Temperature, & Low Engine Temperature			
301-2393	1	Bracket, Mounting			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0612	1	Strip, Marker (3 Place)			
332-0943	2	Spacer			
332-0611	2	Block, Terminal (3 Place)			
332-1043	1	Jumper			
307-0778	3	Spring, Hold-Down			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-3R SPEC 15551AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4445-01(AC)612-4815-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off - Dual Senders			
		High Water Temperature Cut Off - Dual Senders			
		Overcrank Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
309-0178	1	Switch, High Water Temperature Alarm			
309-0064	1	Switch, Low Oil Pressure Cut Off			
301-2288	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
307-0848	1	Relay, Oil Pressure - Time Delay 15 Seconds			
332-1006	1	Strip, Marker (20 Place)			
307-0819	2	Relay, Pre-Alarm - Low Oil Pressure & High Water Temperature			
301-2393	1	Bracket, Mounting			
332-0943	2	Spacer			
332-0611	1	Block, Terminal (3 Place)			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-3R SPEC 15561AB
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5505-01 (AC)612-5486-13

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off - Dual Senders			
		High Water Temperature Cut Off - Dual Senders			
		Overcrank Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
309-0178	1	Switch, High Water Temperature Alarm			
110-1282	1	Bolt, Low Engine Temperature Switch			
309-0064	1	Switch, Low Oil Pressure Cut Off			
502-0058	1	Tee, Street Pipe - Oil Filter Adapter			
301-2288	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
307-0848	1	Relay, Oil Pressure - Time Delay 15 Seconds			
332-1006	1	Strip, Marker (20 Place)			
307-0819	3	Relay, Pre-Alarm - Low Oil Pressure & High Water Temperature, & Low Engine Temperature			
301-2393	1	Bracket, Mounting			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0612	1	Strip, Marker (3 Place)			
332-0943	2	Spacer			
332-0611	2	Block, Terminal (3 Place)			
332-1043	1	Jumper			
307-0778	3	Spring, Hold-Down			
405-1157	1	Flange, Air Duct Adapter			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4R SPEC 15568AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4842-01 (AC) 612-4816-18

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit Engine Coolant Heater Oil Base Heater Overspeed Cut Off Low Oil Pressure Cut Off - Dual Senders High Water Temperature Cut Off - Dual Senders Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
309-0178	1	Switch, High Water Temperature Alarm			
110-1282	1	Bolt, Low Engine Temperature Switch			
309-0064	1	Switch, Low Oil Pressure Cut Off			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
307-0848	1	Relay, Oil Pressure - Time Delay 15 Seconds			
332-1006	1	Strip, Marker (20 Place)			
307-0819	3	Relay, Pre-Alarm - Low Oil Pressure & High Water Temperature, & Low Engine Temperature			
301-2393	1	Bracket, Mounting			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0612	1	Strip, Marker (3 Place)			
332-0943	2	Spacer			
332-0611	2	Block, Terminal (3 Place)			

SPECIAL PARTS LIST FOR MODEL 14.5RDJF-57R SPEC 15592AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-2730-01(AC)612-4922-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Mounted Fuel Tank					
Oil Bath Air Cleaner					
154-0840	1	Manifold, Intake			
140-1212	1	Adapter, Air Cleaner			
526-0108	1	Washer, Flat - Steel (17/64" ID X 7/16" OD X 1/32" Thick)			
140-1260	1	Fitting, Safety Filter			
505-0008	1	Plug, Slotted - Zinc Plated (1/8" Dia. X 1/4")			
232-0200	1	Washer, Rotor Through			
301-2308	1	Panel, Control - Upper			
302-0612	1	Meter, Volt - AC 0-500 Volt			
140-1333	1	Bracket, Air Cleaner Mounting			
140-0679	1	Oil Bath Air Cleaner Assembly (Complete) - Includes Parts Marked *			
140-0500	1	*Cleaner, Air - Oil Bath			
140-0519	1	*Band, Air Cleaner			
503-0274	2	*Clamp, Hose			
503-0444	1	*Hose, Air Cleaner			
800-0003	2	*Screw, Cleaner To Bracket (1/4-20 X 1")			
860-0001	2	*Nut, Hex - Cleaner To Bracket (1/4-20)			
850-0040	2	*Washer, Lock (1/4")			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-9XR SPEC 15612AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 612-2749-01(AC) 612-4951-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
220-2287	1	Stator, Wound			
301-2019	1	Panel, Control - Upper			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-0795	1	Block, Terminal (16 Terminal)			
332-0862	1	Strip, Marker - (Use With 332-0795)			
338-0768	1	Harness, Wiring - Overspeed			
338-0936	1	Harness, Wiring - Voltage Regulator To Running Time Meter			
405-1157	1	Flange, Air Duct Adapter			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-18R SPEC 15612AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-2749-01 (AC) 612-4814-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Water Temperature Cut Off			
		Overcrank Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2019	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
338-0936	1	Harness, Wiring - Voltage Regulator To Running Time Meter			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-0795	1	Block, Terminal (16 Terminal)			
332-0862	1	Strip, Marker (Use With 332-0795)			
405-1157	1	Flange, Air Duct Adapter			

SPECIAL PARTS LIST FOR **MODEL** 17.5RDJF-4XR **SPEC** 15727AA
FOR STANDARD PARTS REFER TO CATALOG 974-0222 **KEY NO.** 1
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4842-01 (AC) 612-4817-06

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit Mounted Fuel Tank Oil Base Heater Overspeed Cut Off Engine Coolant Heater Low Oil Pressure Cut Off - Dual Senders High Water Temperature Cut Off - Dual Senders Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
309-0178	1	Switch, High Water Temperature Alarm			
110-1282	1	Bolt, Low Engine Temperature Switch			
309-0064	1	Switch, Low Oil Pressure Cut Off			
301-2308	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
307-0848	1	Relay, Oil Pressure - Time Delay 15 Seconds			
332-1006	1	Strip, Marker (20 Place)			
307-0819	3	Relay, Pre-Alarm - Low Oil Pressure & High Water Temperature, & Low Engine Temperature			
301-2393	1	Bracket, Mounting			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0612	1	Strip, Marker (3 Place)			
332-0943	2	Spacer			
332-0611	2	Block, Terminal (3 Place)			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-3CR SPEC 15734AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4551-01(AC) 612-4814-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Water Temperature Cut Off			
		Overcrank Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
110-1282	1	Bolt, Low Engine Temperature Switch			
301-2019	1	Panel, Control - Upper			
338-0936	1	Harness, Wiring - Voltage Regulator To Running Time Meter			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
332-1006	1	Strip, Marker (20 Place)			
301-2393	1	Bracket, Mounting			
307-0819	1	Relay, Pre-Alarm - Low Engine Temperature			
332-0943	4	Spacer			
300-0673	1	Control, Alarm Relay Assembly			
307-0696	1	Relay, Cycle Cranker - Time Delay 10 Seconds			
307-0734	1	Relay, Cycle Cranker - Time Delay 5 Seconds			
405-1157	1	Flange, Air Duct Adapter			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4XR SPEC 15749AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 612-4880-01 (AC) 612-4817-12

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Engine Coolant Heater					
Oil Base Heater					
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
Muffler Mounted On Housing					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
110-1282	1	Bolt, Low Engine Temperature Switch			
301-2308	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
307-0819	1	Relay, Pre-Alarm - Low Engine Temperature			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0943	2	Spacer			
332-0611	1	Block, Terminal (3 Place)			
320-0259	1	Relay, Cranking Limiter			
332-1006	1	Strip, Marker (20 Place)			
405-1889	1	Shield, Rain - Muffler			

SPECIAL PARTS LIST FOR **MODEL** 17.5RDJE-4XR **SPEC** 15749AB
 FOR STANDARD PARTS REFER TO **CATALOG** 974-0222 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-5516-01(AC)612-5501-12

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Engine Coolant Heater					
Oil Base Heater					
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
110-1282	1	Bolt, Low Engine Temperature Switch			
301-2308	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
307-0819	1	Relay, Pre-Alarm - Low Engine Temperature			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
332-0943	2	Spacer			
332-0611	1	Block, Terminal (3 Place)			
320-0259	1	Relay, Cranking Limiter			
332-1006	1	Strip, Marker (20 Place)			
332-1043	1	Jumper			
307-0778	1	Spring, Hold-Down			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
405-1889	1	Shield, Rain - Muffler			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-3R SPEC 15787AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-2730-01 (AC) 612-4815-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
City Water Cooled			416-0502	1	*Frame Battery Hold-Down
Water Cooled Manifold			416-0133	1	*Cable Assembly, Battery
Skid & Battery Rack			520-0490	2	*Stud, Battery Hold-Down
154-0840	1	Manifold, Intake	850-0045	2	*Lockwasher (5/16")
140-1194	1	Cover, Air Cleaner	862-0015	6	*Nut, Hex (5/16-18)
517-0059	1	Plug, Expansion - Exhaust	526-0115	2	*Washer, Flat (5/16")
		Manifold (Brass 1-7/16" OD)	505-0002	2	*Nipple, Oil Drain
502-0097	1	Connector, Inverted Male -	504-0011	1	*Valve, Oil Drain
		Exhaust Manifold (By-Pass	503-0197	1	*Clamp, Hose
		Line) (Brass)	503-0316	1	*Hose, Oil Drain
502-0245	1	Tee, Inverted Flared -	416-0037	2	*Cable, Battery
		Manifold (Brass	336-0476	1	*Strap, Ground
		1-7/8" X 7/8")			
103-0228	1	Backplate, Gearcase			
306-0195	1	Plate, Relay Mounting			
		(3-1/4" X 3-1/4")			
503-0478	1	Hose, Water Inlet (9" Long)			
232-0200	1	Washer, Rotor Through			
301-2288	1	Panel, Control - Upper			
416-0522	1	Plate, Battery Mounting			
403-0792	1	Skid Base Assembly (Complete)			
		Includes Parts Marked *			
403-0661	1	*Skid			
402-0285	2	*Mount, Rubber - Engine			
402-0286	2	*Mount, Rubber - Generator			
402-0327	1	*Mounting Hardware			
		(Includes Parts Marked +)			
526-0199	1	+Washer (Notched) - Generator			
		End 29/64" ID X 3-1/4" OD			
		X 1/8"			
800-0082	4	+Capscrew, Hex Head			
		(7/16-14 X 3-3/4" Long)			
526-0195	3	+Washer, Flat			
		(3-1/4" X 29/64 X 1/8")			
402-0290	4	+Bushing, Spacer Mount			
402-0282	4	+Snubber, Shock Mounting			
526-0014	4	+Washer, Flat			
		(1-1/2" X 29/64 X 1/8")			
850-0055	4	+Washer, Lock (7/16")			
862-0004	4	+Nut, Hex (7/16-14)			
526-0198	8	+Washer, Flat			
		(1-1/2" X 5/8 X 1/16")			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4R SPEC 15787AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-2730-01 (AC) 612-4816-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
City Water Cooled			416-0502	1	*Frame Battery Hold-Down
Water Cooled Manifold			416-0133	1	*Cable Assembly, Battery
Skid & Battery Rack			520-0490	2	*Stud, Battery Hold-Down
154-0840	1	Manifold, Intake	850-0045	2	*Lockwasher (5/16")
140-1194	1	Cover, Air Cleaner	862-0015	6	*Nut, Hex (5/16-18)
517-0059	1	Plug, Expansion - Exhaust	526-0115	2	*Washer, Flat (5/16")
		Manifold (Brass 1-7/16" OD)	505-0002	2	*Nipple, Oil Drain
502-0097	1	Connector, Inverted Male -	504-0011	1	*Valve, Oil Drain
		Exhaust Manifold (By-Pass	503-0197	1	*Clamp, Hose
		Line) (Brass)	503-0316	1	*Hose, Oil Drain
502-0245	1	Tee, Inverted Flared -	416-0037	2	*Cable, Battery
		Manifold (Brass	336-0476	1	*Strap, Ground
		1-7/8" X 7/8")			
103-0228	1	Backplate, Gearcase			
306-0195	1	Plate, Relay Mounting			
		(3-1/4" X 3-1/4")			
503-0478	1	Hose, Water Inlet (9" Long)			
232-0200	1	Washer, Rotor Through			
301-2204	1	Panel, Control - Upper			
416-0522	1	Plate, Battery Mounting			
403-0792	1	Skid Base Assembly (Complete)			
		Includes Parts Marked *			
403-0661	1	*Skid			
402-0285	2	*Mount, Rubber - Engine			
402-0286	2	*Mount, Rubber - Generator			
402-0327	1	*Mounting Hardware			
		(Includes Parts Marked +)			
526-0199	1	+Washer (Notched) - Generator			
		End 29/64" ID X 3-1/4" OD			
		X 1/8"			
800-0082	4	+Capscrew, Hex Head			
		7/16-14 X 3-3/4" Long			
526-0195	3	+Washer, Flat			
		(3-1/4" X 29/64 X 1/8")			
402-0290	4	+Bushing, Spacer Mount			
402-0282	4	+Snubber, Shock Mounting			
526-0014	4	+Washer, Flat			
		(1-1/2" X 29/64 X 1/8")			
850-0055	4	+Washer, Lock (7/16")			
862-0004	4	+Nut, Hex (7/16-14)			
526-0198	8	+Washer, Flat			
		(1-1/2" X 5/8" X 1/16")			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4R SPEC 15790AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4880-01(AC)612-4816-08

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
Muffler Mounted On Housing					
Mounted Fuel Tank					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
110-1282	1	Bolt, Low Engine Temperature Switch			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
307-0819	1	Relay, Pre-Alarm - Low Engine Temperature			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0943	2	Spacer			
332-0611	1	Block, Terminal (3 Place)			
320-0259	1	Relay, Cranking Limiter			
332-1006	1	Strip, Marker (20 Place)			
405-1889	1	Shield, Rain - Muffler			

SPECIAL PARTS LIST FOR **MODEL** 17.5RDJF-3CR **SPEC** 15825AA
 FOR STANDARD PARTS REFER TO **CATALOG** 974-0222 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-2749-01(AC)612-5078-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-3862	1	Panel, Control - Upper			
338-0936	1	Harness, Wiring - Voltage Regulator To Running Time Meter			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-0795	1	Block, Terminal (16 Terminal)			
332-0862	1	Strip, Marker - (Use With 332-0795)			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4XR SPEC 15856AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 612-2749-01 (AC) 612-4817-12

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Housed Unit			
		Muffler Mounted On Housing			
		Engine Coolant Heater			
		Mounted Fuel Tank			
		Overspeed Cut Off			
		Low Oil Pressure Cut Off			
		High Water Temperature Cut Off			
		Overcrank Cut Off			
		Oil Base Heater			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2308	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
332-0943	2	Spacer			
332-0795	1	Block, Terminal (16 Terminal)			
332-0862	1	Strip, Marker (Use With 332-0795 Block)			
405-1889	1	Shield, Rain - Muffler			

WIRING DIAGRAM NO. (ENG)612-2730-01(AC)612-5083-03

— 1 . 1

SPECIAL PARTS LIST FOR MODEL 14.5RDJF-55DR SPEC 15935AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4842-01 (AC) 612-4818-05

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		Overspeed Cut Off			
		Low Oil Pressure Cut Off - Dual Senders			
		High Water Temperature Cut Off - Dual Senders			
		Overcrank Cut Off			
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
309-0178	1	Switch, High Water Temperature Alarm			
110-1282	1	Bolt, Low Engine Temperature Switch			
309-0064	1	Switch, Low Oil Pressure Cut Off			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
307-0848	1	Relay, Oil Pressure - Time Delay 15 Seconds			
332-1006	1	Strip, Marker (20 Place)			
307-0819	3	Relay, Pre-Alarm - Low Oil Pressure & High Water Temperature, & Low Engine Temperature			
301-2393	1	Bracket, Mounting			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0943	2	Spacer			
332-0611	2	Block, Terminal (3 Place)			
332-0612	1	Strip, Marker (3 Place)			
150-1046	1	Switch Assembly, Overspeed			

SPECIAL PARTS LIST FOR **MODEL** 15.ORDJF-4R50 **SPEC** 15935AA
FOR STANDARD PARTS REFER TO CATALOG 974-0222 **KEY NO.** 1
(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
WIRING DIAGRAM NO. (ENG)612-4875-01(AC)612-4816-02

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Note: Pennsylvania Approved Overspeed Cut Off Low Oil Pressure Cut Off - Dual Senders High Water Temperature Cut Off - Dual Senders Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
309-0178	1	Switch, High Water Temperature Alarm			
110-1282	1	Bolt, Low Engine Temperature Switch			
309-0064	1	Switch, Low Oil Pressure Cut Off			
201-2158	1	Rotor Assembly, Wound			
220-2043	1	Stator, Wound			
520-0790	1	Stud, Rotor Through			
520-0798	4	Stud, Generator Through			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
307-0848	1	Relay, Oil Pressure - Time Delay 15 Seconds			
332-1006	1	Strip, Marker (20 Place)			
307-0819	3	Relay, Pre-Alarm - Low Oil Pressure & High Water Temperature, & Low Engine Temperature			
301-2393	1	Bracket, Mounting			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0612	1	Strip, Marker (3 Place)			
332-0943	2	Spacer			
332-0611	2	Block, Terminal (3 Place)			

SPECIAL PARTS LIST FOR **MODEL** 17.5RDJF-4XR **SPEC** 15935AA
 FOR STANDARD PARTS REFER TO **CATALOG** 974-0222 **KEY NO.** 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG)612-4842-01 (AC)612-4817-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Overspeed Cut Off					
Low Oil Pressure Cut Off - Dual Senders					
High Water Temperature Cut Off - Dual Senders					
Overcrank Cut Off					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
309-0178	1	Switch, High Water Temperature Alarm			
110-1282	1	Bolt, Low Engine Temperature Switch			
309-0064	1	Switch, Low Oil Pressure Cut Off			
301-2308	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
307-0848	1	Relay, Oil Pressure - Time Delay 15 Seconds			
332-1006	1	Strip, Marker (20 Place)			
307-0819	3	Relay, Pre-Alarm - Low Oil Pressure & High Water Temperature, & Low Engine Temperature			
301-2393	1	Bracket, Mounting			
301-3252	1	Bracket, Relay			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
307-1157	1	Spring, Relay Hold-Down			
332-0943	2	Spacer			
332-0611	2	Block, Terminal (3 Place)			
332-0612	1	Strip, Marker (3 Place)			

SPECIAL PARTS LIST FOR MODEL 14.5RDJF-54R SPEC 15944AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG) 612-4902-01(AC) 612-4816-15

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Engine Coolant Heater					
Oil Base Heater					
154-0840	1	Manifold, Intake			
140-1194	1	Cover, Air Cleaner			
232-0200	1	Washer, Rotor Through			
301-2204	1	Panel, Control - Upper			
332-0943	2	Spacer			
307-1149	1	Relay, Limits Number Of Cranking Periods - Time Delay 1 To 300 Seconds On Energization			
307-0696	1	Relay, Time Delay - 10 Second			
307-0734	1	Relay, Time Delay - 5 Second			
332-0795	1	Block, Terminal (16 Place)			
332-0862	1	Strip, Marker (For 16 Place Block)			
301-2393	1	Bracket, Relay Mounting			
405-1157	1	Flange, Air Duct Adapter			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-4R SPEC 15971AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 2
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)
 WIRING DIAGRAM NO. (ENG)612-2730-01(AC)612-4816-03

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
City Water Cooled			416-0502	1	*Frame Battery Hold-Down
Water Cooled Manifold			416-0133	1	*Cable Assembly, Battery
Skid & Battery Rack			520-0490	2	*Stud, Battery Hold-Down
Overspeed Cut Off			850-0045	2	*Lockwasher (5/16")
154-0840	1	Manifold, Intake	862-0015	6	*Nut, Hex (5/16-18)
140-1194	1	Cover, Air Cleaner	526-0115	2	*Washer, Flat (5/16")
517-0059	1	Plug, Expansion - Exhaust Manifold (Brass 1-7/16" OD)	505-0002	2	*Nipple, Oil Drain
502-0097	1	Connector, Inverted Male - Exhaust Manifold (By-Pass Line) (Brass)	504-0011	1	*Valve, Oil Drain
502-0245	1	Tee, Inverted Flared - Manifold (Brass 1-7/8" X 7/8")	503-0197	1	*Clamp, Hose
103-0228	1	Backplate, Gearcase	503-0316	1	*Hose, Oil Drain
306-0195	1	Plate, Relay Mounting (3-1/4" X 3-1/4")	416-0037	2	*Cable, Battery
503-0478	1	Hose, Water Inlet (9" Long)	336-0476	1	*Strap, Ground
232-0200	1	Washer, Rotor Through			
301-2204	1	Panel, Control - Upper			
338-0768	1	Harness, Wiring - Overspeed			
416-0522	1	Plate, Battery Mounting			
403-0792	1	Skid Base Assembly (Complete) Includes Parts Marked *			
403-0661	1	*Skid			
402-0285	2	*Mount, Rubber - Engine			
402-0286	2	*Mount, Rubber - Generator			
402-0327	1	*Mounting Hardware (Includes Parts Marked +)			
526-0199	1	+Washer (Notched) - Generator End 29/64" ID X 3-1/4" OD X 1/8"			
800-0082	4	+Capscrew, Hex Head 7/16-14 X 3-3/4" Long			
526-0195	3	+Washer, Flat (3-1/4" X 29/64 X 1/8")			
402-0290	4	+Bushing, Spacer Mount			
402-0282	4	+Snubber, Shock Mounting			
526-0014	4	+Washer, Flat (1-1/2" X 29/64 X 1/8")			
850-0055	4	+Washer, Lock (7/16")			
862-0004	4	+Nut, Hex (7/16-14)			
526-0198	8	+Washer, Flat (1-1/2" X 5/8 X 1/16")			

SPECIAL PARTS LIST FOR MODEL 17.5RDJF-18R SPEC 15974AA
 FOR STANDARD PARTS REFER TO CATALOG 974-0222 KEY NO. 1
 (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. (ENG) 612-4880-01 (AC) 612-4814-04

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Housed Unit					
Overspeed Cut Off					
Low Oil Pressure Cut Off					
High Water Temperature Cut Off					
Overcrank Cut Off					
154-0840	1	Manifold, intake			
140-1212	1	Adapter, Air Cleaner			
526-0108	1	Washer, Flat - Steel (17/64" ID X 7/16" OD X 1/32" Thick)			
140-1260	1	Fitting, Safety Filter			
505-0008	1	Plug, Slotted - Zinc Plated (1/8" Dia. X 1/4")			
232-0200	1	Washer, Rotor Through			
110-1282	1	Bolt, Low Engine Temperature Switch			
301-2019	1	Panel, Control - Upper			
338-0936	1	Harness, Wiring - Voltage Regulator To Running Time Meter			
338-0768	1	Harness, Wiring - Overspeed			
320-0259	1	Relay, Cranking Limiter			
332-1006	1	Strip, Marker (20 Place)			
307-0819	1	Relay, Pre-Alarm - Low Engine Temperature			
332-0943	2	Spacer			
307-1143	1	Relay, Generating			
323-0760	1	Socket			
332-0611	1	Block, Terminal (3 Place)			
301-3252	1	Bracket, Relay Mounting			
307-1157	1	Spring, Relay Hold-Down			
140-1297	1	Air Cleaner & Mounting Bracket Assembly (Complete) Includes Parts Marked *			
140-0721	1	*Air Cleaner, Contractor Type Consists Of Following: (Parts Marked **)			
140-0765	1	**Element, Air Cleaner			
140-1267	1	**Baffle Assembly			
140-0722	2	*Clamp, Air Cleaner			
503-0274	1	*Clamp, Hose			
503-0419	1	*Elbow, Molded Rubber			
140-1271	1	*Bracket, Air Cleaner Mounting			
140-0723	1	Pre-Cleaner Assembly			
140-0740	1	Tube, Air Intake			
503-0571	1	Hose, Radiator (2" ID X 2-3/8" OD X 2" Long)			
503-0365	3	Clamp, Hose			