
The following catalog has gaps in its page numbers, or doesn't have any numbers. We have chosen to leave the page numbering in the order that Acrobat assigns it.



Onan

Parts Manual

CCKB Engines





The following catalog has gaps in its page numbers, or doesn't have any numbers. We have chosen to leave the page numbering in the order that Acrobat assigns it.



THIS <u>LEGACY</u> DOCUMENT CONTAINS SOME IMAGES THAT ARE OF POOR QUALITY. THE SEARCH FEATURE WILL BE OF LIMITED USE WITH THIS DOCUMENT. THE DOCUMENT CAN BE PRINTED OR YOU CAN LOCATE THE MODEL AND SPEC IN THE INDEX TO FIND THE ALPHANUMERIC PAGE NUMBER.



SPECIAL PARTS LIST FOR MODEL FOR STANDARD PARTS REFER TO CATALOG KEY NO. 927-0404 OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED. PART NO. OTY DESCRIPTION DESCRIPTION PART NO. OTY. Option - 13 Control (Engine) 110-1283 Cover, Timing Control 105-0234 Camshaft (Includes Center Pin And Spark Advance Mechanism Pins) 150-0075 Pin, Camshaft Center 1 516-0146 2 Pin, Groove - Spark Advance 160-0791 1 Cam, Timing Control 160-0789 2 Weight Assembly, Spark Advance (Includes Pins) 518-0185 Ring, Retaining - Spark Advance Groove Pins 160-0726 Retainer, Weight Assembly -Spark Advance 160-0727 Spring, Spark Advance 102-0791 1 Base, Oil 160-0752 Stator Assembly, Magneto (Includes Parts Marked *) 160-0750 *Coil, Magneto Stator 160-0749 1 *Pole Shoe, Magneto Stator 508-0095 Groftmet, Rubber - Spark Plug ~ Cables 167-0188 Clip, Spark Plug Cables 160-0948 Flywheel (Includes Ring Gear) 134-0673 Gear, Ring - Flywheel

150-0147

149-1393

153-0327

518-0176

154-0951

154-0998

505-0329

154-0973

192-0308

192-0296

502-0020

301-0203

508-0084

134-2998

517-0021

301-4467

308-0068

338-0565

1

1

1

1

Stud, Governor Speed

Bracket, Choke Cable

Clip, Choke Cable To Bracket

Cap, Pipe - Exhaust Muffler

Elbow, Street - Oil Line To Cylinder Block (1/8") Line, Oil - Cylinder Block

Grommet, Rubber - Oil Line Through Blower Housing

Gasket, Exhaust Manifold

Backplate, Rope Sheave

(1-1/4'' Hole)

1 Plug, Dot Button - Blower

Switch, Stop (Toggle) Harness, Wiring - Start

Housing (7/8" Hole)

Bracket, Engine Control

Adjusting.

Manifold, Intake

Manifold, Exhaust

To Oil Gauge

Housing, Blower

Pump, Fuel:

Sheave, Rope

Redistribution or publication of this document by any means, is strictly prohibited.

SPECIA	L PAR	IS LIST FOR MODEL	CGI-M	SPEC _	360 B .í
	기계속 : 이제를 ~~	R STANDARD PARTS REFE		927-0404	KEY NO.
PART NO	OTY.	AL GROUPS IN CATALOG ARE DESCRIPTION	PART NO.	OTY.	DESCRIPTION
		WESCHTIME TO THE PROPERTY OF T			A PESUMPINA
Option -	5	Flywheel Alfernator			
		(Phelon - 15 Ampere)			
Option - 3	1	Gas Carburetor			
110-2942	al dari S Oʻsa re	Minds that I all a			b.
	11	Block Assembly, Cylinder (Refer To Standard Cylin	dor		A
	<u> </u>	Block For Components, Ex		v .	
		Parts/Harked/1)			
110-1827	2	Guide, Valve - Intake			
110-1000	2 4	Insert, Intake Valve Seat			
		(Available In .010 And			
110 100		,025 Oversize)			
110-1037 509-0090		Valve, Intake			\$
× 110-0893	,	Seal, Oil - Intake Valve	and the second second		
323-0853	1	Washer, Valve Spring Retai Body, Alternator Stator	ner		•
		Leads Connector		•	
167-0188	2	Clip, Alternator Stator		· ·	
"	,	Lead Holding			•
134-3019		Plywheel (Includes Ring Ge.	ar)		·
134-0673	. 1	Gear, Ring - Flywheel			
159-1072	1	Line, Fuel - Regulator To			
		Carburetor			
154-0918		Manifold, Intake			
141-0751	4	Carburetor, Gas (Refer To	,		
	***	Optional Carburetor For		· · · · · · · · · · · · · · · · · · ·	
		Components, Except Parts Marked *)			
505-0008	1 *	Plug, Pipe (1/8")			
502-0039		Elbow, Inverted Male -		,	
	•	Carburetor Fuel Inlet			
148-0465		Regulator, Gaseous Fuel			*
_502-0039	1	Elbow, Inverted Male - Fue			
		Regulator Outlet			
505-0099	1	Nipple, Close - Regulator			,
502-0183	1	Vaporizer (1/4" X 7/8")			
207-AT02		Elbow, Male - Vaporizer Fue Inlet	<u>></u> 1		
148-0826	1	Vaporizer			ew. The second second
148-0827		Spacer, Vaporizer Mounting			
148-0756		Bracket, Vaporizer Mounting			
149-0136		Cover, Fuel Pump Hole In			
		Cylinder Block			
م.4					

CASTAN OF THE SECRET OF THE SECRET SECRET OF THE SECRET OF

Hanuffer tured	For:	Mark Industries
Option - 6		Flywheel Alternator
	4	(Syncro - 20 Ampere)
Option - 8		Spin-On Oil Filter
710-1860	1 -	Block Assembly, Cylinder
		(Refer To Standard Cylinder
		Block For Components)
167-0188	2	Clip, Alternator Stator Lead
167-0292	2	Holding Plug, Spark
134-2828	1	Housing, Blower
134-1760	ì	Housing, Cylinder Air - Right
	. 	Side
154-0951	1	Manifold, Intake
153-0223	1	Choke
153-0484	1	Link, Choke To Carburetor
152-0155	1	
155-1472	1	Muffler, Exhaust
505-0618	1.	Cap, Pipe - Exhaust Muffler
154-0973	2	Gasket, Exhaust Muffler

SPECIAL PARTS LIST FOR MODEL 3645J FOR STANDARD PARTS REFER TO CATALOG OFTIGHAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USES. PART NO. DESCRIPTION OTY. DESCRIPTION Manufactured Por: Winter Alternator (Automotive Type, Option - 1 Left Side Mounting) 102-0791 Base, 011 134-0675 Plywheel (Includes Ring Gear) 134-0673 Gear, Ring - Flywheel 150-0635 Bracket, Governor Speed Adjusting 154-0951 1 Manifold, Intake 154-0998 1 Manifold, Exhaust 505-0329 1 Cap, Pipe - Exhaust Manifold 154-0973 Gasket, Exhaust Manifold 134-2926 Housing, Blower

SPECIAL PARTS LIST FOR MODEL ______CKB_KS_ SPEC FOR STANDARD PARTS REFER TO CATALOG 927-0404 OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED. PART NO. OTY. DESCRIPTION PART NO. DESCRIPTION Option + 5 Flywheel Alternator (Phelon - 15 Ampere) Option - B Spin-On Oil Filter Option - 15 Gas - Gasoline Fuel System 110-1860 Block Assembly, Cylinder (Refer To Standard Cylinder · Block For Components) 104-0880 Crankshaft. 134 - 3019 Flywheel (Includes Ring Gear) And Rotor) 134-0673 Gear, Ring - Flywheel 150-0635 Bracket, Governor (Rear Pull) 502-0395 2 Connector, Hose - (1) Fuel Pump Outlet, (1) Carburetor Inlet 134-3828 1. Housing, Blower 134~2760 Housing, Cylinder Air - Right Side Redistribution or publication of this document

by any means, is strictly prohibited.

SPECIAL PARTS LIST FOR MODEL GUR-JE SEC BALL FOR STANDARD PARTS REFER TO CATALOG 227-404 KEY NO. _ 2

PART NO.	GTY.	DESCRIPTION	PART NO.	017	DESCRIPTION
Option - 3	i ,	Top Mounting Alternator			
		(Automotive Type)			
Optión - 22		Variable Speed Governor Control		6	
104-0581	1	Crankshaft			
515-0061	20 May 12	Key, Grankshaft S			
510-0015	10	Ball, Fly - Governor			
134-0675	1	Flywheel (Includes Ring			
		Gear And Pulley)			1
134-0673	1	Gear, Ring - Flywheel		The second of th	A A CONTRACTOR OF THE CONTRACT
193-0108	1,	Sender, Oil Pressure			
\$02-0053		Elbow, Street - Oil Pressu		10 4 64 64 64 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
		Sender (45°)			
191-1168	1	'Bracket, Alternator Adjust'	ing		
191-0639	1, 1,	Baffle, Alternator			, de la companya de
511-0090	1	Belt, Alternator Drive			
153-0327		Bracket, Choke Cable			*
548-0176	1	Clip, Choke Cable Bracket	7		
154-1269	1	Manifold, Exhaust			
134-3924	V i 🖢 in	Housing, Blower			
134-1644		Housing, Cylinder Air - Lef		Service Commence	
and an areas	. .	Side			
134-2916	1	Housing, Cylinder Air -			
	ar de la companya de La companya de la co	Right Side			
	1		,		P .



SPECIAL PARTS LIST FOR MODEL CCKB-NS SPEC 3770) FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY N OPTIONAL GROUPS IN CATACOG ARE LISTED BY GROUP NO. BELOW WHEN USED

EART NO	OTY.	DESCRIPTION	PART NO. OTY.	DESCRIPTION
Option - 4		Flywheel Alternator		
operon		(Wico - 20 Ampere)		
Option - 8		Spin-On Oil Filter		
Option -431		Gas Carburetor		
110 _± 2375	1	Block Assembly, Cylinder		
		(Refer To Standard Cylinder		
		Block For Components,	**************************************	
	P	Except Parts Marked *)		
110-1283		*Cover, Timing Hole		
110-1000	2	*Insert, Intake Valve Seat		
		Standard (Available In		
		.002, .00 3 , .010, .025		
		Oversizes)		
509-0123	1	Seal, Oil - Rear Bearing Plate		4
509-0110.	ı	Seal, Dust - Rear Bearing		*
*	1	Plate		
110-1037	4	Valve, Intake		
110-0893	4	Washer, Valve Spring		
149-0136		Plate, Cover (Fuel Pump		
10.00	3 - 3 - 3 - 3 - 3 - 3 - 3 - 3 - 3 - 3 -	Cavity In Cylinder Block)		
103-0617	, ,	Gearcase Assembly (Refer To) Standard Gearcase For	*	A. A.
	• •	Components, Except Parts		
		Marked #)		
200 0126	1	#Seal, Oil - Crankshaft		
509-0126 509-0105	1	#Seal, Dust - Crankshaft		
	. 14. 1 **	Flywheel (Includes Ring Gear)		
134-2556 134-0673	1	Gear, Ring - Flywheel		
134-1889	$\stackrel{\star}{1}$	Guard, Flywheel - Rotating		
502-0039	. j	Elbow, Street - Carburetor		\$ 31
.302-0033	*	Fuel Inlet		
155-0906	/ 1	Muffler, Exhaust		*
505-0329	. 1	Cap, Pipe - Exhaust Muffler		
154-0973	2	Gasket, Exhaust		st .
134-3963	ī.	Housing, Blower		
134-2760	1	Housing, Cylinder Air - Right	*	•
A		Side	y .	
150-0635	. 1	Arm, Governor Pull		•
309-0237	1	Switch, Low Oil Pressure		
515-0230	$\overline{\mathbf{i}}$	Key, Crankshaft Stud		
				s /
<u> </u>	¥*			•



BPESTAL PARTS LIST FOR MODEL GENERAL STATE TO CATALOG 1927 MAG. HEY NO.

PART NO.	OTY .	DESCRIPTION	PART PRO	atr.	DESCRIPTION
			<i>f</i> .		
Option - 5		Flywheel Alternator (Phelon - 15 Ampere)			
Option + 8	i (a) (filo i)	Spin-De Cil Filter			
Option - 22		Variable Speed Governor	a.e.		
writing		Control			
110-3054	1	Block Assembly, Cylinder			
		Hefer To Standard Cylinde	T		
		Block For Components, Exce		d , <u>≥</u> ' _{1,1}	
		Rear Bearing Plate)		wed.	
101+0429		Plate, Bearing Rear			
104-0915	i i	Crankshaft			and the second
150-1073	1	Extension, Gavernor Arm			Ar and a second
153-0464 .	ľ	Bracket, Choke Cable			
153-0351	į	Cable, Choke	•	Α,	
518-0176	` 1	Clip, Choke Cable Bracket			
140-1087	Ļ	Gasket, Air Gleaner Adapter		- N	No.
		4 To Carburetor			*
308-0140	1	Swatch, Start Stor Goggle	h 3		•
332-4051	1	Claps Start - Stoff putter -		•	, •
		Wige Harness'			
134-2984	1.	Housing, Blower			4.
134-2760	1	Housing, Cylinder Air - Righ	nt ,		
		. े को बिंह	•		
0	- 1				
	ς.*		1.	-	

SECIAL PAR	TS LIST FOR MODEL			
	R STANDARD PARTS REFE HAL GROUPS IN CATALOG AND			ICEY NO _ 3
MIT NO. OTY	DESCRIPTION	PART NO	otr.	DESCRIPTION
mnufactured For	The many			
55-0906	Crankshaft Muffler, Exhaust Cap. Pipe - Exhaust Muffl			
54-0973 7	(1-1/2") Casket Exhaust			
				•
			# # # # # # # # # # # # # # # # # # #	
			4	
			A	
			•	

CITI SPEC ECIAL PARTS LIST FOR MODEL POR STANDARD PARTS REFER TO CATALOG 127-0404 CONTINUENT BROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED DESCRIPTION PART NO. OTY. CT DESCRIPTION 134-1556 Cunni. Scroll Outlet AND DESCRIPTION OF THE PARTY OF * Lead Assembly - Sign To 336-1252 - -Spin-On Cil Filter Switteh Taxu-Flo Cooling Groundt, Robber (Y'00) 500-0031 Block Assembly, Cylinder 110-2194 (For Parts Sreakdown See #927-0404 - Cylinder Block) 104-1325 Crankshaft - Kit (Incl. Parts Marked *) * Key. Crankshaft Gest 515-0001 Mounting . * Key, Wheel Hounting 1 515-0098 Seal, Oil - Intake Valve 509-0090 2 (Incl. Retainer Rings) Washer, Spring Retainer 110-0893 Intake, Exhaust Volves Bracket, Timing - Right 166-0519 Line. Flex (Out Top Of Heg). 501-0203 1 Housing Assembly, Blower 134-2796 1 Plug. Spark - Resistor Type 167-0262 Grounet, Rubber (27/32° II) 508-0084 1 X 1 5/8 OD X 1/16" Thk) 517-0035 1 Dot Button, Timing Hole Carburetor, Natural Gas (Kit) 1 141-0912 (Includes Parts Marked X) X Carburetor (For Parts Break-141-0853 1 Down, Use Opt. 31 - Parts Catalog # 927-0404) 1 X Casket, Mounting 141-0281 Manifold, Intake 154-1051 Housing, Cylinder Air - Right 134-2760 1 Hand (With Oil Filter Drain) 122-0445 Pilter, Oil - Spin-On 1 Wheel, Blower 134-0753 Clip, Cable - High Air Temp. 1 518-0178 Cut-Off Manifold, Intake 154-1051 Cap. Pipe - Exhaust Manifold 505-0329 1 $(1\frac{1}{2})^n$ Fitting Assembly - Intake 1 193-0173 Manifold (Incl. Parts Marked +) Plug, Pipe 505-0057 1 +Connector 502-0003 Scroll Assembly With High 134-4033 Temp. Switch (Incl. Parts Marked *) * Switch, High Temp. Cut-Off 309-0002 (Incl. Strap 160-0144)

	000 美国人	TS LIST FOR MODEL GEN-H	
	10年 2001 中かま	R STANDARD PARTS REFER TO	C. CATALOG SEZ ON WINDER VIEW
PART NO.			PART NO OFF DESCRIPTION
E-Th C	so I Luc	and the second consideration and the second contract of the second c	an finish nga arawan a kadami na mangalahin
10 a0-alq	1870		
	\rightarrow		
10-2194		Block Assembly, Cylinder	
	m / -	(For Parts Breakdons See	
		1927-0404 - Cylinder Block)	
04-1325		Crankshaft Kit	
t & Marian t	1	(Technites Farts Marked *)	
15-0001 15-0098		TRey, Crankehaft Gear Mounting	
09-0090	<u>**</u>	*Kmv. White I Monant tous	
namhain	* *	Seal Oil-Intake Valve	
66-0519		(Includes Retainer Rings)	
01°0201	4	Bracket, Timing - Right	
34-2796	* 7	Line, Flex (Out Top Of Heg)	
67-0262		Mousing Assembly, Slover	
08-0084	# 1	Plug. Spark - Resistor Type	
rad articom.		Grounet, Aubber (27/32 ID	
17-0035 /		N 1 5/8 OD N 1/16" Thk) But Button, Timing Hole	
22-0445		Filter, Oil-Spin-On	
34-0753	- 	Wheel, Blower	
18-0178	**	Clip, Cable - High Air Temp.	
TO THE RESERVE	1.	Cut-Off	
54-105T		Manifold, Intake	
05-0329		Cap. Pipe-Exhaust Mankfold	
Waru aka	ah i	(1½")	
53-0927	*	Bracket, Choke	
93-0173	# - #	Fitting Assembly-Intake	
73-01/3	*	Manifold (Includes Parts	
ar ones		Marked +)	
05-0057		Rlug, Pipe	
02-0003	1	+Connector	
34-4033	*	Scroll Assembly With High	The state of the s
		Temperature Switch (Incl.)	
<u>്യ</u> താണ് തെത്തത്		Parts Marked *)	
09-0002	1 ,	Switch, High Temperature	
		Cut-Off (Includes Strap	
na nnes		160-0144)	
34-2956	* *	*Guard, Scroll Outlet *Lead Assembly - High Temp.	
36-1252	.	and the state of the	
00 0001		Switch	
08-0031		*Grommet, Rubber (14"OD)	
•		6	
			And the second comments of the second second
7			
	6 ~		
West Control			
			[10] [10] 14 (14 14 14 14 14 14 14 14 14 14 14 14 14 1
S. Carlos			



propries	TO DESCRIPTION
134-3019	Flywheel (Includes King George)
122-0321 526-0065 600-0020 122-0320 122-0323 122-0347 122-0345 505-0057	Gasket Washer Screw Adapter Filter Filter Spin-On Seal Air Tube Oil Drain Plug Adapter Dutlet
191-1276 l	Alternator Stator 20 App
153-0223	Chake Electric
191-1275 i	Regulator

	FOR	S LIST FOR MODEL STANDARD PARTS	化抗乳 医神经炎 医神经炎 医抗原性 化烷	化二甲基甲基苯甲基苯甲	27.53		4043J KEY NG
		DESCRIPTION					N USED.
					3.1		
OPTION 15:	Use Ca	ystem (Gaseous Fuel) rburetor 141-0890 In -0892 Called Out In	Place	SI			
OPTION 22:	Govern	or Control (Variable	Speed)				
MISCELLANEO	rs (pr	ONS: 155-0906 Muffl \$65-0618 Cap,	Pipe-				
)	Muff1 154-0973 Gaske					
			st Mani-				
		fold					
123-1417	1	Baffle, Breather T	uha			er user	
134-3976	1	Housing, Cylinder-					
141-0890		Carburetor, Gas (I					
ATA VIVIO	*	Mounting Gaskets)		\$		- 2 m	$x \in \mathcal{N}_{n+1} \cup \mathcal{N}_{n+1}$
0		For Breakdown Part					
•		Option 31 With Exc	-1				•
•		of Ref #29 Float S					100
-	Y .	Also Add:			* 22	•	
141-0713	Ĭ.	Needle, Idle-Gas A	djust		· ·		
		Flywheel Alternato	r-20 Amp		• •		1
	÷	(Phelon)					
134-2624	1	Wheel, Blower (Inc	Tudes -			٠.	
		Magnet Ring) 🗅			•	* N	
191-1276	1	Stator (Includes T		2.0			
`		- and Connector Bodi					•
323-1257	2 .	Body, Terminal Con			**	,	
. •	•	Kit (Includes Part	s Marked	•		100	*
	1	*)	ę.	-		•	•
332-2423	3 .	*Terminal, Stator L		•			•
815-0470	3	Screw, Machine - H	. 1		-		
ag project de la come some som	_	-Self-Lock (#10-32					
191-1275	ļ	Regulator, Voltage		•	•	*	
821-0007	1	Screw, Cap-HWH (%-	ZU X %")				
167-0188	1	Clip, Cable	ator		·		
332-2319	1	Clamp, Wire-Altern	a cur			. *	
		Leads `	3	· .	-		
		ed By Onan					1 y 1 2 y

Hose, Regulator To Carburetor Clamp, Hose:
Nipple, Helf (太 X 1½")
Nipple, Regulator Outlet (½ X 7/8")
Plug, Regulator (1/8")
Elbow, Regulator Outlet (½")
Bushing, Regulator Outlet (3/8 X ½")
Vent: Regulator

Generation

Redistribution or publication of this document by any means, is strictly prohibited.

THIS <u>LEGACY</u> DOCUMENT CONTAINS SOME IMAGES THAT ARE OF POOR QUALITY. THE SEARCH FEATURE WILL BE OF LIMITED USE WITH THIS DOCUMENT. THE DOCUMENT CAN BE PRINTED OR YOU CAN LOCATE THE MODEL AND SPEC IN THE INDEX TO FIND THE ALPHANUMERIC PAGE NUMBER.





SPECIAL PARTS LIST FOR MODEL COM-NS

SPEC

IV

FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY NO. OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO. GTY. DESCRIPTION PART NO. GTY. DESCRIPTION

STANDARD MODEL



CCKB-S

SPECIAL PARTS LIST FOR MODEL

FOR STANDARD PARTS REFER TO CATALOG ___927-0404 KEY NO. OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED. PART NO. QTY. DESCRIPTION PART NO. QTY. DESCRIPTION STANDARD



273 #

Group -9 Redi Pull Starter Variable Speed Governor	OPTION	R STANDARD PARTS REFER T IAL GROUPS IN CATALOG ARE LIST	ED'BY GROUP NO. BELOW	. <u> </u>
Group -22 Variable Speed Governor	PART NO QTY.	DESCRIPTION	PART NO. QTY.	DESCRIPTION
332-0329 1 Clip	Group -9 Group -22	Redi Pull Starter Variable Speed Governor		
332-0329 1 Clip				
	332-0329 1	Clip		
				· · · · · · · · · · · · · · · · · · ·

SPECIAL PARTS LIST FOR MODEL

927-0404

FOR STANDARD PARTS REFER TO CATALOG_ OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO. QTY. DESCRIPTION PART NO. QTY. DESCRIPTION

Group -22

Variable Speed Control



900-0043 Supplementary Parts List for

Model CCKB-S	Spec ²⁸	encounterentained finates

Parts Listed Below Apply to the Above Model. Use These Parts in Place of (or in Addition to) the Parts Listed in the Standard Parts Catalog.

	PART NO.	QUAN.	DESCRIPTION
,	and the state of t		NOTE: This model has a Variable Speed Governor.
		1 1	Complete breakdown in Main Parts Catalog.
	110-0915	1	Block Assembly, Cylinder
٠	104-0872 120-0413	1	Crankshaft Intake, Gil Pump
	102-0468 123-0762	1	Base, Oil Cap and Indicator, Oil Fill
	167-1462	î	Lead, Hi Tension (Left Hand)
	. 167-1463 134-2831	1	Lead, Hi Tension (Right Hand) Housing, Blower
	167-0241 140-1302	1	Plug, Spark - Mon Resistor Gasket, Air Cleaner
		1	k '



SPECIAL	. PARTS LI	ST FOR MODEL	CCKB	H	SPEC	3523
la l	FOR STA	NDARD PARTS	REFER TO		927-0404	KEY NO.
PART NO.	GTY.	PESCRIPTION		PART NO	OTY.	DESCRIPTION
* Group -12	Clu	tch, Rockford	0	and the second s	n a mana di salahan kacamatan kacamatan kacamatan kacamatan kacamatan kacamatan kabupatan kacamatan kabupatan k	russakus gamala na jaug gazi kaging i palagangaya 19 palu-du arm adi Amatika teri He
	0	**************************************				
104-0913	l Cra	nk shaft				<u> </u>
	. 60					
•	 , ,		•			•
· · · · · · · · · · · · · · · · · · ·		• •	•			· ·
			÷.	•		
					ä	*
		·	, i	A-4 _		





SPECIAL PARTS LIST FOR MODEL

SPEC

FOR STANDARD PARTS REFER TO CATALOG 927-0404

KEY NO.

DESCRIPTION

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO.

PART NO.	QTY.	DESCRIPTION
Group -3		Top Mounted Alternator
•		
		en e
T10-1418	1	Block Assembly, Cylinder
104-0883	b L	Crankshaft
105-0251	1 .	Camshaft
105-0030		Gear, Camshaft-Timing
135 - VOSB	ì	Plunger, Camshaft
105-0059	1	Spring, Camshaft Plunger.
102-0564	1	Base, Oil
123-0576	3	Cap and Indicator, Oil Fill
133-0368	1	Tube, OH FIH
103-0224	1	Gearchse
501-0027	1	Line, Oil
508-0084	1	Grommet, Rubber
\$17-0009	1	Button, Dot-Blower Housing
134-1644	. 1	Housing, Cylinder Air L/H
134-1645	1	Housing, Cylinder air R/H 🔧
101-0372	41	Adapter, Clutch
134~1719	1	Housing, Blower
153-0327	l	Bracket, Choke Cable 1
518-0176	1	Clip, Choke/Cable
134-1110	-1	Manifold, Exhaust
-5154 - 0975		Gasket, Exhaust Manifold
167-1491	3	Lead, Hi Tension 🧢
104-0102	1	Clutch, Flywheel

Parts not Furnished by Onan:
Governor and Associated Parts
Oil Gauge
Fuel Pump Primer
Starter Control





SPECIAL PARTS LIST FOR MODEL CONT. BEEC 1523H
FOR STANDARD PARTS REFER TO CATALOG 927-0494 KEY NO. 2
OPTIONAL GROUPS IN GATALOS ARE LISTED BY GROUP NO. BELOW WHEN USED.

PORT NO. GTY. DESCRIPTION PART NO. GTY. DESCRIPTION

Option 1: Alternator (Automotive <u>Type - Left Side Mounting)</u> (35 Ampere)

Miseelleneous Options:

185-0906 Muffler
Front Pull Governor

SPECIAL PARTS LIST FOR MODEL

*SPEC

FOR STANDARD PARTS REFER TO CATALOG

KEY NO.

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED

PART NO	OTY.	DESCRIPTION		PART	NO	QTY	DESCRIPT	108
Group -1	Alt	ernator, Left Side Mounte				1(-1)	4	
	• • • • • • • • • • • • • • • • • • • •			1	.K			-
123-0694	į.	Cup and Indicator, Oil		,r				y . ======
125-0674 150-0755 517-0009	\$. 3 4	- Tube. Gil/Fall Arm. Governor-France Phil Button. Dot	1				•	. و
150-0698 501-000	i i	Spring, Governor	7	All Control of the Co	· .		2 3/5 2 3	
155-0900 154-0973	ь В	Muffler, Exhaust Casket, Exhaust Muffler	M*		•			•
505-0618 153-0327		Cap. Tripe (15) // Bracket, Choke	Î			1		•
518-0176 130-0939	(اچ ^و	Clip, Choke Cable Ball, Joing						
520-0263	1	Stud, Governor Adjustin	eng Pa	-				, . -
* **			٠. ا		٠			

Parts not Furnished by Onan. Off Gauge



Power Generation CC#3-140

SPECIAL PARTS LIST FOR MODEL

SPEC

FOR STANDARD PARTS REFER TO CATALOG

KEY NO.

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO BELOW WHEN USED

PART NO.	OTY	DESCRIPTION		PART NO	OTY "	DESCRIPTION
Group 1	To the state of th	Alternator, Left Sid	e Mr.g.		*,	

			Hyp			
sof Man		Start Start				





SPECIAL PARTS LIST FOR MODEL ___

CAR-ME

SPEC 15456

FOR STANDARD PARTS REPER TO CATALOG (ALLEGE)

·KEY NO.

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO BELOW WHEN USED

PART NO	OTY	DESCRIPTION	PART NO GTY	DESCRIPTION
Group -1 Group -13	F	Alternative Left Side Mot. Top Mounted Engine Control		
**************************************		大樓河 城市者 李明楼上江海北桥市公 经订本 医水黄素		
123-00014 SAM-ININA 124-1706	11 14 14	Turbe. All St. 1. Sironnaet. Alluber Biografica C. Alluber		
307-000-2 -359-0410 -338-0411 -307-0365	1 1	Toomsector #5-9-45 Hering Hering Hering Hering		
2000年1月2日 新年時代 本年代 本年 本年代 本年 本年 本年 本年 本年 本年 本年 	*	- Michigan Called Andrew - Michigan Called Andrew - Canal Andrew Charles Andrews Michigan - Canal Alices - De		

SPECIAL PARTS LIST FOR MODEL ______ SPE

FOR STANDARD PARTS REFER TO CATALOG 917-0404

KEY NO

16249

PART NO. OTT.	OESCRIPTION	PART NO 077:	DESCRIPTION
	Variable Speed Governor		
	下面重要明白度值。 与生活并不分		
			•
			19
		•	•



2Q37H

FOR STANDARD PARTS REFER TO CATALOG_ 927-04 OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

KEY NO.

PART NO.	OTY. S	DESCRIPTION	PART NO. QTY. DESCRIPTION
Group -4 Group -1 Group -2	3	Flywheel Alternator (Wico) Top Mounted Engine Control Solenoid Shift Starter	
是文化。 上度系统 表示 集一次度 字形		Block Assembly, Cylinder Crankshaft	
- 113-0075 -123-0076	14. 14. 21. 31.	Piston and Pin Cap and Indicater, Oil Fill Tube, Bil Fill	
		Conresse Flywheel (includes Ring)	
134-2134 医结肠上纤维性		Gearl (**) Houstne Cylinder, Air 8/4 Grommer, Rubber	
23 4 x 20 54 6 23 4 x 20 4 3 7 28 x 10 4 2 3 7 28 x 10 4 2 3	* *	Housing, Flower Monifold, Exhaust Hasket, Exhaust <u>Manifold</u> mt.	
1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1		् आहे. में स्थल केल्फार्क्षक , हाल्किक	
15 16 - 61 17 16 16 16 16 16 16 16 16 16 16 16 16 16	· ₩ •	Slip, Choke Cable Tipp, Status Lead Harness, Wither	
1. 苏格兰高克苏基 3. 叶子:1. 柳叶芳	*	明治教育な物。 本山市 明治教徒。 1351章	*

	and the same of th			
SPECIAL	PARTS	LIST	FOR	MODEL

CCKB-MS

2123H

0	KEY NO. 2 WHEN USED.				
PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Group -4 Group -22		Flywheel Alternator (Wico) Variable Speed Governor			
307-0367 134-1895 103-0333	$\frac{1}{1}$	Solenoid, Start Flywheel (Includes Ring Gear Gearcase			
167-0188 102-0653	1	Clip, Stator Lead Base, Oil			
	# : :			•	
	*		·	•	
,					
e e e e e e e e e e e e e e e e e e e			The state of the s		
	سامان			المراقع الأمار الفرائد والأمار ومستقد مارور والمسا	






				/ ""	•	1.7	4 10 11	-	* * *	
· * * *		•	CCKB-MS			-	1.35		210	2.1
	DEL		LALAD TAL	/	. CD	FC	1 1	-	4. A.V.	. 4
				-	3 -	E	The State of	and the same	deline a construct	mis.

SUPPLEMENTARY PARTS LIST 900-43 (per above model and spec.) Parts listed below apply to the above model. Use these parts in place of (or in addition to) the parts listed for Parts Key $\frac{2}{100}$ in the standard parts catalog No. $\frac{927-404}{100}$

PART NO.	QUAN.	DESCRIPTION
102B653 104D486 110A915 120B648 123A527 134C2020 150A635 150A698 191C511 397A367 336A102 515A202	1 1 1 1 1 1 1 1 1 1	NOTE: Charging Alternator group in main parts catalog applies to this plant. Base, Oil Crankshaft Block Assy., Cylinder - Incl. Bearing Plate, Bearing Guides and Seats Intake, Oil Pump - Incl. Cup, Screen and Pipe Cap and Indicator, Oil Fill Housing, Blower Bracket, Governor Linkage Spring, Governor Motor Assy., Starting Solenoid, Start Lead, Start Solenoid Key, Crankshaft Stub





CDEC

2232H

FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY NO. OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO.	QTY:	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Øno. w	a. v	Spin on Oil Filter		7. 1	
Group - 8 Group -19		High Profile Breaker Box			A
Group -13		Solenoid Shift Starter	•		g
"GIOUP" - 21		Solemoid Shirt Starter		·**	
	e)			<i>(</i>) ()	
N "		<u> </u>		1	•
	# :	50 m			and the second s
and the same of			, , , , , , , , , , , , , , , , , , ,		
110-1957	n " ", "	Block Assembly, Cylinder		***	
104-0883	1	Crankshaft		e di ma	
509-0090	: <u>.</u>	Seal, Valve Stem Oil			
509-0123		Seal, Bearing Plate			
509-0110		Seal, Dust			Äş.
105-0140		Camshaft			
103-0140 114-0145	[+	Bearing, Connecting Rod			
102-0387		Base, Oil		· · · · · · · · · · · · · · · · · · ·	
110-1827		Guides, Intake Valve		May 1	
103-0381	1.	Gearcover		1.	
149-1063		Baffle, Fuel Pump	ţ		
134-2388	1	Flywheel (Includes Ring Gear	Marie Committee	, V	
502-0058	ĺ	Tee, Oil Line			
154-1116	1	Manifold, Intake	3	1	•
150-0639	$\tilde{2}$	Joint, Ball		*	The state of the s
520-0157	Α	Stud, Governor Adjusting			*
134-2258		Housing, Blower	• •	·	<u> </u>
134-2424		Housing, Cylinder Air R/H	· ,		· ·
150-0635	-	Bracket, Governor	•	e . Y	
150-0698	1, 1	Spring, Governor		1	
140-0936		Adapter, Air Cleaner			
154-1024		Manifold, Exhaust	4 4	- Tw.,	
154-0973		Gasket, Exhaust Manifold	. 4		- W
166-0535		Coil, Ignition		-	
167-1532		Lead, Hi Tension	- **	* 7s.	•
167-1551	. "	Lead, Hi Tension	. ય		
334-0028		Lead, Ignition	ì		•
509-0035		"O" Ring			with the second
150-1339		Bracket, Governor	. * चा (* .	
150-1021		Lever, Throttle Control	,	N _a .	
Į.a.	F^{*} by		*		
			м*.)	





MODEL_

DEC 2233H

SUPPLEMENTARY PARTS LIST 900- 43 (per above model and spec.)
Parts listed below apply to the above model. Use these parts in place of (or in addition to) the parts listed for Parts Key 1 in the standard parts catalog No. 927-404

P/	ART NO.	QUAN.	DESCRIPTION	·
10	2-0688	1	Base, Oil	
	4-0486	1	Crankshaft	· .
No. of the second	0-1904	1	Block Assy., Cyl. (Incl. Bearings, Guides	
	0-1304)	& Seats)	
1-2	0-0413	1	Intake, Oil Pump (Incl. Cup, Screen & Pipe)	
	3-0506	1	Cap & Indicator, Oil Fill	
	9-0123	i	Seal, Bearing Plate	
	9-0110	1	Seal, Dust - Bearing Plate	
	9-0110 9-0090	2	Seal, Valve Stem Oil	
	9-0105	1	Seal, Gear Cover - Outer (Dust)	
	9-0103 9-0126	1	Seal, Gear Cover - Inner (011)	
	3-0120	1	The state of the s	
	3-0350	1 2	Gear Cover Assy., - Complete	
		1 "	Ring Set, Piston	
	5-0238		Camshaft (Includes Center Piń)	
	4-0812	1	Flywhee1	
	4-0369	1 1	Screw, Flywheel Mounting	
1	6-0185	1	Washer, Flywheel Mounting Screw	
	0-0698	1	Spring, Governor	
	0-0635	1.	Bracket, Governor Spring	•
	3-0327	1 -	Bracket, Manual Choke	
	8-0176	1	Clip, Choke Cable	
• •	4-2405		Housing, Blower	
~ -	0-1021	1.	Lever, Throttle Control	, ,
푸실 -	6-0444	1	Bracket Assy., Ignition Coil & Throttle Contro	r re
16	7-1500	1 1	Cable, Spark Plug (Short) - R.H. (Complete)	
Sit ·	7-1501	1	Cable, Spark Plug (Long) - L.H. (Complete)	,
4	7-0229	2	Clip, Spark Plug Cable	
	0-0558	2	Nipple, Rubber - Coil (Incl. in Cable Assy.)	/
16	6-0250	.2-	Cover, Spark Plug (Incl., in Cable Assy.)	
16	66-0253 _%	2	Spring, Contact - Spark Plug (Incl. in Cable As	ssy.
16	6-0346	1	Coil, Ignition	
50	3-0514	1	Clamp, Ignition Coil	
14	0-1023	1	- Adapter, Air Cleaner	
51	5-0202	1	Key, Grankshaft Stub	ν,
11	0-0902	2	Guide, Valve (Exhaust)	j.
11	.0-1827	2	Guide, Valve "(Intake)	
	5-0057	1	Plug, Oil Gauge Hole	i. By
	2-0313	1	Elbow, Fuel Pump Inlet Power	,584

Not Furnished by ONAN:
Air Cleaner Muffler
Rope Sheave 011 Gauge

SPECIAL PARTS LIST FOR MODEL CCKB-4MG

SPEC

2251 H

FOR STANDARD PARTS REFER TO/CATALOG 929-0404 OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Group - 1		Flywheel Alternator-Left Side			
		Mounted			tana ang katalang a
Group -11		4:1 Gear Reduction-Left Side			
Group -13	•	Top Mounted Engine Control		*	
					2
					.
· · · · · · · · · · · · · · · · · · ·			,		4
			· · · · · · · · · · · · · · · · · · ·		
110-1707	1	Block Assembly Cylinder			
104-0641	1	Crankshaft			
123-0694	1	Cap and Indicator, Oil Fill			A
123-0674	. 1	Tube, Oil Fill	•		
150-1268	1	Arm, Governor			
150-0698	. 1	Spring, Governor	•	•	
307-0367	1	Solenoid, Start		9.	
155-0906	1	Muffler, Exhaust			
154-0973	2	Gasket, Exhaust	م مو		6.
505-0618	1	Cap, Pipe-Exhaust Muffler		; ;	
153-0327	1]	Bracket, Choke Arm	·	7	· /
518-0176	- 1	Clip, Choke Cable			٤.
520-0623	1	Stud, Governor Adjusting	The Control of the Co		1
150-0939	2	Joint, Ball	the second	•	•
1434-1796	1	Housing, Blower	•	* * * * * * * * * * * * * * * * * * *	
338-0410	. 1	Harness, Wiring		*	e e
338-0411	1	Harness, Wiring	•		
302-0062	1	Ammeter-45-0-45		,	
508-0084	1	Grommet, Rubber	<u>,</u> ₹		•
502-0203	1 .	Line, Oil	* *	•	· · · · · · · · · · · · · · · · · · ·
	4				
ar -				· ·	





CCKB-MS

SPEC 2255H

FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY NO. OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO. QTY. DESCRIPTION DESCRIPTION PART NO. QTY. Alternator, Left Side Mtg. Group 1 Vacu flo Cooling Group-14 Group-15 Fuel System-Gas 10 Ball, Governor Fly 510-0015 Base: Oil 102-0684 1 123-0694 Cap and Indicator, 0il Fill Tube, *Oil Fill 123-0674 1 191-0305 1 Brace, Alternator Bracket ì Scroll, Blower Housing 134-0564 1 Cover, Fuel Pump Hole 149-0136 Solenoid, Start 1 307-0367 1 Wheel, Blower 134-0753 134-1653 1 Housing, Blower Button, Dot 517-0035 1 Gauge, Oil 193-0005 1 517-0021 1 Button, Dot Elbow, Female 502-0005 1 :: Muffler Exhaust 155-0906 505-0618 Cap. Pipe 154-0973 2 Gasket, Exhaust Muffler Mtg. Joint, Ball 🗺 -150-0939 2 520-0623 Stud, Governor Adjusting 141-0726 *Carburetor, Gas Rod, Governor Control 150-0096 Lead, Hi Tension, #2 Cylinder 167-1073 Lead, Hi Tension, #1 Cyl. 1 167-1330 141-0713 +Needle, Idle Adjusting

* - Same as Carburetor listed in Group 31 except parts marked +.



SPECIAL PARTS LIST FOR MODEL _____CCKB-MS

FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY NOPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED. KEY NO.

PART NO.	QTY.	DESCRIPTION	PARTI	NO. QTY.	DESCRIPTION
Group -4 Group -13 Group -19 Group -21	•	Flywheel Alternator (Wico Top Mounted Control (Engi High Profile Breaker Box & Solenoid Shift Starter	ne) 🔻		
104-0881 102-0653 2 134-2134	1 1 1	Crankshaft Base, Oil Housing, Cylinder Air R/H	Pin .		
134-2036 153-0327 518-0176	1 1	Housing, Blower Bracket, Choke Clip, Cable			
150-0939 520-0623 508-0084	2 1 1	Joint, Ball Stud, Governor Adjusting Grommet, Rubber			· ·

SPEC

2267H

KEY NO.

927-0404 FOR STANDARD PARTS REFER TO CATALOG_ OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO. QTY	DESCRIPTION	PART NO. QT	Y. DESCRIPTION
Group -4 % Group -1.3	Flywheel Alternator (Wico) Top Mounted Engine Control		
Group -1.5	Fuel System-Gas		
Group - 19	High Profile Breaker Box		
Group -21	Solenoid Shift Starter		
			and the state of t
104-0881 1	Crankshaft		
102-0653 1	Base, Oil		· ·
110-0893 2	Retainer, Valve Spring		
149-0136 1	Cover, Fuel Pump Hole		
134-2134 1	Housing, Cylinder Air R/H		•
508-0084 1	Grommet, Rubber		
134-2036 1	Housing, Blower		· · ·
141-0726	*Carburetor, Gas		
140-0921	Gasket, Air Horh		
150-06392	Joint, Ball		•
520-0157 1	Stud, Governor Adjusting		
141-0713	#Needle, Idle Adjusting	,	
	1		

Same as carburetor listed in Group 31 except parts marked #.



SPECIAL PARTS LIST FOR MODEL

SPEC

FOR STANDARD PARTS REFER TO CATALOG 927-0404

KEY NO. 2

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Group -3		Alternator, Top Mounted		₩	
Group-14		Vacuflo Cooling			
Group-31		Carburetor (141-0744)			
					· · · · · · · · · · · · · · · · · · ·
	July 1947				
<u> </u>					
110-1904	1	Block Assembly, Cylinder		4	
104-0906	. 1	- Crankshaft			T
113-0153	2	Ring Set, Piston	in the second of the		
110-0893	2_	Retainer, Valve Spring	· · · · · · · · · · · · · · · · · · ·		
509-0090	``∙	Seal, Valve Stem Oil	i	,	
123-0694	1	Cap and Indicator, Oil Fill			
123-0674	1	Fube, Oil Fill			
110-1827	2	Guide, Valve	* *	÷ .	
140-0645	1	Adapter, Air Cleaner			
134-1576	1	Housing, Blower			•
193-0005	. 1.	Gayage, Oil			•
502-0005	1	Elbow, Female	<u>,</u>		
-51700 8 5	· . 1	Button, Dot	1	,	, es
154-1116	1	Manifold, Intake	<u>'</u>		
502-0008	1	Plug, Pipe (1/8)			:,
502-0039	1	Elbow.		÷,	· • •
150-0939	2	Joint, Ball			•
520-0623	1	Stud, Governor Adjusting	· · · · · · · · · · · · · · · · · · ·	•	f_{ij}
505-0057	1	Plug, Pipe (1/8)			€
149-0136	1	Cover, Fuel Pump Hole	. '		
154-1110	1	Manifold, Exhaust		·	
, 154-0973	•	Gasket, Exhaust Manifold			`
148-0698	. 1	Line, Fuel	"		
134-0753		Wheel, Blower	•		(
134-2155	1		,		·)
140-0554			Î.		, <u>, , , , , , , , , , , , , , , , , , </u>
166-0346	1	Bracket, Coil Mounting			
167-1327		Lead, Hi Tension #1 Cyl.	,		
167-1073	1	Lead, Hi Tension, #2 Cyl.	2.,	-	
•		•			· · · · · · · · · · · · · · · · · · ·

Parts not Furnished by Onan: Governor





230411

SUPPLEMENTARY PARTS LIST 900- 43 (per above model and spec.) Parts listed below apply to the above model. Use these parts in place of (or in addition to) the parts listed for Parts Key 2 in the standard parts catalog No. 927 - 404

P	ART NO.	QUAN.	DESCRIPTION
			NOTE: Optional Top Mounted Alternator group in main parts catalog applies to this plant.
	102E412	1	Base, Oil
	104D486	ı î	Crankshaft
	110A1904	1	Block Assy., Cylinder - Includes Bearing Plate,
		*	Bearings, Guides & Seats
	120B648	1	Intake, Oil Pump - Includes Cup, Screen & Pipe
	123A527	î .	Cap & Indicator, Oil Fill
	509-123	1	Seal, Bearing Plate
	509A134	2	Seal, Valve Stem Oil
	113A152	2	Ring Set, Piston
	509-105	1	Seal, Oil (Outer) - Gear Cover
	509-126		Seal, Oil (Inner) - Gear Cover
	509-110	1 1	Seal, Dust - Bearing Plate
	150A1337	1	Arm, Governor Pull - Left Pull
	134B675	1	Flywheel
•	309-10	1	Switch, Low Oil Pressure
	502-58	1	Tee, Low Oil Pressure Switch
	150A698	1.	Spring, Governor
	15ÓA96	1	Stud, Governor Adjusting
,	153A327	1	Bracket, Manual Choke
!	518P176	1	Clip, Choke Cable .
~.,	134B1719	. 1	Housing, Blower
	S17-9	1	Plug, Dot Button - For 2" Hole
	134D1644	1	Housing, Cylinder Air - Left
	134C2002 ,	1 .	Housing, Cylinder Air - Right
	167A1491	2	Cable, Spark Plug
	140C645	1	Adapter, Air Cleaner
	511-90	1	Belt, Alternator Drive
• .	191A639	1 .	Baffle, Air - Alternator
	515A202	1 .	Key, Crankshaft Stub
	191C511	1	Motor Assy., Starting
9 .	*		Not Furnished by Onan:
			American Company of the Company of t
			Oil Pressure Gauge Power

Air Cleaner



CCKB-MS

SPEC.

2306H

FOR STANDARD PARTS REFER TO CATALOG 927-0404

KEY NO.

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Group -	13	Top Mounted Engine Control			
Froup -		Solenoid Shift Starter			
110-1418	1	Block Assembly, Cylinder	1		
104-0878		Crankshaft			
123-0694		Cap and Indicator, Oil Fill		, , , , , , , , , , , , , , , , , , , ,	
123-0674		Tube, Oil Fill			•
105-0234		Camshaft			·
113-0153		Ring Set, Piston			
160-0752	1	Starter, Magneto (Includes			State of the State
	· S	Parts Marked *)	,		
$\frac{167-0188}{}$	4	, Clip		40° 1	
167-1403	1	Lead, Hi Tension	n .		
167-1404	1 .	Lead, Hi Tension		· ·	*
_160-0750	- 1	*Coil, Magneto Starter			
160-0749	* 1	*Pole Shoe, Magneto Starter			
508-0002	1	Grommet, Magneto Lead		-	
332-0273	1 .	Clip, Magneto Lead	a	•	•
134-2134	1	Housing, Cylinder Air R/H			
160-0948	. 1	Wheel, Magneto (Includes	•		•
•		Ring Gear and Magnets)			\
134-0673	1	Gear, Ring			
154-0998	1.	Manifold, Exhaust		v.	
154-0973	2	Gasket, Exhaust Manifold		•	
505-0329	1	- Cap, Pipe	[•	• • • • • • • • • • • • • • • • • • •
153-0327		Bracket, Choke		#	•
518 -01 76		Clip, Choke Cable	,		
134-2078	1	Housing, Blower		<u>.</u>	•
517-0015	1	Button, Dot			
		•	1 1	•	* G



	0		$\mathbb{R}[C]$	1		,						
COECU	AL PART	TO LIGHT	EOD M	ANEI	e CCVD	WC.	e b	SPEC		2 3 13J	4 .*	٠,
SPECIA					440		CATALOG	927-0404		KEY NO)	2
los.	and the second second							NO. BELOW	NHEN	USED.		

* .

£.

SPECIA		S LIST FO					SPE		2313J	<u> </u>
hos _i		STANDAI							KEY NO. JSED	<u> </u>
PART NO.	QTY.		SCRIPTION			ART NO.	QTY.		ESCRIPTIO	N *.
Group - Group -2	5 **** 2	Flywheel Variable	Alternato Speed Gov	r (Phelon ernor)		.	A		
								.	· · · · · · · · · · · · · · · · · · ·	• •
				, t .			a .	₩	,	
***			•	3,					ø	
		\$ c. /	•	•						Ø.
		•	71	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		,				
		i	•	, - 						
				. B	-	\$	<i>≅</i> **		6	
	٠.	. 1	•	W.		₽ ` ·			ту	,





	PE	_	* *			•	-		•		 _		_	_	-	-
-			ın		_	-				1.2			_			
					_	-		_			 		 			
100		~		Saint .		_	., .				 _		•	-		

CCKB-MS

SPEC 2324H

FOR STANDARD PARTS REFER TO CATALOG 927-0404
OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WH

KEY NO. 2

PART NO.	OTY.	DESCRIPTION	PART NO	QTY.	DESCRIPTION
	7				
Group -8		Spin on Oil Filter			
Group-19		High Profile Breaker Box		Name of the State	ahad hu Onan
Group-21		Solenoid Shift Starter	Parts	NOT FUITI	shed by Onan:
Group-31		Gas Carburetor	.6	راتان اه مساهم او ا	
	1			il Gauge	سحفيهم بيلوم فالأهب أاليشاف الأب
<u> </u>		* 1		ope Sheave	*
110-1957	1	Block Assembly, Cylinder		ir Cleaner	
104-0883	1	Crankshaft	•		ing Grille
509-0090	2	Seal, Valve Stem Oil		otocaps	ınd Associated Parts
509-0123		Seal, Vushing Plate	rı	ոթյ բառի ։	the Associated Farce
509-0110	I .	Seal, Dust			
105-0140	. 1			. 6	
113-0152	. 2	Ring Set, Piston	الهام المراجعة المرا المراجعة المراجعة ال		•
114-0145	2	Bearing Connecting Rod		A STATE OF THE STA	
102-0387	1	Base, Oil			
110-1827	2	Guides, Intake Valves	•		_
103-0381	* 1	Gearcover		*	
149-1063	` 1	Baffle, Fuel Pump	•	•	
134-2388	1	Flywheel (Includes Ring Gear			
502-0058	. 1	Tee, Oil Line			
154-1116	1	Manifold, Intake		.	***
150-0639	2	Joint, Ball			
520-0157	1	Stud, Governor Adjusting			*
134-2258	- 1	Housing, Blower			
1-34-2424	1	Housing, Cylinder Air R/H	* · · ·	•	
150-0635	1	Bracket, Governor	•		₩
150-0698	1	Spring, Governor		,	ϵ_p
140-0936	1	Adapter, Air Cleaner	r F to a	, .	. As
154-1024	1	Manifold, Exhaust			•
154-0973	. 2	Gasket, Exhaust Manifold	all the second of the second o	•	ere et de la companya
166-0535	1	Coil, Ignition			* .
167-1551	1	Lead, Hi Tension			and the second s
167-1552	1	Lead, Hi Tension	•		•
334-0028	3 1	Lead, 'Ignition	•		
509-0035	· 1.	"O" Ring		•••	
150-1339	1	Bracket, Governor			· ·
150-1021	1.	Lever, Throttle Control	18	• .	and the second transfer of
110-0893	3 , 2	Retainer, Valve Spring	• • • • • •	tar terreligi	
. .	•	(Exhaust)	and the second	و المستحدد	Secretary of the secret
. 148-0418	3 1	Vaporizer, LP	Comment to the Control	andrawy in the St.	
148-0465	5 1	Regulator			The state of the s
149-0136	5 1	Cover, Fuel Pump Hole			Control of the Contro
502-0183	3 1	Elbow, Vaporizer Inlet		s i saide	
140-0281		Gasket, Carburetor Flange			
149-0003		Gasket, Carburetor Mtg.			A Company of the Comp
159-1014		Line, Regulator to Car-	in the second		
	·	buretor			K

Elbow, Regulator Outlet Plug, Pipe

502+0076 505-0008 2



SPECIAL PARTS LIST FOR MODEL CCKB-MS

2330H

O	PTIONAL GE	ROUPS IN CATALOG ARE	LISTED BY GROUP N	O. BELOW WH	EN USED.
PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Group -4	F1)	wheel Alternator (Wic	0)		
Group -2	1 So	lenoid Shift Starter			
		··· <u>·</u>	3		
102-0653 134-2134 150-0678	1 Ho	se, Oil using, Cylinder Air R/ ip, Sensitivity	H		
	, , , , , , , , , , , , , , , , , , , 				
	: . • /				
	•				
		•			
					-
,					
				*	
	(

· · · · · · · · · · · · · · · · · · ·				-	





FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY NO. OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED. PART NO. DTY. DESCRIPTION PART NO. QTY. DESCRIPTION 104-0878 1. Crankshaft	SPECIA	. PART	S LIST FOR MODEL	CCKB-MS	·	SPEC	2331H	. "-
PART NO. QTY. DESCRIPTION PART NO. QTY. DESCRIPTION		FOR	STANDARD PARTS F	REFER TO	CATALOG_	927-0404		2
				ARE LISTE	D BY GROUP N	IO. BELOW W	HEN USED.	
104-0878 1. Crankshaft	PART NO.	DTY.	DESCRIPTION		PART NO.	QTY.	DESCRIPTION	1 .
	104-0878		Crankshaft		1			
	· · · · · · · · · · · · · · · · · · ·							*.J
		<u> </u>						-
					44 -		*	¥
				W.		est of		
	A CONTRACTOR OF THE CONTRACTOR	***				:	A	-1 18 _{(%} 18 - 3
				•	A Company	Seguine Control of the Control of th	- Maria	
		•			•		- -	
	*					•.		
				·	es established			
						:		
					, , , , , , , , , , , , , , , , , , ,			4
								ı
		***						·.

Generation

9

SPECIAL PARTS LIST FOR MODEL CCKB-4MG

SPEC

2336H

KEY NO.

FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY I OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PÁRT NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION.
Group - 11 Group -13	4:1	ernator, Left Side Mounting Gear Reduction, Left Hand Mounted Control		77 sax 11 11 11 11 11 11 11 11 11 11 11 11 11	
				0	
110-1707		Block Assembly, Cylinder			
104-0641	1	Crankshaft			
123-0674	. 1	Tube, Oil Fill			
123-0694	1	Cap and Indicator, Oil Fill			
155-0906	7 1	Muffler, Exhaust		,	
154-0973	2	Gasket, Exhaust Muffler		***	
505-0618	1	Cap, Pipe-Exhaust Muffler		· .	
153-0327	1	Bracket, Choke			
518-0176	• 1	Clip, Choke Cable 🔩 📜 🐇			100 M
520-0623	1	Stud, Throttle Adjusting	**	• '	land.
150-0939	2	Joint, Ball	in the second	•	نم
508-0084	1	Grommet, Rubber		* - ·	**
150-0147	1	Stud, Governor Adjusting,			
150-0621	1	Nut, Governor Adjusting Stud		,	
307-0367	1	Solenoid, Start	143		
502-0203	1	Line, Oil			
134-1796	1	Housing, Blower			
302-1796	·. 1	Ammeter, 45-0-45			•
338-0410	, 1	Harness, Wiring		•	
338-0411	1	Harness, Wiring	4.		



SPECIAL PARTS LIST FOR MODEL

CCKB-MS

2350H

QTY.

SPEC FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY NO.

DESCRIPTION

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO.	QTY.	DESCRIPTION	PART NO.
	a a a		300
Group - 4		Flywheel Alternator (Wico)	
Group -15		Fuel System, Gas	
Group -20		Thermo Magnetic Choke	
Group -21		Solenoid Shift Starter	
Group =22		Variable Speed Governor	1
Group -30	<u>). </u>	Carburetor	
110-0893	. 2	Retainer, Valve Spring	
102-0684	1	Base, Oil	
-123 -0694	1	Cap and Indicator, Oil Fill	
123-0674	1	Tube, Oil Fill	
508-0084	1	Grommet, Rubber	
517-0009	1	Button, Dot	, r
502,0020	1	Elbow * .	
501-0004	1	Line, Oil	₹
193-0006	1	Gauge, Oil	4.
134-2134	1	Housing; Cominder Air R/H	
134-2020	1	Housing, Blower	
505-0057	1 ,	Plug, Pipe	
193-0171	<i>9</i> 1	Bracket Fitting, Oil Gauge	Section 1
502-0003	1	Connector	· · · · · · · · · · · · · · · · · · ·
154-1051	1	Manifold, Intake	0
150-0939	2	Joint, Ball	
520-0263	1	Stud, Governor Adjusting	
135-0906	1	Muffler, Exhaust	
505-0618	` * 1	Cap, Pipe	
154-0973	/ . 2	Gasket, Exhaust Manifold	
143-0321	1	Spring, Carburetor	
502-0175	1	Connector	
502-0058	1	[°] Tee, Pipe	
309-0010	1	Switch, Oil Pressure	
/			1





SPECIAL PARTS LIST FOR MODEL

SPEC

FOR STANDARD PARTS REFER TO CATALOG 927-0404

KEY NO.

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO. QTY.	DESCRIPTION	PÀRT NO.	QTY.	DESCRIPTION
Group -1	Alternator, Left Side Mtg.			
Group -14	Vacu flo Cooling			
A CARPON AND A CAR				
104-0806 1	Crankshaft	•	e S	
515-0103 1	Key, Crankshaft	, ·	K.,	<i>3</i>
102-0707 1	Base, Oil	, k		
505-0110 2	Plug, Oil Base	44.	·	· · · · · · · · · · · · · · · · · · ·
505-0019 2	Bushing, Reduer		· `\	
-123-0679 + 1	Tube, Oil Fill			***
134-0753	Wheel, Blower			
502-0058	Tee, Oil Pressure Switch	Les,	**	
501-0004 1	Line, Oil		7	
309-0010 \ 1	Switch, Oil Pressure			
150-1268	Arm. Governor Control-			1975 - 19
150-1208 1	Rear Pull	, A	ren Visit de la companya	A.
150-0698 1	Spring, Governor			
134-0564	Scroll, Blower Housing	\$ 2		
	Brace, Alternator		· · ·	•
191-0305 1			,	•
134-1653 1	Housing, Blower	1	4.	
517-0035 1	Button, Dot	,,		· •
502-0005 1	Elbow, Female		,	
193-0005 1	Gauge, Oil		,	£ 6
517-0021 1	Button, Dot	× 2	•	the second of th
154-0998 1	Manifold, Exhaust			*
154-0973 2	Gasket, Exhaust Manifold			
505-0329 1	Cap, Pippe	•		
153-0327 1	Bracket, Choke	,4	. · · · · · · · · · · · · · · · · · · ·	•
518-0176	Clip, Choke Cáble	1	-X	
ATTO AT	Lead, Hi Tension #2 Cyl.		-	
7 167-1489 1	Lead, Hi Tension #1 Cyl.		, '	
307-0367 1	Solenoid, Start	*	•	
A Committee of the Comm	The state of the s	· · · · · · · · · · · · · · · · · · ·		•
	. · · · · · · · · · · · · · · · · · · ·			
	W 49	[, gr., .		•
**				· · · · · · · · · · · · · · · · · · ·
		. `		





900-0043 Supplementary Parts List

	,	o	đe			<u>.</u>	CCI	(B-	MS.		1 Lant	مستنافي الأرا	<u>يان</u>	S	pe	C	,	2378	311		,			 ÷.		
ide.	Ϋ́È	h	- Tale - 1		-, -	- 5.	Ų						ą) .		-, 								 	•	
74	Š	a	n	Ja	IC	1 6	er!	ts	Ca	ital	log	ſ <u>.</u>	- 	9	<u> 27-</u>	<u>0404</u>				P	arts	K	ey	 		

Parts Listed Below Apply to the Above Model. Use These Parts in Place of (or in Addition to) the Parts Listed in the Standard Parts Catalog.

PART NO.	QUAN.	DESCRIPTION
110+1957	1	Block Assembly, Cylinder (Includes Bearing Plate,
		Bearings, Guides & Seats)
104-0785	1	Crankshaft
102-0387	1 1	Base, Oil
120-0648	1	Intake, Oil Cup
123-0527	1	Cap & Indicator, Oil Fill
509-0134	2	Seal, Valve Stem Oil
105-0140	1 1	Camshaft - Includes Center Pin
509-0123	1	Seal, Bearing Plate *
509-0110	1 1	Sëal, Dust - Bearing Plate
113-0152	-2	Ring Set, Piston
114-0145	4	Bearing, Connecting Rod
∕ 1 f0 ≑0902	2	Guide, Valve - Exhaust
£10-1827	2	Guide, Valve - Intake
509÷0105	1 1	Seal, Gear Cover - Outer
509-0126	1	Seal, Gear Cover - Inner
149-0136	1 1	Cover, Fuel Pump Hole
103-0303	1	Cover Assembly, Gear - Complete
134-4388	1 ,	Flywheel - Includes Ring Gear
104-0170	1 -	Screw, Flywheel Mounting
160-0963	$\begin{bmatrix} 1 & 1 \end{bmatrix}$	Box, Breaker
160-1143	1 1	Diaphragm, Breaker Box
160-0723	1 1	Plunger, Breaker Box
160-0931	1 ,	- Guide, Plunger - Breaker Box
160-09'29	1	Bushing, Breaker Box
150-0635	. 1	Bracket, Governor Spring
150-0698	1	Spring, Governor
154-1116	1	Manifold, Intake
505-0057	1	Plug, Pipe (1/8) - Intake Manifold
154-1024	1	Manifold, Exhaust
154-0973	2	Gasket, Exhaust Manifold
134-2258	1	Housing, Blower
150-1021	1	Lever, Throttle Control
150-1339	1	Bracket Assembly, Ignition Coil & Throttle
		Control Lever
166-0635	1	Coil, Ignition
167-1551	1	Cable, Spark Plug - Short Power
≱67-1552	1	Cable, Spark Plug - Long Generation
509-0035		"O" Ring, Spark Plug Cable
167-0241tion	2	Plug, Spark
134-2424	1 1	Housing, Cylinder Air - Right

900-0043 Supplementary Parts List

N	lodel	1.47	CCK	B-MS	\$	pec	2378H		
111		1. /	arts	Catalog	927	-0404		Parts Ke	y <u>2</u>

Parts Listed Below Apply to the Above Model. Use These Parts in Place of (or In Addition to) the Parts Listed in the Standard Parts Catalog.

PART NO.	QUAN.	DESCRIPTION
123-0732	1 1	Tube, Breather Connector
141-0744	1	Carburetor Assembly (Gas)
502-0076	1°	Elbow, Inverted Male (Carburetor)
505,40008	1	Plug, Pipe - 1/8" (Carburetor)
191-0790	1 1	Motor Assembly, Starting
122-0323	1 1	Filter, Oil
122-0320	1 1	Adapter, Oil Filter Mounting
122-0321	1	Gasket, Oil Filter Adapter
122-0345	1 1	Line, Oil Drain
122-0347	1 1	Seal, Air - Oil Filter
	N1	
		•
•]	Not Furnished by ONAN: Oil Gauge, Rope Sheave,
	1	Air Cleaner, Blower Housing Grille
er en	:	
		•
•	1 ' '	





•				
SPECIAL	. PARTS L	.IST	FOR.	MODEL

CCKB-S

SPEC

QTY.

DESCRIPTION

FOR STANDARD PARTS REFER TO CATALOG 927-0404/ KEY NO. OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO.	QTY.	DESCRIPTION	1.	;	PART N	10.	. •
167-1462	1 1	ead, Hi Tension (17")		Ī			
167-1463	1 L	ead, Hi Tension (1911)					•





150-1386

152-0197

516-0059 - 13

1

Arm, Governor Control

Swivel, Hex

Pin, Cotter

FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY NO:

` 0	PTION	AL GROUPS IN CATALOG ARE LISTE	D BY GROUP N	IO. BELOW WHEN USED.	
PART NO.	QTY.	DESCRIPTION	* PÅRT NO.	QTY: DESCRIPTION	
Group - 5		Flywheel-Alternator (Phelon)	'		
Group - 8		Spin on Oil Filter	140-1073	1 Clamp, Air Cleaner	
			508-0162	1 Grommet, Rubber	
			134-2622	1 Housing, Blower	
110-1885	1	Block Assembly, Cylinder	134-2094	1 Housing, Cylinder Air R/	H
104-0744		Crankshaft	103-0422	1 Plate, Rear Bearing	
110-1037	2	Valve, Intake	110-1000	2 Seat, Intake Valve	
110-0904	2	Rotocaps, Intake Valve	110-1827	2 Guide, Valve	1
509-0090	2	Seals, Valve Stem Oil	191-0932	1 Stator, Alternator	
102-0740	1	Base, Oil	191-0864	2 Spacer, Starter Mounting	,
505-0110	1	Plug, 0il Drain (3/8)	191-0854	1 Flange, Starter Mounting	;
113-0153	2	Ring Set, Piston	166-0535	1 Coil, Ignition	: .
191-0922	1	*Starter	191-0989	1#Bracket Assembly, Front	
502-0388	1	Elbow, Restricted Flow	191-0990	1#Bearing, Front Bracket	
502-0058	1	Tee, Special Pipe	191-0995	1#Clutch Assembly	
<u> 153-0453</u> -	1	Bracket, Choke Arm	191-0996	1#Armature	
145-0398	1	Adapter, Air Inlet		1#Field Coil Set (Includes	•
518-0176	2	Clip	†	positive brush)	
503-0004	1	Člamp, Hose	Parts not	Furnished by Onan:	
140-1094	1	Cover, Air Cleaner		Rope Sheave	
140-1071	1	Element, Air Cleaner	1 "	Oil Gauge	. ,
140-1135	. 1	Cover, Air Cleaner	ľ	Choke	(·)
503-0311	·1 .	Clamp, Hose		Muffler	t
140-1075	1	Elbow, Air Inlet	7.	Regulator Bracket	Dom
140-1133	1	Bracket, Air Cleaner		Regulator, and Associated	Fai
502-0313	1	Elbow, Fuel Pump			
503-0669	1	Line, Fuel		as standard Spec J Starter	
518-0178	1	Clip, Harness	excep	t parts marked #. *	
-123-0998	2	Insulator			٠,
518-0268	1	Clamp			
309-0237	1	Switch, Oil Light			
515,0002	1	Key, Wheel	1		
123-0694	Ι.	Cap and Indicator Oil Fill		•	
134-2131	1	Baffle, Air	1		
503-0582		Hose, Breather			. :
503-0171	2	Clamp, Hose	, ,		
140-1075	1	Elbow, Air Inlet			
150-1384	1	Bracket, Governor Control	*		
150-0147	1	Stud, Governor Adjust			
. 167-1464	,	Lead, Hi Tension			
167-1463		Lead, Hi Tension		734	
509-0035		Coil, Ignition	н		•
160-1165		Bracket, Timing			-
123-1149		Tube, Oil Fill			4
150-1385	Ţ	Baseplate, Governor Control			1.74
· I - () 7 0 / '	1	4 900 CATACATOLE (ATITUS)	•	•	



MODEL.

SUPPLEMENTARY PARTS LIST 900-43 (per above model and spec.)

Parts listed below apply to the above model. Use these parts in place of (or in addition to) the parts listed for Parts Key. 2 in the standard parts catalog No. 927-0404

PART NO.	QUAN.	DESCRIPTION
152A185	1	Stud, Governor Adjusting
152A186	1	Bracket, Variable Speed Governor Mounting
152A184	1 -	Spacer, Variable Speed Governor
102E653	1	Base, Oil
104D488	1	Crankshaft
110A1904	1	Block Assy., Cylinders - Incl. Bearings, Guides
•		& Seats
120B648	1	Intake, Oil Pump - Incl. Cup, Screen and Pipe
123A527	1	Cap & Indicator, Oil Fill
5 10-15	10	Ball, Fly - Governor
193-108	1	Sender, Oil Pressure
104A170	1	Screw, Flywheel Mtg.
₹305C471	1	Regulator, Rectifier
103A333	. 1	Cover Assy., Gear
1918724	1	Stator, Battery Charging Alternator
167-188	1	Clip, Stator Lead
321-162	1	Fuse, 30-Amp.
321P165	1	Holder, Fuse
323C488	4	Connector, Socket
323P759	1	Housing, Socket Connector
332P529	1	Terminal, Female - Alternator Lead
332-556	1	Connector, Alternator Lead
321P169	1	Bracket, Fuse Mtg.
332A1358	1	Bracket, Connector Mtg.
134B1895	1	Wheel, Blower - Includes Ring Gear
191C400	1	Rotor, Charging Alternator
154C1549	1	Manifold, Exhaust
154A973	2	Gasket, Exhaust Manifold
153A327	1	Bracket, Choke Cable
518P176	1	Clip, Choke Cable
145A398	1	Adapter, Carb. Air Inlet
503-4	1	Clamp, Hose - Air Inlet Elbow to Adapter
503-311	1	Clamp, Hose - Air Inlet Elbow to Air Cleaner
140C1066	1	Cleaner, Air
\ 140B1071	1	Element, Air Cleaner
140B1073	1	Clamp, Air Cleaner
140C1061	1	Cover, Air Cleaner
140B1075	1	Elbow, Air Inlet
14081067	1	Bracket, Air Cleaner
503A582	1	Hose, Breather Generati
509A134	2	Seal, Valve Stem Oil

CCKB-MS

SUPPLEMENTARY PARTS LIST 900- 43 (per above model and spec.) Parts listed below apply to the above model. Use these parts in place of (or in addition to) the parts listed for Parts Key_ in the standard parts catalog No. 927-404

	PART NO.	QUAÑ.	DESCRIPTION
	167-241	2	Plug, Spark
	113A153	2	Ring Set, Piston
٠. '	134C2121	i	Housing, Blower
, `	517-9	ī	Plug, Bot Button - 2"
4	134D2134	1	Housing, Cylinder Air - R.H.
	134B2I31	1	Baffle, Air
	167A1533	$\frac{1}{2}$	Cable, Spark Plug
	191D790	1 1	Motor Assembly, Starting - Complete
	191-806	\cdot \mathbf{i}	Yoke Assembly
•	191-743	1	Armature
•	191-744	1 1	Clutch, Starter
1	191-745	1	Stop, Pinion
·	191-746	1 1	Ring
	191-807	$\frac{1}{1}$	Washer, Plain - Armature
,	191-808	ī	Bracket Assembly, Front
	191-749	1	Lever Assembly
	191-750	1	Spring, Lever - Small
٠.	191-751	1	Spring, Lever - Large
	191-752	- 1	Holder, Spring
	191-809	1	Bracket Assembly, Rear
	191-754	i	Washer, Plain - Nearest to Commutator
	191-755	* 1	Washer, Plain - Furthest from Commutator
•	191-756	ī	Washer, Insulator
	191-757	4	Brush
	191-758	4	Spring, Brush
	191-759	2	Bolt, Through
,,	191-760	3	Screw, Machine P.H.
	191-761	1	Switch Assembly, Solenoid
	191-762	1 1	Coil Assembly, Field
•	191-763	1	Bearing, Front
,	191-764	1	Bearing, Rear
	191-765	4	Pole Shoe
	191-766	4	Screw, Pan Head
٠.	· · · · · · · · · · · · · · · · · · ·		Not Furnished by Onan:
÷			
٠,			Oil Gauge
			Rope Sheave
			Fuel Pump Primer Rod Power
			Compretion

SPECIAL PARTS LIST FOR MODEL

FOR STANDARD PARTS REFER TO CATALOG 927-0404 OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN LISED

PART NO.	QTY.	DESCRIPTION .	PART NO.	QTY.	DESCRIPTION
** Design (**) (**) (**) (**) (**) (**) (**) (**		to be a second to the second s			
			1-		
Group -6		Flywheel Alternator (Synero)		· .	8
Group -8		Spin on Oil Filter	№ 140-1094	1	Cover, Air Clamer
	•		140-1071	1	Element, Air Cleaner
	· .		, 140-1135	1	Cover, Air Cleaner
110+1885	I,	Block Assembly, Cylinder		43 I	Clamp, Hose
110+1000	2	Seat, Intake Valve	140-1075	1	Elbow, Mir Inlet
110-1037		Valve, Intake	140-1133	1	Bracket Air Cleaner
110-0904	2	Rototcap, Intake	508-0162	١	Grommet, Rubber
\$09-0090	4	Seal, Valve Stem	150-0939	2	Joint, Bali
101-0422	I	Plate, Rear Bearing	520-0263	į	Stud, Governor Adjusting
104-0744	1	Crankshaft	19 1-09 89	1	#Bracket Assembly, Front
160-1165	ļ	Bracket, Timing	194-0990	1,	#Bearing, Front Bracket
113-0153	·	Ring Set, Fiston	,191-0995	1	#Clutch Assembly
102-0740	, 1	Base, Oil	191-0996	1	#Armature
503-0582		Hose, Breather	191-1001	1	#Field Coil Set (Includes
503-0171 518-0176	2 .	Clamp, Hose			positive brush)
123-0170	$-\frac{1}{2}$	Clip, Harness .	,	,	
518-0268	<u>~</u>	Insulator, Breather	•		ird Spec J Starter
309-0237	1 	Clamp, Insulator Switch, Oit tight	except	parts m	narked #.
- 167-0188-	1 !	Clip, Stator Lead			,
1 2 3-0694		Cap Stator Read * Cap Sand Indicator, Oil Fill	'		
123-1149	1 1	Tube, Oil Fill			•
134-2500	1	Housing; Cylinder Air R/H			
150-1384	· 1	Bracket, Governor Control	Pacts Not	Euroishe	ed by Onan:
150-0147	1	Stud, Governor Adjusting		Oi l- Gat	
134-2622	1	Housing, Blower		Rope Sh	
191-0922.	ľ	*Starter		Manual	•
191-0864	2"	Spacer, Starter Mounting		•	and Associated Parts
191-0854	1	Flange, Starter Mounting			v
134-2131	1	Baffle, Air			•
505-0110	1	Plug, Oil Drain (3/87) "	r i i i i i i i i i i i i i i i i i i i		
150-1385	3 1 .	Base Plate, Governor, Cont.	,		•
150-1386	1	Arm, Governor Control ?			alle Silveria de la Companya de la C
142-0197	1	Swivel, Hex. ".	,		I
516-0059	1	Pin, Cotter		•	
166-0535	1	Coil Ignition	•	•	•
167-1463	1 .	Lead, Hi Tension (19" 1g)	•	、	
167-1464	, , l	Lead, Hi Tension (24" lg)	3		
509-0035	1	"O" Ring			
518-0176		Clip	1 -		· · · · · · · · · · · · · · · · · · ·
502-0388	1 -	Elbow, Restricted Flow	•	1 .s.	
502-0058	1	Tee, Pipe			•
153-0453	1	Arm, Choke Bracket	,	<i>;</i> '	•
145-0398	1	Adapter, Air Inlet			
503-0669		Hose, Fuel			
502-0313 140-1073	2	Elbow, Hose			
1.22.83 1 (1.7 %)		Class Air Cleaner			

Revised

C	CK.	В-	S
---	-----	----	---

PEC 2442H

SUPPLEMENTARY PARTS LIST 900-43 (per above model and spec.)
Parts listed below apply to the above model. Use these parts in place of (or in addition to) the parts listed for Parts Key 1 in the standard parts catalog No. 927-404

PART NO.	QUAN.	DESCRIPTION
102-0688	1	Base, Oil
104-0486	1	Crankshaft
110-1904	1	Block Assy., Cyl. (Incl. Bearing, Guides &
110-1304	•	Seats)
120-0413	» 1	Intake, Oil Pump (Incl. Cup, Screen & Pipe)
123-0506	1 1	Cap & Indicator, Oil Fill
509-0123	1	Seal, Bearing Plate
509-0110	$\frac{1}{1}$	Seal, Dust - Bearing Plate
509-0090	2	Seal, Valve Stem Oil
509-0105	1	Seal, Gear Cover - Outer (Dust)
509-0126	1	
	1 1	Seal, Gear Cover - Inner (011)
103-0380	1 2	Gear Cover Assy., Complete
113-0152	2.	Ring Set, Piston
105-0238	I I	Camshaft (Includes Center Pin)
134-2625	1 1	Flywheel
104-0369	1	Screw, Flywheel Mounting
526-0185	1	Washer, Flywheel Mounting Screw
150-0698	1	Spring, Governor
150-0635		Bracket, Governor Spring
153-0327	1	Bracket, Manual Choke
518-0176	1	Clip, Choke Cable
134-2405	1	Housing, Blower
150-1021	1	Lever, Throttle Control
166-0444	1	Bracket Assy., Ignition Coil & Throttle Control Lever
167-1500	i	Cable, Spark Plug (Short) - R.H. (Complete)
167-1501	1	Cable, Spark Plug (Long) - L.H. (Complete)
167-0229	2	Clip, Spark Plug Cable
160-0558	2	Nipple, Rubber - Coil (Incl. in Cable Assy.)
166-0250	2	Cover, Spark Plug (Incl. in Cable Assy.)
166-0253	2	Spring, Contact - Spark Plug (Incl. in Cable Assy.
166-0346	1	Coil, Ignition
503-0514	1	Clamp, Ignition Coil
140-1023	ī	Adapter, Air Cleaner
51,5-0202	1	Key, Crankshaft Stub
110-0902	2	Guide, Valve (Exhaust)
110-0302	2.	Guide, Valve (Intake)
505-0057	1	Plug, Oil Gauge Hole
502-0313	1	Elbow, Fuel Pump Inlet Generation
	2.19	Section with the second of the
Power Generation		Not Furnished by ONAN:

Air Cleaner

Oil Gauge

2463l

MODEL

SUPPLEMENTARY PARTS LIST 900-43 (per above model and spec.)
Parts listed below apply to the above model. Use these parts in place of (or in addition to) the parts listed for Parts Key 2 in the standard parts catalog No. 927-404

PART NO.	QUAN.	DESCRIPTION
		NOTE: O-+
		NOTE: Optional Top Mounted Alternator group in
•		main parts catalog applies to this engine.
110 1007		Water Cast and Taxan
110-1827	2	Valve Guide, Intake
110-0902	2	Valve Guide, Exhaust
102-0412	1	Base, 0i1
104-0486	1	Crankshaft
110-1904	1	Block Assy., Cylinder - Includes Bearing Plate,
100 0440		Bearings, Guides & Seats
120-0648	1	Intake, Oil Pump - Includes Cup, Screen & Pipe
123-0527	$\frac{1}{2}$	Cap & Indicator - Oil Fill
509-0110	1 -	Seal, Dust - Bearing Plate
509-0134	. 2	Seal, Valve Stem Oil
113-0152	2	Ring Set, Piston
√°,509-0105	1	Seal, Oil (Outer) - Gear Cover
509-0126	- 1	Seal, Oil (Inner) - Gear Cover
502-0313	1	Ëlbow, Street - Fuel Pump Inlet
134-2632	1	Flywheel - Includes Ring Gear
134-1719	1	Housing, Blower
517-0009	1	Plug, Dot Button - For 2" Hole
150-0635	1	Arm, Governor Pull
309-0010	1	Switch, Oil Pressure
502-0058	1	Tee, Oil Pressure Switch
150-0698	1	Spring, Governor
167-1491	2	Cable, Spark Plug
141-0721	1.	Carburetor (Gas-Gaso)
140-0645	1	Adapter, Air Cleaner - Upper
153-0327	1	Bracket, Manual Choke
518-0176	1 .	Clip, Choke Cable
194-0639	1	Baffle, Air - Alternator
191-0511	1	Motor Assy., Starting
509-0123	1 1	Seal, Bearing Plate
134-2002	1	Housing, Cylinder Air - Right
134-1644	$\overline{1}$	Housing, Cylinder Air - Left
	·	Parts Not Furnished by Onan:
		Oil Pressure Gauge
•		Air Cleaner Genera

Muffler

Belt - Alternatør





91	PEC	IAI :	PARTS	LIST FOR	MODEL
			, , ,, , , , ,		

CCKB-MS

2495H

FOR STANDARD PARTS REFER TO CATALOG 927-0404

KEY NO.

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Group* -4		Flywheel Alternator (Wico)			
Group-21		Solenoid Shift Starter		*	
	·			· · · · · · · · · · · · · · · · · · ·	
102-0748	1	Base, Oil			/
123-0555	1	Cap and Indicator, Oil Fill	1 kg		
123-0563	1 .	Tube, Oil Fill			
150-0752	- 1	Arm, Governor (Right Pull)			
193-0108	i	Sender, 0il Pressure			1 100
134-2121	1	Housing, Blower			
517-0009	1	Button, Dot	·		
134-2134	1	Housing, Cylinder			1
150-0698	1	Spring, Governor	* 1	,	
154-0998	1	Manifold, Exhaust			
154-0973	· 2	Gasket, Exhaust Manifold		•	· •
505-0329	1 - '	Cap, Pipe			,
518-0176	-1	Clip, Choke Cable	1	er i	
153-0327	. 1	Bracket, Choke	. "		A.E.
145-0398	1 "	Adapter, Air Inlet	,		
140-1073	1	Clamp, Air Cleaner	2 🐔 🗡		
140-1061	1	Cover, Air Cleaner (Inlet)		•	
140-1071	1	Element, Air Cleaner	,		
140-1066	1	Cover, Air Cleaner (Outlet)			
503-0311_	_ 1_	Clamp, Hose		•	
140-1075	1	Elbow, Air Inlet		<i>,</i>	
140-1067	1	Bracket, Air Cleaner			
503-0004	1_	Clamp, Hose	1 × 1	and the second	
167-1524	2	Lead, Hi Tension	-	de partie	
518-0176	1	Clip			
503-0582	1	Hose, Breather			
503-0171	2	Clamp, Hose	<u> </u>		
				* *	, 4
			· · · · · · · · · · · · · · · · · · ·		

Parts not Furnished by Onan:

Oil Gauge, Rope Sheave





2499H

SPECIAL PARTS LIST FOR MODEL

SPEC

FOR STANDARD PARTS REFER TO CATALOG 927-0404

KEY NO. 2

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO.	QTY.	DESCRIPTION	PART NO. C	RTY.	DESCRIPTION
Group 414		Vacu flo Cooling			,
Group -15		Gas Fuel System		 	ar .
			A State of the Sta		ولسلي سنسير كهام والحارات والأرا
			The second secon		· · · · · · · · · · · · · · · · · · ·
102-0707	1.	Base, 011			
123-0694	i di Lin	Cap and Indicator, Oil Fill			· · · · · · · · · · · · · · · · · · ·
123-0674	1	Tube, Oil Fill		the second second	
149-0136	_	Cover, Fuel Pump			
510-0015	. 10	Ball, Fly-Governor			
134-0564	1	Scroll, Blower Housing			
134-0753	1	Wheel, Blower		•	
517-0109	1	Plug, Blower Houser		1971 - A. J	· · · · · · · · · · · · · · · · · · ·
517-0021	1.	Button, Dot, Blower Housing			
191-0305	1	Brace, Alternator Bracket			
134-1653	` 1	Housing, Blower			u 🦏 ud
517-0035	1	Button, Dot		*	
502-0005	1	Elbow, Pemale			
193-0005	1	Gauge, Oil			
154-0906	-1/1	Muffler, Exhaust			,
505-0618	1	Cap, Pipe (1½")		· .	.,,
154-0973	2	Gasket, Exhaust Muffler		:	
141-0726	" 1 -	*Carburetor			
141-0713	1	#Needle, Idle Adjusting	, .		
		retor listed in Group 31	\		
except	parts r	marked #.		,54 -	





SPECIAL PARTS LIST FOR MODEL CCKB-MS SPEC 2512H

PART NO.	QTY.	DESCRIPTION	PART NO.	QTÝ.	DESCRIPTION
123-0694 123-0674 155-0906 154-0973	1 1 1 2	Cap and Indicator, Oil Fill Tube, Oil Fill Muffler, Exhaust Gasket, Exhaust Muffler			
	A				



CCKB-MS

SPECIAL PARTS LIST FOR MODEL

SPEC

FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY I OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO.	ату, '	DESCRIPTION		PART NO.	QTY		DESCR	IPTION
Group -15		Gas Fuel System				* *		
Group -21		Solenoid Shift Starter			- L		Marie Contract	ν .
Group -22		Variable Speed Governor	: , ^j .	la.	. ,			
01-04P					```;;		. A	
110-2358	1	Block Assembly, Cylinder			Ţ	,	· · · · ·	
110-1000	2	Seat, Intake Valve	1			, ,		
110-1037	2	Valve, Intake					•	e j
110-0893	2	Retainer, Intake Valve				* · · · · · · · · · · · · · · · · · · ·		, j
110-1283	· 1	Cover, Timing	1	ıl		,		
105-0234	√1	Camshaft	ļ					
160-0791	1	Cam, Timing Control					.	
516-0144	4 '	Pin, Roll	. ``			•		**
160-0789	2	Weight Assembly, Timing	1	18 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	· -	3 7.85	*	
		Control	1			, s A.,	A .	٠ .
516-0146	×.2	Groove Pin, Timing Control	1		J.	٠	- ,	•
160-0727	1	Spring, Timing Control	l .			2.1		•
160-0726	1	Retainer, Timing Control		₹ '			•	.3
518-0185	2	Ring, Timing Control		· . *			£.	
· 4	**	Retainer						•
160-0751	1 🛰	Stator, Magneto (Complete)						
160-0750 -	1	Coil Magnetor Stator		**	,	1 .		,
160-0749	. 1.	Pole Shoe, Magneto Stator					4	,
508-0002	1	Grommet, Magneto Lead	l					1
332-0273	1	Clip, Magneto Lead					•	
167-1404	. 1	Lead, Hi Tension (19")	l `	•		m.		· .
167-1403	1	Lead, Hi Tension (16 3/4")			*	•		· ·
160-0948 · ·	1	Flywheel (Includes Ring		•				
		Gear and Magnets)						1
149-0136	1	Cover, Fuel Pump						
508-0095	2	Grommet, Rubber		1		•	.*	
154-0918	I	Manifold, Intake	ł					
141-0726	1	*Carburetor		0			• .	
134-1836	1	Housing, Blower		<i>*</i>				
502-0005	1	Elbow						
193-0031	1	Clamp, Oil Gauge	i					
193-0005	1	Gauge, Oil	·		ui *	· ====		
134-2134	1	Housing, Cylinder Air R/H			480°.	Com.		
313-0018	1 .	Button, Stop				75. 34.		
150-1073	1:	Bracket, Governor		v				
134-2131	1	Baffle, Air	, }			en i		
141-0713	1 #	Needle, Idle Adjusting	1	•		e#		#
* - Same as o		etor listed in Group 31				ا _ي د. اه	•	-
		arked #.	1					



Currents Power Generation

SPECIAL PARTS LIST FOR MODEL CCKI

SPEC

2516H

FOR STANDARD PARTS REFER TO CATALOG 927-0404

KEY NO.

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

	PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
	Group -4 Group-I3 Group-21		Flywheel Alternator (Wico) Top Mounted Engine Control Solenoid Shift Starter			
5 -	104-0699	1	Crankshaft		AS.	
	102-0653 123-0679	1	Base, Oil Tube, Oil Fill	*	•	
a	134-2134	1	Housing, Cylinder Air R/H		•	, i
151	134-2036 153-0327	* 1 * 1	Housing, Blower Bracket, Choke Arm			
	518-0176 155-0906	1	Clip, Choke Cable Muffler, Exhaust		*	
<u> </u>	154-0973	_/_ 2	Gasket, Exhaust Muffler	N.	- v	
Ŋ	505-0618 134-2131	1 1	Cap, Pipe Baffle, Air			
-a					7.2 · · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·





SDECIAL	DADTO	LIST FOR	MADEL
OI EGIVE	i ranio i	LIGI FUD	MODEL

CCKB-MS

2521H

FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY NOPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

KEY NO. 2

PART NO. QTY.	DESCRIPTION	PART NO. QTY.	DESCRIPTION
Group ±3	Alternator-Top Mounted		
	Tube, Oil Fill Lead, Hi Tension		
134-1719 1 193-0005 1 502-0005 1	Housing, Blower Gauge, Oil Elbow, Inverted Male		
191-0639 11 5 511-0090 11	Baffle, Alternator Belt, Alternator		
134-1644 1 134-2002 1 154-0998 1	Housing, Cylinder Air L/H Housing, Cylinder Air R/H Manifold, Exhaust		
154-0973 2	"Gasket, Exhaust Manifold		



-2524H

SUPPLEMENTARY PARTS LIST 900-43 (per above model and spec.) Parts listed below apply to the above model. Use these parts in place of (or in addition to) the parts listed for Parts Key $\frac{2}{100}$ in the standard parts catalog No. $\frac{927-404}{100}$

PART NO.	QUAN.	DESCRIPTION	· · · · · · · · · · · · · · · · · · ·
		NOTE: Optional Top Mounted Alternator	
		Group in Main Parts Catalog applies t	o this
		Engine.	
	4		
141-0689	1	Carburetor Assembly, Gasoline (Manual Choke)	
1.34-1644	1	Housing, Cylinder Air - Left	
134-2002	$\overline{1}$	Housing, Cylinder Air - Right	1
103-0380	1	Cover Assembly, Gear	•
509-0123	1	Seal, Crankshaft Oil	
509-0110	1. 1	Seal, Dust & Bearing Plate	
113=0152	. 2	Ring Set, Piston	
509-0134	* 2	Seal, Valve Stem Oil	ζ.
102-0412	1	Base, Oil	,
110-0893	2	Washer Spring, Retainer - Exhaust Valve	
502-0313	1	Elbow, Street 90° (Fuel Pump Inlet)	
150-0635	1	Arm, Governor	
134-2632	* 1	Flywheel, Blower - Includes Ring Gear	
309-0010	1	Switch, Oil Pressure	
134-1719	1	Housing Assembly, Blower	
153-0327	1	Bracket, Choke Arm	Ý
140-0645	1	Adapter, Air Cleaner	
517-0009	1	Button, Dot (Blower Housing)	
110-1827	2 🐔	Guide, Intake Valve	
110-0902	25	Guide, Exhaust Valve	
110-1904	1	Block Assembly, Cylinder	
104-0486	1	Crankshaft	
104-0170	. 1	Screw, Flywheel Mounting	•
120-0648	1 /	Cup, Oil Intake	
123-0527	41.	Indicator & Cap Assembly, Oil	ar
150-0698	1 1	Spring, Governor	
509-0105	1	Seal, Oil (Outer) - Gear Cover	ı
509-0126	· 1 .	Seal, Oil (Inner) - Gear Cover	•.
502-0058	1 :	Tee, Oil Pressure Switch	
/526-0208	18	Washer, Flat - Cylinder Head	* * * *
/ 167-1491	2	Cable, Spark Plug - Includes Rubber Coil Nip	ple
191-0639	* 1	Baffle, Air - Alternator	*
191-0511	1	Motor Assembly, Starting	4.
518-0176	1 1	Clip, Choke Cable	er
112-0136	2 *	Piston and Pin Assembly (Includes Retaining	Rings
Powl44-0203	 う まが	Rod Assembly, Connecting	A 12 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1

Sheave, Muffler, V-Belt for Alternator, Air Cleaner

SPECIAL PARTS LIST FOR MODEL CCKB-MS 100 100 100

SPEC 2529H

FOR STANDARD PARTS REFER TO CATALOG 927-0404

KEY NO.

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
	•				
Group - 1		Alternator Left Side Mountg.			
Group - 8		Spin on Oil Filter			
Group -14		Vacu flo Cooling			
Group -21		Solenoid Shift Starter			
			p ⁽ⁿ⁾	,	
110-1860	1	Block Assembly, Cylinder	Z_{a}		**
104-0806	<u> </u>	Crankshaft			
134-2131	, 1	Baffle, Air			
191-0305	1	Brace, Alternator		181	
134-2424	1	Housing, Cylinder Air R/H		•	
150-0755	.1	Arm, Governor Front Pull			
134-1653		Housing, Blower			
517-0035	1	Button, Dot.	*		
502-0005	1	Elbow, Female		•	
517-0021	- 1	Button, Dot	ŀ	Z	
193-0005	1	Gauge, Oil			
154-0998	1 '	Manifold, Exhaust	,	75.	•
154-0973 505-0329	4	Gasket, Exhaust Manifold Cap, Pipe		· ·	
134-0564	1,	Scroll, Blower Housing	'	1	
134-0753	. ⊥ 1}	Wheel, Blower			
150-0698	1	Spring, Governor			
	. 1	phine, continue	}		
				r	
	•			•	





CCKB-MF

PART NO.	QTY	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Group - 1 Group -12 Group -22		Alternator, Left Side Mtg. Rockford Clutch Variable Speed Governor			
	4		3		··· -
104-0344 150-0639 167-1483	1 2 1	Crankshaft' Joint, Ball Lead, Hi Tension #2 Cyl.			
167-1489	1	Lead, Hi Tension #1 CyI.		* . • . • . • . • . • . • . • . • . • .	
				•	· . '
				•.	



_		_			- '	_					·	'				_	_		
c		E .	_	IΛ		п	Λ.	П.	TO	. 1		- 1		v	- 6	-		,	
	_	_		14		-		ж		• 1			⊢ ≀	11-6				-	
•			•	"		,					IS"		•	/ I I			_		-

2549Н

FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY NO. OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Group - 1		Alternator Left Mounting	0 0	, A	
Group - 8		Spin On Oil Filter	*	Ψ	
Group - 13		Top Mounted Engine Control			en es assertes de la compansión de la comp
110-2375	1	Block Assembly, Cylinder	1		
110-1000	<u>2</u>	Seat, Intake Valve			
110-1037	2	Valve, Intake			
110-0904	2	Rotocap, Intake Valve		1000	<u> </u>
307-0367	1	Solenoid, Start			
134-2323	. 1	Housing, Blower			•
134-2057	1	Housing, Cylinder Air RH			Section 1995
150-0147	1	Stud, Speed Adjusting	₩ *	·	
140-1023	1 .	Adapter, Air Cleaner			,
302-0062	1 '	Ammeter 45-0-45		• • •	
•				•	



2594H

SUPPLEMENTARY PARTS LIST 900- 43 (per above model and spec.) Parts listed below apply to the above model. Use these parts in place of (or in addition to) the parts listed for Parts Key_
in the standard parts catalog No. 927-0404 in the standard parts catalog No...

PART NO.	QUAN.	DESCRIPTION
		NOTE: This engine has OPTIONAL full flow oil
		filter and low oil pressure switch.
4		
102-0688	1	Base, Oil
-104+0486	1 1	Crankshaft
110-1957	1	Block Assy., Cyl. (Incl. Bearings, Guides &
110 100		Seats)
105-0238	100	Camshaft (Includes Center Pin)
120-0413	1	Intake, Oil Pump (Incl. Cup, Screen & Pipe)
123-0506	1	Cap & Indicator, Oil Fill
509-0123	1	Seal, Bearing Plate
509-0110	1	Seal, Dust - Bearing Plate
509-0090	2	Seal, Valve Stem Oil
509-0105	1	Seal, Gear Cover - Outer (Dust)
509-0126	1	Seal, Gear Cover - Inner (011)
103-0380	_ 1	Gear Cover Assy., - Complete
113-0152	2	Ring Set, Piston
134-2625	1	Flywheel
104-0369	1	Screw, Flywheel Mounting
526-0185	1	Washer, Flywheel Mounting Screw
150-0698	1	Spring, Governor
150-0635	1	Bracket, Governor Spring
153-0327	1	Bracket, Manual Choke
518-0176	1	Clip, Choke Cable
134-2306	1	Housing, Blower
150-1021	1	Lever, Throttle Control
166-0444	1	Bracket Assy., Ignition Coil & Throttle Control Leven
167-1500	1	Cable, Spark Plug (Short) - R.H. (Complete)
167-1501	1	Cable, Spark Plug (Long) - L.H. (Complete)
167-0229	2	Clip, Spark Plug Cable.
160-0558	2 2	Nipple, Rubber - Coil (Incl. in Cable Assy.)
166-0250	2	Cover, Spark Plug (Incl. in Cable Assy.)
166-0253	2	Spring, Contact - Spark Plug (Incl. in Cable Assy.)
166-0346	1	Coil, Ignition
503-0514	1	Clamp, Ignition Coil
140-1023	1	Adapter, Air Cleaner
515-0202	-1	Key, Crankshaft Stub
134-2237	.1.	Housing, Cylinder Air Power
517-0009	1	Button, Dot - Blower Housing Generation
110-0902	2	Guide, Valve (Exhaust)
Generalenn		The control of the co

Guide, Valve (Intake)
Elbow Fuel Pump Inlet





	•	CCKB-S
MAREL	?. .	40110

2594H

SUPPLEMENTARY PARTS LIST 900-43 (per above model and spec.)
Parts listed below apply to the above model. Use these parts in place of (or in addition to) the parts listed for Parts Key 1 in the standard parts catalog No. 927-0404

in the standa	rd parts	catalog No. <u>+ 92/-0404</u>
PART NO.	QUAN.	DESCRIPTION
505-0057	1	Plug, Oil Gauge Hole
		Not Furnished by ONAN:
		Air Cleaner Rope Sheave Oil Gauge Muffler
	• •	



GCKB-MS

SPEC

2620H

FOR STANDARD PARTS REFER TO CATALOG 927-0404

KEY NO.

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Group - 8		Crim On Odl Edland	1	, 1	
Group - 19		Spin On Oil Filter			·
Group - 21	``	High Profile Breaker Box		•	<u>.</u>
Group - ZI		Solenoid Shift Starter	. با ا	en e	
110-1957	1	Block Assembly, Cylinder			
110-1827	$-\frac{7}{2}$	Guide, Intake Valve			
509-0123	1	Seal, Crankshaft Oil		***	
509-0110	1	Seal, Dust	Ř		
, 105-0140	$\bar{1}$	Camshaft			
113-0152	2	Ring Set, Piston			
114-0145	4	Bearing, Connecting Rod			
102-0667	1	Base, 0i1	J		
134-2131	1	Baffle, Air-Starter	i di		
509-0090	2	Seal, Valve Stem Oil		er en	***
103-0381	ī	Gearcase Assembly			the second second
149-1063	1	Baffle, Fuel Pump	,	•	
150-0635	1	Bracket, Governor			
150-0698	1	Spring, Governor		7	
134-2424	1 .	Housing, Cylinder Air RH		1	
154-1116	1	Manifold, Intake			b .
150-0639	· 2	Joint, Ball	. I . I . I . I . I . I . I . I . I . I		
520-0187	1	Stud, Governor Adjusting	f	•	•
154-1024	1	Manifold, Exhaust			
154-0973	2	Gasket, Exhaust Manifold		1 1 ×	
134-2258	1	Housing, Blower			,
150-1339	1	Bracket, Governor		· · · · · · · · · · · · · · · · · · ·	The second secon
150-1021	1	Lever, Throttle Control	·	-95	
509-0035	1	"O" Ring			,
167-1552	1	Lead, Hi Tension	11 11		•
167-1551	1	Lead, Hi Tension	÷.	. 2	
134-2388	1	Flywheel (Includes Ring Gear)			
			. № 6	•	•
Parts Not Fu		- 1 · 1 · 1		3	
	11 Ga	-	, ,		·.
Ro	pe S	heave			ì
•		The state of the s			
			1		•





SPECIAL PARTS LIST FOR MODEL

CCKB-MS

SPEC

2633H

FOR STANDARD PARTS REFER TO CATALOG_

927-0404

KEY NO.

2

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
	j			1	
Group - 4		Flywheel Alternator (WICO)			
Group - 15		Gas Fuel System			
102-0653	1	Base, 0il			
110-0893	2	Retainer, Valve Spring			
307-0367	1	Solenoid, Start			The state of the s
149-0136	1	Cover, Fuel Pump Hole			The state of the s
134-2020	1	Housing, Blower			
141-0726	1 *	Carburetor			- Call Control
154-0918	1.	Manifold, Intake			The desired and the second
150-0639	2	Joint, Ball		din di	
520-0187	1	Stud, Governor Adjusting		Market Market .	
141-0713	1 : #	Needle, Idle Adjusting	and the state of t		•
the commence of a phononic le	in the first field in the sail.	and the second of the second o	The state of the s		
			The state of the s	•	
	r is here	The state of the s	1	, d	
		and the second s	1 <i>l</i> *	34	•

Same as carburetor listed in Group 31 except parts marked #.





	IAL GROUPS IN CATALOG ARE LIST	ED	BY GROUP N	IO. BEL	OW WHE	N USED.
PART NO. QTY.	DESCRIPTION	:	PART NO.	QTY.	· · ·	DESCRIPTION
Group - 21	Alternator Left Side Mtg. Thermo Magnetic Choke Solenoid Shift Starter Variable Speed Governor Carburetor (141-0690)					
134-2131 1 134-2134 1 154-0918 1 167-1483 1 167-1489 1	Baffle, Air-Starter Housing, Cylinder Air RH Manifold, Intake Lead, Hi Tension #2 Cyl. Lead, Hi Tension #1 Cyl.					



900-0043 Supplementary Parts List

Model	CCKB-MS	Spec	2671 H	· * /	/2.
		/		/	
Standard	Parts Catal	927-0404	• •	Parts Kev	2

Parts Listed Below Apply to the Above Model. Use These Parts in Place of (or in Addition to) the Parts Listed in the Standard Parts Catalog.

PART NO.	QUAN.	DESCRIPTION
	•	
NOTE: This Mode	l has a F	ywheel Charging Alternator - 12 Volt (Components listed
		ent (Spec G & H) in Parts Catalog except for flywheel)
110-1904	1	Block Assembly, Cylinder (Includes Bearings, Guides,
		& Seats)
509-0090	2	Seals, Valve Stem Oil
104-0488	1	Crankshaft
-102-0653	1	Base, 0il
120-0648	1	Cup, Oil Pump Intake (Includes Pipe, Screen, & Cup)
123-0527	1 -	Cap and Indicator, Oil Fill
503-0582	1	Hose, Breather
154-0951	1 - 1	Manifold, Intake
154-1549	· 1	Manifold, Exhaust
145-0398	1	Adapter, Carburetor Air Inlet
140-0921	1	- Gasket, Air Horn
518-0176	1	Clip, Choke Cable
153-0327	1	Bracket, Choke Cable
134-1895	1 1	Flywheel (Includes Ring Gear)
191-0790	1	Starter - 12 Volt - (Components listed as Optional
		Equipment in Parts Catalog)
134-2121	1	Housing, Blower
134-2134	1	Housing, Cylinder Air - R/Hand
152-0041	1	Washer, Spring Tension - Vari Speed Governor
152-0083	1	Arm, Speed Control - Vari Speed Governor
152-0184	1	Spacer - Vari Speed Governor
152-0186	1	Bracket, Governor Mounting - Vari Speed Governor
	-	
NOTE: Parts Not	: Furnishe	d by Onan-
Air Cle		R
Rope Sh		
Oi 1 Gau		was the same of th





SPEC.

SUPPLEMENTARY PARTS LIST 900- 43 (per above model and spec.)
Parts listed below apply to the above model. Use these parts in place of (or in addition to) the parts listed for Parts Key 1 in the standard parts catalog No. 927-0404

	PART NO.	QUAN.	DESCRIPTION
			This aming has postional full flow oil
			NOTE: This engine has optional full flow oil
			filter and low oil pressure switch.
	110 1057		Dial ton Cul (Incl Bearings Crides &
	110-1957	1	Block Assy., Cyl. (Incl. Bearings, Guides &
			Seats)
	104-0468		Crankshaft
•	102-0688	1	Base, Oil
	120-0413	1	Cup, Oil Pump Intake (Incl. Cup, Screen & Pipe)
	123-0506	1 1	Cap & Indicator, Oil Fill
	509-0090	2	Seal, Valve Stem Oil
	105-0238	1 1	Camshaft (Includes Center Pin)
	509-0123	1.	Seal, Bearing Plate
	509-0110	1 1	Seal, Dust (Bearing Plate)
	113-0152	2	Ring Set, Piston
	502-0313	1 1	Elbow, Fuel Pump Inlet
	134-2237	1 .	Housing, Cylinder Air (Right)
	150-0698	1	Spring, Governor
	103-0380	1	Gear Cover Assy., - Complete
	140-1023	1 1!	Adapter, Air Cleaner
	134-2555	1 1	Flywheel
-	134-1889	1 1	Guard, Blower Wheel (Rotating)
	153-0327	1	Bracket, Choke Cable
	518-0176	1	Clip, Choke Cable
	509-0105	- 1	Seal, Gear Cover - Outer (Dust)
	509-0126	ı î	Seal, Gear Cover - Inner (Oil)
	110-0902	2	Guide, Valve (Exhaust).
٠,	110 030 <u>2</u> 110-1827	$\frac{2}{2}$	Guide, Valve (Intake)
	150-1021		Lever, Throttle Control
1	166-0444	\mathbf{i}	Bracket Assembly, Ignition Coil & Throttle
	100, 0111 .	P	Control Lever
	134-2862	1: 1	Housing, Blower
	167-1501	1	Cable Assy., Spark Plug (Long) - L.H. (Complete
	167-1501	† †	Cable Assy., Spark Plug (Short) - R.H. (Complet
	167-1300	2	Clip, Spark Plug Cable
,	,	, ,	Nipple, Rubber - Coil (Incl. in Cable Assy.,)
	166-0558	1 5	Cover, Spark Plug (Incl. in Cable Assy.)
	166-0250	4 4	Spring, Contact - Spark Plug (Incl. in Cable As
. 3	166-0253	4	
٠.,'	505-0057		Plug, Oil Gauge Hole
, , , , , , , , , , , , , , , , , , ,	104-0369		Screw, Flywheel Mounting
	526-0185	.	Washer, Flywheel Mounting Screw Power
	150-0635	1 1	Bracket, Governor Spring Generation

CC	K	8-	S
----	---	----	---

MODEL ...

2676H

SUPPLEMENTARY PARTS LIST 900- 43 (per above model and spec.)
Parts listed below apply to the above model. Use these parts in place of (or in addition to) the parts listed for Parts Key in the standard parts catalog No. 927-0404

		<u></u>
PART NO. QUA	N. DESCRIPTION	
166-0346	Coil, Ignition	
503-0514	Clamp, Ignition Coil	•
515-0202 1 812-0125 3	Key, Crankshaft Stub Screw, Blower Guard Mounting	Ç.
850-0035	Washer, Blower Guard Mounting	, \
526-0006 3	Washer, Blower Guard Mounting	
	NOTE: Parts Not Furnished by ONAN:	
	• Oil Gauge,	-
	Rope Sheave	7.
	Air Cleaner Muffler	•
	•	



WODEL GCKR-

SUPPLEMENTARY PARTS LIST 900- 43 (per above model and spec.)
Parts listed below apply to the above model. Use these parts in place of (or in addition to) the parts listed for Parts Key 2 in the standard parts catalog No. 927-0404

2679H

<u> </u>	PART NO.	QUAN.	DESCRIPTION
	110 1007	1	Die 1 Amerika Calindar (Tradudas Passins
	110-1957	1	Block Assembly, Cylinder (Includes Bearing
	104 070E	1	Trace, bearings, ourdes and bears),
	104-0785	1 1	Crankshaft
	102-0457	. <u>1</u>	Base, 0il
	120-0648		Intake, Oil Cup
	123-0527	1 1	Cap & Indicator, Oil Fill
	509-0090	2 '	Seal, Valve Stem Oil
	105-0140	1	Camshaft (Includes Center Pin)
	509-0110	1 1	Seal, Dust (Bearing Plate)
	509-0123	1 1	Seal, Bearing Plate
	113-0152	2	Ring Set, Piston
	114-0145	4	Bearing, Connecting Rod
	110-0902	'2	Guide, Valve - (Exhaust)
	110-1827	2	Guide, Valve - (Intake)
	509-0105	1.	Seal, Gear Cover - (Outer)
7	509-0126 =	1	Seal, Gear Cover - (Inner)
•	149-1063	.] 1	Baffle, Fuel Pump
	103-0380	1	Cover Assembly, Gear (Complete)
.,	134-2388	1	Flywheel (Includes Ring Gear)
•	160-0928	1 1	Box, Breaker
	160-0723	1	Plunger, Breaker Box
	160-0931	1 1	Guide, Plunger (Breaker Box)
	160-0929	1 1	Bushing, Breaker Box
•	150-0698	1 . 1	Spring, Governor
٠	154-1116		Manifold, Intake
	505-0057	. 1	Plug, Pipe (1/8) - Intake Manifold
29	154-1024	l -	Manifold, Exhaust
	154-0973	4 2	Gasket, Exhaust Manifold
. 2)	134-0373	7 7	Housing, Blower
	150-1021	1	Lever, Throttle Control
	150-1339,	1	Bracket Assembly, Ignition Coil & Throttle Co
•	100-1000	• •	Lever
	166-0535	1 1	Coil, Ignition
,	167-1551	i	Cable, Spark Plug (Short)
	167-1552	1	Cable, Spark Plug (Long)
	· ·	1	"O" Ring, Spark Plug Cable
	509-0035	1	Housing Cylinder Air (Right)
	134-2424	1	
	134-2131,	1	Baffle, Air
1.	123-0732	* 1	Tube, Breather Connector
1 .	191-0930	- 3 Lag Age 🖎	Starter, Solenoid Shift Generation Filter, Oil

Cumurins

2/18/74

Revised

Page

nf.

MODEL CCKB-MS

CDEC 2679H

SUPPLEMENTARY PARTS LIST 900-43 (per above model and spec.) Parts listed below apply to the above model. Use these parts in place of (or in addition to) the parts listed for Parts Key $\frac{2}{100}$ in the standard parts catalog No. $\frac{927-0404}{100}$

mine signourd par	s cafalog No. 927-0404
PART NO. QUAN	DESCRIPTION
122-0320 1 122-0321 1 122-0345 1 122-0347 1	Adapter, Oil Filter Mounting Gasket, Oil Filter Adapter Line, Oil Drain Seal, Air (Oil Filter)
	NOTE: Parts Not Furnished by ONAN:
	Rope Sheave Air Cleaner
	Blower Housing Grille
*	





2688н

__ **SPEC** _ 927-0404

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO.	QTY _f	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Group - 14		Vacu Flo Cooling			
Group - 20	11/4 -	Thermo Magnetic Choke		*	
: Group - 28	\mathbb{E}/\mathcal{Y}	Carburetor (141-0690)			
123-0694	1.	Cap Indicator, 011 Fill			
123-0674	1	Tube, 011 F111			
150-1016	. o 1 .	Arm, Governor			
134-0753	1.	Wheel, Blower			
134-0564	1.	Scroll, Blower Housing			90
517-0035	1	Button, Dot			4
150-0698	1 .	Spring, Governor			
150-0096	1	Stud, Governor Adjusting		1.	•
134-1953	1 -	Housing, Blower			· ·
167-1483	1	Lead, Hi Tension #2 Cyl.	**		
167-1489	1	Lead, Hi Tension #1 Cyl.			
154-1051	1	Manifold, Intake		7	
154-0998	1	Manifold, Exhaust	:		
505-0329	1	Cap, Pipe	•		
154-0973	2	Gasket, Exhaust Manifold Mtg.		, •	
502-0003 ^I	1	Connector, Inverted Male .			v
309-0237	2	Switch, Oil Pressure		•	1,
193 ±0171	, 1	Bracket, Fitting		,	
505-0057	1	Plug, 1/8 Pipe			,
502-0058	1	Tee, Pipe			
1. 4	r .		1		· · · · · · · · · · · · · · · · · · ·
					•
Parts Not Fu	rnish	ned By Onan		4	•

Oil Gauge





SPECIA		S LIST FOR MODEL *	CCKB-S	SPEC	27,11H
		I STANDARD PARTS REFE AL GROUPS IN CATALOG ARE	,		KEY NO Men used.
PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Group - 22		Variable Speed Governor	4		
110-2358 110-1037 110-0904 110-1000	2 2	Block Assembly, Cylinder Valve, Intake Rotocap, Intake Valve Seat, Valve-Intake			V ₁₋₁ -1
	4.				<u></u>
	~			7	
<u>-1</u>				*	*
	المام أ			di di	And Section 1
				* · · · · · · · · · · · · · · · · · · ·	er el
	*			e e	



Power Generation



Power Generation

2719J

SPECIAL PARTS LIST FOR MODEL CCKB-MS SPEC 2719
FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY I
OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

KEY NO. <u>2</u>

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
104-0907	1	Crankshaft			
509-0123	7	Seal, Crankshaft Oil			
509+0110	7	Seal, Dust			
105-0140	/ 1	Camshaft			
114-0145	4	Bearing, Connecting Rod	در		
102-0387	*1 · ·	Base, 011			
191-0511	-1*	Starter			
134-0670	1	Baffle, Air-Starter			
103-0514	î '	Gearcase-Complete	1		
123-0527	1	Cap & Indicator, Oil Fill	P.		4
123-0508	î	Tube, Oil Fill	"		
509-0107	$\overline{1}$	Seal, Oil (Gearcase)			a
509-0097 *	1 ~	Seal, Oil (Gearcase)			
^149-1063	1	Baffle, Fuel Pump		•	
134-1210	ì	Flywheel (Includes Ring Gear)	1.		
501-0127	- 1	Line, 011	, ,		
502-0020	1	Elbow	· .		•
508-0008	1	Grommet, Oil Line			•
134-1664	1	Housing, Blower	, ,	1 .	٠.
167-0229	2	Clip, Wire	<u> </u>		
167-1500	1 '	Lead, Hi Tension #1 Cyl.		r	٠
167-1409	1	Lead, Hi Tension #2 Cyl.			
166-0346	1	Coil, Ignition		,	1
503-0514	1 .	Clamp, Coil			
166-0444	ĺ	Bracket, Coil Mtg.		•	
150-1021	1	Lever, Trhottle Control			
150-0635	1	Bracket, Governor			•
	1	Spring, Governor			
	1	Manifold, Intake			
149-1097	1	Line, Fuel	#'		· Land
154-1024	1	Manifold, Exhaust		-	
154-0973	2	Gasket, Exhaust Manifold	1.	·	
140-1087	1	Gasket, Air Cleaner		•	
140-0971	1	Adapter, Air Cleaner		•	•
134-1552	1	Housing, Cylinder Air RH			•
150-0639	2	Joint, Ball			
520-0187 -	1	Stud, Governor Adjusting			3.
191-0508	1	Flange, Starter Mounting			
	2		· · · · · · · · · · · · · · · · · · ·		
Parts Not Fu	rnisĥ	ned By Onan			

Spec G and H Starter used. Breakdown in PTC



CCKB-MS

SPEC

2720J

FOR STANDARD PARTS REFER TO CATALOG_

927-0404

KEY NO.

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
110-1904	. •	Block Apporbly Colindor			
110-1904	1	Block Assembly, Cylinder		in the second	
104-0883	2	Guide, Valve Crankshaft			
509-0123		Seal, Crankshaft			
509-0110	 	Seal, Dust			
105-0140	<u>_</u>	Camshaft			
113-0152	2 ·	Ring Set, Piston	7		
114-0145	Δ .	Bearing, Rod		e e	
509-0090	" 2	Seal, Valve Stem Oil	,		
102-0387	1	Base, 011	•		P.
- 191-0511	1 7	Starter			
134-0670	. 1	Baffle, Air-Starter			
191-0508	1	Flange, Starter Mounting			
103-0477	1	Gearcase (Complete)	, , , , , , , , , , , , , , , , , , ,		
134-0599	1	Clip, Cylinder Air Housing	,		
149-1063	- 1	Baffle, Fuel Pump			
123-0527	1	Cap & Indicator, Oil Fill		-	$\mathbf{x} = \mathbf{x}$
123-0508	1	Tube, Oil Fill		. ,	
134-2388	1	Flywheel (Includes Ring Gear)	, a		
501-0167	ī	Line, 011			,
502-0020	1	Elbow 1/8		· .	*
502-0020	i	Elbow-Fuel PUmp	,		1
509-0105	ī	Seal-Gearcase	,		
509-0126	1	Seal-Gearcase	1	-	_
150-0635	1	Bracket, Governor			· <u>-</u>
508-0155	1	Grommet, Oil Line		•	
149-1097	1	LIne, Fuel			
150-0698	1	Spring, Governor			•
154-1116	1	Manifold, Intake			
154-1024	1	Manifold, Exhaust		,	
154-0973	2	Gasket, Exhaust Manifold		•	
154-1302	<u>-</u>	- Gasket, Air Cleaner			•
150-0639	2	Joint, Ball			
520-0187	` 1	Stud, Governor Adjusting	1.		•
134-1552	1	Housing, Cylinder Air RH			
140-1304	$ar{f 1}$	Adapter, Air Cleaner		-	1
134-1966	1	Housing, Blower			
167-0229	· 2	Clip, Wire			•
- 167-1501	1	Lead, Hi Tension #1 Cyl.	· ,		
167-1500	- 1	Lead, Hi Tension #2 Cyl.	* *	•	· 's
166-0444	$ar{f 1}$	Bracket, Coil Mounting	l l		
150-1021	1	Lever, Throttle Control			
166-0346	· · · · · · · · · · · · · · · · · · ·	Coil, Ignition	M		
Maria Carante	and Taylor				**************************************
· 🍽 , 179. ilian ja		The state of the second			

Parts Not Furnished By Onam

Air Cleaner, Blower Housing Grille

and A starter used. Breakdown in PTC



•		· · .		;	ا مسین ماری		
SPECIA	AL PAR	TS LIS	T FOR MODEL	• .	CCKB-S	SP	EC' 2726J
			DARD PARTS				
			UPS IN CATALOG				, <u>, , , , , , , , , , , , , , , , , , </u>
PART NO.	QTY.		DESCRIPTION		PART NO.	QTY.	DESCRIPTION
:		1		,	i i		
							明 Tri かず Hi Li in Me William Tri Tri Vice (All Color) 27
			uipped With A S		167-1501	• 1.	Cable, Spark Plug #1 Cyl
	vance r lter.	echanis	m And Full Flo	011	167-1500	1	Cable, Spark Plug #2 Cyl
a de la companya de	LCCL.	41	- 18:		- 167-0229	2	Support, Spark Plug Cabl
110-1827	2	Guide-	Valve - Intake	,	160-1135 160-0723		Box, Breaker (Complete)
110-1957	1		Assembly, Cylin		160-0723	1 0	Plunger, Breaker Box
	* .		ludes Bearings,		160-1041	1	Bushing, Breaker Box
			Seats)		160-0931	1	"O" Ring - Breaker Box
104-0872	1	Cranks	haft	,	160-0261	1	Guide, Breaker Box Plung Wick, Breaker Box t
102-0688	. 1	Base,	011		700 0207	••••	wick, bleaker box
120-0413	1		, Oil Pump (Inc		Parts Not	Furnish	ned By Onan:
			, Cup And Scree				
123-0506	1		d Indicator, Oi		'Air Cle	aner	
309-0237	1		, Low Oil Press	ure			rew Guard
122-0345	. 1		Oil Drain		Rope Sh	eave	
509-0090 509-0105	2 1	-	Valve Stem Oil		** · · ·		
509-0126	1		Gear Cover (Out	-	· ·		*
105-0295	1.		Gear Cover (Inn ft (Includes Ce			¥.	
103 0275	. 4		Spark Advance M		,	4	*
•		Pins		echanism (· · · · · · · · · · · · · · · · · · ·	,	
140-1023	1		r, Air Cleaner		,		
154-0951	1		ld, Intake	,			
153-0327	1	•	t, Choke			2	· · · · · · · · · · · · · · · · · · ·
518-0176	1'		Cable - Choke		•		
134-2555	. 1 .		Blower		i		
134-1889	1	Screen	, Rotating	-	•		
134-2862	1		g, Blower				•
103-0477	1	•	Gear Case (Com	* * *	,	•	
140-1302	1		, Air Cleaner A	^		•	
134-2237	1		g, Cylinder Air	(R/H).			•
150-0698 150-1021	1	,	, Governor	. 1			
166-0346	1	-	Throttle Contr	\ \ \ \			
304-0060	$egin{array}{c} 1 \ 1 \end{array}$		attery Ignition or, Ignition	•		•	
304-0000	. 2		or, ignicion , Resistor Moun	tine	٥,	•	. 6 .
304-0610	. 1 .		t, Resistor Ter		. *		
166-0402	1		t, Coil Mountin			3	
526-0179	$\overline{1}$		#10 - Resistor	_	- 7 _h		
854-0010	1		IT Shakeproof				•
			stor Mounting	,/		, int	·
813-0112	1		Resistor Mount	ing -	•	•	· · · · ·
· · · · · · · · · · · · · · · · · · ·			32 X 2-1/2")	-			en de energie general (n. 1865). Programa
870-0053	1		esistor Screw M	ounting			
· · · · · · · · · · · · · · · · · · ·		(10-	32)			. 1	
503-0514	1		Hose" - Coil Mo	unting	••		
160-0558	2	Nipple	, Rubber Coil	, s			Power
				- 1		4.5	Generation



SPEC

2729J

FOR STANDARD PARTS REFER TO CATALOG 927-0404 **KEY NO.** OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

DESCRIPTION DESCRIPTION QTÝ. PART NO. PART NO. QTY. This Model Is Equipped With A Spark Bushing, Breaker Box 160-1041 1 Advance Mechanism "O" Ring - Breaker Box 160-1040 Parts Not Furnished By Onan: 110-1827 Guide, Valve - Intake Block Assembly, Cylinder 110 - 1904(Includes Bearing, Guides Rope Sheave And Seats) Flywheel Cap Screw Guard Crankshaft Air Cleaner 104-0872 Base, Oil 102-0688 1. Intake, Oil Pump (Includes 120-0413 Cup, Pipe & Screen Cap & Indicator, Oil Fill 123-0506 1 509-0090 -2 Seal, Valve Stem Oil 1 Seal, Gear Cover (Outer) 509-0105 Seal, Gear Cover (Inner) 1 509-0126 1 Camshaft (Includes Center Pin 105-0295 And Spark Advance Mechanism Pins) Manifold, Intake 154-0951 1 1 Bracket, Choke 153-0327 Clip, Cable - Choke 1 518-0176 1 Adapter, Air Cleaner 140-1023 Gasket, Air Cleaner Adapter 140-1302 1 Cover, Gear Case (Complete) 1 103-0477 1 Spring, Governor 150-0698 1. Bracket, Governor 150-0635 1 Lever, Throttle Control 150-1021 Wheel, Blower 134-2625 • 1 Housing, Blower 134-2405 1 Coil, Ignition 1 166-0346 Clamp, Coil Mounting 503-0514 2 Nipple, Rubber - Coil 160-0588 Cable, Spark Plug #1 Cylinder 167-1501 1 Cable, Spark Plug #2 Cyllinder 1 167-1500 Support, Spark Plug Cable 2 167-0229 E 1 Bracket, Coil Mounting 166-0402 304-0060 1 Resistor, Ignition 2 Washer, Resistor Mounting 304-0014 Support, Resistor Terminal 304-0610 1 Washer, Resistor Mounting #10 1 526-0179 854-0010 Washer, Internal Shakeproof 1. (#10-32)Screw, Resistor Mounting 813-0112 1 $(#10-32 \times 2-1/2")$ Nut, Resistor Screw Mounting 870-0053 1 (#10-32)Box Breaker - Complete 160-1135 Guide, Plunger - Breaker Box 160-0931 1. 160-0723 Plunger, Breaker Box

SPEC 927-0404

KEY NO.

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Group - 8	, s ₁	oin On Oil Filter			
110-1885		lock Assembly, Cylinder			
110-1883		iide, Intake Valve			
110-1027	and the second second	eat, Intake Valve			
110-1000	-	alve, Intake	,		
110-1037		ptocap, Intake Valve	· · · · · · · · · · · · · · · · · · ·		
509-0090	· <u>-</u>	eal, Valve Stem	gle men		
104-0880		rankshaft			
160-1165		rankshait racket, Timing		· · · · · ·	
102-0770		ase, 0il	· [
505-0110		lug, Oil Base	*	•	
167-0188		lip, Stator		•	1
123-1149		ube, Oil Fill	II ^A		
518-0178		lip, Harness	•		· · · · · · · · · · · · · · · · · · ·
503-0582	- (ose, Breather	dus o	,	•
503-0171	-	lamp, Hose	il .		
123-0998	- 1	nsulator, Breather Tube			•
309-0237	- /	witch, Oil Light			
134-2642	,	lywheel (Includes Ring Gear)	}		,
134-2871	· · · ·	ousing, Blower			
150-1385		late, Governor Control			
150-1386	(rm, Governor Control			•
152-0197	. •••• }	wivel, Hex		,	
516-0059		in, Cotter	ŕ		
150-1384	/ ·	racket, Governor Control		,	,
150-0147		tud, Governor Adjusting			
520-0751	2,	tud, Special-Blower Hsg.	,	4,	
134-2760	· , — ·	ousing, Cylinder Air RH	,		and the same of th
502-0388	, , —	1bow, Restricted Flow	r. . '		
150-0639	" / 2. J	oint, Ball		191	
520-0187	, ~	tud, Governor Adjusting			
153-0453	,	racket, Choke		* :	
146-0398		dapter, Air Inlet			,
503-0004 /		lamp, Hose		c .	
140-1073		lamp, Air Cleaner			
140-1094/		over, Air Cleaner			ja j
140-1071/		lement			í
503-031/1		lamp, Hose		•	•
140-1035		over, Air Cleaner		•	
140-11/33		racket, Air Cleaner			
140-1075		lbow, Air Inlet			
<u>508-0/162</u>	-	rommet, Rubber			į.
101-0422		late, Rear Bearing			er sakt og gang i bli
191–1016	1 S	tator, Alternator	1		
Parts Not	Furnished	By Onan			Power

Parts Not Furnished By Onan Alternator Regulator lternator Rectifier



2736J

NOTE: This model has a variable speed governor and a 20 ampere flywheel charging alternator.	PART NO.	QUAN.	DESCRIPTION
Block Assembly, Gylinder (Includes Bearings Guides and Seats) Sop-0090 2 Seals, Valve Stem Oil Crankshaft Base, Oil Intake, Oil Pump (Includes Cup, Screen & Pin Cap and Indicator, Oil Fill Tube, Oil Fill Cap, Breather Valve Housing, Cylinder Air R/Hand Housing, Blower Includes Ring Gear Lat-2892 Lat-2887 Lat-2887 Lat-2892 Lat-2887 Lat-2895 Lat-2895 Lat-2887 Lat-2895 Lat-28			
Block Assembly, Gylinder (Includes Bearings Guides and Seats) Sop-0090 2 Seals, Valve Stem Oil Crankshaft Base, Oil Intake, Oil Pump (Includes Cup, Screen & Pin Cap and Indicator, Oil Fill Tube, Oil Fill Cap, Breather Valve Housing, Cylinder Air R/Hand Housing, Blower Includes Ring Gear Lat-2892 Lat-2887 Lat-2887 Lat-2892 Lat-2887 Lat-2895 Lat-2895 Lat-2887 Lat-2895 Lat-28	7		
Block Assembly, Gylinder (Includes Bearings Guides and Seats) Sop-0090 2 Seals, Valve Stem Oil Crankshaft Base, Oil Intake, Oil Pump (Includes Cup, Screen & Pin Cap and Indicator, Oil Fill Tube, Oil Fill Cap, Breather Valve Housing, Cylinder Air R/Hand Housing, Blower Includes Ring Gear Lat-2892 Lat-2887 Lat-2887 Lat-2892 Lat-2887 Lat-2895 Lat-2895 Lat-2887 Lat-2895 Lat-28			NOTE: This model has a variable speed
Charging alternator.			
Block Assembly, Cylinder (Includes Bearings Guides and Seats) Seals, Valve Stem Oil (Crankshaft 102-0759		*	
Guides and Seats) 509-0090 104-0881 102-0759 1		. 4	
Seals, Valve Stem Oil Crankshaft Base, Oil Intake, Oil Pump (Includes Cup, Screen & Pin Cap and Indicator, Oil Fill Tube, Oil Fill Tube, Oil Fill Tube, Oil Fill Cap, Breather Valve Housing, Cylinder Air R/Hand Housing, Cylinder Air R/Hand Housing, Blower Includes Ring Gear Cover, Fuel Pump Hole Manifold, Intake Elbow, Inverted 45° Clip, Cable Bracket, Choke Adapter, Carburetor Air Inlet Gasket, Air Horn Bracket, Variable Speed Governor Mtg. Arm, Speed Control Governor Sacket, Namifold, Exhaust Stud, Governor - Control Stator Assembly, 20 ampere Bracket, Regulator, Voltage Regula	110-1904	1	Block Assembly, Cylinder (Includes Bearings, Guides and Seats)
104-0881 1	509-0090	2	
Base, Oil Intake, Oil Pump (Includes Cup, Screen & Pin 123-0527 1 Cap and Indicator, Oil Fill Tube, Oil Fill Tube		i	
120-0648		1	1
123-0527	· ·	1	
Tube, Oil Fill Cap, Breather Valve Housing, Cylinder Air R/Hand Housing, Blower Includes Ring Gear Wheel, Blower - Includes Ring Gear Cover, Fuel Pump Hole Manifold, Intake Elbow, Inverted 45 Clip, Cable Bracket, Choke Adapter, Carburetor Air Inlet Gasket, Air Horn Bracket, Variable Speed Governor Mtg. Arm, Speed Control Spacer, Variable Speed Control Spacer, Variable Speed Control Governor Manifold, Exhaust Stud, Governor - Control Stator Assembly, 20 ampere Bracket, Regulator/Rectifier Rectifier, Voltage Regulator, Voltage	•	1	
123-1118		1	· · · · · · · · · · · · · · · · · · ·
134-2791		1	
134-2892	•	1	
134-2887		.1	
154-0951 502-0065 1 518-0176 153-0327 145-0398 140-0921 152-0186 152-0184 152-0184 152-0185 152-0185 152-0185 191-1095 191-10938 191-0939 1 Manifold, Intake Elbow, Inverted 45° Clip, Cable Bracket, Choke Adapter, Carburetor Air Infet Gasket, Air Horn Bracket, Variable Speed Governor Mtg. Arm, Speed Control Spacer, Variable Speed Control - Governor Washer, Spring Tension Manifold, Exhaust Stud, Governor - Control Stator Assembly, 20 ampere Bracket, Regulator/Rectifier Rectifier, Voltage Regulator, Voltage		1	
502-0065 518-0176 153-0327 145-0398 1	149-0136	1	Cover, Fuel Pump Hole
518-0176 1 Clip, Cable 153-0327 1 Bracket, Choke 145-0398 1 Adapter, Carburetor Air Inlet 140-0921 1 Gasket, Air Horn 152-0186 1 Bracket, Variable Speed Governor Mtg. 152-0083 1 Arm, Speed Control 152-0184 1 Spacer, Variable Speed Control - Governor 152-0041 1 Washer, Spring Tension 154-1549 1 Manifold, Exhaust 152-0185 1 Stud, Governor - Control 191-1095 1 Stator Assembly, 20 ampere 191-1078 1 Bracket, Regulator/Rectifier 191-0938 1 Rectifier, Voltage 191-0939 1 Regulator, Voltage	154-0951	1	Manifold, Intake
518-0176 1 Clip, Cable 153-0327 1 Bracket, Choke 145-0398 1 Adapter, Carburetor Air Inlet 140-0921 1 Gasket, Air Horn 152-0186 1 Bracket, Variable Speed Governor Mtg. 152-0083 1 Arm, Speed Control 152-0184 1 Spacer, Variable Speed Control - Governor 152-0041 1 Washer, Spring Tension 154-1549 1 Manifold, Exhaust 152-0185 1 Stud, Governor - Control 191-1095 1 Stator Assembly, 20 ampere 191-1078 1 Bracket, Regulator/Rectifier 191-0938 1 Rectifier, Voltage 191-0939 1 Regulator, Voltage	502-0065	1	Elbow, Inverted 45°
Adapter, Carburetor Air Inlet 140-0921 1	518-0176	1 .	Clip, Cable
140-0921 152-0186 152-0083 152-0184 152-0041 152-0041 154-1549 152-0185 191-1095 191-0938 191-0939 1 Gasket, Air Horn Bracket, Variable Speed Governor Mtg. Arm, Speed Control Spacer, Variable Speed Control - Governor Washer, Spring Tension Manifold, Exhaust Stud, Governor - Control Stator Assembly, 20 ampere Bracket, Regulator/Rectifier Rectifier, Voltage Regulator, Voltage	153-0327	1	
152-0186 152-0083 152-0184 152-0184 152-0041 154-1549 152-0185 191-1095 191-0938 191-0939 1 Bracket, Variable Speed Governor Mtg. Arm, Speed Control Spacer, Variable Speed Control - Governor Washer, Spring Tension Manifold, Exhaust Stud, Governor - Control Stator Assembly, 20 ampere Bracket, Regulator/Rectifier Rectifier, Voltage Regulator, Voltage	145-0 398	1	Adapter, Carburetor Air Inlet
152-0083 1	140-0921	1	
Spacer, Variable Speed Control - Governor 152-0041 154-1549 1	152-0186	1	Bracket, Variable Speed Governor Mtg.
152-0041 1 Washer, Spring Tension 154-1549 1 Manifold, Exhaust 152-0185 1 Stud, Governor - Control 191-1095 1 Stator Assembly, 20 ampere 191-1078 1 Bracket, Regulator/Rectifier 191-0938 1 Rectifier, Voltage 191-0939 1 Regulator, Voltage	152-0083	1	
154-1549 152-0185 191-1095 191-0938 191-0939 1 Manifold, Exhaust Stud, Governor - Control Stator Assembly, 20 ampere Bracket, Regulator/Rectifier Rectifier, Voltage Regulator, Voltage	152-0184	1	Spacer, Variable Speed Control - Governor
152-0185 191-1095 191-1078 191-0938 191-0939 1 Stud, Governor - Control Stator Assembly, 20 ampere Bracket, Regulator/Rectifier Rectifier, Voltage Regulator, Voltage	152-0041	. 1	Washer, Spring Tension
191-1095 191-1078 191-0938 191-0939 1 Stator Assembly, 20 ampere Bracket, Regulator/Rectifier Rectifier, Voltage Regulator, Voltage	/ 154-1549	1	
191-1078 1 Bracket, Regulator/Rectifier 191-0938 1 Rectifier, Voltage 191-0939 1 Regulator, Voltage	152-0185	1 ,	
191-0938 1 Rectifier, Voltage 191-0939 1 Regulator, Voltage	,191-1095	. 1	
191-0939 1 Regulator, Voltage	191-1078	1	Bracket, Regulator/Rectifier
	191-0938	1 1	
NOTE: Parts Not Furnished by ONAN	191-0939	1	Regulator, Voltage
I NOTE: Parts Not Furnished by ONAN		. 4	***
			NOTE: Parts Not Furnished by ONAN
Air Cleaner	,		
Fuel Pump	\$		Fuel Pump



SPEC

2746J

FOR STANDARD PARTS REFER TO CATALOG 927-0404 OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
	,				
110-1418	1,	Block Assembly, Cylinder			
		(Includes Bearing, Guides	4		
45 g		and Seats)			
104-0882	1	Crankshaft		•	
105-0251	"]	Camshaft	,		
-102-0773 -	1	Base, Oil	Si *		
120-0648	1	Intake, Oil Pump (Includes			*
· · · · · · · · · · · · · · · · · · ·		Cup, Screen & Pipe)	, ,		· · · · · · · · · · · · · · · ·
123-0576	1	Cap & Indicator, Oil Fill	Carre Carre	, e	•
123-0568	1	_Tube, Oil Fill		4	
501-0027	. 1	Line, Oil	•		
502-0017	1	Connector, Oil Line	4		
502-0020	1	Elbow, Street - Oil Line	· ·	•	a'
		a(1/8)	Ð	,	
508-0084	1	Grommet, Oil Line - Blower			· · · · · · · · · · · · · · · · · · ·
		Housing			•
154-1110	. 1	Manifold, Exhaust		· n	
154-0951	1	Manifold, Intake	1	· • • · · · · · · ·	. "
154-0973	. 2	Gasket, Exhaust Manifold			
134-2924	1	Housing, Blower			
134-1644	1	Housing, Cylinder Air-L/Hand	abi e		•
134-2916	$\overline{1}$	Housing, Cylinder Air-R/Hand	,		
103-0224	1::	Gearcase (Complete with Oil			1.3
	-	Seal)		*	
134-0675	1	Wheel, Blower (Includes Ring	*		
107 0070		Gear)	- `. (,	:	į.
104-0369	1	Screw, Flywheel Mounting			
526-0185	. †	Washer, Blower Wheel			•
104-0102	. <u>†</u> 1	Flywheel (Includes Bearing)			•
510-0020	1	Bearing (Flywheel)			
101-0372	1	Adapter, Clutch	,	F	
800-0050 «	<u>.</u> 4	Screw, Hex Head - Clutch	• _ '		
000-0030	<u> </u>	Adapter Mounting			
OFA AAFA	ŕ, A	Washer, Lock - Clutch Adapter		,	
850-0050	4			,	•
101 05/7	1	Mounting Alternator - Top Mounted	, 7 (f)	-	
191-0543	1 .	· · · · · · · · · · · · · · · · · · ·			
101 0710	1	(12 Volt)		· ·	
191-0642	1	Regulator - Voltage (12 Volt)	\frac{1}{3}		•
404 0550		- Top Mounted		-	
191-0638	. 1	Bracket, Regulator Mounting			
191-0623	1	Pulley, Alternator			
191-0636	1	Bracket, Alternator Mounting		V 1	
	4	- Top Mounted	1		
191-0637	* 1	Bracket, Alternator Mounting			
	ingen in de la company	- Top Mounted Adjusting			en e
191-0639	1	Baffle, Air		•	
511-0090	1 .	Belt, Alternator			
				1 5.0 °	Power
			_		



SUPPLEMENTARY PARTS LIST 900-43 (per above model and spec.) Parts listed below apply to the above model. Use these parts in place of (or in addition to) the parts listed for Parts Key $\frac{2}{1000}$ in the standard parts catalog No. $\frac{927-0404}{1000}$

PART NO.	QUAN.	DESCRIPTION
		NOTE: This model has a 35 ampere (Neg. ground) 12 Volt Alternator with Voltage Regulator
110-0915 104-0872 102-0772 120-0648 123-0694 191-0572 191-0537 191-0535 511-0051 191-0623 191-0574 134-0675 104-0369 134-2926 134-2791 150-0635 150-0698 150-0096 154-0951		Block Assembly, Cylinder (Includes Bearing, Guides and Seats) Crankshaft Base, Oil Intake, Oil Pump (Includes Cup, Screen & Pipe) Cap and Indicator, Oil Fill Alternator - 12 Volt - 35 Amp - Negative Ground Bracket, Alternator Mtg. Bracket, Alternator Mtg. Adjusting Belt, Alternator Drive Pulley, Alternator Regulator, Voltage - Alternator Wheel, Blower - Includes Ring Gear Screw, Flywheel Mtg. Housing, Blower Housing, Cylinder Air - Right/Hand Bracket, Governor Spring, Governor Stud, Governor Manifold, Intake
154-0998 154- 0973 505-0329	1 2 1	Manifold, Exhaust Gasket, Exhaust Manifold Pipe, Cap - Exhaust Manifold
\$- *'\h		NOTE: Alternator shown as Optional Equipment in Parts Catalog.
, and the		



CCKB-MS MODEL_

SUPPLEMENTARY PARTS LIST 900- 43 (per above model and spec.) Parts listed below apply to the above model. Use these parts in. place of (or in addition to) the parts listed for Parts Key 2 in the standard parts catalog No. 927-0404

=			
	PART NO.	QUAN.	DESCRIPTION
•	110-1957	1.	Block Assembly, Cylinder (Includes Bearing Guides
			and Seats)
	104-0883	1	Crankshaft
	105-0140	1	Camshaft (Includes Center Pins)
	102-0775	1	Base, Oil (Rear Drain)
	120~0648	1	Cup, Oil Pump Intake (Includes Cup, Screen
	e e e e e e e e e e e e e e e e e e e		and Pipe)
	123-0527	1	Cup and Indicator, Oil Fill
٠.	509-0090	2	Seals, Valve Stem Oil
	509-0110	1	Seal, Dust
	509-0123	1	Seal ,
	122-0320	1	Adapter, Oil Filter Mounting
•	122-0321	1	Gasket, Oil Filter Mounting
	122-0323	1	Filter, Oil (Spin On Type)
	122-0347	1	Seal, Air - Oil Filter
	526-0065	1 2	Washer, Copper - Oil Filter Adapter Mounting
•	800-0028	2	Screw, Hex Head Cap - Oil Filter Adapter Mounting
	149-0136	1. 1.	Cover, Fuel Pump Hole
` ,	526-0063	2	Washer, Copper - Fuel Pump Hole Cover Mounting
	800-0004	2	Screw, Hex Head Cap - Fuel Pump Hole Cover Mounting
	Bearing, Conne	ecting Ro	
	114-0145	2	Standard
	114-0145-02	2	.002" Oversize
	114-0145-10	2	.010"-Oversize
	114-0145-20	2 .	.020" Oversize
	114-0145-30	\ 2	.030" Oversize
	154-1116	~~~	Manifold, Intake
	154-1024	1 1	Manifold, Exhaust
	505-0057	1	Plug, Pipe - Intake Manifold
	140-0936	1	Adapter, Air Cleaner
1	505-0008	1 7	Plug Pipe (1/8) - Carburetor
٠.	502-0076	1	Elbow - Carburetor
,	870-0131	4 4	Nut, Hex (Keps 10-32) Governor Linkage
	F's		
	526-0196	1	Washer, Flat - Governor Linkage
•	150-0635	1	Bracket, Governor Linkage
4	<u>150-1339</u>	1	Bracket, Governor Assembly
•	150-1021	1	Lever, Throttle Control
	862-0001	2 = -	Nut, Hex (1/4-20)
	526-0209		Washer, Flat
	134-2933	1	Housing, Cylinder Air - Righthand Power
	103-0477	1 1	Gear Case - Complete Generation
SOR.	Downer	F .	

	A 70 B		1 '	
ت مساء م		2.4		at a more i ii
MOI				-MS∃
	16.			
		·		77 171 1 1

SPEC. 2759J

SUPPLEMENTARY PARTS LIST 900-43 (per above model and spec.)
Parts listed below apply to the above model. Use these parts in place of (or in addition to) the parts listed for. Parts Key 2 in the standard parts catalog No. 927-0404

PART NO.	QUAN.	DESCRIPTION
174 2700	•	Maria Diagram Tradada Diagram Caine
134-2388	1	Wheel, Blower - Includes Ring Gear
150-0698	1	Spring, Governor
160-1135	1	Box, Breaker - Ignition - Complete (Tall)
160-1042	1	Box, Breaker
160-0931	1	Guide, Plunger
160-0002	1	Point Assembly, Breaker
160-0349	1	Block and Terminal Assembly, Insulator
160-0075	1	Cam, Point Gap Adjusting
160-0428	• 1	Strap, Jumper
815-0285	3	Screw, Roundhead Machine (8-32 x 5/16" long)
312-0069	1	Condenser, Breaker Point
160-0261	1	Wick, Breaker Box
160-1041	1	Bushing, Breaker Box
160-1040	1	Gasket, Breaker Box
160-0723	1.	Plunger, Ignition - Breaker Box
802-0035	2	Screw, Socket Head Cap (1/4-20 x 7/8")
526-0214	2	Washer, Flat (1/4)
850-0040	· 2	Washer, Lock (1/4)
812-0077	. 2	Screw, Roundhead Machine (8/32 x 3/8")
. 141-0744	1	Carburetor, LPG - (Liquid Withdrawal)
134-2929	1	Housing, Blower
	+ //	-
4 7		Parts Not Furnished by ONAN:
	, ist	Air Cleaner





SPECIAL PARTS LIST FOR MODEL ______
FOR STANDARD PARTS REFER

CCKB-MS

2763J

0. م		AL GROUPS IN CATALOG ARE LISTED	· · · · · · · · · · · · · · · · · · ·	O. BÉLO	
PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Group - 6		Flywheel Alternator (Syncro)			
134-2824	1	Guard, Flywheel			
			e.		
	71				



SPECIAL PARTS LIST FOR	ΔM	ODEL
------------------------	----	------

FOR STANDARD PARTS REFER TO CATALOG 927-0404

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

Group - 3 Top Mounted Alternator	
Top Hourted Afternator	
110-1418 1 Block Assembly, Cylinder	
104-0882 1 Crankshaft	the first of the second second
105-0251 1 Camshaft	in the control of the second o
105-0030 1 Gear, Timing	
105-0058 1 Plunger, Camshaft	
105-0059 1 Spring, Camshaft Plunger	
102-0782 1 Base, Oil	
123-0576 1 Cap and Indicator, Oil Fill	-
123-0568 + 1 Tube, 0il Fill	9.
103-0224 1 Gearcase	
134-0675 1 Flywheel (Includes Ring Gear)	
501-0027 1 Line, 011	
508-0084 1 Grommet, Rubber	
502-0020 1 Elbow, Street (1/8)	
104=0102 1 Clutch, Flywheel	
101-0372 1 Adapter, Clutch	1.7
153-0327 1 Bracket, Choke	
518-0176 1 Clip, Cable	
154-1110 1 Manifold, Exhaust	
154-0973 2 Gasket, Exhaust Manifold	
134-2924 1 Housing, Blower	
134-1644 1 Housing, Cylinder Air L/H	4T.
134-2916 1 Housing, Cylinder Air R/H	
167-1463 1 Lead, Hi Tension	
167-1464 .1 Lead, Hi Tension	* .
To 1404 the dead, hi leasion	, ,
Parts Not Furnished By Onan	,
Governor and Associates Parts	•
The same and the s	n
	<i>\$</i> -:





SUPPLEMENTARY PARTS LIST 900-43 (per above model and spet.)

Parts listed below apply to the above model. Use these parts in place of (or in addition to) the parts listed for Parts Key 2 in the standard parts catalog No. *927-0404

PART NO.	QUAN.	DESCRIPTION
110-1957	1	Block Assembly, Cylinder (Includes Bearings, Guide and Seats)
104-0883	1	Crankshaft
105-0140	1	Camshaft (Includes Center Pins)
509-0090	2	Seal, Valve Stem Oil
509-0110	1	Segl, Dust
509-0123	1	Seal **
102-0775	1	Base, Oil (Rear Drain)
120-0648	1	Cup, Oil Pump Intake (Includes Cup, Screen and Pipe)
123-0527	1	Cup and Indicator, Oil Fill
BEARING, COM	NECTING F	(op
114-0145	2	Standard
114-0145-02		.002" Oversize
114-0145-10	2	.010" Oversize
114-0145-20	2	.020" Oversize
114-0145-30	2	.030" Oversize
RING SET, PI	STON	
113-0152	2	Standard
113-0152-05		.005" Oversize
113-0152-10	2	.010" Oversize
113-0152-20	2	.020" Oversize
113-0152-30		.030" Oversize
113-0152-40	2	.040" Oversize
122-0320	1	Adapter, Oil Fiter
122-0321.	1	Gasket, Oil Filter Adapter Mounting
122-0347	1 ,	Seal, Air - Oil Filter
122-0323	1	Filter, Oil (Spin on type)
526-0065	2	Washer, Oil Filter Mounting
800-0028	. 2	Screw, Oil Filter Mounting (5/16-18 x 1")
122-0345	1	Hose, Oil Drain
154-1116	1	Manifold, Intake
505-0057	1	Plug, Pipe - Intake Manifold
154-1024	1	Manifold, Exhaust
154-0973	2	Gasket Exhaust Manifold
149-1063	1	Baffle, Fuel Pump
134-2933	- 1	Housing, Cylinder Air - Righthand
134-2929	1	Housing, Blower
134-2388	1	Wheel, Blower (Includes Ring Gear)
150-0698	1	Spring, Governor
150-0635	1 1	Bracket, Governor Spring

SUPPLEMENTARY PARTS LIST 900-43 (per above model and spec.)
Parts listed below apply to the above model. Use these parts in place of (or in addition to) the parts listed for Parts Key 2 in the standard parts catalog No. 927-0404

The state of the s		
PART NO.	QUAN.	DESCRIPTION
103-0477	1	Gear Case - Complete
150-1339	1 1	Bracket, Governor Mounting
150-1021	71	Lever, Throttle Control
526-0209	1	Washer, Flat
862-0001	2	Nut, Hex (1/4-20)
160-1135	. 1	Box, Breaker - Complete (Tall)
160-1042	(I	Box, Breaker
160-0931	1	Guide, Plunger
160-0002	1	Point Assembly, Breaker
160-0349	1	Block and Terminal Assembly, Insulator
160-0075	1	Cam, Point Gap Adjusting
160-0428	1	Strap, Jumper
160-0261	1.	Wick, Breaker Box
. 160-1041	1	Bushing, Breaker Box
. 160-1040	1	Gasket, Breaker Box
160-0723	1	Plunger, Ignition Breaker Box
312-0069	1	Condenser, Breaker Points
815-0285	3	Screw, Roundhead Machine (8-32 x 5/16" 1g.)
802-0035	2	Screw, Socket Head Cap (1/4-20 x 7/8" 1g.)
812-0077	. 2	Screw, Round Head Machine (8/32 x 3/8" 1g.)
526-0214	2	Washer, Flat (1/4)
850-0040	2 _	Washer, Lock (1/4)
	V.	NOTE: Parts Not Furnished by ONAN.
·		
**************************************		Blower Housing Grille
1		Air Cleaner
•		





SPEC

SUPPLEMENTARY PARTS LIST 900-43 (per above model and spec.)
Parts listed below apply to the above model. Use these parts in place of (or in addition to) the parts listed for Parts Key________
in the standard parts catalog No.______

PART NO.	QUAN.	DESCRIPTION
		NOTE: This Model has a 15 Ampere Flywheel Charging Alternator.
110-1860	1	Block Assembly, Cylinder (Includes Bearings, Guides and Seats)
104-0872	1	Crankshaft
102-0759	$\frac{1}{1}$ $\frac{1}{1}$ \cdots	✓ Base, Oil
120-0648	1	Intake, Oil Pump - (Includes Cup, Screen & Pipe)
123-0694	1	Cap and Indicator, Oil Fill
122-0320	1	Adapter, Oil Filter
122-0321	1	Gasket, Oil Filter Adapter
505-0057	1 .	Plug, Oil Filter Adapter
122-0323	1	Filter, Oil
122-0347	1	, Seal, Oil Filter Air
134-2828	1	Housing, Blower
134-2791	1	Housing, Cylinder Air R/Hand
150-0635	1	Bracket, Governor Arm
150-0096	1,	Stud, Governor
150-0698 `	1	Spring, Governor
134-2621	1 *	Wheel, Blower (Includes Ring Gear)
191-0885	1	Stator -
191-0886	1	Regulator, Voltage
134-2100	2	Spacer, Voltage Regulator
191-1078	1	Bracket, Regulator Mtg.
154-0951	1	Manifold, Intake
	. ,	· · · · · · · · · · · · · · · · · · ·
•		



SPECIAL PARTS LIST FOR MODEL

QTY.

PART NO.

CCKB-MS

SPEC

2771J

FOR STANDARD PARTS REFER TO CATALOG_

DESCRIPTION

927-0404

PART NO. | QTY.

KEY NO.

DESCRIPTION

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

<u></u>				
		'		
Group - 5	Flywheel Alternator Phelon			
Group - 8	Spin On Oil Filter			
Group - 31	Carburetor (141-0744 LPG)			
110-1860 1	Block Assembly, Cylinder			
110-0893 2	Retainer, Valve Spring			
149-0136	Cover, Fuel Pump Hole		4	ar .
167-0188 2	Clip			
134-2824 1	Guard, Flywheel	5	*	
505-0057 1	Plug, Pipe 1/8			
134-2828 1	Housing, Blower	\.		
150-0635	Bracket, Governor Arm			
150-0698 1	Spring, Governor			
150-0096 1	Stud, Governor Adjusting	, a	•	
134-2760	Housing, Cylinder Air RH			T 1
505-0008 1	Plug, Pipe 1/8	•	F	
502-0039 1	E1bow		, •	t atron
150~0639 2	Joint, Ball	· ·		
520-0187 1	Stud, Governor Linkage Adj.		1434 - M	
· ·			4	



900-0043 Supplementary Parts List

	-	_	٠
1	Т		•
۰		•	,

· • ·				*	CC	CKB-MS	•	•	· 🛌 🖟	:	• - 27	775J		
IV	10(de	l		• •		2 5	1.3	_ Sמ	ec`		·	•	
				4	۰.			e,			,			

Standard Parts Catalog 927-0404 Parts Key 2

Parts Listed Below Apply to the Above Model. Use These Parts in Place of (or in Addition to) the Parts Listed in the Standard Parts Catalog.

102 509 509 103 103 104 RIN 113 113 113 114 114 114 114 114 114 114	0-1904 4-0883 9-0123 9-0110 5-0135 5-0332 4-0032 NG SET, PISTON 3-0152 3-0152-05 3-0152-10 3-0152-20 3-0152-20 3-0152-40 ARING, CONNECT 4-0145 4-0145-02 4-0145-20 4-0145-30	2 2 2 2 2 2 - 2		Block Assembly, Cylinder Crankshaft Seal, Crankshaft Seal, Dust Camshaft Gear Assy., Camshaft Timing Gear, Crankshaft Timing Standard .005" Oversize .010" Oversize .020" Oversize .030" Oversize .040" Oversize .040" Undersize .040" Undersize	
102 509 509 103 103 104 RIN 113 113 113 114 114 114 114 114 114 114	4-0883 9-0123 9-0110 5-0135 5-0332 4-0032 NG SET, PISTON 3-0152 3-0152-05 3-0152-10 3-0152-20 3-0152-30 3-0152-40 ARING, CONNECT 4-0145 4-0145-02 4-0145-10 4-0145-30	1 1 1 1 1 2 2 2 2 2 2 2 1NG ROD 4 4 4 4		Crankshaft Seal, Crankshaft Seal, Dust Camshaft Gear Assy., Camshaft Timing Gear, Crankshaft Timing Standard .005" Oversize .010" Oversize .020" Oversize .030" Oversize .040" Oversize .040" Undersize .010" Undersize	
102 509 509 103 103 104 RIN 113 113 113 114 114 114 114 114 114 114	4-0883 9-0123 9-0110 5-0135 5-0332 4-0032 NG SET, PISTON 3-0152 3-0152-05 3-0152-10 3-0152-20 3-0152-30 3-0152-40 ARING, CONNECT 4-0145 4-0145-02 4-0145-10 4-0145-30	2 2 2 2 2 - 2 TNG ROD 4 4 4 4		Crankshaft Seal, Crankshaft Seal, Dust Camshaft Gear Assy., Camshaft Timing Gear, Crankshaft Timing Standard .005" Oversize .010" Oversize .020" Oversize .030" Oversize .040" Oversize .040" Undersize .010" Undersize	
509 509 109 109 109 113 113 113 114 114 114 114 114	9-0123 9-0110 5-0135 5-0332 4-0032 NG SET, PISTON 3-0152 3-0152-05 3-0152-10 3-0152-20 3-0152-30 3-0152-40 ARING, CONNECT 4-0145 4-0145-02 4-0145-10 4-0145-30	2 2 2 2 2 - 2 TNG ROD 4 4 4 4		Seal, Crankshaft Seal, Dust Camshaft Gear Assy., Camshaft Timing Gear, Crankshaft Timing Standard .005" Oversize .010" Oversize .020" Oversize .030" Oversize .040" Oversize .040" Undersize .010" Undersize	
509 109 104 RIN 113 113 113 114 114 114 114 114 509 120 103 123 134	9-0110 5-0135 5-0332 4-0032 NG SET, PISTON 3-0152 3-0152-05 3-0152-10 3-0152-20 3-0152-30 3-0152-40 ARING, CONNECT 4-0145 4-0145-02 4-0145-10 4-0145-30	2 2 2 2 2 - 2 TNG ROD 4 4 4 4		Seal, Dust Camshaft Gear Assy., Camshaft Timing Gear, Crankshaft Timing Standard .005" Oversize .010" Oversize .020" Oversize .030" Oversize .040" Oversize .040" Undersize .010" Undersize	
105 105 107 RIN 113 113 113 114 114 114 114 114 116 506 120 103 123 134	5-0135 5-0332 4-0032 NG SET, PISTON 3-0152 3-0152-05 3-0152-10 3-0152-20 3-0152-30 3-0152-40 ARING, CONNECT 4-0145 4-0145-02 4-0145-10 4-0145-30	2 2 2 2 2 - 2 TNG ROD 4 4 4 4		Camshaft Gear Assy., Camshaft Timing Gear, Crankshaft Timing Standard .005" Oversize .010" Oversize .020" Oversize .030" Oversize .040" Oversize .040" Undersize .010" Undersize	
103 104 RIN 113 113 113 114 114 114 114 509 120 103 123 134	5-0332 4-0032 NG SET, PISTON 3-0152 3-0152-05 3-0152-10 3-0152-20 3-0152-30 3-0152-40 ARING, CONNECT 4-0145 4-0145-02 4-0145-10 4-0145-30	2 2 2 2 2 - 2 TNG ROD 4 4 4 4		Gear Assy., Camshaft Timing Gear, Crankshaft Timing Standard .005" Oversize .010" Oversize .020" Oversize .030" Oversize .040" Oversize .040" Undersize .010" Undersize	
104 RIM 113 113 113 114 114 114 114 114 114 114	4-0032 NG SET, PISTON 3-0152 3-0152-05 3-0152-10 3-0152-20 3-0152-30 3-0152-40 ARING, CONNECT 4-0145 4-0145-02 4-0145-10 4-0145-30	2 2 2 2 2 - 2 TNG ROD 4 4 4 4		Gear, Crankshaft Timing Standard .005" Oversize .010" Oversize .020" Oversize .030" Oversize .040" Oversize .040" Undersize .010" Undersize	
RIN 113 113 113 113 114 114 114 114 509 120 103 123 134	NG SET, PISTON 3-0152 3-0152-05 3-0152-10 3-0152-20 3-0152-30 3-0152-40 ARING, CONNECT 4-0145 4-0145-02 4-0145-10 4-0145-20 4-0145-30	2 2 2 2 2 - 2 TNG ROD 4 4 4 4		Standard .005" Oversize .010" Oversize .020" Oversize .030" Oversize .040" Oversize Standard .002" Undersize .010" Undersize	
113 113 113 113 114 114 114 114 114 509 120 103 123 134	3-0152 3-0152-05 3-0152-10 3-0152-20 3-0152-30 3-0152-40 ARING, CONNECT 4-0145 4-0145-02 4-0145-10 4-0145-20 4-0145-30	2 2 2 2 2 - 2 TNG ROD 4 4 4 4		.005" Oversize .010" Oversize .020" Oversize .030" Oversize .040" Oversize Standard .002" Undersize .010" Undersize	
113 113 113 113 114 114 114 114 509 120 103 123 134	3-0152-05 3-0152-10 3-0152-20 3-0152-30 3-0152-40 ARING, CONNECT 4-0145 4-0145-02 4-0145-10 4-0145-20 4-0145-30	- 2 TNG ROD 4 4 4 4		.005" Oversize .010" Oversize .020" Oversize .030" Oversize .040" Oversize Standard .002" Undersize .010" Undersize	
113 113 113 114 114 114 114 509 120 103 123 134	3-0152-10 3-0152-20 3-0152-30 3-0152-40 ARING, CONNECT 4-0145 4-0145-02 4-0145-10 4-0145-20 4-0145-30	- 2 TNG ROD 4 4 4 4	The second secon	.010" Oversize .020" Oversize .030" Oversize .040" Oversize Standard .002" Undersize .010" Undersize	
11: 11: 11: 11: 11: 11: 11: 11: 50: 12: 10: 12: 13:	3-0152-20 3-0152-30 3-0152-40 ARING, CONNECT 4-0145 4-0145-02 4-0145-10 4-0145-20 4-0145-30	- 2 TNG ROD 4 4 4 4		.020" Oversize .030" Oversize .040" Oversize Standard .002" Undersize .010" Undersize	
113 BE/ 114 114 114 114 509 120 103 123	3-0152-30 3-0152-40 ARING, CONNECT 4-0145 4-0145-02 4-0145-10 4-0145-20 4-0145-30	- 2 TNG ROD 4 4 4 4		.030" Oversize .040" Oversize Standard .002" Undersize .010" Undersize	
113 BE/ 114 114 114 509 120 103 123 134	3-0152-40 ARING, CONNECT 4-0145 4-0145-02 4-0145-10 4-0145-20 4-0145-30	- 2 TNG ROD 4 4 4 4		.040" Oversize Standard .002" Undersize .010" Undersize	
BEA 114 114 114 114 509 120 103 123 134	ARING, CONNECT 4-0145 4-0145-02 4-0145-10 4-0145-20 4-0145-30	4 4 4 4		Standard .002" Undersize .010" Undersize	
114 114 114 114 509 120 103 123 134	4-0145 4-0145-02 4-0145-10 4-0145-20 4-0145-30	4 4 4 4		.002" Undersize .010" Undersize	
114 114 114 509 120 103 123 134	4-0145-02 4-0145-10 4-0145-20 4-0145-30	4 4		.002" Undersize .010" Undersize	
114 114 509 120 103 123 134	4-0145-10 4-0145-20 4-0145-30	4 4		.010" Undersizé	
114 509 120 102 103 123 134	4-0145-20 4-0145-30	4		·	
114 509 120 102 103 123	4-0145-30	1 1	1	.020" Underŝize"	
509 120 102 103 123		1 4		.030" Undersize	,
120 102 103 123 134	9-0090,	2		Seal, Oil-Valve stem	•
102 103 123 134	0-0648	1 1		Cup, Oil Pump Intake	# 7-
103 123 134	2-0791	1 1		Base, Oil	
123 134	3-0477	1 1		Cover Assembly, Gear	
134	3-0694	1 1	-	Cap and Indicator, Oil Fill	•
	4-2388	1 1 -		Flywheel and Ring Gear	·
- 10	4-3002	1 1	-	Housing, Blower	1
	0-1339	1 1		Bracket, Governor Throttle	· ,
1 10	0-1021	1 . 1 .	,	Lever, Governor Throttle	
9	7-0237	*2	¥.	Plug, Spark - Resistor	
	7 ₁ -1560	1, [· .	Cable, Spark Plug - Hi Tension - 24"	
	7-1581	1 1		Cable, Spark Plug - Hi Tension - 15"	.
1	1-0689	1 1		Carburêtor - Complete Breakdown in Mai	n Parts C
	0-1087	1 1		Gasket, Air Cleaner	
	4-2941	1 1		Housing, Cylinder Air - R.H.	
	0-0698	$\begin{vmatrix} 1 \end{vmatrix}$	i dia	Spring, Governor	, v
The state of the s	3-0958:	2		Screen, Breather Tube	ower
					eneration

SUPPLEMENTARY PARTS LIST 900-43 (per above model and spec.)
Parts listed below apply to the above model. Use these parts in place of (or in addition to) the parts listed for Parts Key 2 in the standard parts catalog No. 927-0404

PART NO.	QUAN.	DESCRIPTION
S. S. S.	b	
		This model has a High Performance Governor and
٠	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	has Vacu-Flo Cooling
110 1070		
110-1832	1	Block Assembly, Cylinder (Includes Bearings Guides &
104-0872	1 L	Crankshaft
102-0772	1	Base, Oil
120-0648	1	Intake, Oil Pump (Includes Cup, Screen & Pipe)
123-0694		Cap & Indicator, Oil Fill
122-0320	1 1	Adapter, Oil Filter
122-0321	1	Gasket, Oil Filter Adapter Mounting
122-0323	1 .	Filter, Oil (Spin on Type)
122-0347	1	Seal, Air Oil Filter
503-0391		Line, Oil Drain - Oil Filter
800-0028	. 2	Screw, Hex Head - Oil Filter Adapter Mounting
526-0065	2	Washer, Copper - Oil Filter Adapter Mounting
110-1037	2	Valve, Intake
509-0090	2	Seal, Oil - Valve Stem
154-1364	1	Manifold, Exhaust
154-1338	1	Manifold, Intake 🧖
149-0136	1 1	Cover, Fuel Pump Hole
800-0004	2	Screw, Hex Head - Fuel Pump Hole Cover Mounting
- 526-0063	2	Washer, Copper - Fuel Pump Hole Cover Mounting
503-0582	1	Hose, Breather
140-1067	1	Bracket, Air Cleaner
140-1066	\downarrow 1	Cover, Air Cleaner - Outlet
140-1061	1	Cover, Air Cleaner - Inlet
140-1071	• 1	Edement, Air Çleaner
140-1073	1 1	Clamp, Air Cleaner
503-0311	*· · 1	Clamp, Hose - Air Cleaner
140-1075	1	Elbow, Air Inlet &
815-0178	2	Screw, Hex Head Ar Cleaner Bracket Mounting
526~0234	. 2	Washer, Flat - Air Cleaner Bracket Mounting
850-0030	2	Wäsher, Lock - Air Cleaner Bracket Mounting
141-0726	10.33	Carburetor (Gas)
150-0096	1	Stud, Governor
- 1 5 0-1264		Spring, Governor
503-0004	1	Clamp, Air Cleaner Hose
815-0235	7 2	Screw, Air Cleaner Mounting
853-0013	2 2	Washer, Lock Air Cleaner Mounting
134-2943	1 .	Housing, Blower Power
<i>1</i> ∙134-′2215 · · ·	1 1 .	Scroll Generation

SUPPLEMENTARY PARTS LIST 900- 43 (per above model and spec.) Parts listed below apply to the above model. Use these parts in place of (or in addition to) the parts listed for Parts Key_in the standard parts catalog No. 927-0404

and the second		
PART NO.	QUAN.	DESCRIPTION
134-2760 134-0753 191-0134 517-0021 517-0035 800-0511 821-0008 515-0198 120-0698 193-0171	1 1 2 2 4 4 1	Housing, Cylinder Air R/Hand Wheel, Blower (Vacu-Flo Cooling) Pulley, Generator Button, Dot Button, Dot Screw, Hex Head - Blower Wheel Mounting Whizlock, Scroll Mounting, Key, Crankshaft Line, Oil Bracket, Fittings
		NOTE: Parts Not Furnished by ONAN: Ignition Coil High Tension Leads

SPECIAL PARTS LIST FOR MODEL GCRB MS

2807J

FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY NO.

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

	PART NO.	QTY.	DESCRIPTION "		PART NO.	OTY.	DESCRIPTIO
,	Group - 1	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	Alternator, Left Side Mtg	• "			
19	102-0791		Base, Oil		A Section of the sect		
	150-0755	~ 1	Arm, Governor				
	150-0698	10	Spring, Governor				
1.	150-0096	1	Sutd, Governor Adjusting	S 8 2 35			
	505-0057	1	Plug, Pipe 1/8				
'	134-1684"	1	Flywheel (Includes Ring C	Gear')			,
٠.	134-2926	1.	Housing, Blower				ute s
	155-0906	1	Muffler, Exhaust				•
	154-0973	2	Gasket, Exhaust Muffler 🖡	(tg.			
	505-0618 🛶	1	Cap, Pipe 🐃 👡	9	***	. 4	·
	150-0639/	2 .	Joint, Ball				
•	520-0187	. 1	Stud, Governor Linkage Ad	IJ.			
	•	ji.	16.				4





٠	~	~	17	73		114	\sim	•
•	u	۱.	N	Б	-	М	2	

SUPPLEMENTARY PARTS LIST 900-43 (per above model and spec.)

Parts listed below apply to the above model. Use these parts in place of (or in addition to) the parts listed for Parts Key 2 in the standard parts catalog No.__

, 	<u> </u>	
PART NO.	QUAN.	DESCRIPTION
9	•	NOTE: This Model has a 12-Volt, 35-Amp - Top Mounted Alternator
110-0915	1	Block Assembly, Cylinder (Includes Bearings,
		Guides and Seats)
104-0872	1	Crankshaft
102-0756	1 1	Base, Oil
120-0648	- 1. /	Intake, Oil Pump (Includes Cup, Screen & Pipe
123-0527	1 1	Cap and Indicator, Oil Fill
123-0679	1 - 1 -	Tube, Oil Fill
134-0675	1	Wheel Blower (Includes Ring Gear)
104-0369	1	Screw, Flywheel Mounting
134-2924	1	Housing, Blower
134-1644	1	Housing, Cylinder Air L/Hand
134-2916	1	Housing, Cylinder Air R/Hand
140-0921	1	Gasket, Air Cleaner Mtg.
191-0643.	1	Alternator - 12 Volt - 35 Amp - Top Mounted
191-0636	$\frac{1}{1}$	Bracket Alternator Mtg.
191-0637	1	Bracket - Alternator, Mtg.
191-0639	$-\frac{1}{1}$	Baffle, Alternator
511-0090	1 7	Belt, Alternator
154-0951	1 1	Manifold, Intake
154-0998	1	Manifold, Exhaust
154-0973	1 2	» Gasket, Exhaust Manifold
505-0329	1	Cap, Pipe - Exhaust Manifold
*		
*		
•		





2811J

SPECIAL PARTS LIST FOR MODEL GCKB-MS SPEC FOR STANDARD PARTS REFER TO CATALOG 927-0404

· KEY NO.

	···	GROUPS IN CATALOG ARE LIST	ED BY GROUP N	O. BELOW	WHEN USED.		
PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	* DESCRIPTION		
Group - 1	A	lternator, Left Side Mtg.		• 1.0			
Group - 22°		ariable Speed Governor					
102-0791	1 B	ase, 0i1 😽		7.4			
134-0675 134-2924	1 F	lywheel (Includes Ring Gear) ousing, Blower			, A		
·							
					*		
			*				
	/ •			* *. •			
			e di	t e *			
	2_00				***		
	*						
		4.			₩		
	in de la companya de La companya de la co	*		,			
	ė, a						
			*:	And			
				· \$ 4.	, s = 1		
				•			
*				***			
للمنظورة الأسراء المنظورة الأسراء المنظورة الأسراء	<u> </u>				المنال الشار المعالم ا		
			a				
	•			· · · · · · · · · · · · · · · · · · ·			
	e s						
		,		a ·			
					and the state of t		
1			1		*		
		5					
	y				A. A.		
					Current Power Generation		
	Wer	The polytomeranian and the second	S. Amer		A Company of the Company		

__ **SPEC** 927-0404

PART NO.	QTÝ,	DESCRIPTION		PART NO.	QTY.	DESCRIPTION
				T	Τ	3 m ² /3
Group - 14		Vacu Flo Cooling			•	
Group - 20	• .	Thermo Magnetic Choke	<i>F</i>	•		
Group - 28		Carbure or (141-0690)				*
Group - 20	i diamenta	Carnare of (1741-0030)				
134-0599		Clip, Cyl. Air Housin				
150-1016		Arm, Governor	ب _ا "	•	ž,	
501-0203	· · · · · · · · · · · · · · · · · · ·	Line, 0i1				
502-0020	. L .	Elbow	√ № ~	(*		
149-1097	* <u>1</u>	Line, Fuel		· ·	* *	
134-0753		Wheel, Blower				
134-0564	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Scroll, Blower Housin				
134-2996	1. #	Guard, Blower Housing				
154-1051	1. T.	Manifold, Intake	3. . ∖	e e e e e e e e e e e e e e e e e e e		
154-0998	. ⊥ \ . 1,***,**		\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	Altri A	· /	
154-0973	Ž.	Gasket, Exhaust Manif	ental Mea			
505-0329		Cap, Pipe	71.5		and the same of the same	· · · · · · · · · · · · · · · · · · ·
309-0237	. 2 *	Switch, Oil Pressure				
302 0058	*2 ** . 1	Tee, Pipe				· ·
505-0057 *.	. 1	Plug, Pipe		*	Dad	
191-01-71	-	Bracket & Fitting Ass	\$ 14P			X2 ,02 H
150-0698	j. 1	Spring, Governor	, ,	· ** -		
517-0035	1	Button, Dot		. Ass		
517-0021	1 T ,	Button, Dot	· · · · · · · · · · · · · · · · · · ·	38	10	
134-2961	1.	Housing, Blower		*	1 454	***
1234, 2302	. + .	110001115	÷.	AND THE RESERVE OF	DB	
,						
		The Mark the Committee of the Committee	~	**** <u>-</u> _		in a
	`.	the state of the s	<i>y</i>			ma .
A Company		the state of the s	· .			
		a residence	λ.			
		· · · · · · · · · · · · · · · · · · ·			ń,	n'
and the second s		الدوارية الروادية المحمولة والمستوادية المحمولة المحمولة المحمولة المحمولة المحمولة المحمولة المحمولة المحمولة المحمولة المحمولة ال		e de la companya de La companya de la co	, , , , , , , , , , , , , , , , , , , 	·· · · · · · · · · · · · · · · · · ·
			,e			
			, ,	, ,	• .	





2830J

SPECIAL PARTS LIST FOR MODEL CCKB-MS SPEC 2830
FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY N
OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

KEY NO.

PART NO.	QTÝ	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
4:		*	, ,		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
Group - 8		Spin On Oil Filter	. *		
Group -19		High Profile Breaker Box			4
110-1957	1	Block Assembly, Cylinder		Ì,	
110-1827	2	Guide, Intake Valve	ens e		
509-0090	· . 2	Seal, Valve Stem Oil	<i>'</i>		
509-0123	1	Seal, Crankshaft Oil			
509-0110	$\bar{1}$	Seal, Dust			¥
104-0872	1.	°Crankshaft			*
113-0152	· 2	Ring Set, Piston			
114-0145	4	Bearing, Connecting Rod			
105-0140	1. 1.	Camshaft		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	/* · · · · · · · · · · · · · · · · · · ·
.103-0477	.1	Gearcase (Complete)		and the second s	,
7509-0105	1	Seal, Dust	, , , ,		•
50 9 -0126	1	Seal, Dust			.'.
-149 - 1063	1 · · ·	Baffle, Fuel Pump	A)		
123-0527	• 1.	Cap & Indicator, 011 Fill	7.		
12B-05 ₀ 8	1.	Tube, Oil Fill			
154-1116	11 -	Manifold Intake			•
154-1024	1	Manifold, Exhaust		. 64	i i
154-0973	. 2 ≥	Gasket, Exhaust Manifold Mtg.		. /	
150+0635	1	Bracket, Governor Linkage			
150-0698	1	Spring, Governor	*		(
505-0057	. 1	Plug, Pipe			
134-2388	$\sim 1^{\circ}$.	Flywheel (Includes Ring Gear)			,
134-2933	1	Housing, Cylinder Air RH			
134-2929	1	Housing, Blower	1.		
150-1339	1 .	Bracket, Governor			
150-1021	1	Lever, Throttle Control		* -1 ***	
r in English and a second	 -1	g	" " " V ly.		* * * * * * * * * * * * * * * * * * *
• .	+ +				e e e e e e e e e e e e e e e e e e e
نست د ماگر در این شماسه شدیسه ۲۰۰۵ صدالت این این در ۱۰۰۸ در		the state of the s		e e e e e e e e e e e e e e e e e e e	
₹ 6 c	.".		1	•	
4					€0.
	·			~ {	
Age Control					
AV.	×		»	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	





2849J

SPECIAL PARTS LIST FOR MODEL _____CCKB-MS ______
FOR STANDARD PARTS REFER TO CATALOG_

___**SPEC** 927-0404

KEY NO.

PART NO. OTY DESCRIPTION PART NO. OTY. DESCRIPTION Group - 6 Flysheel Alternator (Syncro) Group - 22 Variable Speed Governor 134-2824 1 Guard Flysheel Screw 505-0057 1 Plug, Pipe 1/8	0	PTIONAL GRO	UPS IN CATALOG A	ARE LISTED	BY GROUP N	O. BELOW W	VHEN USED.
Group - 22 Variable Speed Governor 134-2824 1 Guard, Flywheel Screw 505-0057 1 Plug, Pipe 1/8	PART NO.	QTY.	DESCRIPTION		*PART NO.	QTY.	DESCRIPTION
505-0057 1 Plug, Pipe 1/8	Group - 6 Group - 22	Flywhe Variab	el Alternator (S) le Speed Governo	ynero)	***		
	134-2824 505-0057	1 Guard, 1 Plug,	Flywheel Screw Pipe 1/8				
	u a					•	
						e e	
			•			en e	•
		m. « ma					
						.e	
	· · · · · · · · · · · · · · · · · · ·			^-	•	* • • • • • • • • • • • • • • • • • • •	
					i i i i i i i i i i i i i i i i i i i		
	A			A CONTRACTOR OF THE PARTY OF TH		· · · · · · · · · · · · · · · · · · ·	
Power Generation							Power Generation



CCKB-MS

. <mark>28</mark>53ፓ

SPECIAL PARTS LIST FOR MODEL CCKB-MS SPEC SPEC FOR STANDARD PARTS REFER TO CATALOG 927-0404

KEY NO.

roup - 5 roup - 8		*	- T	1000
	**			
	to	ye.	and Garage	
roup - 8	Flywheel Alternator (Phelon)		, .	
٠.১	Spin On Öil Filter	n .		Ch.
10-1860 1	Riccle Accombing Culinder		·	
34-2828 1	Block Assembly, Cylinder Housing Blower		- 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1	
34-2760 1	Housing, Cylinder Air RH			•
50-0635 1 °	Bracket, Governor Linkage	* 9.		· · · · · · · · · · · · · · · · · · ·
500096 1	Stud Covernor Adjusting	.		0
50-0698 1	Spring, Governor			
			**	
			S.	, , , , , , , , , , , , , , , , , , ,
		4	, <u> </u>	
		*,		· ·
*			,	•
			, *	
		c *** *** ****		·
	<i>**</i>			
		` •		
ye da a		3	- <u> </u>	
	· .	*	• .	s.
*			n i	e grand de la companya de la company
· · · · · · · · · · · · · · · · · · ·	9		ā	· · · · · · · · · · · · · · · · · · ·
*		:	.*	
		Se Se	**	
•		41	% √2.	
**			•	(,
				, wa
		A. V.	·	' [†] .
				,
*			of the second se	•
#		(4)	Mrs. I	The second second
	Ann.	£ 40		A STA
The second second				A Print
			The state of the s	
		-	441	The state of the s
A STATE OF THE STA		F 11.20 8		Power
		E. T. Same		Generation

900-0043-Supplementary Parts List

Model	CCKB-MS	<u> </u>	Spec	2854J		
Standard	Parts Catalog	g	927-0404		_Parts Key	2'*

Parts Listed Below Apply to the Above Model. Use These Parts in Place of (or in Addition to) the Parts Listed in the Standard Parts Catalog.

PART NO.	QUAN.	DESCRIPTION	
		NOTE: This model has a Variable Speed	Governor.
		Full Flow Oil Filter and 12 Volt	
and the second s		Flywheel Alternator. Complete b	
		in Main Parts Catalog.	,
		The state of the s	· • •
1.10 - 1860	1 1	Block Assembly, Cylinder -	. á.,
104-0872	1	Crankshaft	
120-0648	i	Cup, Oid Pump Intake	8 yan
102-0759	1	Base, 0il	A Part of the second
167-0188	2	Support, Clip Hi Tension Cable	Market .
336-2192	1	Lead Assy. = 24"	
123-0694	1	Cap and Indicator, Oil Fill	
134-2984 *	1	Housing, Blower	
167-0237	2	Plug; Spark - Resistor	4
141-0689	1	Carburetor - Complete breakdown in Mair	n Parts Cat
153-0464	1	Bracket, Choke Arm	
153-0351	1	Choke Assembly	w S
140-1087	1	Gasket, Air Cleaner	
134-2760 *	1	Housing, Cylinder Air - R.H.	***
3 23÷0958 °	. 2 .	Screen, Breather Tube	
A. Marie			·
			4.
W		-	
Ser.			,
		•	
	_		



900-0043 Supplementary Parts List

Model CCKB-M	ns,	Spec 2859J		<u> </u>
*	,	200		•
Standard Par	ts Catalog	927-0404	Parts Kev	2

Parts Listed Below Apply to the Above Model. Use These Parts in Place of (capacition to) the Parts Listed in the Standard Parts Catalog.

	PART NO.	QUAN.	DESCRIPTION	
. e c.	r			i Aski
	154-0951	1	Manifold, Intake	
	154-0998	1.	Manifold, Exhaust	, 4° j ' e fr.
· Sep	505-0329	*1	*Cap, Pipe	- · · · · · · · · · · · · · · · · · · ·
	141-0281	1 1	Gasket, Carburetor Flange	
	154-0973	2	Gasket, Exhaust Manifold	
* p	153-0327	$\mathbf{I}^{\mathbf{r}}$	Bracket, Choke	
(*************************************	191-1095	- , 1	Stator (20 Ampere).	*8
	191-0938	1	Rectifier, Voltage	,
	191-0939	ľ	Regulator, Voltage	
	191-1107	1 2	Bracket, Rectifier/Regulator Mounting -	· 15
, 2	134÷2100 502-0020°	2 ,	Spacer, Regulator Mounting	ř
₿.	302-0020	1	Elbow, Street - Fuel Pump Inlet	*
19 Con				18 13
		*		,
		* .		·r.
•	4			, ,
	•			
				• •
				. 6
		•		
	.			
		* , , , , , , , , , , , , , , , , , , ,		,n
-05				, t
	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1	· · · · · · · · · · · · · · · · · · ·	
4				. •
и ' 🐇 .		N		
الله الله الله الله الله الله الله الله				
		The state of		
				* .
gr (c.		· 人、水水杨		
No.	***			∌ ;
		The second of th	- 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	

Model CCKB-MS	4	Spec	 	
Standard Parts	Catalog	927-0404	Parts Key	2

PART NO.	QUAN.	DESCRIPTION
	18	
		NQTE: This Model has a 20 Ampere Flywheel
		Charging Alternator
	*	
110-1418	1 7	Block Assembly, Cylinder (Includes Bearings,
		Guides and Seats)
104-0878	1 🚸	Crankshaft
102-0759	1	Base, Oil
120-0648	1	Intake, Oil Pump (Includes Cup, Screen & Pipe)
123 0694	1 1 1	Cap and Indicator, Oil Fill
502,0020	\mathbf{p}_{d}	Line Oil
501-0203		Line, Oil Top of Blower Housing
\$08-0084		Grommet, Oil Line Housing, Cylinder Air R/Hand
134-2791 134-2642	1	Wheel, Blower (Includes Ring Gear & Magnet)
134-2995	1	Housing, Blower *
502-0055	1	Elbow, Pipe (90°)
502-0002	1	Elbow, Inverter Male (90°)
193-0005	ī	Gauge, Oil Pressure
193-0031	1	Clamp, Oil Gauge
152-0041	%1	Washer, Spring Tension
	1	Arm, Variable Speed Governor Control
192-0397	$1,\sqrt{-2}$,	Sheave, Rope
302-0060	1, 1	Ammeter, Charge 20-0-20
309-0029	1	Switch, Start
	.1	Switch, Ignition
- 301-2780	1	Panel, Control
PISTON AND PIN	Includes	Retaining Rings)
112-0073	2	Standard .005" Oversize
112-0073-05 112-0073-10	2	.010" Oversize
112-0073-10	2	,020 Oversize
112-0073-20		.030" Oversize
112-00-73-40.	2	040" Oversize
RING SET, PISTO	_	
113-0126	2	Standard
113-0126-05	2.	.005" Oversize
113-0126-10	2 .	.010" Oversize
113-0126-20	2	020" Oversize (
12340126-30	_ 2 ·]	.030" Oversize
113-0126-40	2 ***	.040" Oversize

The following catalog has gaps in its page numbers, or doesn't have any numbers. We have chosen to leave the page numbering in the order that Acrobat assigns it.



THIS <u>LEGACY</u> DOCUMENT CONTAINS SOME IMAGES THAT ARE OF POOR QUALITY. THE SEARCH FEATURE WILL BE OF LIMITED USE WITH THIS DOCUMENT. THE DOCUMENT CAN BE PRINTED OR YOU CAN LOCATE THE MODEL AND SPEC IN THE INDEX TO FIND THE ALPHANUMERIC PAGE NUMBER.



Supplementary Parts List

9	V	E) (d	e	ز ا		C	C	KΒ	-l	1S	14.1 14.1 15.1	3	*	,		, t	• (S	6	ec		,	28	61	J.		ġ. Gv.			j.			1 (1) 1 (1) 1 (1)			$\epsilon_{i_2} \dots$	
7				97	(T).	62		. 2, .		77	,) 		i.						7.1	Γ,		7.7	14.1				1.19	J. 10.	36		•		T; [7]				-6	
1		Ì:	<u>.</u>	h	A	ar	Ä	P	a	H	œ.	•			9	ما	-		9	27	7 –	0,4	0	4	**	ند :	 		p	آھ	rt.	s Ì	Z.	a u	ic 🚣	ن	_ 2	Ans.	

	PART NO.	*	QUAN,	DESCRIPTION
To the second				NOTE: Unit has Magneto Ignition System.
		, ·	4 4 3 5 10	Complete breakdown in Main Parts Catalog.
	110-0915		1	Block Assembly, Cylinder
	104-0887		1.	Crankshaft
الآب مقيد	\$15-0130	_		Key, Crankshaft Stub
	105-0234		1	Camshaft - Includes Center Pins and Spark Advance
	120-0648	: \$ N	1	Mechanism Pins Cup, Oil Pump Intake
	102-0828		1	Base, Oil
<i>i</i>	516-0141		2	Pin, Gear Cover
e e ak	167-0188	* 1. j	4	Clip, Spark Plug Cable
	160-0752		ĺ	Magneto Stator Assembly
· ·	167-1557	الجري إلا	1	Cable, Spark Plug - Hi Tension - 17"
*, *,	. 167-1559	T .	1 4	Cable, Spark Plug - Hi Tension - 19"
, ",	123-0527	,	1	Cap and Indicator, Oil Fill
	123-0679		1	Tube, Oil Fill
•	123-0958	, ,	. 2	Screen, Breather Tube
•	160-0948		1	. Wheel, Magneto - Includes Magnets and Ring Gear
÷	~ * 501-0203 <u>}</u> •		1	Line, Oil
*	134-2998		1	Housing, Blower
	. 308-0029	•	- 1	Switch, Start
	338-0565	٠.	1	Harness, Start Switch
	193-0005	•	1	Gauge, Oil Pressure
. e ef	517-0009	• •	1 7	Plug, Dot Button
e .º .	313-0018	lı fe ,	1 1	Switch, Ignition Stop
. ė.	334-0028	٠	1	Lead, Ignition Stop
··· · · · · · · · · · · · · · · · · ·	167-0237		1 2	Plug, Spark - Resistor Muffler
	505-0618 .		1	Cap, Muffler
	503-0016	*.	1 1.	Clip, Choke Cable
	153-0327		1	Bracket, Choke Cable
	141-0689		1 .	Carburetor - Complete Breakdown in Main Parts
**************************************	# - # 0002	,	7 %	Catalog.
*	- 1 5 4-0973		2.1	Gasket, Exhaust Mahifóld
1500	149-1024	. *	1 1	Rod, Fuel Pump Primer
	150-0147	, •	1	Stud, Governor Speed

Supplementary Parts List

2863J

for

Moděl

CCKB-MF / Spec

Standard Parts Catalog &

927-0404

Parts Key _

State of the Contract of the C		*	
*	PART NO.	QUAN.	DESCRIPTION
		1 1	
	And the second s		NOTE: This model has a 12 Volt; 35 Amp -
			Negative Ground Alternator and a
			Clutch
erio de la composición dela composición de la composición dela composición de la composición de la composición de la com	110-1418	. 1	Block Assembly, Cylinder (Includes Bearings,
	engag (1. kuli 1. kuli Tanan manada ing panganan mana	*	Guides and Seats)
· · · · · · · · · · · · · · · · · · ·	104-0877	1	Crankshaft
	102-0772	1	Base, Oil
	120-0648	1	Intake, Oil Pump (Includes Cup, Screen & Pipe)
See and the second	190-0267	· · · · 1	Bearing, Sleeve
	193-0108	1	Sender, Oil Pressure
	502-0058	1	Tee, Oil Pressure Sender
	/ 505-0057	1	Plug, Tee
	123-0527	1	Cap and Indicator, Oil Fill
	123-0508	1 .	Tube, Oil Fill
	160-1135	1	Box, Breaker - (Includes Points and Condensers)
	160-1040	1 7	Seal, "O" Ring
	160-1041	1	Bushing, Breaker Box
in in the second	160-0723 104-0369	1	Plunger, Breaker Box Screw, Flywheel
	134-0675	1	Wheel, Blower (Includes Ring Gear)
	190-0266	1	Housing, Clutch
	104-0614	. 1	Flywheel ·
	134-2791	1	Housing, Cylinder Air - Right/Hand
	191-0572	. i	Alternator - 12 Volt - 35 Amp - Negative Ground
٠, ١,	191-0537	1	Bracket, Alternator Mounting
· .	191-0535	1	Bracket, Alternator Adjusting
	511-0051	- 1	Belt, Alternator
	167-0239 .	2	Plug, Spark
	502-0313	2	Elbow, Hose
	503-0669	1	Hose, Fuel
	503-0301	2	Clamp, Fuel Hose
	149-0693	1	Pump, Fuel
	154-0951	1.	Manifold, Intake
	502-0313		Elbow; Hose
	140-0921		Gasket, Adapter
	140-0867		Adapter, Air Cleaner
	134-3031		Housing, Blower
Sign of	150-1486 Generation		Arm and Shaft, Governor Redistribution or publication of this document by any means, is strictly prohibited.
l) ii E Sa		in The Committee	NOTE: Parts Not Furnished by ONAN: Grille

Supplementary Parts List

foi

Model CCKB-MS	*
	`
■ 100 日本 日本 日本 100 mm - 100	┛.

Spec

2864J

Standard Parts Catalog

927-0404

Parts Key

Parts Listed Below Apply to the Above Model. Use These Parts in Place of (or in Addition to) the Parts Listed in the Standard Parts Catalog.

PART NO.	QUAN.	DESCRIPTION
e e e e e e e e e e e e e e e e e e e		NOTE: This Model has a top mounted Alternator
		Hodel. This model has a cop modified Afternacor
110-1904	1	Block Assembly, Cylinder (Includes Bearings, Guides & Seats)
104-0872	1	Crankshaft
509-0123	1	Seal, Crankshaft Oil
509-0110	1	Seal, Dust
509-0134	. 2	Seal, Valve Stem Oil
120-0648	1	Intake, Oil Pump (Includes Cup, Screen & Pipe)
. 102-0780	1	Base, 0i1
123-0694	1	Cap and Indicator, Oil Fill
150-0635	1	Bracket, Governor Linkage
309-0010	1 .	Switch, Oil Pressure
502-0058	. 1	Tee, Oil Pressure Switch
134-2632	1	Wheel, Blower (Includes Ring Gear)
134-2924	1.	Housing, Blower
134–1644	1	Housing, Blower Air - Left/Hand
134-3000	1	Housing, Cylinder Air - Right/Hand
140-0921	1	Gasket, Air Cleaner
149-1097	1	Line, Fuel
140-0936	1	Adapter, Inlet
140-0645	1	Adapter, Air Cleaner
191-0543	1	Alternator - Top Mounted
191-0640	2	Spacer, Bracket Mounting
191-0636	1	Bracket, Alternator Mounting
191-0637	1	Bracket, Alternator Mounting
191-0639	* 1	Baffle, Alternator Air
150-0698	1	Spring, Governor
502-0002	1	Elbow, Inverted Male
502-0313		Elbow, Street (90°)
149-1393	1	Pump, Fuel
509-0105	4	Seal, Oil - Gearcase
509-0126	1	Seal, Oil - Gearcase
141-0721	1. 1.	Carburetor (Gas-Gaso) Component Listed in
154 0051		Parts Catalog as Optional Equipment
154-0951	1	Manifold, Intake
502-0065	1 1	Elbow, Inverted 45°
153-0327	1	Bracket, Choke Arm
518 0176 Generation	1	Clip, Choke Cable Redistribution or publication of this document
		NOTE: Parts not furnished by ONAN: Alternator Belt,

Air Cleaner

Supplementary Parts List

for

ä	V	¢	F	le			-\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\		CCI	KB-	-MS	\$			- I.		Sı	DE	C.		 	28	7.4	J		s da r.		(1) (1)		_		, , ,		Ì.
1			177			S.,	- V	11.1					128	J. J.	 77 <u>L</u> ".	[37]) 		ر ارام الانت		É	P.	7 : 17 1 : 1	3 100	7.) 		7 60			1.	3		ئ _{ىد} ۇ. ا	
	3	t	31	١d	a	rđ	P	8	rts	1)a	ta	lo	9	 1	,)	92	7-	04	04			11.30	: بيني	P	rt	3	(e	٧	у 1 4-и	Z		<u> </u>	۰: ۵۵

	PART NO:	QUAN.	DESCRIPTION
	FANLAV.	WOAN.	DESCRIPTION
l (g. Littar			
		į.	NOTE: This Model has a 12-Volt, 20 Ampere Flywheel
			Charging Alternator (shown as Optional Equip
Maria Maria		1	ment with Associated Parts in main Parts
			Catalog).
		1	
	110-0915	1 1	Block Assembly, Cylinder (Includes Bearings,
			Guides & Seats)
	104-0884	$\cdot \cdot \cdot $	Crankshaft
	102-0759	1	Base, 0il
	120-0648	1	Cup, Oil Pump Intake (Includes Cup, Screen
			& Pipe)
		Associate	d Parts shown as Optional Equipment in a
	Parts Catalog.	*	Maria Diama (Tarahali a Dina Conn)
	134-2642	<u>.</u>	Wheel, Blower (Includes Ring Gear)
	123-0694	1	Cap and Indicator, Oil Fill
:	134-2995	1	Housing, Blower Housing, Cylinder Air (Right Hand)
	134-2941 VARIABLE SPEED	COMEDNOD T	shown as Optional Equipment in main Parts Catalog.
; -	160-1135	OVERNOR 1	Breaker Box Assembly
	160-1133	1	"O" Ring - Breaker Box Base Seal
	160-1041	1	Bushing - Breaker Box
	160-0723	1	Plunger, Breaker Box Points
	321-0169	$\frac{1}{1}$	Bracket, Fuse
,	167-0188	2	Clip, Retaining - Electrical Leads
-	140-0921	1	Gasket, Carburetor Air Horn
	150-0147	1	Stud, Vari-Speed Governor
.:	192-0397	1	Sheave, Rope
	508-0084	1	Grommet
	**	, s,	
	•	+)	
'			promise the second of the seco



* SPECIAL PARTS LIST FOR MODEL CCKB+S SPEC
FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY NO. 1
OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO. QTY. DESCRIPTION
Group - 9 Red1 Pull Starter

PART N	O. (Q1	ΓY.	DESC	RIPTION		F	PART NO.	QTY.		DESCRI	PTION '
Group -	- 9 - 22	Re Va	edi Pull St eriable Spe	arter, eed Governo	or		¥				
134-309)2 1	Ho	ousing, Blo	ower .	د			· .		1 4	
	4					*	i de				
		4			,) "	The state of the s		
										•	
	•	z	8	9		ţ	`e · .	, \$	*	,	
		a,	**		*		K.				7
			39.7	4	1 N .		ا غدم د	, **			e.
	P	r -					· .				3
		Ą				i de			* * **		
ord Service Landar Johann				s y a nasi	n th		**		ه مرید در مداه	9	
						ė,					
		w.		ar Linguage Maria (1984)				B Comment			
CHILIPATE .	Power Genera	ation	<u></u>	and the state of t				Re	edistribution or any means, is	publication of t strictly prohibi	this document ited.

SPECIAL PARTS LIST FOR MODEL .

CCKB-MS

SPEC

2876J ≪ ॄ

FOR STANDARD PARTS REFER TO CATALOG_

927-0404

KEY NO:-_

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO BELOW WHEN USED.

	OPTIONAL GROU	JPS IN CATALOG ARE L	ISTED	BY GROUP NO	BELOW	WHEN	USED
PART NO.	ФТҮ. э	DESCRIPTION		PART NO.	QTY.		DESCRIPTION
Group - 3 Group - 22 134-0675 505-0057	Variab 1 Flywhe 1 Plug,	ator, Top Mounted le Speed Governor el (Includes Ring Ge Pipe 1/8 g, Blower	ear)			***************************************	
134-1644 134-2916 140-1087 511-0090 191-0639	1 Housin I Housin 1 Gasket 1 Belt,	g, Cylinder Air SH g, Cylinder Air RH , Air Cleaner Alternator , Alternator					
					, a	ru³ s	
						1	
				35			e de la companya de
		Andrew Control Provided to					



SPECIAL PARTS LIST FOR MODEL L

CCKB-MS

2878 J

FOR STANDARD PARTS REFER TO CATALOG

SPEC 927-0404

KEY NO.

	OPTION	AL GROUPS IN CATALOG ARE LISTI	D BY GROUP N	O. BELOW WHEN	USED.
PART NO.	QTY.	DESCRIPTION	PART NO.	QTY	DESCRIPTION
			المرين	for-exercise.	
Group -	6	Flywheel Alternator Syncro		, ***	-
Group - 1	3	Top Mounted Engine Control	7		<u> </u>
	ný i			$\frac{1}{2} \left(\frac{1}{2} \right) $	
104-0887	1	Crankshaft		es.	
123-0527	1	Cap & Indicator, 011 Fill			23%
123-0679	1	Tube, 0il Fill			
167-0188	1	Clip, Gearcase		n et plant of	Management with a greater of a collection of the
167-0188		Clip, Harness			v ² - 1
134~3024	1	Housing, Blower			
150=0147	1	Sutd, Governor Adjusting		A said	
134-2941	. 1	Housing, Cylinder Air RH			
501-0203	* 1	Line, Oil		* .	
502-0020	1.	Elbow 1/8	A STATE OF THE STA	n	
155-0906	1 1	Muffler, Exhaust			
505-0618	1	Cap, Pipe Clip, Choke Cable			eri Tarihin dan salah sa
518-0176 153-0327	1	Bracket, Choke			***
154-0973	1	Gasket, Exhaust Muffler Mtg.	- / Mar .		
134-05/3	2	Gasker, Ballador Horizon			
		*	, .	`	$f_{p^{\prime}}$
				•	
· An	*. *.	A			
		·			
	,				
* * *	4		1 /		·
-			\mathbf{I}_{i}		$\frac{d}{dt} = -\frac{1}{2} \frac{dt}{dt}$
	, 4	بيق		j i	
					المجاور
		-	1		
				•	(
				Ų.	3
4				•	
•		, =·	· ·	•	
4	•	<i>F</i>			



	FOR STAN	FOR MODEL DARD PARTS REF UPS IN CATALOG ARI	ER TC	CATALOG_	SPEC 927-0404	2882J KEY NO 1
PART NO.	OTY.	DESCRIPTION	LISTE	PART NO.	17.7	DESCRIPTION
Group - 22	Variab	le Speed Governor				48
134-2824	1 Guard,	Flywheel Capscrew	7			
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1			•			
	ya. a				· · · · · · · · · · · · · · · · · · ·	
					· · · · · · · · · · · · · · · · · · ·	ု ႏုိ ေလ ၂၀ န္မို့ရာန
		**				3
			Ę.			and the second s
						e de la companya de l
	**	e e e e e e e e e e e e e e e e e e e	- J. F	• 1	, e.	Jorge of the
v.	ð. Í					and the second second
6				4		e de la companya de l
	· , · · · · · · · · · · · · · · · ·		,	,		a de
n e				4		
	•		É	<u>.</u>		
			•	*		
, d			,	· · · · / · · ·	. •°	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
				¢.	; · · · · · · · · · · · · · · · · · · ·	
		*		<i>*</i>		· · · · · · · · · · · · · · · · · · ·
					teras .	S

			, a.			
.	ver	Supply of a property of the second	ali de Nationalis		Padistribution o	r publication of this document
Ger Ger	neration			<u> </u>	by any means,	r publication of this document is strictly prohibited.

SPECIAL PARTS LIST FOR MODEL

CCKB-MS

SPEC

[®] 2895J

FOR STANDARD PARTS REFER TO CATALOG.

927-0404

KEY NO.

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO.	άτγ.	DESCRIPTION	PART-NO. QTY.	DESCRIPTION
Group - 6 Group - 13		l Alternator (Syncro) nted Engine Control		
167-0188 501-0203 502-0020	2 Clip, H 1 Line, O 1 Elbow			
150-0147 150-1000- 134-2995	1 Arm, Go	overnor Adjusting vernor , Blower		
154-0998 505-0329 153-0327 518-0176	1 Manifol L Cap, Pi 1 Bracket 1 Clip, C	, Choke		
154-0973	2 Gasket,	Exhaust Manifold Mtg		
	And the second s			
	in the state of th			Stern
. Le				4

			Sa.	
	· · · · · · · · · · · · · · · · · · ·	A Comment of the Comm		
	*			
Carrining Pov	ver ieration	a programme (Maria and Maria a Maria and Maria	Redistribution by any means	or publication of this document is strictly prohibited.

Supplementary Parts List

for

	ď	ij	Ĺ.	4	~	1	1	Η,		1	C	`ĸ	R	١	М.	ς.	Î	li p	1		٠,	43		9	-4	•	- ,5	C		Ċ.	9(1	'y '	- 1	į.	- 2	R	9	7		i,		4		: '.		41		$\sigma_{i+1}^{(i)}$		è, e	1			20	4	4
	¥	Pξ	ψŢ	Ÿ.	Ü	1	بني	بسند	÷	- 2	~~			5	1	_	4	ببن	Α,	نظها	نښد	4	3.5	4	4		– ;",		4	,	5	1	- ننب	1	-	-	-	-	1	۳,	-		بين	<u> </u>			****	إسبي			 -		- 6	7		• • • • •	p.
à	10		1.	al A	in a	54	V	10	Α,	ΔŢ.		•	1	- 17	, 4	١.		٠,٠	1.1	Ÿ.	٥	e - T.	1.	Z.	10		* /	1.1	•			":		10	•	٠.		٠			,	1			4		4	•		30	 		~ .	- "	av.	ر کال ا	
Ť	•	À,	i÷.	1	فن	gr.	14	ú		-	1	1		Ç.		•			Ė	ŧ.			J		- 7	'n	6.	Q	2 "	7	n	A	n.	A.	. ()	i, j.		e.			Ź.,	'n.	B			4	_	L	1	١.		٠.,	4	•			4

PART NO.	QUAN.	DESCRIPTION
		**
		ed as Optional Equipment in Parts Catalog
(Complete Brea	kdown of	Components)
309-0237	1.	Sender, Pressure Switch
103-0512	1 1	Gear Case
. 145-0460	1 '	Adapter, Air Cleaner
140-1151	· 1	Tube, Air Inlet
134-2130°	1	Wheel, Blower
104-0740	1 1	Flywheel and Ring Gear
. 520-0560	1 1	Link, Throttle - Governor Control
148-0747	1	Carburetor (LPG)
502-0395	1	Connector, Hose
503-0745	1	Hose (1/4 I.D. x 5" Lg.)
505-0101	2 -	Nipple, Hose (3/8" x 1")
505-0019	- 1	Bushing, Reducer (3/8" x 1/2)
505-0039	1	Elbow, Pipe
148-0758	·1 ,	Fitting, Hose
· * *	. •	
	4	

		All and the second seco
	ė «.	
	· ·	
	٠,	

	, 1984	
je i roje		
9		
·		
9 40	13	
*	_	
	*	

٨	1	٥	d	e				C	ζB	٦,	IS	3					- 10°		S	D	e	C	9119 9123	2(39	7	J			3	1: 1:	Mary I			12.5	3.		Aug.		
1,7	7	<u>.</u> (k	7	1		0	-1 Č	- 3		. 5.1	0		4.1		10	∵.	,)	•	÷.	Ξ.	\mathcal{F}_{i}	7.7	7			57		सम्बद्धाः स्टब्स	77. T	1				rozer) Tovo s	1			ing?
Č		à	Ď	A	2	rd	F	þ.	•	2	Č	a	1.	ı,	<u> </u>				92	27	-6)4	04	,) , , , , , , , , , , , , , , , , , ,				•	P	ar	te	i	(e	V.		(150,7) (140,4)	2) 1.74 (1.72	

PART NO.	QUAN.	DESCRIPTION
	, a	
	a	
		ed as Optional Equipment in Parts Catalog
(Complete Brèa	kdown of	
309-0237	1	Sender, Pressure Switch
103-0512	1 . 7	Gear Case
145-0460	1	Adapter, Air Cleaner
140-1151	1	Tube, Air Inlet
134-2130	1	Wheel, Blower
104-0740	1	Flywheel and Ring Gear
520-0560	1	Link, Throttle - Governor Control
148-0747	1 1	Carburetor (LPG)
502-0395	1	Connector, Hose
503-0745	1	Hose (1/4 I.D. x 5" Lg.)
*505-0101	,2	Nipple, Hose (3/8" x 1")
505-0019	1	Bushing, Reducer (3/8" x 1/2)
505-0039	1	Elbow, Pipe >
148-0758	1 .	Fitting, Hose
3"		
,		



Supplementary Parts List

for

there are little	35	医多性髓 ""第二	10	All Street Control of the Control of	البريافة كالوجي		
		. *- 5.2 41.1 1.*		10 €	4.0% Date: 10 1.5	-	the second of th
14 (41) 44		1.0	ו מיודיי	4.	and the same of		
		1.1	1 K K	Account to the second	العالية		2898 J
	4 4 4	3.5 (2)	CCKB-N	AND SALES OF THE SALES	and the second second	Spec	
\$ 7 TO 10 TO	4			THE RESERVE OF THE PERSON NAMED IN COLUMN TWO IS NOT THE PERSON NAMED IN COLUMN TWO IS NOT THE PERSON NAMED IN			· recommendation

Standard Parts Catalog 927-0404 Parts Key 2

e .	PART NO.	QUAN.	DESCRIPTION
ė	NOTE: This Model	is Vacu	flo Cooled
	.110=2289 • *	1	Block Assembly, Cylinder (Includes Bearings, Guides
*			& Seats)
	110-1827	2-	Guide, Intake Valve
	110-1000	2	Seat, Intake Valve
i suit Tra	110-1037	2	Valve, Intake
	110-0904	2	Rotor, Valve (Intake)
	509-0090	2	Seals, Valve Stem Oil
	104-0915	1	Crankshaft
	101-0429	<u> </u>	Plate, Bearing
٠.,	520-0114	5	Stud, Bearing Plate Mounting
. s. 	110-0445	5	Nut, Bearing Plate Mounting
}. . 	509-0123	1 1	Seal, Crankshaft Oil
•	509-0110	1.	Seal, Dust
	102-0759	1	Base, Oik
	120-0648	1	Cup, Oil Pump Intake (Includes Cup, Screen & Pipe)
	123-0527	1	Cap and Indicator, Oil Fill
4	149-0136	1	Cover, Fuel Pump Hole
	800-0004	. 2	Screw, Fuel Pump Hole Cover Mounting
ay '	103-0522		Gear Case
	166-0519	1	Bracket, Timing
	134-2130	1 1	Wheel, Blower
	104-0740	1	Flywheel and Ring Gear
•	134-3061	1	Housing, Blower
	166-0279	1	Bracket, Ignition Coil Mounting
	517-0034	1	Plug, Dot Button
	№ 66-0286	1	Screw, Ignition Coil Bracket
	134-3057	1, 4	Scroll, Blower Housing
151	134-3095		Housing, Cylinder Air - L/Hand
`	134-3096	1	Housing, Cylinder Air - R/Hand
	149-1322	1	Pump, Fuel (Includes Parts Marked *)
	142-0537		*Valve Plate Assembly
	142-0540	2	*Screw, Pump Cover
	149-1323	1 1	*Gasket, Cover to Valve Plate
	142-0541	1	*Gasket, Base to Diaphragm
,	142-0545	1	*Spring, Pump Diaphragm
ne i tra	_149-1326	1 1 .	*Cover, Fuel Pump

Model C	CKB-MS	Spec	2898.		and the second second

Standard Pa	rts Catalog	927-04	04	Parts Kev 🗅	. 2 *

· <u>'-</u>	PART NO.	QUAN.	DESCRIPTION
	4	g.	
4	140 1724 88	*	*Base, Fuel Pump
	149-1324 ** */ * 142-0552	@.1 1	
•	142-0555	1 1	*Plate, Pump Spring
	149-1321	1 1	*Diaphragm, Pump Cap, Fuel Inlet.
	503-0301	2	
	505-0573	, 2	Clip, Corbin # Hose, Vacuum (Pump to Block)
v	15 4 1 2 2 2 2	1	Manifold, Exhaust
	154-1/35 154-0973	1 2	Gasket, Exhaust Manifold Mounting
		TEP	Parts Catalog - Optional Equipment
	_(Complete brea		
	309-0237	AUOWIL II	Switch, Pressure
	140-0864	1 · ·	Adapter, Air Cleaner (Carburetor Air Inlet)
	123-0732	4	Tube, Breather Connector
	140-0921	1 1	Gasket, Air Horn
V	502-0313	1	Elbow, Hose
	140-1240	1 1	Adapter, Air Cleaner (Remote)
A ₄	503-0365	. 1	Clamp, Hose
	140-1176	1	Elbow, Air Inlet
	154-0951	1 1	Manifold, Intak
	153-0453	1	Bracket, Choke Arm
	133-0433	· · · · · · · · · · · · · · · · · · ·	bracket, Groke Alm
دعي	:		
	* N	1 .	
	·	S	
•	w.		ab at
•	. >	ra se	
,15	•	٠ ا	
À	41		
		्र	
1.			
		· ·	
	•		
	• • • • • • • • • • • • • • • • • • •	4	
		,	
0		1 2	



Supplementary Parts List

Model CCKB-MS Spec 2900J

Standard Parts Catalog 927-0404

Parts Key

PART NO.	QUAN.	DESCRIPTION
		NOTE: This Model has a Variable Speed Governor
110-1418	4.17	Block Assembly, Cylinder (Includes Bearings, Guides
		and Seats)
104-0878]	Crankshaft
102-0756	1 -	Base, Oil
120-0648	1	Intake, Oil Pump (Includes Cup, Screen & Pipe)
123-0694	-1	Cap and Indicator, Oil Fill
502-0020	1	. Elbow, Oil Line
501-0203	1. 1.	Line, Oil - Out of Top of Blower Housing
508°-0095	1	Grommet, Oil Line
. 134-2791	1	Housing, Cylinder Air R/Hand
	(Includes	
112-0073	. 2	Standard
112-0073-05	2	.005" Oversize
112-0073-10	2	.010" Oversize
112-0073-20	2	.020" Oversize
112-0073-30	2	.030" Oversize
112-0073-40	2	.040" Oversize
RING SET, PISTO		
113-0126.	2	Standard
113-0126-05	2	.005" Oversize
113-0126-10	265	.010" Oversize
113-0126-20	2	.020" Oversize
113-0126-30	2	.040" Oversize
113-0126-40	4	Gauge, Oil Pressure
193-0005	1 1	Clamp, Oil Gauge
193-0031	1	Washer, Spring Tension
152-0041 152-0170	1	Arm, Variable Speed Governor Control
302-0060		Ammeter, Charge 20-0-20
309-0029	1 1	Switch, Start
308-0232	1	Switch; Ignition
301-2780	1 1	Panel, Control
505-0329	1 1	Cap, Pipe
141-0281	1	Gasket, Carburetor Flagne
154-0951	$\int_{0}^{\infty} \bar{1}$	Manifold, Intake
153-0327	1 1	Bracket, Choke
502-0313	1 , 1	Elbow, Hose
154-0998 ₀₀	- <u>1</u>	Manifold Exhaust Redistribution or publication of this document
154-0973	2	Gaskets, Exhaust Manifold by any means, is strictly prohibited.
		Charles 1 (1997) 1997 (1997

	V,	ľ	3 (ć	e	Ŧ.		Ļ	ة. تنجة		ું	Ć	ľ	•	F	3	-1	4	S	1					7			. 1	1 . 1 . 1 ~			1			٤	3	C) (9	C		,			;	· -	2	ļĢ)()().	J.				-	· .		· -	٤.		٠.		`. 		:	ď	•	** (4			9	
į,	.,		Trum Sull	Ţ,	(T.		1	5		3	·r	,	ì			7			gree Section		1.1	- T.		,			1		7.	,			:		-7		•			-	`		: .		,	7	:	ì.		,			-			4						,	11	. •							 Ė,	ri.		-
	ì	1	2	n	Ç.	2	ĺ	1	ď		J)	3	r	t	Ş		1	3	ź	ì	Ė	1	ı	0	ť	1				C) ;	2	7	_	() 4	4(),	4			/	/	٠.	ď				· ·	į	•	٠.	, i	I)	Я	r	ť	S	1	K	(ġ.	V	,	1	•			٠.	2	 	

PÅRT NØ.	QUAN.	DESCRIPTION
140-0921 160-0948	1	Gasket, Air Horn Wheel, Magneto (Includes Ring Gear)
	· Manageria	
	4	
	•	
	Control of the contro	Redistribution or publication of this document by any means, is strictly prohibited.

		200	. I. L			v .	3 to 1	· 1			10	3	7				1 (1 (1 (i))
	1		d	•	 .4 24	CCKI) MC	100					4	2	00A	T	
1	v	ı	u	C	 <u> </u>	CURL	כשיו יייכ	32 00	والأسامة والدائد	أخطأ	. 3 L) ec			7 04	U	1,600
	100	-	1		 												

Standard Parts Catalog 927-0404 Parts Key 2

PART NO.	QUAN.	DESCRIPTION	.
NOTE: This Model	has a 20	Ampere Flywheel Charging Alternator (Comp	olete
breakdown	n Parts	Catalog) - Optional Equipment	, T
110-1911	.1	Block Assembly, Cylinder (Includes Beari	ng.
	7 m	Guides & Seats)	
110-1000	2 .	Seat, Intake Valve	
104-0872	. 1	Crankshaft	
509-0123	1	Seal, Crankshaft Oil	<u>.</u>
509-0110	1	Seal, Dust	
102-0759	1	Base, Oil	;
120-0648	1	Cup, Oil Pump Intake (Includes Cup, Scre	en & Pipe)
123-0694	1	Cap and Indicator, Oil Fill	
FULL FLO OIL FILT	TER Show	n as Optional Equipment in Parts Catalog -	er e
Components List	ted	•	
134-2462	1	Wheel, Blower (Includes Ring Gear & Magn	iets)
134-2824	1 -	Guard, Flywheel	
134-2933	1	Housing, Cylinder Air - R/Hand	w•
134-3054	1	Housing, Blower	* \$
503-0582	1	Hose, Breather	1 1 1 5 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
140-1073	1	Clamp, Air Cleaner	•
140-1061	1	Cover, Air Cleaner (Inlet)	
140-1071	1	Element, Air Cleaner	
140-1066	1	Cover, Air Cleaner (Outlet)	
503-0311	1	Clamp, Hose (2" x 1/2")	*
140-1067	1	Bracket, Air Cleaner Mounting	
140-1075	1	Elbow, Air Inlet	· ·
154-1051	1	Manifold, Intake	,
154-1024	1	Manifold, Exhaust	,
154-0973	2	Gasket, Exhaust Manifold	
145-0398	1	Adapter, Carburetor Air Inlet	5
153-0464	1	Bracket, Manual Choke	¢
518-0176	1	Clip, Cable	
152-0155		Swivel, Choke Lever	
145-0479	<u> </u>	Arm, Carburetor Throttle Extension	
505-0057	1 1 1	Plug, Square Head (1/8)	
153-0327	1 1	Bracket, Cable	, i
140-0921	I I	Gasket, Air Horn	e .
508-0084	1	Grownet	
Generation	<	Redistribution or public by any means, is strictl	

	V,	K	31	ł	۱,	``		ريا خاصت	CC.	KΒ	– M	S					Si	οÝ	ЭC	1	1	290	14,	J	رمدري بر	8.7			1	7		A. Ja	ŝ.
			1	3	海湾		j.,	e de la composición dela composición de la composición dela composición de la composición de la composición dela composición dela composición de la composic	*	g	14.0	1	* .		io de						•		, j	3	100		3.77	711 . 111.		,	ا درومید. ماریخوس	$h(\mathcal{M})$	
Ï	Š		100 A	11	1:	, Fi	1	P	ar	ts	C	a	la	loc	1		.9 2	27	-0	40	4	3 37 1		13.4 13.4	ी	22	rts	(e	V.		2	المحداد	<u>.</u>

PART NO.	QUAN.	DESCRIPTION
501-0203	1	Line, Oil
502-0196	1 1	Elbow, Street 90°
167-0188	1 1	Clip (one lower right Gearcase Cover and one
101-0100%		fill tube)
193-0171	` 1	Bracket and Fitting Assembly (Oil Gauge)
505-0057	1	Plug, Pipe
502-0003	-1	Connector
	. "	
	· l ;	
en de Argentale de la Companya de l La companya de la Co		
	,	
	'	
	1	The state of the s
The second of the second		
The state of the s		
	1	
	1	
是有可能是对于19	•	
The state of the s	e,	
	£μ	
	A. C.	
	A-Sec.	
3.6. 等的 2. 第二次 3. 3. 3. 3. 3. 3. 3. 3. 3. 3. 3. 3. 3.		
	La participa (Marine) (Sa.)	
EEL TERON		Redistribution or publication of this docume by why means, is strictly prohibited.

SPECIAL PARTS LIST FOR MODEL CCKB-MS

2906J

FOR STANDARD PARTS REFER TO CATALOG 927-0404

KEY NO.

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO. OTY.	DESCRIPTION PART NO. QTY DESCRIPTION
Group - 6	Flywheel Alternator (Syncro)
Group - 13	Top Mounted Engine Control
167-0188 2	Clip, Harness
154-0998 1	Manifold, Exhaust
153-0327 1	Bracket, Choke
505-0329 1	Cap, Pipe
154-0973 2	Gasket, Exhaust Manifold
518-0176 1	Clip, Choke Cable
508-0084 1	Grommet, Rubber
134-2995	Housing, Blower
501-0203	Line, Oil
502-0020 1	Elbow (Jane 1996 - 1996 - 1996 - 1996 - 1996 - 1996 - 1996 - 1996 - 1996 - 1996 - 1996 - 1996 - 1996 - 1996 -
150-1023 1	Stud, Governor Adjusting
0	

SPECIAL PARTS LIST FOR MODEL CCKB-MS

2907J

FOR STANDARD PARTS REFER TO CATALOG 927-0404

KEY NO.

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART	NO. OTY DESCRIPTION		PART NO. QTY.	DESCRIPTION
Grou	5 - 6 Flywheel Alternator (Syn	ncro)		
167-0	우리 중에 되는 사람들이 가장 그는 사람들이 모든 사람들이 모든 사람들이 가장 그는 사람들이 되었다.			
104-0 134-2	the state of the s	ew e		

	. 11	111		Ŀ
ь.	-	ų.		٠
	ı.	и	к.	

,	A	a	ir	e	ĺ		10.			CC	:KI	3-	MΣ							•	Si	D	80			i F		1 (2	90	9	J	Ţij.	, a.,		za.	7	蛋			1)4 1,124	in in in	
, de			ş Ş	1			4 .	. de . d ₁₀		de estas. Az				-	3	1	7	7		T - '	Ţ,		T.														1	-				u	
	5	la	П	d	la	rc	•	P	a	rt.	S	C	a	ŧε	ķ	0	1	ų.		_}	<u> </u>	1:	- U	4	04		۸		٠	1	P	a	rt	\$	K	e	y	***		۷.	نغانيا		-

PART NO.	QUAN.	DESCRIPTION
110-0915	1	Block Assembly, Cylinder (Includes Bearings,
		Guides & Seats)
104-0872	1	Crankshaft/
102-0759	1	Base, Oil
120-0648	1 1	Cup, Oil Pump Intake (Includes Cup, Screen
	, ,	§ Fipe)
123-0694	1,	Cap and Indicator, Oil Fill
134-2995	1	Housing, Blower
134-2791	1	Housing, Cylinder Air (Right Hand)
VARIABLE SPEED (OVERNOR	shown as Optional Equipment in main Parts Catalog.
154-0998	1	Manifold, Exhaust
150-0147	1	Stud, Vari-Speed Governor

						OR		

CCKB-S

PART NO. QTY.

2911J

FOR STANDARD PARTS REFER TO CATALOG 927-0404 OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

KEY NO.

DESCRIPTION

PART NO.	QTY,	DESCRIPTION
Group + 8	900	Spin On Oil Filter
Group -19	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	High Profile Breaker Box
110-1827	2	Guide, Valve - Intake
110-1957	1	Block Assembly, Cylinder
509-0090	2	Seal, Valve Stem Oil
509-0123	1	Seal, Crankshaft Oil
509-0110	1	Seal, Dust
104-0872	1	Crankshaft
105-0238	- 1-	Camshaft
102-0688	- 1	Base, 0il
123-0506	- 1	Cap and Indicator, Oil Fill
123-0508	1	Tube, Oil Fill
309-0237	_1	'Switch, Low Oil Pressure '
103-0533	1	Gear: Cover - (Complete)
509-0105	1	Seal, Oil-Gear Cover
509-0126	1	Seal, Oil-Gear Cover
150-0635	1	Arm, Governor
150-0698	1	Spring, Governor
134 22555	1	Wheel, Blower
134-1889	1	Guard, Blower Wheel
140-0645	1	Adapter, Air Cleaner
140-0584	$_{I}$ 1	Gasket, Adapter to Adapter
140-1087	1	Gasket, Air Cleaner
134-2862	1	Housing, Blower
167-0229	2	Support, Hi Tension
167-1596	1	Lead, Hi Tension
167-1595	1.	Lead, Hi Tension
166-0346	. 1.	Coil Ignition
517-0034	1	Button, Dot
153-0327	1	Bracket, Choke
518-0176	1	Clip, Cable
134-2237	1	Housing, Cylinder Air R/H
166-0444	" 1 · ·	Bracket, Coil and Governor
150-1021	1	Lever, Throttle Control
515-0202	1 .	Key, Crankshaft
	S	
	· ·	· · · · · · · · · · · · · · · · · · ·
Parts Not	Furnis	hed by Onan:
Air Cl	leaner	
97.441	1 77	



Flywheel Capscrew Guard Rope Sheave

SPECIAL PARTS LIST FOR MODEL

CCKB-S

SPEC

2912J

FOR STANDARD PARTS REFER TO CATALOG

927-0404

KEY NO.

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO BELOW WHEN USED.

PART NO. QT	Y. DESCRIPTION	PART NO.	QTY, DESCRIPTION
110-1827 2	Guide, Valve - Intake		
110-1904 1	Block Assembly, Cylinder	* /	
	(Includes Bearings, Guides		
The state of the s	And Seats)		
104-0872 1	Crankshaft	3	
509-0090 🔩 2	Seal, Valve Stem Oil		y
120-0413 1	Intake, Oil Pump (Includes		8
- AN	Cup, Screen And Pipe)		
102-0688 1	Base, 0il		The state of the s
the state of the s	Cap And Indicator, Oil Fill		
123-0508 1	* Tube, 0i1 Fill		
509-0117 1	"O" Ring	•	
509-0105 1	Seal, Oil - Gearcase		**************************************
509-0126 1	Seal, Oil - Gearcase	.	
	Box, Breaker (Complete) -		
*.	* Tall		•
160-1040 1	"O" Ring		
160-1041 1		·	
160-0723 , 1	Plunger, Breaker Box		·
	👺 Guide, Breaker Box	*	
160-0261 1	Wick, Breaker Box		
140-0645 1	Adapter, Air Cleaner	•	
140-0584 1	Gasket, Air Cleaner	·w ₄	·di 2
154-0951 1	Manifold, Intake	. jik	
153-0327 1	Bracket, Choke		, -
518-0176 1	Clip, Cable	·* 	•
150-0635 1	Bracket, Governor	්ය .	
150-0698 1	Spring, Governor	· .	
134-2405 1	Housing, Blower		
134-0588 1	Housing, Cylinder Air R/Hand		
153-0097 1	Choke		
167–1500 1	Cable, Hi-Tension #2 Cylinder		a second of the
167-1501 1	Cable, Hi-Tension #1 Cylinder	-	A STATE OF THE STA
	A		43
		; to	The state of the s
,	· ·		

	•	0	~	11	D'	-1	ŧ.	r	
5	h			ĸ	ĸ	— \	4.	```	

MODEL_

1						- :	7. 2.	- / 1	~/!	
		- 1		11 2		₩.	-24	22	60	l
			110	-	10000	اللحدا				

SUPPLEMENTARY PARTS LIST 900-43 (per above model and spec.)
Parts listed below apply to the above model. Use these parts in place of (or in addition to) the parts listed for Parts Key______in the standard parts catalog No.______

DARTNO			DEC COLOTION
PART NO.	QUAN.		DESCRIPTION
	•		NOTE: This Model has a 15 Ampere Flywheel
i y	6	ė.	Charging Alternator and Full Flo
110-1860	• 1	, ,	Block Assembly, Cylinder (Includes Bearings, Guides
	. No.	·	and Seats)
104-0872	1	4	Crankshaft
102-0759	1	ŀ	Base, Oil
123-0694	1 americ		Çap and Indicator
120-0648	1,		Intake, Oil Pump (Includes Cup, Screen & Pipe)
122-0320	1		Adapter, Oil Filter
122-0321	1	₩.	Gasket, Oil Filter Adapter
122-0323	1	1	Filter, Oil
122-0347	. 1		Seal, Air Oil Filter
505-0057	1	320	Plug, Oil Filter
149-0136	Ĩ	,,	Cover, Fuel Pump Hole
191-0885	1.		Stator - 15 Ampere
191-0886	1 .		Regulator, Voltage
134-2100	2		Spacer
191-1078	1		Bracket, Regulator Mtg.
134-2828	1		Housing, Blower
134-2760	1		Housing, Cylinder Air R/Hand
134-2621	1		Wheel, Blower (Included Ring Gear & Magnets)
152-0086	1		Bracket Mounting - Vari Speed Governor
152-0083	1		Arm, Control
152-0041	1		Washer, Tension
152-0090	.1		Stud, Governor
150-0621	2		Nut, Governor
150-0098	1		Spring, Governor
141-0726	-]		Carburetor (LPG) Components listed in Carburetor
4, 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1	×	,	Section (Begin Spec H) in Parts Catalog
_ -	4		
	· .		· And the second of the second

Redistribution or publication of this document by any means, is strictly prohibited.

SPECIAL PARTS LIST FOR MODEL CCKB-MS SPEC 2933J FOR STANDARD PARTS REFER TO CATALOG : 927-0404 OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED. PART NO. QTY. DESCRIPTION PART NO. QTY. DESCRIPTION Group - 4 Flywheel Alternator (WICO) Group -Spin On Oil Filter Group - 31 Carburetor (141-0744) 110-2289 Block Assembly, Cylinder 520~0187 Stud, Governor Adjusting 110 + 1827Guide, Intake Valve, 301-3843 Bracket, Terminal Block Valve, Intake 2 110-1037 Strip, Marker 332-1273 110-0893 Retainer, Valve Spring Block, Terminal 332-0604 509-0090 Seal, Valve Stem Oil 338-0619 ĺ Harness, Wiring 101-0429 Plate, Bearing 505-0008 1 Plug, Pipe Bearing, Bearing-Camshaft 101-0449_{\$\sigma} 1 £502-0039 E1bow 3-0582 5 ' 520-0114 Stud, Bearing Plate Mtg. Hose, Breather Not, Bearing Plate: Mtg. 110-0445 **2**03-0171 Clamp, Hose 104-0916 1 Crankshaft 1 102-0791 Base, 0il 123-0527 Cap & Indicator, Oil Fill Parts Not Furnished By Onan 123-0675 1 Tube, Oil Fill Air Cleaner 149-0136 Cover, Fuel Pump Hole Seal, Oil 509-0008 134-3088 Housing, Blower 134-2760 Housing, Cylinder Air RH 191-0919 1 Pulley, Drive 191-1112 1 Spacer, Drive Pulley 150-0147 1 Stud, Governor Adjusting 4 152-0193 Arm, Governor-Rear Pull Swivel, Choke 152-0155 1 516-0059 1 Pin, Cotter. 140-1319 1. Bracket, Air Cleaner 508-0051 1 Grommet, Rubber 140-1240 Adapter, Air Cleaner Elbow Air Inlet 140-1186 1, 503-0365 Clamp, Hose Line, Fuel 159-0865 1 503-0004, 1 Clamp, Air Cleaner Manifold, Intake 154-1116 .1 145-0398 1 Adapter, Carb Air Inlet -154-0998 Manifold, Exhaust 505-0329 Cap, Pipe 1 154-0973 Gasket, Exhaust Manifold 2 Plug, Pipe 505-0057 1 140-0921 1 Gasket, Air Horn 148-0465. Regulator, LP Gas .1 Elbow, Inverted Male 502-0039 Nipple, Close 505-0099 Vaporizer, Gas 148-0418 148-0756 Bracket, VPR Regulator

Elbow, Male Flare

Joint, Ball

502-0183 150-0974

Redistribution or publication of this document by any means, is strictly prohibited:

2934J

FOR STANDARD PARTS REFER TO CATALOG 927-0404

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

RART NO.	оту.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Group -/5_		Flywheel Alternator (Phelon)		$\int_{0}^{\infty} \frac{f(x)}{x} dx = \int_{0}^{\infty} \frac{f(x)}{x} dx$	
Group - 8		Spin On Oil Filter			
110-1860	· 1	Block Assembly, Cylinder.			, .
104-0778 *	1	Crankshaft			
509-0123	1	Seal, Crankshaft Oil			,
\$09-011 0	'n	Seal, Chankshaft Dust			Ko .
102-0782	1	Base, Oil	Val. V		
505-0040	1	Elbow	5. 5. 5. 5. 5. 5. 5. 5. 5. 5. 5. 5. 5. 5		
505-0210	7 1 3 1 7 1	Nipple, Pipe			
505-0100	1)	Nipple "			, , , , , , , , , , , , , , , , , , ,
- 505-0307	. 1	Coupling, Reducer	ن ۴ 🐔 ر	•	*
123-1279	1	Bracket, Oil Fill Tube	, w	6	,
123-0286	1	Plate, 0il Fill		0 .00	
123-1281	1 1	Tube, Oil Fill			
123-0876	, 1 ,	Cap And Indicator Oil Fill	rs.	***	
502-0020	1	Elbow, Street	. 6		
501-0004	1	Line, Oil	•	*	
103-0533	1	Gearcase (Complete)		÷	
509-0105	.1	Seal, Oil	3	•	r (Ar
509-0126	1 ~	Seal, Oil			
134-2824	. 1'.	Guard, Flywheel Capscrew			q
145-0398	1	Adapter, Carb Air Inlet	. 0		,
140-0921	1 '	Gasket, Air Inlet			· · · · · · · · · · · · · · · · · · ·
153-0327	1	Bracket, Choke	4	1	i i
518-0176	` <u>1</u>	G M ip, Cable	•	٠ ٠	*
152-0193	. 1	Arm, Governor		23	, §
152-0196	· 1	Spacer	4	, se	
150-0147	⊥ ^y ∗	Stud, Governor Adjusting		a .	4 .
152-0155	1	Swivel, Choke Lever		•	2
153 0103	1 · · · · · · · · · · · · · · · · · · ·	Pin, Cotter Bracket, Governor Control	<i>'</i> .	•	٠ .
152-0192 518-0176	- ' <u>1</u>	Clip, Cable	•	• ,	
503-0004	<u>. E</u> 1	Clamp, Air Cleaner			
140-1073	, <u> </u>	Clamp, Air Cleaner			e e e e e e e e e e e e e e e e e e e
140-1073	* <u>L</u> *	Côver, Air Cleaner (Inlet)	ė.		•
140-1001	, <u>, , ,</u> 1 ,	Element	a. A		- A
140-1071	1	Cover, Air Cleaner (Outlet)	Br.		
503-0311	1	Clamp, Hose			H
140-1075	1	Elbow, Air Inlet			
140-1073	, f	Bracket, Air Cleaner			
134-3066	1 1	Housing, Blower		• • • • • •	
193-0005	1	Gauge, 011			
502~0017	· 1	Connector, Female			► e ^{N°}
	-		* **	, v	· · · · · · · · · · · · · · · · · · ·
		A CONTRACTOR OF THE PROPERTY O	,	***	



Supplementary Parts List

4		~ ·
		■.
	-	_

Model CCKB-S

Spec

2935J

Standard Parts Catalog

927-0404

Parts Key ___1

PART NO	QUAN.	DESCRIPTION
	2	
(c)		NOTE: This model has a Optional Variable Speed
*	ي. په	Governor - Complete breakdown in Marin Parts
· · ·	d	Catalog
110-0915	1,	Block Assembly, Cylinder
104-0881	1	Crankshaft
515-0061	1 .	Key, Crankshaft Stub
120-0413	1	Cup, Oil Pump Intake
102-0468	1	Base, Oil
516-0011	2	Pin, Gear Cover
167-1557	1	Cable, Spark Plug - Hi Tension - 17"
167-1559	1	Cable, Spark Plug - Hi Tension - 19"
123-0762	`1	Cap and Indicator, Oil Fill
123-0958	2	Screen, Breather Tube
134-1579	1 .	Housing, Blower
517-0021	1 1	Button, Dot - Housing
193-0068	1	Gauge, Oil Pressure
167-0237	2	Plug, Spark - Resistor
141-0689	1 ,	Carburetor - Complete breakdown in Main Parts Cata
140-1302	1	Gasket, Adapter to Carburetor

SPEC

2947J

FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY NO OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

KEY NO.

PART NO.	QTY.	DESCRIPTION	PART NO. OTY. / DESCRIPTION
Group - 13		Top Mounted Engine Control	
104-0881	1	Crankshaft	
105-0234	1	, Camshaft	
160-0752	1	Stator Assy Magneto	•
		(Includes Parts Marked *)	
160-0750		Goil, Magneto Stator	
. 160-0749	1	Pole Shoe, Magneto Stator	
167-1557	. 1	Lead, Hi Tension	
167-1559		Lead, Hi Tension	
167-0188	. 4 .	Clip, Harness	
508-0095	2 · ·	Grommet, Hi Tension	
160-0791	1 .	Cam, Timing Control	
160-0789	1	Weight Assy, Timing Control	
518-0185	2	Ring Retaining, Timing Cont.	
160-0727	- 1 1	Spring, Timing Control Retainer, Timing Control	
160-0726 150-0075	1.	Pin Governor Center	
160-0948	1	Wheel, Magneto (Includes Ring	
100-0940	Τ.	Gear & Magnets)	
192-0308	1 .	Sheave, Rope	
192-0296	· 1	Backplate	
508-0084	1	Grommet, Oil Line	
502-0020	1	Elbow	# 1
501-0203	$\bar{1}$	Line, 0il	
140-1087	1	GAsket, Air Cleaner	
154-0998	1	Manifold, Exhaust	
505-0329	1	Cap, Pipe	
153-0327	1	Bracket, Choke	
154-0973	2	Gasket, Exhaust Manifold	
518-0176	1	Clip, Choke Cable "	
134-2998	. 1	Housing, Blower	the state of the s
517-0009	1	Button, Dot	
150-0147	1	Stud, Governor Adjusting	
150-0098	1	Spring, Governor	
- /	e e		
<i>j</i> .		,	
1	,		
ļ.			
F .			



SPECIA	38、连连载点,上点到《发发》的"生产发行"。 人	T FOR MODEL		EC : 4 2953J
	医动物性多元的 医肾性胚 海绵机管 化二氯化甲基乙烷	NDARD PARTS REFER TOUPS IN CATALOG ARE LIST		0404 KEYNO. 2 DWWHEN USED.
PART NO.	OTY.	, DESCRIPTION	PART NO QTY.	DESCRIPTION
Group – 6 Group – 22		heel Alternator (Syncro) able Speed Governor		
193-0108 502-0058 134-2824	l Tee,	er, 011 Pressure -011 Pressurer Sender i, Flywheel Cap Screw		
		· · · · · · · · · · · · · · · · · · ·	2	
	•			
				#*************************************
			3	
			•	

Redistribution or publication of this document by any means, is strictly prohibited.

Supplementary Parts List

for

	17.	and the con-		C:		1.lies
		1.0		1.1-		
Ν.Л	•	no	. A			. "
WI	U			1, 1	٠.	

CCKB-MS

29,69J

Standard Parts Catalog

927-0404

Spec

Parts Key __

PART NO.	QUAN.	DESCRIPTION
	wonis.	DEOUTH HOM
	÷	
	· · · · · · · · · · · · · · · · · · ·	This Model has Vacu-Flo Cooling and Optional
		Full Flow Oil Filter-Complete Breakdown in Main
· · · · · · · · · · · · · · · · · · ·		Parts Catalog
35		
11,0-1832	1	Block Assembly, Cylinder
104-0872	1	Crankshaft
110-1037	12	Vålve, Intake
110-0904	4	Rotocap
509-0090	2	Seal, Valve Stem
120-0648	1 ,	Cup, Oil Pump Intake
102-0828	1:-	Base, Oil
122-0345	, 1	Tube, Oil Filter Drain
166-0519	1	Indicator, Timing Bracket
123-0694	-, 1 ·	Cap and Indicator, Oil Fill
123-0958	2	Screen, Breather Tube
309-0237	1	Switch, Low Oil Pressure
134-3320	1 '	Housing, Blower
. 517-0035	1.	Plug, Dot Button - 1-1/16"
* 150-1560	1	Bracket and Lever - Throttle Control
167-0237	2	Plug, Spark
150-0635	1	Bracket, Governor
134-2956	[.]	Guard, Scroll Outlet
134-3317	4	Scroll, Air Discharge
309-0002	1	Switch, Temperature Cutoff
166-0641	, 1	Bracket, Coil Mounting
167-1581		Cable, Spark Plug - 15"
167-1557	1 4.	Cable, Spark Plug - 17"
503-0311	2	Clamp, Coil Mounting
154-0973	2,,,	Gasket, Exhaust
155-0906	1 2	Muffler, Exhaust
141-0281	2	Gasket - Carburetor and Coil Bracket Mounting
154-1116	1	Manifold, Intake
301-3843		Bracket, Terminal Block Mounting
332-1273	1	Marker, Strip
332-0604	1 1	Block, Terminal
338-0619	1 -	Harness, Wiring
- 140-1087	1	Gasket, Adapter to Carburetor
134-3095	1 1 <u>1</u>	Housing, Cylinder Air - L.H.
G134-3096	7	Housing, Cylinder Air - R.H. Redistribution or publication of this document by any means, is strictly prohibited.
517-0021	2	wheel, Blower by any means, is strictly prohibited. Plug, Dot Button - 7/8"
21/~0021		1/ IIUE, DUU, DUUUUII # +// U

															969						
						B-															
		al.									D(
													4								
						C												9 V			

PART NO.	QUAN.	DESCRIPTION
150-0698 515-0202 141-0689	1 **	Spring, Governor Key, Crankshaft Stub Carburetor - Complete Breakdown in Main Part
505-0057 505-0618	1	Plug, 1/8" - Intake Manifold Cap, Muffler
	al al	

SPECIAL PARTS LIST FOR MODEL CCKB-MS SPEC 2984J FOR STANDARD PARTS REFER TO CATALOG 327-0404 KEY NO. OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED. PART NO. QTY. DESCRIPTION DESCRIPTION PART NO. Alternator Left Side Mt. Vacu-Flo Cooling Base, 011 Plug, Oil Base 2 Bushing, Reducer

Group - 1 Group - 14 102-0791 505/-0110 50/5-0019 123-Q527 1 Cap & Indicator, 011 Fill 123-0679 Tube, Oil Fill Crankshaft 104-0879 Tee, Oil Pressure Switch 502-0058 Line, Oil 501-0004 309-0237 Switch, Pressure Brace, Alternator Support .1 191-1113 Wheel, Blower 134-0753 1 Scroll, Blower Housing 1 134-0564 Lead, Hi Tension #2 Cyl. 1 167-1483 1 Lead, Hi Tension #1 Cyl. 167-1489 166-0346 Coil,-Ignition-Bracket, Governor Linkage 150-1268 Housing, Blower 134 - 3122517-0035 Plug, Dot Button Plug, Dot Button 517-0021 Gauge, Oil 193-0005 Elbow, Inverted Male 502-0005 154-0998 Manifold, Exhaust Cap, Pipe 505-0329 153-0327 .1. Bracket, Choke Clip, Choke Cable 518-0176 Gasket, Exhaust Manifold 154-0973 2

Key, Crankshaft

515-0103

Supplementary Parts List

: 11	1.1		11.00			107 11 1	 	4	
		.3.	18.	1.0	1 11	200	 	- M	~
							 ш.		
ш	.,					- A - 2		- IV +	
u						-		1: 4-4	~~

Spec 2985 J

Standard Parts Catalog <u>927-0404</u>

Parts Key __2_

Parts Listed Below Apply to the Above Model. Use These Parts in Place of (or in

		Landing to the second s	DESCRIPTION
	110-1860	1	Block Assembly, Cylinder (Includes Bearings, Guides
Z			and Seats)
	104-0872	-1 , $\overline{1}$	Crankshaft
4-1-1-	102-0782	1 1	Base, Oil
	120-0648	. i -	Cup, Oil Pump Intake (Includes Cup, Screen & Pipe)
1	123-0694	1	Cap and Indicator, Oil Fill
	141-0726	1 1	Carburetor (Gas) - NOTE: Carburetor Parts listed
	***	•	in main parts catalog - Begin Spec H.
14 - S	152-0090	1	Stud, Governor Adjusting
	FULL FLO OIL F	ILTER AND	ASSOCIATED PARTS Listed As Optional Equipment
	in Main Parts (Catalog.	
	134-2828	1	Housing, Blower
	134-2760	୍ର 1	Housing, Cylinder Air - R/Hand
		· · · · · · · · · · · · · · · · · · ·	
		1	
	A		
	and the same		
• • •			
*** LL 2	· W		
		1 .	!
(*			

SPECIAL PARTS LIST FOR MODEL _____CCKB-MS

SPEC

2989J

FOR STANDARD PARTS REFER TO CATALOG 927-0404

DESCRIPTION

PART NO. QTY.

KEY NO.

DESCRIPTION

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

110-1904	1 Block Assembly, Cylinder	
110-1827	2 Guide, Valve	
110-0893	2 Retainer, Valve Spring	
509-0090	2 Seal, Valve Stem 011	
149 - 0136	1 Cover, Fuel Pump Hole	
150-0755	· 1 Arm, Governor	_
150-0096	1 Stud, Governor Adjusting	
150-0698	1 Spring, Covernor	
141-0726	1 * Carburetor	
134-2824	1 Guard, Flywheel Capscrew 🔧	
134-2926	1 National Housing, Blower	
150-1262	1 Bracket, Governor	86
141-0713	1 #Needle, Idle Adjusting	
المراز بالتهايين المحرام	والمنتبعة والمنتفر وا	4

Same as carburetor listed in Group 31 except parts marked #.

d	ľ	è		ř	e	. 5	e en Gran		4	_(](K	В	-1	15	10.0		, j	ļ.,		4	d		и. Н	¢	1	1))				le T		3	0	17		J	N	- -			1 1	Š				3.		; ·
1		en:	1		7				1		W:		***	***	-						•	-	***	····		1	•	•	-		14.	 			7 Tr.		_	****		e e e	i.	٠.,			-	75				
į	Š	į.		n	d	2		A		þ	្ន	r				ŧ	2	ı		n	i de la companya de l			ं • • }	·	9	2	7 -	0	4()4		i ji	1			D	2		te		()	67	,			?		. ,	

		l some me as a series and a series and a
		NOTE: This Model has a 12-Volt, 15 Ampere Flywhe
		Charging Alternator (shown as Optional
		Equipment with Associated Parts in main
		Parts Catalog).
110 0015		Da la la Calla la Citada la Despisa
110-0915	1	Block Assembly, Cylinder (Includes Bearings, Guides & Seats)
104-0872	. 1	Crankshaft
102-0759	1 3 1	Base, 0i1
120-0648	1	Cup, Oil Pump Intake (Includes Cup, Screen
	a	& Pipe)
123-0694	(*) 1	Cap and Indicator, Oil Fill
134-2995	1	Housing, Blower
134-2791	1 ACTUEDNOD	Housing, Cylinder Air (Right Hand)
150-0147	TOVERNOR 1	shown as Optional Equipment in main Parts Catalog. Stud, Vari-Speed Governor
134-3019	1	Flywheel (Includes Ring Gear)
20, 0010		
4. 2	(· · · · · · · · · · · · · · · · · · ·
		· din
· ·	-	•
	<i>j</i>	



CCKB-MS

° 3030J

FOR STANDARD PARTS REFER TO CATALOG

KEY NO.

	ANOITAC	L GROUPS IN CATALOG ARE LIST	ED	BY GROUF	NO. BELOV	v when used:
PART NO.	QTY.	DESCRIPTION		PART NO	. QTY.	DESCRIPTION
Group - 6 Group - 13		Flywheel Alternator (Syncro) Top Mounted Engine Control	M. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1.			
167-0188 501-0203 508-0084 150-0147 134-3024	2 1 1 1	Clip, Harness Line, Oil Grommet, Oil Line Stud, Governor Adjusting Housing, Blower	Common process, many			
			de la companya de la			
•	-		r		/	
	, ,		F			,
3.			,		٠ ٢ ٢ ١	· · · · · · · · · · · · · · · · · · ·
	P			, • •		
					*	2.5
	* 1 1 v					
Current Pol	ver neration	A STATE OF THE STA			RedistN by any	bution or publication of this document

	T 1 T 1 T 1 T 1 T 1 T 1			and the contract of	and the second of the second	5.5	- 12 1
	- Colonia Carrier Library		Training for page special and the second	S LIST	السند السود المشارات	 Lose Contract 	
- 1	X PATE OF THE						
		1.41		- 1 - 1			
	سفاك يستنان والاست						

CCKB-MS

PART NO.

SPEC

3032J

FOR STANDARD PARTS REFER TO CATALOG

927-0404

QTY.

KEY NO.

DESCRIPTION

PART NO. UTY.	DESCRIPTION
Group - 5	Flywheel Alternator (Phelon)
Group - 8	Spin On Oil Filter
Group - 13	Top Mounted Engine Control
110-1860 1	Block Assembly, Cylinder
167-0188 2	Clip, Harness
134-3019 1	Flywheel (Includes Ring Gear)
501 / 0203 1	Line, Oil
150-0147 1	Stud, Governor Adjusting
153-0327 1	
518-0176 1	Clip, Choke Cable
508-0084 1	Grommet, Oil Line
134-2760 1	Housing, Cylinder Air RH
134-3222 1	Housing, Blower
, i	

CCKB-MS

° 3049J

FOR STANDARD PARTS REFER TO CATALOG -927-0404

KEY,NO.

PART NO. Q	TY. DESCRIPTION	PART NO:	, QTY.	DESCRIPTION
Group - 5 Group - 8	Flywheel Alternator (Phelon) Spin On Oil Filter			
110-1860 104-0382	l Block Assembly, Cylinder 1 Crankshaft		8	
167-0188 150-0635	2 Clip, Harness 1 Bracket, Governor Arm	6		
150-0096 * 150-0698	1 Stud, Governor Adjusting 1 Spring, Governor	٠,٠٠٠ من		
155-0906 . 154-0973	1 Muffler, Exhaust 2 Gasket, Exhaust Muffler Mtg		. u	
.134-2760 .134-2828	1 Housing Cylinder RH 1 Housing, Blower			
***		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		



CCKB-MS

3061J

FOR STANDARD PARTS REFER TO CATALOG

SPEC 927-0404

KEY NO.

PART NO.	QTY.	DESCRIPTION		PART NO.	QTY.	'8" : "T	DESÇ	RIPTION	
Group - 1		Alternator Left Side Mtg.				•		•	ā.,
Group - 8		Spin On Oil Filter						4	. ~
Group - 22		Variable Speed Governor	١.		*				
Group - 29	A CONTRACTOR OF THE PARTY OF TH	Carburetor (141-0721)	. "			200			
110-1860	1	Block Assembly, Cylinder .				4	1 -		
102-0791	<u>/ 1</u>	Base, 011	*						
134-0675		Flywheel (Includes Ring Gear)				•	•	,	,
501-0004	1	Line, 011	. "	1		•			
-508-0095	1.	Grommet, Rubber	`			Q	•		
134-2760	1	Housing, Cylinder Air RH	·	•		•	•		
154-1051	1	Manifold, Intake	l :	Ì	, ,	192			1
154-0998	1	Manifold, Exhaust	l	· • • • • • • • • • • • • • • • • • • •	1		* :*		,
154-0973	2	Gasket, Exhaust Manifold Mtg.					œ.		
505-0329	1	Cap, Pipe		* *				1.	
502-0395	1	Elbow, Hose					,		
153-0327	1	Bracket, Choke	<u> </u>		. *.	7		•	
518-0176	1	Clip, Choke Cable	l.		٥ .	wi .	٠.		•
* 193–0173	1	Bracket & Fitting Assy, Oil			. •	¥			٠.
		Lihe	, .						- W
505-0057	1	Plug, Pipe	ļ [*]		,	٠.	•		
134-3262	1	Housing, Blower						4	
			ļ		-	•			. *
	¥ .		ļ	,	5.	•	, s	•	
	o Salaharan			* *		•			
			۲.	· · · · · · · · · · · · · · · · · · ·				• • • • • • • • • • • • • • • • • • • •	′

CCKB-MS

SPEC

3074J

• oi	FOR STAND PTIONAL GROUP	ARD PARTS R S IN CATALOG A	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1			The second secon	Y NO. 2 D. 3
PART NO.	OTY.	DESCRIPTION		PART NO.	OTY.	* DES	CRIPTION
						•	
Group - 1		tor Left Side			* • • • • • • • • • • • • • • • • •		
Group - 20		Magnetic Choke		, ,	46		
Group = 22		e Speed Govern			4 NW	•	NE STORY
Group = 28	Carbure	tor (141-0690)	*				لأعاشين بالعاداء
102 0701	1 = 0	4.1	**	4	\$	*	· · · · · · · · · · · · · · · · · · ·
102-0791 ··· 155-0906	1 Base, 0	, Exhaust				· *	
154-0973		, Exhaust Exhaust Muffl			ć . 6		13
505-0618	Gasker,		EI				
502-0015	1 Elbow,	7				et e e e e e e e e e e e e e e e e e e	
	2. Joint,		,	KI S			
520-0263		overnôr Linkag	_		¢	•	
140-0971	<u> </u>	, Air Cleaner			<u>.</u>		
		Air Cleaner A	danter	9.0	*.0	. # 	and the second second
140 0721	(GASKEL)	, All Gleaner	Mageer	8	1 4. 1	*	*
				_			
Parts Not F	urnished By On	an į			ae.	. 9	, ,
	Cleaner	*		•	. e-	•	
· · ·	A STATE OF S	, c			•		
	₩		*~	*	4	*	, ·
	· . %		,	4		·	
		,		ę ·		*	100
-		3, 1		- J. W	•		s. 5
	<u>ن</u> .	a t					
				, , ,	ø .	ę. "	
	•	**	<u> </u>		Į.		
•	***	*		.	, , ,		
0		ς.	, l·	4 -		• •	. fy
		3		™ P	Þ		k 2 * 3
- 	· u		1		•		ş. . 6
~	· · · · · · · · · · · · · · · · · · ·	*	, ,			· e .*	41 -
*	3 - 1 - 2 - 3 - 3	, <u>-</u>	'.	Ď	;.		- ·



CCKB-MS

SPEC

3083J

	FOF	IS LIST FOR MODEL R STANDARD PARTS REFER TO AL GROUPS IN CATALOG ARE LISTE		KEY NO. 2
PART NO.	QTY.	DESCRIPTION	PART NO. QTY.	DESCRIPTION
Group - 5		Flywheel Alternator (Phelon)		
150-0635 150-0698 150-0096	1 1 1	Bracket, Governor Arm Spring, Governor Stud, Governor Adjusting		
· · · · · · · · · · · · · · · · · · ·				
The second secon	i e e e e e e Koji isa			
P	i The			
,		a a	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	
	n			
		75.		
		, ę	A New	
	7		a a second and a second a second and a second a second and a second a second and a second and a second and a	
	°0, .			
14,				
÷ .		· · · · · · · · · · · · · · · · · · ·	9	
		· · · · · · · · · · · · · · · · · · ·		
vi.			· · · · · · · · · · · · · · · · · · ·	the second secon
* i .				•
,	ia '			٠ ٧
				and the second
	* .			
* • • • • • • • • • • • • • • • • • • •	* <u>.</u>			
	,	· · · · · · · · · · · · · · · · · · ·		1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1
			* **	



CCKB-MS

SPEC

3089J

FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY

KEY NO.

	OPTIONAL	GROUPS IN CATALOG	ARE LISTI	ED BY GROUP N	O. BELO	N WHEN US	ED.
PART NO.	ОТУ	DESCRIPTION	1	PART NO.	QTY.	DES	CRIPTION
			, a		19. E. J.		A
Group - 6	F 1	ywheel Alternator (Syncro)		. The se		
Group - 8		oin On Oil Filter			, ,		
110-1911	1 B	Lock Assembly, Cylin	der				
110-1000		eat, Intake Valve	-		`		, A
110-1037	2 V.	alve, Intake				,	
110-0904	2	otocap, Intake Valve	i 4, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1,			,	
167-0188		Lip, Harness	•		a .	*	
309-0237		vitch, Oil Pressure				**	
19 1 -1148		ılley Alternator Dri		4	•	ţ.	e + ,
134-2760		ousing, Cylinder Air	RH				
155-0906		iffler, Exhaust				*	1
505-0618	7.7	ap, Pipe	aw Mta			* ;	
■ 154-0973 153-0327		asket, Exhaust Muffl racket, Choke				Æ.	4
518-0176		lip, Choke Cable	The same of the sa		, s		
134-3262		ousing, Blower					
150-0635		racket, Governor Arm	1		r '	a	+6
150-0096		tud, Governor Adjust			*7		
150-0698		pring; Governor	J			, ·	4
					,		· ,
,	3 "	~ , o	,		o · · · · · · · · · · · · · · · · · · ·	<i>i</i>	٠, '
		· · · · · · · · · · · · · · · · · · ·	73°		•	6	•
	募		· "	i sa	· · ·		•) ~
		*** · · · · · · · · · · · · · · · · · ·	a		4		*
•	•		·	, , , , , , , , , , , , , , , , , , ,	76	* *	, #
					at Table of the state of	e s	.
	•		(− 2 ₁ ,				a
	<u>.</u>		<u>- ' </u>	1	· · · · · · · · · · · · · · · · · · ·		•
		<i>y</i>	€	F	£9 ^{1°} 7°	•	
				1,			» "
				•		, * • • • •	•
			·	ez.	•		⊕
and the second s					F. 7	ę	. ^
		• • • • • • • • • • • • • • • • • • • •			1 200		
	- * *	*					: A9
	6.	g ·	•	•		· ·	
		9 .		è	and the section of		
*		A TO THE RESIDENCE OF THE PARTY	narana arawinina	And the second s		-	<u> </u>
				Maria Santa	1 1 1 2 1	*	φ.
	•	0		. ~			
			·	1 a	. 🏚	• "	*
			• " ° .	4 *		J	•



CCKB-MS


3098J 🔭

FOR STANDARD PARTS REFER TO CATALOG_

SPEC 927-0404

KEY NO.

PART NO. OTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Group - 5	Flywheel Alternator (Phelon)			
Group - 13	Top Mounted Engine Control			
110-0893 2	Retainer, Valve Spring			south the court with
167-0188 2	Clip, Harness			
501-0203 • 1	Line, Oil			
502-0020 1	Elbow, Oil Line			
150-0147 1	Stud, Governor	, , , , , , , , , , , , , , , , , , ,		
150-009 8 1	Spring, Governor			
141-0726 * 1	Carburetor			3
134-2995 • 1	Housing, Blower			
141-0713 1 #	Needle, Idle Adjusting			
		d .		
			X •	
<u>* - Same as carbur</u>	etor listed in Group 31		,	
except parts m		The state of the s	i ja jaar ee	rangaan kan kecamatan ka





900-0043

Supplementary Parts List

٠		_		٠.	
i			-		-
	9				
7		i	п	м	۰
	7	м			
i			_		

i.	, i	. .			11-7		CCI	⟨B-	MS
ı	13		1:	M Žijus		5 4	(ga∳illeria Gal—ala	1,800	25%

Spec

3100J

Standard Parts Catalog

927-0404

Parts Key .

PART NO.	QUAN:	7 DESCRIPTION
		NOTE: This model has a Variable Speed Governor and 12 Volt, 20 Amp Flywheel Alternator. Complete breakdown in Main Parts Catalog.
110-0915 104-0872 110-0893 120-0648 102-0828 149-0136 149-0003 526-0063 800-0004 123-0694 123-0958 134-2826 167-0237 167-1560 167-1581 141-0726 140-0921 152-0090 150-0621	1 1 4 1 1 2 2 1 2 1 2 1 1 1 1	Block Assembly, Cylinder Crankshaft Washer, Spring Retainer - Intake Valve Cup, Oil Pump Intake Base, Oil Cover, Fuel Pump Hole Gasket, Fuel Pump Hole Washer, Copper Fuel Pump Hole Screw, Fuel Pump Cover Cap and Indicator, Oil Fill Screen, Breather Tube Housing, Blower Plug, Spark - Resistor Cable, Spark Plug - Hi Tension - 24" Cable, Spark Plug - Hi Tension - 15" Carburetor (Gas) - Complete breakdown in Main Part Catalog Gasket, Adapter to Carburetor Stud, Variable Speed Adjusting Nut, Variable Speed Adjusting Stud Parts Not Furnished by Onan:
		193-0108 - Sender, Oil Pressure Gauge 193-0107 - Meter, Oil Pressure

900-0043

Supplementary Parts List

		`	٦
æ	1		4.
•			٠.
			4

İ	М	O	de		٠. (CKB-	MS			168 1 ()		Sp	ec			3 .	(04.	J.:				(V.)		
l	i,	.	· - 4 .				4			12 S 1 Sept.		7-04		3	ň	. 4.						, ,		 it h
	51	la	nd	arc	I P	arts	Ca	talc)g		92	-01	1 04				- (_P	art	s K	(ey	1	2 ع م	1

PART NO.	QUAN.	DESCRIPTION
	2	
		NOTE: This model has a 12-Volt, 20-Ampere
		Flywheel Charging Alternator - Complete
	*	breakdown of component and associated
T		parts in parts catalog - Optional Equipmer
110-1418	1	Block Assembly, Cylinder (Includes Bearings, Guides and Seats)
104-0878	1	Crankshaft
102-0759	- 1 -	Base, Oil
120-0648	-1	Cup, Oil Pump Intake (Includes Cup, Screen & Pipe)
123-0694	1	Cap and Indicator, Oil Fill
RING SET, PISTON		
113-0126	2	Standard
113-0126-05	2	.005" Oversize
113-0126+10	2	.010" Oversize
/ 113-0126-20	2	020" Oversize
/ 113-0126-30	2 ·	.030" Oversize
/ 113-0126-40	2	.040" Oversize
154-0998	1	Manifold, Exhaust
505-0329	1	Cap, Pipe
154-0951	1	Manifold, Intake
153-0327	1	Bracket, Choke
518-0176	1	Clip, Cable
143-0973	2 ,	Gasket, Exhaust Manifold
140-0921	1 ′	⊌ Gasket, Air Horn
134-2642	1 .	Wheel, Blower (Includes Ring Gear)
134-2995	1 .	Housing, Blower
502-0055	1	Elbow, Pipe (90°)
502-0002	1	Elhow, Inverted Male (90°)
193-0005	. 1 '	Gauge, Oil Pressure
153-0328	1	Cable, Choke
152-0041	1	Washer, Spring Tension
- 152-0170	1	Arm, Vari Speed Governor Control
150-0147	1	Stud, Governor Adjusting
19 2-0397	1	Plate, Rope Sheave
***		land the second of the second



Special parts list for model<u>cckb-ms</u>

AL PARTS LIST FOR MODEL CCKB-MS SPEC 3105Ú
FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY NO. 2
OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO.	ony. DESCRIPTION	PART NO.	OTV DESCRIPTION
	odel has a Magneto on System		
110-1418	1 Block Assembly,	152-0041	1 Washer, Spring Tension
	Cylinder (Includes	160-0948	1 Wheel, Magneto -
12 (1) (1) (1) (1) (1) (1) (1) (1) (1) (1)	Bearings, Guides and		Includes Ring Gear
	Seats)		and Magnets
104-1320	1 Grankshaft	150-0147	1 Stud, Governor Adjusting
102-0861	1 Base, Oil	192-0397	1 Plate, Rope Sheave
120-0648	1 Cup, Oil Pump Intake	153-0328	1 Cable, Choke
	(Includes Cup, Screen		
100 0004	and Pipe)		
123-0694	1 Cap and Indicator, Oil Fill		
	Ring Set, Piston		3
113-0189	2 Standard		a. Vi
97,	2 .005" Oversize	٠,	
	2 .010" Oversize		
	2 .020" Oversize		
	2 030" Oversize		
	2 .040" Oversize	•	
110-1283	1 Cover, Timing, Hole		
502-0020	1 Elbow, Oil Line - Up		40.5
501-0203	1 Line, Oil - Out Top	6	
	of Blower Housing	,	
154-0998	1 Manifold, Exhaust		· Commence
	(Cross-over)		
505-0329	1 Cap, Pipe		
	1 Manifold, Intake	-	
153-0327	1 Bracket, Choke		
518-0176	1 Clip, Choke Cable	,	
154-0973	2 Gasket, Exhaust		- · · · · · · · · · · · · · · · · · · ·
	Manifold		
140-0921	1 Gasket, Air Horn		ę d
134-2998	1 Housing, Blower		
517-0009	1 Plug, Dot Button		
502-0055 503-0003	1 Elbow, Pipe		
502-0002 313-0018	1 Elbow, Inverted Male		
193-0015	1 Button, Stop 1 Gauge, Oil Pressure		
152-0170	1 Arm, Vari Speed		
	Governor Control		
	www.itwi-wwifWi	1	

900-0043

Supplementary Parts List

3113J

2 44			أبهار والمستعدد	7
CCKB-M	S	i dit.		

Standard Parts Catalog 927-0404 Parts Key 2

Parts Listed Below Apply to the Above Model. Use These Parts in Place of (or in Addition to) the Parts Listed in the Standard Parts Catalog.

PART NO.	QUAN.	DESCRIPTION
		Note: This model has a Variable Speed Governor, Full Flow Oil Filter and 12 Volt, 15 Amp Flywheel Alternator shown as optional equipment. Complete breakdown in Main Parts Catalog.
110-1860 104-0872 120-0648 102-0828 149-0136 149-0003 800-0004 526-0063 123-0694 123-0958 134-3019 134-2828 167-0237 167-1560 167-1581 141-0689 134-2760 150-0096 150-0098	1 1 1 1 2 2 1 2 1 1 1	Block Assembly, Cylinder Crankshaft Cup, Oil Pump Intake Base, Oil Cover, Fuel Pump Hole Gasket, Fuel Pump Hole Screw, Fuel Pump Hole Washer, Fuel Pump Hole Cap and Indicator, Oil Fill Screen, Breather Tube Wheel, Blower and Ring Gear - Includes Magnets Housing, Blower Plug, Spark Cable, Spark Plug - Hi Tension - 24!' Cable, Spark Plug - Hi Tension - 15" Carburetor - Complete Breakdown in Main Parts Catalog. Housing, Cylinder Air - R.H. Stud, Variable Speed Adjusting Spring, Governor
		Not Furnished By Onan: Fuel Pump



Model

900-0043

Supplementary Parts List

CCKB-MS -3116J

Standard Parts Catalog

Model

Parts Key

Gı

Parts Listed Below Apply to the Above Model. Use These Parts in Place of (Addition to) the Parts Listed in the Standard Parts Catalog.

927-0404

PART NO.	QUAN.	DESCRIPTION
		This model is Vacu-Flo Cooled
110-1885	1	Block Assembly, Cylinder (Includes Bearings,
		and Seats)
104-0872	1	Crankshaft
110-1037	2	Valve, Intake
110-0904	2	Rotocap, Intake Valve
509-0090	2 .	Seals, Valve Stem Oil
102-0756	1	Base, Qil
120-0648	1	Cup, Oil Pump Intake (Includes Cup, Screen &
123-0703	1	Tube, Oil Fill
123-0690	,1	Cap and Indicator, Oil Fill
122-0320 *	- 1	Adapter, Oil Filter
122-0321	1	Gasket, Adapter
122-0323	"·1	Filter, Oil
122-0347	_ 1	Seal, Air-Oil-Filter
149-0136	1	Cover, Fuel Pump Hole
. 166≃0519	1	Indicator, Timing
103-0515	71	Gearcase
150-1541	1	Arm & Shaft Governor
140-1240	1	Adapter, Air Cleaner
503-0365	2	Clamp
140-1176	-, 1	Hose, Carburetor Air Inlet
134-0753	1	Wheel, Blower
134-2760	1	Housing, Cylinder Air (Right Hand)
* 134-1727	1 1	Scroll, Blower Housing
134-2956	. 1	Guard, Blower Housing Scroll
134-3273	1	Housing, Blower
508-0084	1	Grommet
517-0035	10	Plug, Dot Button
517-0021	1	Plug, Dot Button
150-1433	1	Bracket, Governor Adjusting
150-1214	1	Spring, Governor
150-1418	1	Stud, Governor Adjusting
154-1051	1 1	Manifold, Intake
140-0921	+	Gasket, Air Cleaner Adapter
501-0203	- <u> </u>	Line, Oil
502-0196		Elbow, Oil Line
Power503-0311	# ' \$1.4 - 1996) - 1911 (Clamp Coil Mounting
General66-0641	1	Clamp, Coil Mounting. Redistribution or publication of this document
Meller autout 1		Bracket, Coil Mountingby any means, is strictly prohibited. Bracket, Oil Pressure Switch

DOG-COAS

Supplementary Parts List

les al. 10	del	CCKB	and the latter of the first of the con-	JAN 4 March 5233 Per	33 d 2526 5 mg 1 mg 5 mg	ويسود فللملحف وكروا وأسا	and the same	e cara, transport a compa
	 	the second second	The second of th	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	in the second state of	311		and the second of the second
A STATE OF THE PARTY OF THE PAR		The first of the f	3 Page 1 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	والتقفيا المشوار فطيعة			
		11 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		1 (58) 1 (51) 243			整理を基準 と もばに	of Color to the action of the
		and a second to the state of the second state	M. Carlott M. S. A. Carlott and M. Carlott and Carlotte a	1. Lide Sat Address of the Control		manufacture of the second second	and an extension of the conflict.	Marie radio man bushe arang
14 2			1 7 1 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2		100			

Standard Parts Catalog 927-0404 Parts Key _____

Addition to) the Rar	ts Listec	he Above Model. Use These Parts in Place of (or in in the Standard Parts Catalog.
PART NO.	OUAN.	DESCRIPTION
502-0003 140-0867 123-0732	1 1 1	Connector Adapter, Air Cleaner Tube, Breather Connector
		Parts Not Furnished by Onan Fuel Pump Air Cleaner Choke
	-	
· · · · · · · · · · · · · · · · · · ·		
*		

. A	71 4
100	
-	

UЧ		1.4	W.	121	310	31137	! · · ·	A 14.	10.546	9.35	70 (2.0	Taker	1.6	5.7	(* T)		Carrier (C	200	ir i _e .	18	4 (1) 1 (2)	5 - 5 - L	医多种抗菌	25000	1.77
ď	1.36	р.	W.		كالله أأو	All the	1.		. 13 - J. J	4	de la constant		400	11.	200	is	ي دو ال	الرق ھا "		4. (19)		等价值 点		. ^ +	19.00	4.7
4	w	h-	رنايا	4	-11	ш,	824	مواليم	وفالحاد	-13	KB.	₩ MZ	-4	1.5 11	- Marin 1969 *	شور و الله	*****		212				- 5 L*	1111	4 - 1 i	
	٠,	f.	W	a f	: 1		i		11.5	~	****				1,31	Sec.	F 11 1	, ,	5,0	10	•				4 4 5	
i i		A.	di.	الد	ďΑ.	legio.	4				-	-		سيمستث			-		- K		₩.	-			-	

Standard Parts Catalog

927-0404

Parts Key

2

PART NO.	QUAN.	DESCRIPTION
	(9	
		NOTE: This model has a Variable Speed Governor
المنظمة المنظم المنظمة المنظمة		shown as Optional Equipment in Main Parts
		Catalog.
110-0915	1	Block Assembly, Cylinder
104-0872	1	Crankshaft
120-0648	1	Cup, Oil Pump Intake
102-0828	1	Base, Oil
123-0694	1	Cap and Indicator, Oil Fill
123-0958	1	Screen, Breather Tube
134-2984	1	Housing, Blower
167-0237	, 2	Plug, Spark - Resistor
167-1560	1	Cable, Spark Plug - Hi Tension - 24"
167-1581	1 .1	Cable, Spark Plug - Hi Tension - 15"
154-0998	- 1	Manifold, Exhaust
505-0329	1	Cap, Exhaust Manifold
141-0689	1 "	Carburetor - Complete Breakdown in Main Parts Cata
153-0464	J	Bracket, Choke
154-0973	2	Gasket, Exhaust Manifold
153-0351	1	Choke Assembly, Manual
518-0176	1	Clip, Choke Cable
308-0140	1	Switch - Start, Run, Off
•		
· · · · · · · · · · · · · · · · · · ·		
	. 1941. <u>1941.</u>	



r	- 10	Ιij	 12	da.	
	٠,	7	٦.	100	
	æ	ч	ı.		
	~			- 1	

	М	O	de	1	L	C	CKB	-MS				S	ad a	C	. (X <u>i</u>)	3	141J			i dy Santana		- <u> </u>					,
v	ē, i i i	T	-			٠.,	4 .			.4						· . · · ·	۰. ۲۶	5	. , , , , ,	· ·				× 2			Ç.Ş.
1	S	ta	nc	lai	ď	P	rt	s C	at	alc	a		92	7,-	U4	υ4		ا ست داده	្ឋ	ar	s	Ke	٧.	<u> </u>		er.	*

PART NO.	QUAN.	DESCRIPTION
. 27		This model is equipped with a 12 Volt 20 Ampere Flywheel Alternator
110-1904	1	Block Assembly, Cylinder (Includes Bearings, Guides
104 0001		and Seats) Crankshaft
104-0881	1 1	
509-0090	2	Seals, Valve Stem Oil (Intake)
102-0759	1 1	Base, Oil
123-0508	1 1	Tube, Oil Fill Cap and Indicator, Oil Fill
123-0527	4	Cup, Oil Intake (Includes Cup, Screen & Pipe)
120-0648	1 1	Manifold, Exhaust
154-1549	4	
153-0327	1	Bracket, Choke
518-0176	1	Clip, Choke Cable
154-0951	$\frac{1}{1}$	Manifold, Intake
140-0921	1	Gasket, Carburetor Air Horn
145-0398	1	Adapter, Carburetor Air Inlet
503-0170	2	Clamp, Breather Hose
152-0186	1	Bracket, Variable Speed Governor
152-0083	1	Arm, Speed Control
152-0184	1	Spacer, Vari Speed Governor
510-0015	_ ' 10	Ball, Governor Fly
149-0136	1	Cover, Fuel Pump Hole
154-0973	2	Gasket, Exhaust Manifold
152-0185	I	Stud, Governor Adjusting
503-0582	1	Hose, Breather
•	ľ	Parts not furnished by Onan
•		Air Cleaner
		Fuel Pump
·		
<u> </u>		

12	-	į	n 111	1 153		-11		-,,-	T .T	11.	7	371	1100 0	10.0	W 1 4 4		200	91	100	11.0			î	100			14.65	9.77	- 5	13. *		27.		. 2.71		50 mg	3 Table 1			
107	44.1	277	11114	M. 11	T- 13c	(5 4	1. 5			-	10.00		al. 10		44. 1		1200	, 1	20.0	51.	275.7	1.	'	5 Fr	1.		JI 1	7.0	1.1		77 19 1				•		
и.	3 10		1111	11.	1.9	· h		i		. * **		7.TH 8	, ,,	4.5.	MS			1.51				10.00		1	- 3 -		. 20	2 4			2.1			7.0	•	. 42	15.	2 .		7.00
1		1		117.5	61	100	1.30	1.4	4	'11' '11									- 21	100			10.00			5.10	. 1.5	41- 1			100		10.0	1 1				3.	- 11	1
Ич	GI. I		45.	114	. 10.11	W 16.7	C., b	2, 17		11.5			·	17,1	L'Alle	٠		14. 1		11 4-5			9.7	**	. 8 .	1	·	11.0	50 B	10.00	- 1	- 4		4.7	-		~			
ж			1.70	vi. 10		1.0			1.	11	-		*****	. 15	MF.	F 16.	41.1							* 2	,			4 L	98 a a	45.00				3.5			. ' :		1.	
		14.1	110		1 1 11 1		٠	. N/.	1.0		4.7		100.00	• .	117			4 .	1.30			2.2		- 1 Table 1		* 1 * . š					100		6.			1000	·			
		510	a 7	-			1		~			70.7	* T *	70.0	1.00	10.0		1				DIL			17	,	\$	1.0		10.00	ly s		. · ·	41	1.	•i			1.	i .

Standard Parts Catalog ______927-0404 Parts Key _ &___

	QUAN.	DESCRIPTION
1000年 豐富 人名克雷斯特		
		This Model has a 12 Volt 35 Ampere Top Mounted
	1	Alternator (Shown as Optional Equipment in
	•	Main Parts Catalog)
110-0915	1 1	Block Assembly, Cylinder (Includes Bearings, Guides
		and Seats)
104-0872	1 1	Crankshaft «
102-0756	1	Base, Oil
120-0648	1.	Cup, Oil Intake (Includes Cup, Screen & Pipe)
123-0679	1 1	Tube, Oil Fill
123-0527	1	Cap and Indicator, Oil Fill
154-1816.	1	Manifold, Exhaust
154-0973	2	Gasket, Exhaust Manifold
103-0515	_l 1	Gear Cover
150-1541	1 1	Arm & Shaft, Governor
191-0639	1 1	Baffle, Alternator Air
511-0090	1 1	Belt, Alternator
134-3280	1	Housing, Blower
518-0176	1	Clip, Cable
150-1343	1	Bracket, Governor Mounting
150-1269	1 🗭	Bushing, Governor Control
134-1644	1	Housing, Cylinder Air (Left Hand)
134-2916	1 :	Housing, Cylinder Air (Right Hand)
140-0921	1	Gasket, Air Cleaner
134-0675	1	Wheel, Blower
150-1435	1 1	Arm, Governor Control
152-0155	1	Swivel, Choke Lever
150-1398	1	Spring, Governor Idle
516-0059	1 1	Pin, Cotter
	1	
•		



Model CCKB-MS	Spec 3163J	
	[요일: #1][요일 [요일 [2] [2] [2] [2] [2] [2] [2] [2] [2] [2]	
Standard Parts Catal	927-0404	Parts Key2

PART NO.	QUAN.	DESCRIPTION
	4	NOTE: This Model Mas a 12-Volt, 15 Ampere Flywheel
		Charging Alternator (shown as Optional
		Equipment with Associated Parts in main
		Parts Catalog).
110-2375	1	Block Assembly, Cylinder (Includes Bearings, Guides & Seats)
104-0872	1 1	Crankshaft
110-1037	2	Valve, Intake
110-0904	2	Rotocap, Intake Valve
102-0782	1 1	Base, Oil
120-0648	1 1	Cup, Oil Pump Intake (Includes Cup, Screen
	1	ቼ Pipe)
OIL FILTER ar	nd Associated	Parts shown as Optional Equipment in Parts Catalog.
149-0136	1 1	Cover, Fuel Pump Hole
123-0694	1	Cap and Indicator, Oil Fill
134-2828	1 1	Housing, Blower
134-2760	1	Housing, Cylinder Air (Right hand)
 VARIABLE SPEE 	ED GOVERNOR s	hown as Optional Equipment in main Parts Catalog.
154-0998	1	Manifold, Exhaust
	•	
-]	
•		
·		



SPEC

3170J

FOR STANDARD PARTS REFER TO CATALOG_

927-0404

KEY NO. 2

PART NO QTY.	DESCRIPTION	PART NO GTY	DESCRIPTION
The state of the s			***
Group - 1	Alternator Left Side Mtg.		
Group - 13	Top Mounted Engine Control		
104-0881 1			
105-0234 1	Crankshaft Camshaft		
160-0752 1	Stator Assy, Magneto		7
100-0752 1	(Includes Parts Marked *)		
160-0750 1	* Coil, Magneto Stator		
	* Pole Shoe, Magneto Stator	1 P	
167-0188 4	Clip, Harness		
167-1557 1	Lead, Hi Tension		# .
166-1559 1	Lead, Hi Tension		
508-0095 2	Grommet, Rubber		
160-0791 1	Cam, Timing Control	٠, ١	
160-0789 1	Weight Assy, Timing Control	<u> </u>	
⇒ 518−0185 2	Ring, Retaining-Timing		
5	Control		-
160-0727 1	Spring, Timing Control		20
160-0726 1	Retainer, Timing Control	,	uris.
150-0075 1	Pin, Governor Center		
160-0948 1	Wheel, Magneto (Includes	· · · · · · · · · · · · · · · · · · ·	•
•	Ring Gear & Magneto)	4 3	
192-0308 1	Sheave, Rope		
192-0296 1	Backplate	•	
508-0084 1	Grommet, Oil Line		
140-1087 1	Basket, Air Cleaner		•
~ 154 ~ 0998 1	Manifold, Exhaust		•
505-0329 1	Cap, Pipe		•
153-0327 1	Bracket, Choke		
154-0973 2	Gasket, Exhaust Manifold		4
518-0176 1	Clip, Choke Cable	45	
134-2998 1	Housing, Blower	,	
517-0021 1	Button, Dot		
152-0164 1	Arm, Variable Speed Control		
502-0020 1	Elbow, Oil Line		
501-0203 1	Line, Oil		
150-0098 1	Spring, Governor		
302-0062 1 150- 0 147 1	Ammeter (45-0-45)	***	
150- 0 147 4	Stud, Covernor Adjusting	а .	
•			en e
		. .	· · · · · · · · · · · · · · · · · · ·

SPE

SPEC - 3193J - 7-0404 KEY NO.

FOR STANDARD PARTS BEFER TO CATALOG 927-0404 KEY I

FART NO.	оту.	DESCRIPTION	PART NO. OTY. DESCRIPTION,
Group - 8		Spin On O41 Filter	
Group - 14		Vacu-Flo Cooling	
Server - Are		*	
110-1832	1	Block Assembly, Cylinder	
110-1000		Seat, Intake Valve	
110-1827	2	Guide, Intake Valve	
110-1037	2-		
110-0893	2	Retainer, Intake Valve Spring	•
509-0090	2	Seal, Valve Stem Oil	
102-0791	1	Base, 011.	
166-0519	1	Bracket, Timing	
149-0136	1	Cover, Fuel Pump Hole	
150-0755	1	Arm, Governor	
150-1264	1	Spring, Governor	
150-0096	1.	Stud, Governor Adjusting	
191- 0134	1	Pulley, Drive	
120-0698	. 1	Line, 0il	
502-0002	1	Elbow, 0il Line	j .
508-0084		Grommet, Oil Line	
134-2943	. 1	Housing, Blower	
134-2760	1	Housing, Cylinder Air RH	
503-0582	1_	Hose, Breather	
503-0171	~ 2	Clamp, Hose	
134-2215	1	Scroll, Blower Housing	
134-0753	1	Wheel, Blower	
517-0021	. 2	Button, Dot Scroll	
517-0035	1	Button, Dot Blower Hsg.	N.
140-1073	1	Clamp, Air Cleaner	
140-1061	<u>_</u>	Cover, Air Cleaner (Inlet)	
140-1071	1	Element, Air Cleaner (Outlet)	-
140-1066	1	Clamp, Hose	
503-0311 — 140-1075	. H	Elbow, Air Inlet	
140-1073	1	Bracket, Air Cleaner	
154-1338	1	Manifold, Intake	j ,
154-1364	1	Manifold, Exhaust	
154-0973.	<u>, </u>	Gasket, Exhaust Manifold Mtg.	
145-0398	1.	Adapter, Air Inlet	,
150-0639	2	Joint, Ball	
520-0187	1. 	Stud, Governor Linkage	,
193-0171	1	Bracket & Fitting, Oil Line	
505-0057	3	Plug, Sq. Head	
141-0726		Carburetor*	
141-0713	1	#Needle, Idle Adjusting	
		in a series in the control of the co	The state of the s
	21 N 3 P		
والمراجع المتابع		والمرابعة فيعور المراجع والرابي المراجع المراج	

Same as carburetor listed in group 31 except parts marked #.

Redistribution or publication of this document

SPECIAL PARTS LIST FOR MODEL CCKB-MS
FOR STANDARD PARTS REFER TO CATALOG

ART NO.	ÒΤΥ.	DESCRIPTION	PART NO	OTY.	DESCRIPTION
و المالية					
roup - 6 roup - 13	, (¹⁷)	Flywheel Alternator (Syncro) Top Mounted Engine Control			
10up - 13		TOP HOURTED ENGINE CONCIOT			
10-2358	1	Block Assembly, Cylinder	-		4
10-1000	2	Seat, Intake Valve			
10-1037	- 2	Valve, Intake			
.10-0904	2	Rotocap, Intake Valve			
.53-0327	Γ	Bracket, Choke			
18-0176 08-0084	1	Clip, Choke Cable		The second contraction of the second	A December of the Control of the Con
01-02 0 3	. <u>1</u>	Grommet, Oil Line. Line, Oil			
502-0020	<u> </u>	Elbow, Oil Line			
50-0147	1	Stud, Governor			
50-0098	1	Spring, Governor		ı	
40-1087	, 1.	Gasket, Air Cleaner	Ž.	*	Company of the Control
.67-0188	2.	Clip, Harness			
.34–3024	1	Housing, Blower			
٠.				-	
ั้ง	•		*		
			<i>₹</i> •		
			3	•	
		•	•:		
:					
	•	e constant	,		
		•	*		and the second
			,		
	-				
				·	· · · · · · · · · · · · · · · · · · ·
				•	1 1
	•		' .		
,			*		
	• • •		,	•	
			5.1		
Samuel Company of the		•			
					N.
	1				,
		* 6	N.	ينقدمندين بندري	<u></u>
			•	10 W	



SPECIAL	PART	S LIST FOR MO	NDEL S	ССКВ-	3	SPEC	3 19 6J	
	こうない しょうこうかんき	STANDARD PA	Constant of the Life of Control of the	A		92)-040	and the second of the second o	. 1
		L GROUPS IN CA				O. BELOW	WHEN USED.	
"自然的"。 计特别编码 计可控制 医神经神经病	OTY.	DESCRIP		بيني بالساب بالمناف	RT NO.	_атү. 🦖	DESCRIPTI	ON
Group - 9		Redi Pull Star	ter .			•		
	1	Housing, Blower Gasket, Air Clo	r					
and the state of t	.10	Ball, Governor	Fly					:
105-0295		Camshaft				·•		· e
						•	•	
						•	<u> </u>	•••
				45				
	3 .				į K	,	3	
			×8		1.		, r	
						•		
		•						
	 -							
		•	 -	ŀ		•	• ,	
		•	· 					
					1	&	•	
	-			,				
		,	•	v [*] ·		3	,	
	-		· •		•		•	
	i saka asala T		•			;		• •
	1 }		,					
· .	·				•			
	• •		55		``		p1	
•	•	•		,		•		
					•			
	, 1		₩	-	•)	
			, ·					
						$\mathcal{A}_{\mathcal{A}}$		
			**					r."
			**		•	•	ing sa	
			•					• ,
					•			1.
				· · ·				
		1	Elescophy Co.					
curic Gen	er eratior				e best engage	Redistribu	ion or publication of this d ans, is strictly prohibited.	ocument

SPECIAL PARTS LIST FOR MODEL CCKB-MS

PART NO.

3211J

FOR STANDARD PARTS REFER TO CATALOG OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

927-0404

QTY.

KEY NO.

DESCRIPTION


Group - 5	
ox cop	Flywheel Alternator (Phelon)
Group - 22	Variable Speed Governor
110-0893 2	Retainer, Valve Spring
	Cover, Fuel Pump Hole
	Flywheel (Includes Ring Gear)
141-0726 1 *	Carburetor
141-0713 1 # 1	Needle, Idle Adjusting

Same as carburetor listed in Group 31 except parts marked #.

B	A	O	ð	e	ı,			()	,, ,, ,	٧.	1 : 24:	C),	Į	(I	}-	ŀ	S					· .						S	Ľ	3	Ė	C		٠,			0	d.		. '	1,		3	2	1	8		J		ï						!		,			:	4.	•		. '	4'4		
	ĵν.	Ŧ,		10	- 47			1		1		•			,	1.0	14										ï			•		•			- 1					•			,		Ä													:			÷,			•	. :				
		d	in	ıd	ŀ	31	d		É	Ý		۲	Ì.	Ė	1	C	4	sÍ	Ĺ	a	l	3	Ö	1	٠,	Ť		4.4	 (1) (1)	9	2	7	-	0	14	C	14	ļ					` '>	٠			-	P	g	ì	ł	ġ	1	K	e	y				2	•					.,		544	,

	PART NO.	QUAN.	DESCRIPTION
	110-1832	1	Block Assembly, Cylinder (Incl udes Bearings, Guides & Seats)
	110-1000	2	Seat, Intake Valve
·	110-1827	2 2	Guide, Valve
	110-1037	2	Valve, Intake
	509-0090-	2	Seal, Valve Stem Oil
•	104-0872	1	Crankshaft
	102-0772	1	Base, Oil
•	FULL FLO OIL FI	TER and	Associated parts listed in main Parts Catalog as
	Optional Equipme		
	149-0136	1	Cover, Fuel Pump Hole
	166-0519	1	Bracket, Timing
	123-0694	1	Cap and Indicator, Oil Fill
	123-0674	1 1	Tube, Oil Fill
	503-0582	1 *	Hose, Breather
	150-0755	1	Arm, Governor - Front Pull
. *	134-0753	1	Wheel, Blower
	502-0002	1	Elbow, Oil
	120-0698	1	- Line, Oil
. •	517-0021	2	Button, Dot - Scroll
	150-0096	1	Stud, Governor
	150-1264	1	Spring, Governor
	191-0134	1	Pulley, Generator
•	503-0391	1	Line, Oil Drain
	134-2943	1	Housing, Blower
	134-2215	1	Scroll, Blower Housing
	134-2956	1	Guard, Scroll Outlet
	134-2760	1	Housing, Cylinder Air (Right Hand)
	154-1338	1	Manifold, Intake
	505-0057	3	Plug, Square Head
	502-0003	1	Connector, Inverted Male
	193-0071	1.	Fitting, Oil Pressure Gauge
-	145-0398	1	Adapter, Carburetor Air Inlet
	140-0921	1	Gasket, Carburetor Air Inlet
	150-0939	1	Joint, Ball
• ,	520-0623	1	Stud, Governor Linkage
	154-1364	1	Manifold, Exhaust
$\frac{N_{\rm cons} + \frac{m_{\rm cons}}{1000}}{1000} = 1$	141-0077	1 2	Washer, Main Jet Assembly - Carburetor
dins	141-0730	1,400	Nut, Bowl - Carburetor
THIS .	141-0726	1 1	Carburetor, Straight Gas Redistribution or publication of this document by any means, is strictly prohibited.

PART NO.	QUAN.	DESCRIPTION
140-1073	1	Clamp Assembly, Air Cleaner (Includes Screw)
140-1061	1	Cover, Air Cleaner (Inlet)
140-1071	1	Element, Air Cleaner
140-1066	1	Cover, Air, Cleaner (Outlet)
503-0311	1	Clamp, Hose (2" x 1/2")
140-1067	1	Bracket, Air Cleaner Mounting
140-1075	1	Elbow, Air Inlet
154 0973	2	Gasket, Exhaust Manifold Mounting
525-0143		Paint - Marine White - Special Enamel
3 L	14 ·	**
•		
·		Parts Not Furnished by ONAN.
•		Ignition Coil Hi Tension Leads



3233J

FOR STANDARD PARTS REFER TO CATALOG.

927-0404

KEY NO.

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO.	QTY.	DESCRIPTION	2" :	PART NO.	QTY.	DES	CRIPTION
Group - 8		Spin On Oil Filter		1			
Group - 14		Vacu-Flo Cooling					
	. 49. 2	Maca-tio Cooting			$ x = \frac{x}{\sqrt{x}} = x^{-\frac{1}{2}}$		
110-1832	7 3	Block Assembly, Cylinder		₹.			
110-1827	2	Guide, Valve Intake		<u>a</u>			
110-1000	2	Seat, Intake Valve			•		gan Mag
110-1037	<u> </u>	Valve, Intake			-	· .	
110-0904	. 2	Rotocap, Intake Valve	الشراء				
509-0090	2	Seal, Valve Stem 0il		San San San San San	*		
102-0791	1	Base, 011		. Pinangan			
1 6 6-0519	1	Bracket, Timing			*		
149-0136	*1°	Cover, Fuel Pump Hole					,*9
150-0755 ·	1	Arm, Governor			*	ý.	. 8
120-0698	1.	Line, Oil					•
502-0002	<u> </u>	Elbow, 011 Line			•	•	J
508-0084	1	Grommet, 0il Line					
150-1264	1	Spring, Governor		4 *			
150-0096	$\mathbf{\bar{1}}$	Stud, Governor					
191-0134	· · · · · · · · · · · · · · · · · · ·	Pulley, Drive		1 . The state of t			
134-2760	_ 1	Housing, Cylinder Air RH	٠,		e de la companya del companya de la companya del companya de la co		•
134-2943	$\sim \hat{\mathbf{i}}$	Housing, Blower					
503-0382	1	Hose, Breather			•		
503-0171	2	Clamp, Hose				,	
140-1061	1	Cover, Air Cleaner (Inlet)					
140~1073	1	Clamp, Air Cleaner		<i>,</i> `			
140-1071	. 1	Element, Air Cleaner					
140-1066	1	Cover, Air Cleaner (Outlet)					t
503-0311	1	Clamp, Hose			•		
140-1075	1	Elbow, Air Inlet					
140-1067	1	Bracket, Air Cleaner		٠ .	•	_	
503-0004	1	Clamp	. ;	j.		, .	
134-0753	11	Wheel, Blower, 👍	e,				
134-2215	1	Scroll, Blower Housing	•		at the		
154-1051	1	Manifold, Intake	٠.			•	
154-1364	1	Manifold, Exhaust	, =	· • • • • • • • • • • • • • • • • • • •			
154-0973	2	Gasket, Exhaust Manifold Mtg.	٠. ا				
193-0171	1	Bracket & Fitting, Oil Gauge				•	÷,
153-0438	1	Bracket, Choke Cable	.بلار			7	
518-0176	1	Clip, Choke Cable					a .
145-0398	1	Adapter, Air Horn	-				
517-0021	2 .	Button, Dot					•
517-0035	1	Button, Dot					
			,	/ ₂ >			
Parts Not	Furnish	ned By Onan				•	$(x_i, x_i) \in \mathcal{X}_{i+1}^{k}(x_i)$
Fuel 1	Pump	****	,				

Fuel Pump

Ignition Coil

Hi Tension Leads



900-0043

Supplementary Parts List

CCKB-MS Spec 3239J

Standard Parts Catalog ___9

Model

927-0404

Parts Key _____2

	PART NO.	QUAN.	DESCRIPTION
		,	
i ·			This Model has Optional Left Side Mounted 12 Vol
,			35 Amp Alternator and Full Flow Oil Filter -
			Complete breakdown in Main Parts Catalog.
		, ,	Vacu-Flo Cooling.
	110-1832	1	Block Assembly, Cylinder
÷	104-0872	1 -	Crankshaft
	110-1037	2	Valve, Intake
•	110-0904	4	Rotocap
	509-0090	2	Seal, Valve Stem
	120-0648	.1	Cup, Oil Pump Intake
•	102-0791 ,	1	Base, 0il
,	122-0345	1	Tube, Oil Filter Drain
	166-0519	1	Indicator, Timing Bracket
	123-0694	1	Cap and Indicator, Oil Fill
	309-0237	1	Switch, Low Oil Pressure
	134-3320	1	Housing, Blower
	517-0035	1	Plug, Dot Button - 1-1/16"
•	150-1560	1	Bracket and Lever, Throttle Control
•	167-0237	2	Plug, Spark
•	150-0635	1	Bracket, Governor
	134-2956-; -	1	Guard, Scroll Outlet
	134-3317	1	Scroll, Air Discharge
,	309-0002	1	Switch, Temperature Cut-Off
	141-0689	1	Carburetor, Complete Breakdown in Main Parts
	•	,	Catalog
. •	166-0641	1	Bracket, Coil Mounting
*	167-1557	1	Cable, Spark Plug - 17"
•	167-1581	1 -1	Cable, Spark Plug - 15"
,	503-0311	2	Clamp, Coil Mounting
•	154-0973	2	Gasket, Exhaust
	155-0906	1	Muffler
	141-0281	2	Gasket-Carburetor and Coil Bracket Mounting
	154-1116	1	Manifold, Intake
. ,	505-0057	1	Plug, 1/8" Intake Manifold
	505-0618	I	Cap. Muffler
	301-3843	1.	Bracket, Terminal Block Mounting
	332-1273	1	Marker, Strip
Thins	P332e0604	1 1	Block, Terminal Redistribution of publication of this document
CURR	G338-06191	1	Harness, Wiring by any means, is strictly prohibited.
	140-1087	1 1	Gasket, Adapter to Carburetor

	و رات	J.	3 36 3 44	و مالعة	14			100	CCI	V D	14	Ċ.	933	1.7	Ţ.,	960	27.7	ing.		94.1	. 10		$\sigma \in \mathbb{R}$	v 14	. 4	18 July 4	2 7	70	T	400	9. 11. 1	1 1	. 15		. 11		10.1	71.1	
			i,	le		10.09	: (4)		انات	V D	TAT	30	95173	10 10	100		(1) T		S	1	4		·**	5%		1.	J 4	39	J	177	10.0	4 2 V	100	. 1		' · .			. 10
7.	L	1	£Ψ		24.		4	<u> </u>			1	14	111	فانوابت ا		بعظمه	. Dec	-	- 33	ø	ВĽ	E	سأنث	والمساب	سنستنث	1	i Jen	A		. Y. T. L.	and of	Table .	0.55	all or	100	- *1 _.	A . 180	1.41	
130	1	95	~~		1.375	. W. Y.	1,50	1,	100	9.	100	11,11	1 1 1		7	1 10	4		1	•			1.7		10.			7.	31							.h =	٥	.**	
100	160	10.	1,50			1.75		4.7		1440	"	7	1,17		ng in	1	J. S. C.	1.1	1) ii (<u> </u>		ينجا		400	70	' -			. 14.14			1.00	-41.				•	: :
1	e.	ă.	-	- 11 m		فرمدا ا	4. 1		مندي	وأنتفها		1	أعطدنا	أه سنا	<u> </u>	15	A 11 .	11	34	7	7(114	134	L	. 2					*3	4		100		4.	٠.	2	100	
		u	: Ⅱ	1 1 8		110	1 1		a n		100	ЯI	1:1	lo	0 1	130		1.5		3.				•					U	D٢	ts	IK i	ΔU			8 2 3		150	
ķ"i	7	77	7	7.7	7						т.	2		•	7	A P	****	-	-	***		-	176	-	بليدائي	-	-	_					v y			_	***************************************		

PART NO.	QUAN.	DESCRIPTION
134-3095 134-3096 150-0698 134-0753 191-1113	1 1 1 1	Housing, Cylinder Air - L.H. Housing, Cylinder Air - R.H. Spring, Governor Wheel, Blower Brace, Alternator Support
	1	
	*	
	ě.	
و د		
	<i>~</i>	
	i de la composición dela composición de la composición de la composición dela composición dela composición dela composición de la composición de la composición de la composición dela composición de la composición dela c	Redistribution or publication of this document by single strictly prohibited.

900-0043

Supplementary Parts List

for

Model

CCKB-MF

Spec.

3280J

Standard Parts Catalog

927-0404

Parts Key _

PART NO.	QUAN.	DESCRIPTION
110-2461	1	Block Assembly, Cylinder
104-0877	1	Crankshaft
190-0267	1	Bearing, Sleeve
509-0090	2	Seal, Valve Stem Oil
120-0648	l, ī	Cup, Oil Pump Intake
102-0791	1 1	Base, Oil
193-0108	1	Sender, Oil Pressure Gauge
502-0058	1	Tee, Oil Pressure Sender
505-0057	1	Plug, Tee
150-1486	1 1	Arm and Shaft Assembly, Governor
149-0693	1 1	Pump, Fuel
123-0527	1 1	Cap and Indicator, Oil Fill
123-0508	1 1	Tube, Oil Fill
123-0508	2	Screen, Breather Tube
•	1 2	l v
160-1042	1 1	Box, Breaker
' 160-0931	1 1	Guide, Breaker Box Plunger
160-0261	1	Wick, Breaker-Box
134-0675	1 1	Wheel - Blower and Ring Gear
104-0369	1	Screw, Wheel Mounting
160-1040	1	Gasket, Breaker Box
160-1041	1 1	Bushing, Breaker Box
160-0723	1	Plunger, Breaker Box
3134-3031	1 1	Housing, Blower
167-0252	2	Plug, Spark
167-1560	1	Cable, Spark Plug - 24"
167-1581	1	Cable, Spark Plug - 15"
123-0732	1	Tube, Breather Connector
140-0864	1	Adapter, Air Cleaner
140-0921	. 1	Gasket, Adapter to Carburetor
134-3086	1	Housing, Cylinder Air - Right Hand
190-0266 - ²	1	Housing, Clutch
104-0614	1 .	Flywheel, Clutch
 515-0146	1	Key - Clutch Flywheel
193-0107	1	Meter, Oil Pressure
141-0689	1	Carburetor - Complete Breakdown in Parts Catalog
		Parts Not Furnished by Onan:
		Air Cleaner
Power		Blower Housing Grille, Redistribution of publication of this document
Gonoration	I '	

for

		(42)			CKR-W2	3-		1.0	1.	3453 J					
		ode				1.		Spec		1.95	1 × 1 × 1		·		
	γıç	JUE			حدث بأجأب تعاريب أنعم	- اسروانات		Ohen	<u> </u>				-		
(d)	di si	17 %	1.51		1 1 W			in a la	4"		,			2	ic.
	4			- A			92	7-040	+					4	٠.
.53	3.11	nnr	ard	Park	s Catalo	ን ለግ					Parts	Kev.			
		HE A		4 651 60	a microcara	- M						~,			-

# 	PART NO.	QUAN.	DESCRIPTION
**************************************	ng ang ang ang ang ang ang ang ang ang a		
la [
	5		NOTE: This model has a Full Flow Oil Filter and
· · ·	4		12 Volt, 20 Amp Flywheel Alternator shown
 	-		as Optional Equipment in Main Parts Catalog.
		ł	
,	110-1860	1	Block Assembly, Cylinder
	104-0872	1	Crankshaft
	120-0648	1	Cup, Oil Pump Intake
ъ	102-0828	1	Base, Oil
	123-0694	1	Cap and Indicator, Oil Fill
-	123-0958	2	Screen, Breather Tube
1	134-2828	.1	Housing, Blower
* .	167-0237	2	Plug, Spark - Resistor
	167-1560	1	Cable, Spark Plug - Hi Tension - 24"
	167-1581	1	Cable, Spark Plug - Hi Tension - 15"
	154-0973	2	Gasket, Exhaust Manifold
	141-0689	1	Carburetor - Complete Breakdown in Main Parts Catal
5	155-1472	1	Muffler
	505-0618	1	Cap, Muffler
•	140-1087	1	Gasket, Adapter to Carburetor
	134-2760	1	Housing, Cylinder Air - R.H.
	153-0223	1	Choke '\
	153-0484	1	Linkage
	516-0059	1	Pin, Choke Lever
	152-0155	- 1	Swivel, Choke Lever
	526-0006	1	washer, Choke Lever
	ÿ		
<i>و</i>	•		·
	A		•
	•		

3316J

		R STANDARD PARTS REFER AL GROUPS IN CATALOG ARE LIS		KEY NO. 2 HEN:USED	
PART NO.	ÒΤΥ.	DESCRIPTION	PART NO. OTY	DESCRIPTION	
Group - 8 Group - 22		Spin On Oil Filter Variable Speed Governor			
110-1860 134-2984 134-2760	1 1 1	Block Assembly, Cylinder Housing, Blower Housing, Cylinder Air RH			
308-0356 308-0140 154-0998 154-0973	1 1 1 2	Guard, Switch Switch, Toggle Manifold, Exhaust Gasket, Exhaust Manifold			
153-0464 153-0351 518-0176	1 1 1	Bracket, Choke Cable, Choke Clip, Choke Cable		A TO SERVICE STATE OF THE SERVICE STATE STATE OF TH	
505-0329	1	Cap, Pipe			
	٠	A Programme of the Prog			
	· -				
	٠.				

SPEC

3320J

DESCRIPTION

FOR STANDARD PARTS REFÉR TO CATALOG 927±0404

KEY NO.

PART NO.	אדג.	DESCRIPTION PART NO); <u> </u>
Group - 5 Group - 8	the house	Flywheel Alternator (Phelon) Spin On Oil Filter	
Group + 12 Group - 13		Rockford Clutch Top Mounted Engine Control	
110-2375		Block Assembly, Cylinder	Y.,
110-1037 110-1000	2:	Valve, Intake Seat, Valve Intake	, i
149-0136	1	Crankshaft Cover, Fuel Pump Hole	
	-2	Clip Retainer, Valve Spring	, , , , , , , , , , , , , , , , , , ,
1 92- 0308	1 .	Carburetor-Straight Gas. Sheave, Rope	
501-0203 502-0020	1	Line, Oil Elbow, Pipe (1/8)	
134-2760 508-0084	Ì	Housing, Cylinder Air R/H Grommet, Rubber	
134-3379 338-0565 141-0713	1	Housing, Blower Harness, Wiring	
141-0/13	.1 #	Needle, Idle Adjusting	. 4

^{* -} Same as carburetor listed in Group 31 except parts marked #.



KEY NO.

SPECIAL PARTS LIST FOR MODEL CCKB-MS SPEC 3340J FOR STANDARD PARTS REFER TO CATALOG 927-0494 KEY NO OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED;

PARTINO	OTY	DESCRIPTION	PART NO.	ату.	DESCRIPTION
Group -6		Flywheel Alternator (Syncro)			
Group8		Spin On Oil Filter			
110-1860	1	Block Assembly, Cylinder			
167-0188	2	Clip, Harness	126 S. S. S. S. S.		
150-0755	1	Arm, Governor			
193-0108	1	Sender, Oil Pressure			
502-0020	- 1 -	Elbow, Oil Pressure			93
134-2828	1	Housing, Blower		in a second second	en e
134-2760	1	Housing, Cylinder Air RH			1
150-0096	1	Stud, Governor			Note that the same of the same
I50-0698	1	Spring, Governor		er e	Note to
140-0867	1	Adapter, Air Cleaner			
154-1110	1	Manifold, Exhaust			
154-0973	2	Gasket, Exhaust Manifold		·	

SPECIAL PARTS LIST FOR MODEL CCKB-MS

SPEC

3355J KEY NO.

FOR STANDARD PARTS REFER TO CATALOG 927-0404 OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO. GTY.	DESCRIPTION	PART NO. OTY.	DESCRIPTION
Group - 5	Flywheel Alternator (Phelon)		
Group - 8.	Spin On Oil Filter		Carlos Milans
110-1860 1	Block Assembly, Cylinder		والمرابط والمتناف والمحجور المتناف والمتناف والم
134-2828 1	Housing, Blower	36/	
134-2760 1	Housing, Cylinder Air RH		
104-0880 1	Crankshaft		
515-0230 1	Key, Crankshaft		
150-0635 1	Bracket, Governor		
150-0096 - 1	Stud, Governor		
150-0698 * 1	Spring, Governor		
167-0188 2	Clip, Harness		

	att 克拉斯斯 化基本基本 医水体性炎	ST FOR MODEL	CCKB-MF	SPEC _ 927-0404	3357J
	机式气度的 医静脉 医皮肤 用机 化氯化 医皮肤性的 医皮肤 化氯磺酸	ANDARD PARTS REF Roups in catalog are	The state of the s	ويت بالمرافقة والمرافقة وا	KEY NO2 IEN USED.
PART NO.	• оту	DESCRIPTION	PART NO:	ату.	DESCRIPTION
roup - 1		rnator, Left Side Mtg			
roup - 12	and the first of the state of the	ford Clutch			
roup - 13	17 * ** * * * * * * * * * * * * * * * *	Mounted Engine Contro			and the second
04-0913	1 Cran	kshaft			
2+0791	1 _∫ -Base				
.0-0893		iner, Valve Spring			
19-0136 01-0203		r, Fuel Pump Hole			
02-0020		, 011 w, Street (1/8)			
41-0726		uretor, Straight Gas			1
08-0084		met, Rubber			g d Royal
34-2995		ing, Blower	_1		
52-0164 02-0062		Variable Speed Contr ter 45-0-45	01	€	
38⊬0565		ess, Wiring		,	S.
38-0411		ess, Wiring			
41-0713	1 #Need	le, Idle Adjusting	• 1		
Parts Not	Furnished B	w. Onan			
	nd Assorted			•	
المستعدد المستعدد	para de les la Successione de Laci	The second secon			
		hij the a step of the sistepine			
iller (18 19 19 19 19 19 19 19 19 19 19 19 19 19	and production for the Salahara New Spagnation of Contraction				
- Same as	carburetor	listed in Group 31			1 - 1
except	parts marke	d #.			
to the second	الماران المستحدد والمستعددين				•
	,				
· · · · · · · · · · · · · · · · · · ·		· · · · · · · · · · · · · · · · · · ·	. ~	•	

			<u> </u>	C. S	٠.,
	W. C.	1			
æ		\$			
	, in				· · · · · · · · · · · · · · · · · · ·
	-				· · · · · · · · · · · · · · · · · · ·
		· · ·		11-	
14 - 15 - 15 - 15 - 15 - 15 - 15 - 15 -	ii.		7	1	
			A STATE OF THE STATE OF	·	
		.2			
					4 理

3360J

SPECIAL PARTS LIST FOR MODEL CCKB-MS
FOR STANDARD PARTS REFER TO CATALOG

			TED BY GROUP NO: BELOW WHEN USED:				
ART NO.	GTY.	DESCRIPTION	PART NO. QTY.	DESCRIPTION			
roup -	5	Flywheel Alternator (Phelon)					
roup -		Spin On Oil Filter					
roup - 2		Variable Speed Governor					
10-1860	1	Block Assembly, Cylinder					
04-0880		Crankshaft		· · · · · · · · · · · · · · · · · · ·			
15-0230	1	Key, Crankshaft	11. 人名英格兰克勒 病				
40-1087	1	Gasket, Air Cleaner					
34-2760	1	Housing, Cylinder Air RH					
34-2984	1	Housing, Blower					
08-0356	1	Guard, Switch					
08-0140	1	Switch, Toggle					
53-0351	1	Cable, Choke					
18-0176	1	Clip; Choke Cable					
67-0188	2	Clip, Harness					
53-0464	1	Bracket, Choke					
	1			· And on the same of the same			
				1			
			**				
		•					
Part - James							
	· · ·						
	4.						
	· .						
	•		*				
	٠,	· · ·		and the second s			
	· • • • • • • • • • • • • • • • • • • •	,					
	6	<u></u>					
				* * * * * * * * * * * * * * * * * * * *			
				t in the second			
7	•		s tot				
				· · · · · · · · · · · · · · · · · · ·			
,	,	•	e	r .			
		3	*				
		,					
	*	transfer					
-			9.7				
	× .						
•	e i i i						
				A second of the second			
		-1 , -1 ,		A stranger			

SPEC

3365J

FOR STANDARD PARTS REFER TO CATALOG OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

927-0404

KEY NO.

PART NO.	QTY.	DESCRIPTION	PART NO.	оту.	DESCRIPTION
Group + 3		Alternator-Top Mounted			
Group - 29		Carburetor-Gas-Gasoline			
110-1904	, i	Block Assembly, Cylinder			
110-1827		Guide, Valve			la garage de la companya de la comp
110-0893	2	Retainer, Valve Spring			
509 –0090	2 -	Seal, Oil-Valve Stem			
509-0123	1	Seal, Crankshaft	_		
509-0110	1	Seal, Dust			
102-0780	1	Base, 0il			
103-0533	1	Gearcase (Complete)			
, 509–0105	1.	Sea1, 0i1			
-509- 0125	1	Seal, 011			* * *
150-0635	1 "	Arm, Governor		\mathcal{L}	? .
150-0698	1	Spring, Governor		· · · · · · · · · · · · · · · · · · ·	
149-1097		Line, Fuel		2	
191-1168		Bracket, Alternator Mtg.		•	#
309-0237	1	Switch, Oil Pressure		."	
134-1644	1	Housing, Cylinder Air LH			
134-3000	1	Housing, Cylinder Air RH			
134-2924	1	Housing, Blower			•
502-0313	1 1	Elbow, Fuel Pump			
140-1304		Adapter, Air Cleaner		··,	
140-0584	1	Gasket, Air Cleaner Adapter Mtg.			
140-0645	ر المستريخ المام المستريخ	Adapter, Air Cleaner]		
153-0327	1	Bracket, Choke	4		
518-0176	$1_{t_{N}}$	Clip, Choke Cable		,	
520-0187	1	Stud, Governor Linkage			•
150-0639	2	Joint, Ball			
134-2632	ī	Flywheel (Includes Ring Gear)			
		,	. v	• • • • • • • • • • • • • • • • • • •	A STATE OF THE STA
Parts Not	Furnis	hed By Onan	·	•	
Altern			· ·		
Air Cl			,		
		· · · · · · · · · · · · · · · · · · ·	, ,	<i>\$</i>	
		we want			
·* **					$\cdot \cdot $
			:		/ /
					. /
			**************************************		/ *

SPECIAL PARTS LIST FOR MODEL CCKB-MS 33713 SPEC FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY NO. OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED. PART NO. QTY. DESCRIPTION DESCRIPTION PART NO. QTY. Group - 8 Spin On Oil Filter 110-1957 1 Block Assembly, Cylinder. 110-1827 2 Guide, Intake Valve 509-0090 Seal, Valve Stem 011 Crankshaft 104-0882 Key, Crankshaft 515-0006 1 309-0255 1 Switch, Hatko 1 Screw, Cylinder Head-Special 114-0171 Lead, Hatko To Ign. Box 336-1500 Switch, Low 011 Pressure 309-0237 134-2828 Housing, Blower 134-2760 1 Housing, Cylinder Air RH Muffler, Exhaust 155-0906 154-0973 2 Gasket, Exhaust Muffler Mtg.

Cap, Pipe

Bracket, Choke

Clip, Choke Cable

Adapter, Air Cleaner

1

1

1

1

505-0618

153-0327

518-0176

140-0971

3393J

SPECIAL PARTS LIST FOR MODEL CCKB-MF SPEC 339 FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

		AL GROUPS IN CATALOG ARE LIST	Age to the later than the second		THEN USED.
PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
110-1418		Block Assembly, Cylinder			
104-0882	7 1	Crankshaft	*		
102-0782	\mathbf{i}	Base, 011			
105-0058	1	Plunger, Camshaft			
105-0059	ī	Spring, Camshaft Plunger			
105-0251	and the second	Camshaft		<i>-</i>	
105-0030		Gear, Timing		/	
123-0576	1	Cap & Indicator, 011 Fill			
123-0568	1	Tube, 011 Fill			 /b/
123-0998	1	Insulator, Breather	l		<i>∞</i> − .
134-0675	1	Flywheel (Includes Ring Gear)	. /	·	
501-0027	1	Line, Oil	· /	•	
502-0017	1	Connector, Oil Line			
502-0020	1	Elbow, Oil Line		æ K	<i>r</i>
508-00 84	1	Grommet, Oil Line	/		
103-0224	1	Gearcase - (Complete)	<i>#</i>	•	•
509-0040	1	Seal			
516-0051	1	Plug			
134-2924	1	Housing, Blower		w.	
134-1644	1	Housing, Cylinder Air LH]		
134-2916	1	Housing, Cylinder Air RH			
153-0327	1	Bracket, Choke		17	* * *
518-0176	1.	Clip, Choke Cable) v		,
154-1110	1	Manifold, Exhaust Gasket, Exhaust Manifold Mtg.			•
154-0973 101-0372	2 1	Adapter, Clutch		,	
101-03/2		Flywheel, Clutch		,	
TOT-OTOS		rlywneel, oldeen		•	
					· ·
	27 .		•		· ·
· · · · · · · · · · · · · · · · · · ·	- /	/• · · · · · · · · · · · · · · · · · · ·			
. • .				v	
	/ .				
	/ .			·	
	.		ĺ		

SPECIAL PARTS LIST FOR MODEL

CCKB-MS

3395J

FOR STANDARD PARTS REFER TO CATALOG 927-0404

KEY NO.

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO. QTY.	DESCRIPTION	PART NO. QTY.	DESCRIPTION
Group - 5 Group - 13	Flywheel Alternator (Phelon) Top Mounted Engine Control		
167-0188 2	Clips, Harness		
192-0308 1	Sheave, Rope		and the state of the
501-0203 1	Line, 0il		
502-0020 1	Elbow, Oil Line		
508-0084 1	Grommet, Rubber		
134-2995	Housing, Blower ^		
301-4376 1	Bracket, Engine Control		n
332-0592 1	Jumper, Ground		
308-0140 1	Switch, Toggle	4 N	
154-0998 1	Manifold, Exhaust		* * * * * * * * * * * * * * * * * * * *
505-0329 1	Cap, Pipe	c .	
153-0327 / 1	Bracket, Choke		
_518-0176 1	Clip, Choke Cable		
154-0973 2	Gasket, Exhaust Manifold	ر الشار	
515-0230 1	Key, Crankshaft	· ·	7
			P. Committee of the com

SPECNA	LPAR	TS LIST FOR	MODEL	ĞC	KB-MS		SPEC	3402J
	Arthur de la la	RSTANDARD	二、出版 實際 新工 医乳头皮炎	11.0			27-0404	KEY NO. 2
	9 in N. P. Son (1971), 18 (1975)	ial Ġroups in	13, 5, 7, 11, 11, 16, 17, 17, 17, 17, 17, 17, 17, 17, 17, 17	المناف في المسائل على المسائل على المسائل المس	and the state of t	and the second second	the state of the state of the state of	IEN USED.
PART NO.	ОТУ	DESC	RIPTION		PART N	о. ат	Υ.	DESCRIPTION
7					F (
Option -	6 -	Flywheel Alt	ernator					
	1.50	(Syncro -	20 Ampere)	*				
Option - Option -		Gas Fuel Sys						
Operon -	_ &&	Variable Spe Control	ed Governor					
110 0000			0	8.	3 11	1		
110-0893	4	Washer, Valve Retainer	e Spring	-+		,		4
167-0188		Clip, Altern				. ₩		
140-0921 141-0726	15 a. 159 a. 1	Gasket, Adap					۹	
141-0/20	1	Carburetor, Optional Carburet				· · · · · · · · · · · · · · · · · · ·		ì
		Components	, Except Par		**	•		
141-0713	1	Marked #) #Needle, Idle	Adjusting				e _m	
					:	•	• .	
							f	
	- *				,	1	•	
			· · · · · · · · · · · · · · · · · · ·	1		**	ÿ,	•
	~	Andrews (1994) Andrews (1994)						
		4	e de la companya de La companya de la co		•		. ₩	, ••
					•		•	
					, ·			•
			· /		٠.	-	,	. *** ~
*								
				1	2.			
								No.
			•		,	÷.;		
		8		ĺ		ø	* ,	
	in the second			, l	,			
	Some C				* . *		5	\$
	: #						. ,	a distribution of the state of
					p			
	Nav (¥ = -	· .]	•		1	
								N.
	* 1		3年4年10年			**	框	
•	Jower	集团总数	Lander were kinner to	han taken				
	enera	tion					Redistribution by any mea	on or publication of this document ns, is strictly prohibited.

FOR STANDARD PARTS REFER TO CATALOG OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
	1.35				
Group - 8		Spin on Oil Filter			
Group -19		High Profile Breaker Box			
110-1827	'2-	Guide, Valve - Intake			
110-1957	$\sqrt{1}$	Block Assembly, Cylinder			
509-0090	/ 2	Seal, Valve Stem Oil		***	
\ 509-0123	1.	Seal, Crankshaft Oil			
509-0110	1	Seal, Dust			
104-0880	1	Crankshaft			<u> </u>
105-0238	1	Camshaft			
102-0688	1 .	Base, Oil	91		
123-0506	1	Cap and Indicator, Oil Fill			
123-0508	1	Tube, Oil Fill		•	
309-0237	1	Switch, Low Oil Pressure		No.	
103-0533	<u>1</u>	Gear Cover - (Complete)		Y	
509-0105	1	Seal, Oil - Gear Cover			,
509-0126	1	Seal, Oil - Gear Cover		u.	
150-0635	1	Arm, Governor			•
150-0698	1	Spring, Governor			
134-2555	1	Wheel, Blower			
134-1889	1	Guard, Blower Wheel		• * *	
. 140-0645	. 1	Adapter, Air Cleaner	* * * * * * * * * * * * * * * * * * * *		•
140-0584	1	Gasket, Adapter to Adapter		•	
140-1087	1	Gasket, Air Cleaner		مد	
134-2862	1	Housing, Blower			
167-0229	, 2	Support, Hi Tension	- ,		
167-1596	1	Lead, Hi Tension	<u> </u>		
167-1595	.1	Lead, Hi Tension		•	
166-0346	1 ,,	Coil, Ignition	·	, a	
517-0034	1 .	Button, Dot		•	
153-0327	1	Bracket, Choke		1	
518-0176	1	<u>Clip</u> Cable	,	, ,	•
134-2237	1 ,	Housing, Cylinder Air R/H			•
166-0444	1 '	Bracket, Coil and Governor		*	•
150-1021	1.	Lever, Throttle Control	,		
515-0202	1	Key, Crankshaft		4	
				1	
2					
		shed by Onan:			•
Air Cl					
		oscrew Guard	***		
Rope S	heave	· ·			•
					
	**	, T	*		•
	*			i	4
•			_	*	
	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1				λ
	<i>(</i> 1)			the second second	



SPEC _

3439J

FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY NO. OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO. GTY. DESCRIPTION PART NO. QTY.

PART NO.	COLUMN TO		1,44	PART NO. UTT.
			. 1	
Option -	6 -	Flywheel Alternator		
		(Syncro - 20 Ampere)		
Option -	8	Spin-On Oil Filter		
Option -	13	Control (Engine)		
110-1860	1	Block Assembly, Cylinder		
	•	(Refer To Standard Cylinder	ή ×	· ·
		Block For Components)		
502-0020	1	Elbow, Street - Oil Line To		
	. V	Cylinder Block (1/8")		**
501-0203	1.	Line, Oil - Cylinder Block		
	ŕ.	To Gauge		
167-0188	2	Clip, Alternator Stator Leads		
150-0147	L	Stud, Governor Speed Adjusting	_	
153-0327	1	Bracket, Choke Cable	•	
518-0176	1	Clip, Choke Cable To Bracket		**************************************
154-0951 154-0998	1 1 °	Manifold, Intake Manifold, Exhaust		
505-0329	1	Cap, Pipe - Exhaust Manifold		
154-0973	2	Gasket, Exhaust Manifold		
134-3222	1	Housing, Blower		q
134-2760	1	Housing, Cylinder Air -		
· 104 27.00		Right Side		€ _{ac}
301-4376	1	Bracket, Engine Control		
308-0140	$\bar{1}$	Switch, Start-Stop (Toggle)		
338-0565	1	Harness, Wiring - Start	,	
508-0084	1	Grommet, Rubber - Oil Line		
		Through Blower Housing		
	, · •	(1-1/4" Hole)	,	
· · · ·			-	
				•
		·		

2.0016					4-14	
FO	RTS LIST FOR MO OR STANDARD PA NAL GROUPS IN CAT	RTS REFER T	的复数人名 解释成合金 经分分 计扩充 医抗原药	SPEC927_0404	3455Jf KEY NO	<u>.</u> 2
ART NO. GTY			PART NO	оту.	DESCRIPTION	
ption - 6	Flywheel Alterna	itor				
	(Syncro - 20 A	A Company of the Comp				

Option - 6	Flywheel Alternator
Operon	그 그 그는 그는 그는 그를 하는 것이 그는 하는 경기를 통해 가장하다 하게 됐다면 하는 것이 없다.
	(Syncro - 20 Ampere)
Option - 15	Gas Fuel System
Option - 22	Variable Speed Governor
<u> </u>	Control
110-0893	4 Washer, Valve Spring Retainer
168-0188	2 Clip, Alternator Stator Lead
140-0921	1 Gasket, Adapter To Carburetor
141-0726	1 Carburetor, Gas (Refer To
Ψ <i>μ</i>	Optional Carburetor For
	Components, Except Parts
	Marked #)
141-0713	1 #Needle, Idle Adjusting
154-0951	1 Manifold, Intake
155-0906	1 Muffler, Exhaust
505-0618	1 Cap, Pipe - Exhaust Muffler
154-0973	2 Gasket, Exhaust Manifold
	4

SPECIAL PARTS LIST FOR MODEL CCKB MS SPEC SPEC FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY NO. OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

PART NO	OTY.	DESCRIPTION	PARTN	о. ету	DESCRIPTION
Manufactu	The second secon	ニース さいがん はんけい アニー・ア・ストー・アース かんしょう さいだい アービュー			
Option -	5	Flywheel Alternator (Phelon - 15 Ampere)			
Option -	13.	Control (Engine)			
. 323-0853	1	Body, Alternator Stator			
1/7 07.00	0 *	Leads	The same of the sa		وراه المراجع المراجع
167-0188 134-3019	- 1	Clip, Alternator Stator Lead Flywheel (Includes Ring Gear)			No.
134-0673	1	Gear, Ring - Flywheel	1		Light State of the
502-0020	1	Elbow, Street - Oil Line	- W		
		To Cylinder Block			
501-0203	. 1	Line, Oil - Cylinder Block	*		
ىرىنى ئىلىنى ئىلىنىڭ ئىلىنى ئىلىن ئىلىنى		To Gauge			
134-2995	1	Housing, Blower		3 <u>5</u> 	
301-4376	1	Bracket, Engine Control			
308-0140	. 4.	Switch, Start-Stop (Toggle)		6	
338-0565	1	Harness, Wiring - Start		•	
508-0084	\$ 1	Grommet, Rubber - Oil Line	`		*
		Through Blower Housing		7	
	- :	(1 ¹ 4" Hole)	*		
1.50°0147	1	Stud, Governor Speed	*		
	# · · · · · · · · · · · · · · · · · · ·	Adjusting	*	, 4	- S. B
153-0327	1 .	Bracket, Choke Cable	, ,	ر عب م	
518-0176	1	Clip, Choke Cable To Bracket	۴.		* · · · · · · · · · · · · · · · · · · ·
,	F.,				
\$ •	•				
	.			*	•

SPECIAL PARTS LIST FOR MODEL _____ CCKB-MS 3463J SPEC KEY/NO. FOR STANDARD PARTS REFER TO CATALOG 927-0404 OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED. DESCRIPTION PART NO. QTY. PART NO. DESCRIPTION QTY. Control (Engine) Option - 13 301-4467 Bracket, Engine Contro 1. 104-0881 Crankshaft 308-0068 1 Switch, Stop (Toggle) Cover, Timing Control 110-1283 Harness, Wiring - Star 338-0565 105-0234 Camshaft (Includes Center Pin And Spark Advance Mechanism Pins) Pin, Camshaft Center **150-0075**... Pin, Groove - Spark Advance 🦠 516-0146 Cam, Timing Control 160-0791 160-0789 Weight Assembly, Spark Advance (Includes Pins) Ring, Retaining - Spark 518-0185 Advance Groove Pins Retainer, Weight Assembly -160-0726 Spark Advance 160-0727 Spring, Spark Advance 1 1 102-0791 Base, Oil Stator Assembly, Magneto 160-0752 (Includes Parts Marked *) *Coil, Magneto Stator 160-0750 **≈**160-0749 *Pole Shoe, Magneto Stator Grommet, Rubber - Spark Plug 508-0095 Cables" Clip, Spark Plug Cables: 167-0188 Flywheel (Includes Ring Gear) 160-0948 Gear, Ring - Flywheel 134-0673 Stud, Governor Speed 150-0147 Adjusting Pump, Fuel 149-1393

Bracket, Choke Cable

Manifold, Intake

Manifold: Exhaust

To Oil Gauge

(1-1/4" Hole)

Housing, Blower

Sheave, Rope

Clip, Choke Cable To Bracket

Cap, Pipe - Exhaust Muffler

Elbow, Street - Oil Line To

Grommet, Rubber - Oil Line

Through Blower Housing

Plug, Dot Button - Blower

Housing (7/8" Hole)

Cylinder Block (1/8") .

Line, Oil - Cylinder Block.

Gasket, Exhaust Manifold

Backplate, Rope Sheave

Power Generation

153-0327

518-0176

154-0951

***5**05-0329

154-0973 192-0308

192-0296

502-0020

501-0203

508-0084

134-2998

517-0021

154-0998 · ·

1

1

2 ~

.1

1

1

Redistribution or publication of this document by any means, is strictly prohibited.

CCKB-MS

SPEC

• <u>3473</u>J

FOR STANDARD PARTS REFER TO CATALOG OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

927-0404

KEY NO:

PART NO. QTY. DESCRIPTION PART NO. QTY. DESCRIPTION Flywheel Alternator Option - . 5 (Phelon - 15 Ampere) Option - 8 Option - 22 Spin-Qn Oil Filter Variable Speed Governor Control 110-2375 Block Assembly, Cylinder (Refer To Standard Cylinder Block For Components, Except Parts Marked *) 110-1000 *Insert, Intake Valve Seat (Available In .010 And .0250 Oversize) . 11Ó-£037 Valve, Intake 110/0904 Rotocap, Intake - Exhaust Valve* 10270782 Base, Oil 134-3019 Flywheel (Includes Ring Gear) 134-0673 Gear, Ring - Flywheel 1 323-0853 Body, Alternator Stator. Leads Connector * 167-0188 Clip, Alternator Stator Lead Holding 154-0951 Manifold, Intake 154-0998 Manifold, Exhaust 505-0329 Cap, Pipe - Exhaust Manifold 154-0973 Gasket, Exhaust Manifold 134-2828 Housing, Blower * 134-2760 Housing, Cylinder Air -Right Sidê

FOR STANDARD PARTS REFER TO CATALOG 927-0404

KEY NO.

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

41.00	PART NO.	e QTY.	DESCRIPTION	PART NO.	оту.	DESCRIPTION
	Option -,	b	Flywheel Alternator (Syncro - 20 Ampere)			
	Option -	13	Control (Engine)	, 1		
•						
	167-0188	2	Glip, Alternator Stator Lead			
_			Holding		a '	
•	502-0020	1 *	Elbow, Street - Oil Line To	0		
	E01 0001	70. (1)	Cylinder Block Line, Oil - Cylinder Block	,		
:	501-0203	<u> </u>	To Gauge			4.
-:-	508-0084		Grommet, Rubber - Oil Line			
4	9 .		Through Blower Housing		,	
-		40	(1½" Hole)		· · · · ·	
	134 2995	1	Housing, Blower		· · · ·	√ N _e ktσ
	301-4376	1	Bracket, Engine Control		3	
9	308-0140		Switch, Start-Stop (Toggle)		<u>/</u> :	*
	338-0565.		Harness, Wiring - Start		K.	
	150-0147	1	•Stud, Governor Speed		е * » У	
	153-0327	· /•	Adjusting Bracket, Choke Cable		4	•
	518-0176		Clip, Choke Cable To Bracket	n		
ò	154-0951	. <u> </u>	Manifold, Intake	b		
	155-0906	_	Muffler, Exhaust		3 .	(.)
٠.	· 505-0618	1	Cap, Pipe - Exhaust Muffler			
•	154-0973	2	Gasket, Exhaust Muffler			
		•				•
•		ه , _				
		•				
	*		1	1		

SPECIAI	L PAR	TS LISTIFOR MODEL	CC	KB-MS ₄	SPEC	3476J
	tar base til tar grade.	R STANDARD PARTS REF	11. 1. 14 14 1. 16 14 14 16 16 16 16 16 16 16 16 16 16 16 16 16	第二十二十二十二十二十二十二十二十二十二十二十二十二十二十二十二十二十二十二十	11 15 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	eKEY NO
	and the state of t	AL GROUPS IN CATALOG ARE	化炼厂进程室 的复数多级		じょうしゃ あいしゃ おんじゅ おりまだん おおばり はいけい	· · · · · · · · · · · · · · · · · · ·
PART NO.	OTY.	DESCRIPTION		PART NO.	QTY	DESCRIPTION
					1	
Option -	.	Flywheel Alternator				
Oberon -		(Phelon - 15 Ampere)				
Option - 1	3	Control (Engine)				
Operon 1.						
32340853	1	Body, Alternator Stator	1			4 May
	E	Leads Connector	U = U	in the same of the		
167-0188	2	Clip, Alternator Stator	1		*	A Committee of the Comm
	Francisco	Lead Holding	17.	ir .		10 10 10 10 10 10 10 10 10 10 10 10 10 1
134-3019	1	Flywheel* (Includes Ring G	ear)		50	
134-0673	1	-Gear, Ring - Flywheel		•		
502-0020	_ 1	Elbow, Street - Oil Line	To		(4	
	**	Cylinder Block		· · · · · · · · · · · · · · · · · · ·		
501-0203	. , 1 . *	Line, Oil - Cylinder Blog	k 🦠		,	15 3c
*	G	To Gauge		•		
508-0084	1,-	Grommet, Rubber - 011 Lir				
	دين ۾ انها پيريون جاهو	Through Blower Housing	12	•	- -	
	•	(14" Hole)	,		·	
134 +2995	. 1	Housing, Blower"				
301–4376	1	Bracket, Engine Control			1 P V	3 · · · · · · · · · · · · · · · · · · ·
308-0140	1.	-Switch, Start-Stop (Toggl	Le)		, ,	
338-0565		*Harness, Wiring - Start			· a	**************************************
150-0147	1. 1.	Stud, Governor Speed	œ.	•		
	17.	Adjusting		\mathcal{A}	, , , , , , , , , , , , , , , , , , , ,	
153-0327	* 1 .5	Bracket, Choke Cable		· 5.		
518-0176		Clip, Choke Cable To Brac	ket	mi de la companya de		
154-0951	•	Manifold, Intake			· · · · · · · · · · · · · · · · · · ·	
) 155-0906	1	Muffler, Exhaust			, 新華電影	
505-0618		Cap, Pipe - Exhaust Muffl	er			
154-0973	v. 2.	Gasket, Exhaust Muffler	1 1 1 1 1 1 1		es es	

SPECIAL PARTS LIST FOR MODEL CCKB-MS

SPEC":

3485J

FOR STANDARD PARTS REFER TO CATALOG.

	OPTIONAL GROUPS IN: CATALOG ARE LIST	ED BY GROUP N	IO, BELOW WHEN USED.
PART NO.	GTY. DESCRIPTION	PART NO.	CTY. DESCRIPTION
Option	5 Flywheel Alternator .	148-0465	1 Regulator, Gaseous Fuel
	(Phelon - 15 Ampere)	502-0039	1 Elbow, Inverted Male -
Option -			Regulator Outlet
Option -		505-0099	1 Nipple, Close - Regulate
.	ing		Vaporizer (1/4" X 7/8
;-110-2942	1 Block Assembly, Cylinder	502-0183	1 Elbow, Male - Vaporizer
	(Refer To Standard Cylinder	*	Inlet
6	Block For Components, Except	148-0838	1 Kit, Vaporizer Replacem
1 12 W 11 	Parts Marked #)	***	(Includes Mounting Spa
110-1827			To Replace Original M
110-1000	2 #Insert, Intake Valve Seat		· Vaporizer)
	(Available In .010 And	148-0827	l Spacer, Vaporizer Mount:
أحكمه كرسو	.025 Oversize	148-0756	1 Bracket, Vaporizer Moun
110-1037		149-0136	1 Cover, Fuel Pump Hole In
509-0090	1 Seal, Oil - Intake Valve		Cylinder Block
110-0893	4 Washer, Valve Spring Retainer		
323-0853	Body, Alternator Stator		
167-0188	Leads Connector 2 Clip, Alternator Stator		
TO\-OTOO			
134-3019			\
134-30,19			or No. 1 € No
501-0203	1 Line, Oil - Gauge To Cylinder		*
	Block Cylinder		· · · · · · · · · · · · · · · · · · ·
502-0020	1 Elbow, Street - Oil Line To	*	
	Cylinder Block		
508-0084	Grommet, Rubber - Oil Line		
TO SEAL THE	Through Blower Housing		
301-4376			The state of the s
308-0140	1 Switch, Start-Stop (Toggle)		
338-0565	1 Harness, Wiring - Start		
134-2995			, (6
150-0147	1 Stud, Governor Speed	, 5	e e
en e	Adjusting		
159-1072	1 Line, Fuel - Regulator To		
**			<u>a</u> "

154-0918

141-0751

505-0008 502-0039

Carburetor

Manifold, Intake

Marked *) *Plug, Pipe (1/8")

Carburetor, Gas (Refer To Optional Carburetor For

*Elbow, Inverted Male -Carburetor Fuel Inlet

Components, Except Parts

3489J

SPECIAL PARTS LIST FOR MODEL CCKB-MS
FOR STANDARD PARTS REFER TO CATALOG

	OKTION	IAL GROUPS IN CATALOG ARE LISTED	BY GROUP N	O. BELC)W WHE	N USED.
PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	7	DESCRIPTION
Option -	6	Flywheel Alternator		jaura krodini bilini Tarih di karangan		
Operon		(Syncro - 20 Ampere)				
Option -	8	Spin-On Oil Filter	***		h ,	4
The form of the control of the contr		Variable Speed Governor				
		, Control	•		*****	
110-2375	1	Block-Assembly, Cylinder				
A A		(Refer To Standard Cylinder	•		· .	
	* : Ť	Block For Components	a	t fet i s	160	
		Except Parts Marked *)	i Maria	4 .		
110-1000	Z 2	*Insert, Intake Valve Seat	•			, a.
		(Available In .010 And			en et al d	·
		\ .025 Oversize)				
110-1037	- 2	Valve, Intake	a			•
110-0904		Rotocap, Intake-Exhaust Valve				
149-0136		Cover, Fuel Pump Hole In		• ,		
		g Cylinder Block	•		- 15 mare	
167-0188	. 2	Clip, Alternator Stator Lead	•			1 ·
,		Holding	i			-3
134-3828	1	Housing, Blower	7	Mary San	/ ds	
134-2760	1	Housing, Cylinder Air - Right				
, .	. 1	Side	95			
154-0951	1	Manifold, Intake	,	τ		
154-0998	1 .	Manifold, Exhaust			ą,	
505-0329	, 1	Cap, Pipe - Exhaust Manifold			e	•
154-0973	. 2	Gasket, Exhaust Manifold	,			** · · · · · · · · · · · · · · · · · ·
3.					•	
Parts Not	Furnis	shed By Onan		100	,`	
Fire1 Pun	a p		1			
		A second of the second of	•	•		, 8
100	A STATE OF THE STA					, * *
anta, in the second			*	-		1
į.	4				•	
			 '40	•		1
A J		- 20 · · · · · · · · · · · · · · · · · · ·		ē		
						1.

1.1	100	er di sa	C. C.	A					N					•								. 2.30				74 7 4		A 1 4 1 1						
	1. 1.	8 miles	- 1 al	- "						* * . *								2.5			1.0	1.1					1						1 4	
200	1	- Alexander			*						*											4.4		- 1 -				4.7	2					1.0
13911	ستاء يشطا	4.1				ن سد	-	سر ختخه				7				<u></u>		<u> </u>	•			* 1 * * *	<u> </u>					4.6					4 2 5	٠.
110			1000		6.000.00		- Tage .	T C)R			_			٠, ٠		200		CKI				9 .		1000	SP	- CO. 47		1.6	
100	_					_	_		V.,	_			-		16 8			٠.		2.1			lK. 1			***		77 11		_				-
	we				-	, ,	11 1	, ,					<i>-</i> 1 1		•								~					<u> </u>			_		1	_
-1-	heat a man	- Sec. 10.		1.15.4	7		9 7		7		1	5 Table 17	70 1		7	77.									4.1			,	75	F9 .			1	77
716			-3			ω l-∴.	1-4		- "		, k	11.74	A comment							10 mm	211		5.0				57.5			. F.C				- 1
111		10.00	544 1		1975	* 			غند- حس				-		- C	-							-			1.0		** 1.			ه شد	40.0	100	
	marke 1 1	F . M.	C 14.5	1 2 5	1117		44.	2.0			N.III	ъΛ.	E3 E		3 /		- 64	7	D		3 1					$\boldsymbol{\cap}$			(3.	7 7		. / ` / .		٠.

3493.1 KEY NO. _

PART NO. OTY.	and the completion of the first	PART NO. QTY.	DESCRIPTION
	DESCRIPTION	PART NO. QTY.	
Option - 8 👞	Spin-On Oil Filter	κ	
Option - 22	Variable Speed Governor		
	Control		
110-2375 1	Block Assembly, Cylinder		
	(Refer To Standard Cylinder		$f = f \cdot f$
	Block For Components,		
alito tropo	Except Parts Marked *)		أراني والمستوا والمتاري
110-1000 - 2	*Insert, Intake Valve Seat	•	
	——(Available In .010 And .025 Oversize)		
110-1037 2	Valve, Intake		and a second
160-1072 1	Flywheel	· , 30	i i
140-1087 1	Gasket, Air Cleaner		
134-3406 1	Housing, Blower	*	
134-2237- 1	Housing, Cylinder Air - Right		
	Side	4	
		à	
?			
		•	į
	*)
		ų,	A
	_		
3	4		
and the second of the second	************************************	***	
· ·		,	and the second second
		,	ė
\$ 100			
";. · · · · · · · · · · · · · · · · · · ·	·	<u> </u>	
•		k *	*
, i	1	•	
· · · · · · · · · ·	The state of the s	%	
-	*	* *	}
			د
			>
		<i>t</i>	
· · · · · · · · · · · · · · · · · · ·			
		A	· · · · · · · · · · · · · · · · · · ·

FOR STANDARD PARTS REFER TO CATALOG 927-0404

KEY NO.

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO. BELOW WHEN USED.

A TOPATO	NAL GROUPS IN CATALOG ARE LISTE	:D'RA CHOOK N	G BELUW W	HEN USES.
PART NO. QTY	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
Option - 8	Spin-On Oil Filter			
Option - 19	Ignition Breaker Box			M
	(High Profile)			
110-1957 1				
TT0-TA34 T	Block Assembly, Cylinder			
	(Refer To Standard Cylinder			
A 24	Block For Components,			
110-1827 2	Except Parts Marked *)			
509-0123 1	*Guide, Valve - Intake	*		
703-0123 I	Seal, Oil - Crankshaft			
509-0110	Rear Bearing Plate	a •		
TOTTO T	Seal, Dust - Crankshaft			
509-0090 2	Rear Bearing Plate			
509-0090 2 105-0140 1	Seal, 011 - Intake Valve Stem.			
T07-0140 T	Camshaft (Includes Center	* *		
150-0075 1	Pin)			
113-0152 2	Pin, Camshaft Center			
113-0132 2	Ring Set, Piston (Available	,		An interpresentation
4	In .005, .010; .020, .030 And .040 Oversize	,;	, <u>156</u>	· ·
114-0145 4	Bearing; Connecting Rod		'y an	
"TT4OTHO H	(available In .002, .010,	į.		·
	.020 And .030 Oversize)			*
103-0533 1	Cover Assembly, Gear (Refer			
; ±03 0333;; ±	To Standard Gear Cover For			
	Components, Except Parts		4	
	Marked #)		%	F
509-0126 1	#Seal, 011 - Gear Cover			
509-0105	#Seal, Dust - Gear Cover			
123-0508 1	Tube, 011 Fill	**	4	
123-0527 1	Cap And Indicator, Oil Fill			
223 332, 37 A	(Includes Gasket)	· · · · · · · · · · · · · · · · · · ·	÷.	
123-0191 1	-Gasket, Oil Fill Cap		*	
134-2388 1	Flywheel (Includes Ring Gear)			
•	Gear, Ring - Flywheel	, N	and the state of	
150-0635 1	Bracket, Governor Speed			
	Adjusting			
150-1021 1	Lever, Throttle Control'.	*		•
150-1339 1	Bracket, Throttle Lever	<i>a</i> 2		
• 1	Mounting			
150-0698 1	Spring, Governor			
149-1063 1	Baffle, Fuel Pump Air	Sec. 1	· · · · · · · · · · · · · · · · · · ·	s to grant the grant of the state of the sta
154-1116 / 1	Manifold, Intake			
505-0057 1	Plug, Pipe - Lotake Manifold			
154-1024 1	Manifold, Exhaust			
	Gasket, Exhaust Manifold	r **		
	Housing, Blower		;	a 4
3 3	Housing, Cylinder Air - Right			A
	V Side			
	A contact of the cont		W	The second second second

SPECIAL PARTS LIST FOR MODEL CCKB-MS SPEC 3545.1.
FOR STANDARD PARTS REFER TO CATALOG 927-0404 KEY NO.
OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO BELOW WHEN USED.

PART NO.	QTY.	DESCRIPTION "	PART NO.	QTY.	DESCRIPTION
Option -		Flywheel Alternator	A Sugar		
		(Syncro - 20 Ampere)	1		
Option -	1 3	Control (Engine)			
					•
104-0887	1 -	Crankshaft'		die en	
123-0527	1	Indicator And Cap, Oil Fill			,
		(Includes Gasket)			
123-0191	1	Gasket, Oil Fill Cap			
123-0679	•	Tube, Oil Fill		· · · · · · · · · · · · · · · · · · ·	and the second s
167-0188	2	Clip, Alternator Stator Lead		#	
Company of the control of the contro	* * *	Holding			
502-0020	1	Elbow, Street - Cylinder	4		
FOT 0000		Block To Oil Line (1/8")			The second second
501-0203	. Т	Line, Oil - Cylinder Block	, , , ,	· ·	ts
5080084	1.	To Gauge		•	
JU6UU64		Groumet, Rubber - Oil Line Through Blower Housing	1		
		(1-1/4" Hole)			
134-2995	1	Housing, Blower		# A .	,
301-4376	1	Bracket, Engine Control			•
308-0140	. 1	Switch, Start-Stop (Toggle)	and the second s		_. .
∴33 8– 0565	1	Harness, Wiring - Start		c	•
150-0147	1:	Stud, Governor Speed		* *	
		Adjusting			. (
140-0921	1.	Gasket, Adapter To Carburetor		· · ·	- <u>-</u> - a
, 1 54+0951 .	1	Manifold, Intake		•	2
153-0327	1.	Bracket, Choke Cable			•
518-0176	. 1	Clip, Choke Cable To Bracket	· ·	5	
155-0906	1	Muffler, Exhaust	41 .	957	
505-0618	* 1	Cap, Pipe - Exhaust Muffler			
154-0973	Z	Gasket Exhaust Manifold			, <u>\$</u>
515-0130	T/	Key; Crankshaft Stub	1 . 1	,	•
			, '		•
Я			u,	, 9	٠

DESCRIPTION

PART NO. QTY.	DESCRIPTION	PART NO. OTY:
Option - 8	Spin-On Oil Filter	
Option - 22	Variable Speed Governor	
	Control *	
110-1860 1	Block Assembly, Cylinder	
	(Refer To Standard Cylinder	**
	Block For Components)	
153-0464	Bracket, Choke Cable	. A
518-0176 1	Clip, Choke Cable To Bracket	
	Cable, Choke	
134-2 2 84 1	Housing, Blower	
134-2760 1	Housing, Cylinder Air - Right	
	Side	(A)
308-0140 1	Switch, Start-Stop (Toggle)	
*		
,		



SPEC	FOF	TS LIST FÖR MODEL R STANDARD PARTS REFER AL GROUPS IN CATALOG ARE US	TO CATALOG	927-0404	KEY NO.
PART NO.	1		PART NO.	QTY.	DESCRIPTION
Option -	5	Flywheel Alternator			
Option.	î 2	(Phelon - 15 Ampere)			
Option -		Variable Speed Governor			
104-0913	is	Crankshaft	\$4 65	, we will also the second	
۵09-023 7 م	1	Switch, Low Oal Pressure			
323-085	1	Body, Alternator Stator		•	
168-0188	. 2	Clip, Alternator Stator	***	10 m	
134-3019	%	Lead Holding Flywheel (Includes Ring Gear			, n
134-0673	1	Gear, Ring - Flywheel		्र के पर्य क	
				1 4	
	1				
			N ₁	1	
				4	*
B				A Company of the Comp	
April 1					
				i i r V	
. ₽. ¥	7			4	t A section of the se
en e	?				B
	4				
				, e ₀ ,	
					* #,
			¥.	*	
	Selection of the select				

Redistribution of publication of this document by any means, is strictly prohibited.

KEY NO.

OPTIONAL GROUPS IN CATALOG ARE LISTED BY GROUP NO BELOW WHEN USED.

PART NO.	QTY.	DESCRIPTION		PART NO.	QTY.	DESCRIPTION
Option -	5	Flywheel Alternator				
		(Phelon - 15 Ampere)		•		W
Option -	8	Spin-On Oil Filter				
Option -	31 °	Gas Carburetor	3.5			
	6 1			e e e e e e e e e e e e e e e e e e e		
110-1860	1	Block Assembly, Cylinder	. F			
the state of		(Refer To Standard Cylinder	. 0%			
		Block For Components)	7			Φ
104+0880	1_{n}	Crankshaft	, ,			
110-0893	, 4	Washer, Valve Spring Retainer	` `.			
149-0136		Plate, Cylinder Block Fuel	.			
,		Pump Hole Cover				
150-0635	, <u>, , , , , , , , , , , , , , , , , , </u>	Bracket, Governor Speed				
323-0853	. Š.	Adjusting				
్రామ−५ ०୭૩		Body, Alternator Stator Leads Connector				
167-0 1 88	2	Clip, Alternator Stator Lead				
	· •	Holding	g- 1	4	્ દે 😘	
154-0951	1	Manifold, Intake		, s		
505-0008	-1	Plug, Pipe - Carburetor (1/8"	<u>,</u> Ι		1	
502-0039	1	Elbow, Inverted Male - (4)	Ί.		`	
	€3.	Carburetor Fuel Thlet	* :	ş.	b	40
154-0998	1 1	Manifold, Exhaust	1	4	¥ .	
505-0329	·· 1	Cap, Pipe - Exhaust Manifold	ŀ	7		
154-0973	2	Gasket, Exhaust Manifold			-44	
134-2760	1_{c_0}	Housing, Cylinder Air - Right	, * *	4		
		Side			*	
51,5-0230	. 1.	Key, Crankshaft. Stub	, I -		A	7 3
	en (Sp. var. Sp. var				70 £	a = 1
*			·-			* *



SAFETY PRECAUTIONS

The following symbols are used in Onan manuals to alert users to the potentially dangerous conditions relating to maintenance of the equipment and replacement of parts. Please read and observe.

This symbol warns of immediate hazards which will result in severe personal injury or death.

AWARNING
This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.

This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.

MODEL IDENTIFICATION

To avoid errors or delay in filling your parts order, always give the MODEL, SPEC NO., and SERIAL NO. from the Onan nameplate.

For handy reference, insert your nameplate information in the spaces below:

MODEL AND SPEC NO.

SERIAL NO.

PRODUCT SAFETY PRECAUTIONS

AWARNING

Contact with USED ENGINE OILS has been identified by a United States federal agency and some USA state agencies as causing CANCER or REPRODUCTIVE TOXICITY. When checking or changing engine oils take all necessary precautions not to ingest, breathe the fumes or contact the used oil.

AWARNING

Contact with ASBESTOS has been identified by a United States federal agency and some USA state agencies as causing CANCER or REPRODUCTIVE TOXICITY. When handling engine gaskets take all necessary precautions not to ingest, breathe or contact the dust from the gaskets! Use adequate ventilation and wear protective gloves, masks and clothing!

△WARNING

Contact with BENZINE and LEAD, found in gasoline, fuel additives and solvents has been identified by a United States federal agency and some USA agencies as causing CANCER or REPRODUCTIVE TOXICITY. When checking, draining or adding gasoline and fuel additives, or using solvents take all necessary precautions not to ingest, breathe the fumes, or contact the liquids. Use adequate ventilation and wear protective gloves, masks and clothing!



INDEX

GROUP TITLES	LOCATION	
DATA TABLE	Α4	
INTRODUCTION	A4	
STANDARD ENGINE GROUPS	A4	
Block, Cylinder	A6,7	
Box, Ignition Breaker	B5	
Camshaft	A10	
Carburetor Parts - Gasoline - Begin Spec H	B2	
Carburetor Parts - Gasoline - Spec G Only	B3	
Crankshaft and Flywheel	A5	
Fuel System	A12,13	
Gearcase	Á11	
Governor	B10	
Housing, Air	B10	
Ignition System (Battery) - Key 2	B6,7	
Ignition System (Magneto) - Key 1	B 4	
Piston and Rod	A10	
Pump Parts, Fuel	B1	
Service Kits and Miscellaneous	B11	
Spark Advance Mechanism - Key 1	A14	
Starter - Spec G and H	В8	
Starter - Begin Spec J	B9	Optional Group
OPTIONAL EQUIPMENT SECTION		Number
Alternator (Automotive Type) Left Side Mounting	C2	1
Alternator (Automotive Type) Right Side Mounting	C2	2
Alternator (Automotive Type) Top Mounting	C3	3
Alternator, Flywheel (15 Ampere Phelon) - Key 2	C4	5
Alternator, Flywheel (20 Ampere Syncro) - Key 2	C4	6
Alternator, Flywheel (WICO) - Key 2	C3	4
Box, Ignition Breaker - (High Profile)	C14	19
Carburetor (Gasoline, Electric Choke) - Spec G Only	D4	24
Carburetor (Gas-Gasoline, Manual Choke) - Spec G Only	D5	25
Carburetor (Gas-Gasoline, Electric Choke) - Spec G Only	D6	26
Carburetor (Gas) - Spec G Only	D7	27
Carburetor (Gasoline, Electric Choke) - Begin Spec H	D8	28
Carburetor (Gas-Gasoline, Manual Choke) - Begin Spec H	D9	
Carburetor (Gas-Gasoline, Electric Choke) - Begin Spec H	D10	~~
Carburetor (Gas) - Begin Spec H	D11	~ ·
Choke, Thermo Magnetic	D1	20
Clutch	C9	12
Control (Cayanas) Mariable Speed	C9	13
Control (Governor) - Variable Speed	D3	22
Filter, Fuel	D3	23
Fuel System (Gaseous Fuel)	C5	8
Gear Reduction (3:31)	C11	15
Gear Reduction (4:1)	C7	10
Generator (Automotive Type)	C8	11
Housing, Air - Vacu-Flo Cooling (And Flywheel)	C5	7
Miscellaneous Parts	C10	14
Starter Readi Pull - Key 1	D12,13	n
Starter (Solenoid Shift) - Key 2	C6	9
Tank, Fuel (Day) One Quart	D2 C12	21 16
Tank, Fuel (Day) Two Quart	C12	17
Tank, Fuel (Side Mounted)	C13	18
, ,	0.13	10



927-0404 (APRIL 1981)

INTRODUCTION

This catalog applies to the industrial CCKB Engines listed below and factory installed options. Parts are arranged in groups of related items. Each illustrated part is identified by a reference number corresponding to the same reference number in the parts list for that group. Parts illustrations are typical. Using the MODEL and SPEC NO. from the engine nameplate, select the Parts Key No. (1,2,etc., in the last column) that applies to your Engine Model and Spec No. This Parts Key No. represents parts that differ between models. Unless otherwise mentioned in the description, parts are interchangeable between models. Right and left engine sides are determined by facing the blower end (front) of the engine.

ENGINE DATA TABLE

MODEL AND SPEC NO.	PARTS KEY NO.
CCKB-S*	1
£CCKB-MS/*	2

- * The Specification Letter Advances (A to B,B to C, etc.) with manufacturing changes.
- £ New model designations shown, begin during 1969. Previous designations used a V in the model to designate Vacu-Flo cooling.


STANDARD ENGINE PARTS SECTION

This section contains the engine parts used on standard engines listed in the Engine Data table.



927-0404 (APRIL 1981)

CRANKSHAFT AND FLYWHEEL




REF. NO.	PART .NO.	QTY. USED	PART DESCRIPTION	REF.		QTY. USED	PART DESCRIPTION
1	104-1316	1	Crankshaft (Includes Parts	10	WASHER,	FLAI-WHEE	L MOUNTING
			Marked *)		526-0017	1	Key 1 (15/32" ID x 1-1/4" OD x
2	515-0001	1	*Key Crankshaft Gear Mounting				1/4" Thk)
3	515-0227	1	Key, Wheel Mounting (Kit)		526-0128	1	Key 2 (15/32" ID x 1-1/2" OD x
			(Includes Parts Marked †)				1/4" Thk)
	515-0002	1	†Key (#9-3/4" x 3/16")	11	850-0055	1	Washer, Lock - Spring Flywheel
	515-0098	1	*†Key (#61-5/8" x 3/16")				Mounting
4	104-0032	1	Gear, Crankshaft	12	SCREW, W	HEEL MOU	NTING
5	104-0043	1	Washer, Crankshaft Gear		104-0170	1	Key 1
			Retainer		104-0369	1	Key 2 - Spec G and H
6	518-0014	1	Lock, Crankshaft Gear Washer		104-0170	1	Key 2 - Begin Spec J
7	KEY, CRANK	SHAFT	STUB (Order By Length)	13	192-0083	1	Roper, Manual Starting
	515-0198	1	2-1/2" lg	14	192-0296	1	Backplate - Rope Sheave
	515-0202	1	2-3/8" ig				(Optional - Key 2)
8	FLYWHEEL-	KEY 1 (Ir	ncludes Magnets: 2-160-0748, 2-160-0751)	15	134-0673	1	Ring Gear, Flywheel - Key 2
	160-0761 .	1	Spec G and H	16	192-0308	1	Sheave Rope (Optional -
	160-1072	1	Begin Spec J				Key 1, 2)
9	FLYWHEEL (Includes	Ring Gear)				
	134-1684	1	Key 2 - Spec G and H				316 Crankshaft Kit.
	134-2728	1	Key 2 - Begin Spec J	† -	Parts Inclu	aea in 515-0:	227 Wheel Mounting Kit.





CYLINDER BLOCK



927-0404 (APRIL 1981)




CYLINDER BLOCK


REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	
1	110-0915	1	Block Assembly, Cylinder	24	110-0880	2	Valve, Exhaust	
			(Includes Parts Marked *)	25	INSERT, EXH			
2	123-0954	1	Cap and Valve, Breather -		110-0872	2	Standard	
			Begin Spec H		110-0872-02	2	.002" Oversize	
2A	123-0787	1	Cap, Breather Tube -		110-0872-05	2	.005" Oversize	
			Spec G Only		110-0872-10	2	.010" Oversize	
3	TUBE, BREAT	THER			110-0872-25	2	.025" Oversize	
	123-0868	1	Spec G Only	26	110-0902	4	Guide, Valve	
	123-0953	1	Begin Spec H	27	110-0539	4	Spring, Valve	
4	123-0865	1	Baffle, Breather Tube	28	110-0893	2	Washer, Spring Retainer -	
5	505-0057	1	Plug (1/8"), Pipe - Oil Line				Intake Valve	
_			Plug	29	110-0639	8	Lock, Valve and Spring	
6	110-0666	2	Cover, Valve Compartment				Retainer	
7	110-0667	2	Gasket, Valve Cover	30	TAPPET, VAL			
8	517-0048	1	*Plug, Camshaft Expansion		115-0006	4	Standard	
•	000 0540	_	- Key 2		115-0006-05	4	.005" Oversize	
9	800-0512	5	*Screw, Cap - Hex Head	31	110-0904	2	Rotocap, Exhaust Valve	
			Bearing Plate Mounting -	32	110-1283	1	*Cover, Timing Control-	
			Replaces Stud and Nut Used				Key 1	
	FRR 2000	_	On Early Models (Special)	33	123-0951	1	Clamp, Breather Tube Cap -	
10	502-0020	1	Elbow, Street - Oil Line				Begin Spec H	
11 12	110-0892	2	Gasket, Cylinder Head	34	123-0958	2	Screen, Breather Tube -	
12	HEAD, CYLIN	1	1 - 24 5 1 / 114 5	0.5	500 0447		Begin Spec H	
	110-0883 110-0884	1	Left Hand (#1) -	35	509-0117	1	"O" Ring, Breather Tube	
13				36	Cap - Begin Spec H			
,,,	101-0450	2	Standard - Begin Spec J	36	SCREW, CAP-HEX HEAD-CYLINDER HEAD MOUNTING			
	101-0450-02	2	.002" Undersize		110-0879	8	Special	
	101-0450-10	2	.010" Undersize		114-0022	10	Special	
	101-0450-20	2	.020" Undersize	37	526-0122	18	Washer, Flat - Cylinder	
	101-0450-30	2	.030" Undersize	9,	020-0122	10	Head Mounting (11/32" ID	
14	104-0575	2	*Washer, Crankshaft Bearing				x 23/32" OD x 10 Ga. Thk)	
			Thrust	38	800-0012	2	Screw, Cap - Hex Head	
15	101-0115	1	*Gasket Kit, Bearing Plate				Valve Cover Mounting	
16	101-0316	1	*Plate, Rear Bearing				(1/4-20 x 2-1/4" lg)	
			(Excludes Bearing)	39	526-0063	2	Washer, Flat - Valve Cover	
17	101-0405	2	*Bearing, Camshaft Front and				Mounting (17/64" ID x 7/16"	
			Rear (Precision)				OD x 1/32" Thk)	
18	509-0041	1	Seal, Bearing Plate	40	850-0045	5	Washer, Lock - Spring - Bearing	
19	516-0072	2	*Pin, Main Bearing Stop				Plate Mounting (5/16")	
20	110-0445	5	Nut, Bearing Plate Stud	41	809-0035	1	Screw, Tapping, Pan Head	
			(Special) Used On Early				Breather Clamp (#8 x 3/4")	
			Models	42	516-0141	2	*Pin, Gear Cover Alignment	
21	123-0315	1	Valve, Breather Tube -	43	110-3136	2	*Gasket, Intake Valve Guide	
_			Spec G Only	44	104-0776	1	Shim, Crankshaft Thrust Bearing	
22	120-0386	1	*Tube, Crankcase Oil					
23	110-0881	2	Valve, Intake	• -	Parts Included	in 110-0	915 Cylinder Block Assembly.	

^{* -} Parts Included in 110-0915 Cylinder Block Assembly.



OIL SYSTEM








OIL SYSTEM

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	BASE, OIL			10	526-0066	1	Washer, Flat - Oil By-Pass
	102-0468	1	Key 1				(25/64"ID x9/16"OD x1/6"Thk)
	102~0339	1	Key 2 - Spec G and H	11	120-0140	1	Spring, Oil By Pass Valve
	102-0861	1	Key 2 - Begin Spec J	12	120-0398	1	Valve, Oil By Pass
2	TUBE, OIL F	ILL		13	120-0161	1	Gasket Kit, Oil Pump
	123-0508	1	Spec G and H	14	PLUG, OIL	DRAIN	
	123-0674	1	Begin Spec J		505-0110	1	Some Early Models (3/8")
3	CAP AND IN	DICATOR	I, OIL FILL		505-0056	1	Late Models (1/2")
	123-0506	1	Key 1 - Spec G and H	15	102-0455	4	Screw, Cap - Hex Head Oil Base
	123-0762	1	Key 1 - Begin Spec J				Mounting (Special)
	123-0527	1	Key 2 - Spec G and H	16	850-0050	4	Washer, Lock - Spring Oil Base
	123-0694	1	Key 2 - Begin Spec J				Mounting (3/8")
4	123-0191	1	Gasket, Oil Fill Cap	17	800-0004	2	Screw, Cap - Hex Head - Oil Fill
5	102-0158	1	Gasket, Oil Base				Tube Mounting(1/4-20 x 5/8" lg)
6	CUP, OIL PU	IMP INTA	KE	18	850-0040	2	Washer, Lock - Spring Oil Fill
	120-0413	1	Key 1				Tube Mounting (1/4")
	120-0648	1	Key 2	19	800-0007	2	Screw, Lock - Spring - Oil Pump
7	141-0078	1	Gasket, Oil Fill Tube				Mounting (1/4-20 x 1" lg)
			Mounting	20	850-0040	2	Washer, Lock - Spring - Oil
8	120-0491	1	Pump, Oil (Internal Parts Not Sold Separately)				Pump Mounting (1/4")
9	801-0048	1	Screw, Cap - Hex Head Oil By- Pass (3/8-24 x 3/4" lg)				






REF.	PART	QTY.	PART	REF.	PART	QTY.	PART
NO.	NO.	USED	DESCRIPTION	NO.	NO.	USED	DESCRIPTION
1	150-0078	1	Ring, Camshaft Center Pin	10	150-0075	1	*Pin, Center - Camshaft
2	150-1695	1	Cup, Governor (Kit) (Includes Parts Marked **)	11	105-0058	1	Plunger, Camshaft Thrust (Manually Controlled Engine)
3	510-0015	5	Ball - Governor	12	105-0059	1	Spring, Camshaft Plunger
4	150-1257	1	tSpacer, Governor Fly Ball, Begin				(Manually Controlled Engine)
			Serial #370369 During Spec H	13	150-1519	1	**Hub, Governor Cup
5	150-0077	1	†Plate, Governor Fly Ball, Begin	14	150-1520	1	**Cup and Bushing, Governor Cup
			Serial #370369 During Spec H	15	105-0030	1	†Gear, Camshaft
6	105-0332	1	Gear, Camshaft (Includes Parts Marked †)	٠.	Parts Includ	ted in Car	nshaft Assembly.
7	105-0541	1	Washer, Camshaft Gear Thrust				-1695 Governor Cup Kit.
8	515-0001	1	Key, Camshaft Gear Mounting	† - Parts Included in 105-0332 Camshaft Gear Assemb			
9	CAMSHAFT	(Includes	Center Pin)	•			The state of the s


KEY 1 105-0234 Spec G and H 105-0295 Begin Spec J 105-0238

Key 2

PISTON AND ROD



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	PISTON AND	PIN (fn	cludes Retaining Rings) Piston Has Slotted	5	RING SET, PI	STON	
	Oil Ring Gre	oves (To	op Grove 5/32" From Top of Piston)		113-0153	2	Standard
(Includes Parts Marked *)					113-0153-05	2	.005" Oversize
	112-0179	2	Standard		113-0153-10	2	.010" Oversize
	112-0179-05	2	.005" Oversize		113-0153-20	2	.020" Oversize
	112-0179-10	2	.010" Oversize		113-0153-30	2	.030" Oversize
	112-0179-20	2	.020" Oversize		113-0153-40	2	.040" Oversize
	112-0179-30	2	.030" Oversize	6	805-0010	4	Bolt, Place - Connecting Rod
	112-0179-40	2	.040" Oversize	7	114-0036	2	Bushing, Piston Pin -
2	112-0069	2	Pin, Piston				Connecting Rod
3	112-0003	4	*Ring, Piston Pin Retainer	8	BEARING, CO	DNNECT	ING ROD
4	114-0203	2	Rod Assembly, Connecting		114-0188	4	Standard
			(Forged) - Includes Bushing		114-0188-02	4	.002" Undersize
			and Place Bolts		114-0188-10	4	.010" Undersize
					114-0188-20	4	.020" Undersize





.030" Undersize

114-0188-30



GEARCASE





C-1048

REF. NO.	PART NO.	QTY. USED	PART Description
1	509-0008	1	†*Seal, Oil - Governor Shaft
2	510-0013	1	†*Bearing, Governor Shaft Upper (Spec J Use 2)
3	ARM & SHAF	TASSE	MBLY, GOVERNOR
	150-1422	1	†Begin Spec J
	150-1315	1	*Spec G and H
4	YOKE, GOVE	RNORS	SHAFT
	150-1187	1	t*Begin Spec J
	150-0620	1	Spec G and H
5	518-0129	1	Ring, Yoke Retainer -
			Spec G and H
6	516-0130	1	†*Pin, Governor Cup Stop
7	BEARING, G	OVERNO	OR SHAFT — LOWER
	510-0013	1	*Begin Spec J
	510-0008	1	*Spec G and H
8	510-0014	1	†*Ball, Bearing - Governor Shaft
9	EXTENSION ONLY	GOVER	NOR ARM - STANDARD GOVERNORS
	150-1000	1	Spec G Only
	150-1073	1	Begin Spec H


REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
10	COVER ASS	EMBLY,	GEAR
	103-0655	1	Spec G and H (Includes Parts Marked *)
	103-0480	1	Begin Spec J (Includes Parts Marked †)
11	103-0011	1	Gasket, Gear Cover
12	815-0181	1	Screw, Cup - Hex Head with External Lock Washer (#10-32 x 1/2" lg)
13	SCREW, CA	P-HEX HI	· 3.
	800-0034	1	5/16-18 x 2-1/4" lg
	800-0032	4	5/16-18 x 1-3/4" lg
14	815-0046	2	†*Screw, Machine - Pan Head Yoke Mounting (#8-32 x 3/8" lg) Begin Spec J
15	850-0045	5	Washer, Lock-Spring-Gear Cover Mounting (5/16")
16	509-0040	1	† Seal, Gear Cover
17	516-0141	2	Pin, Gear Cover Alignment (5/16 x 1-1/8" lg)
18	167-0188	1	Clip, Oil Fill Mtg Tube

- * Parts Included in 103-0655 Gear Cover Assembly. † Parts Included in 103-0480 Gear Cover Assembly.

927-0404 (APRIL 1981)



FUEL SYSTEM





FS-1199



927-0404 (APRIL 1981)

FUEL SYSTEM


REF. NO.	PART NO.	QTY. USED	PART Description	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	PUMP, FUEL	- include	es Mounting Gasket	15	149-0003	2	†Gasket, Fuel Pump Mounting
	(Includes Par			16	ADAPTER,	AIR CLEA	NER
	(See Separate	e Group f	or Components)		140-0760	1	Spec G Only
	149-1792	1	Key 1		140-1304	1	Begin Spec H
	149-1784	1	Key 2	17	PAN, AIR C	LEANER	
2	149-1024	1	Rod, Fuel Pump Primer -		140-0828	1	Spec G Only
			Key 1		140-0595	1	Begin Spec H
3	ELBOW, CAP	RBURETO	R INLET	18	140-0636	1	Element, Air Cleaner
	502-0313	1	Begin Spec J	19	503-0301	2	Clamp, Fuel Pump to
	502-0065	1	Spec G and H				Carburetor Hose
4	LINE, FUEL-F	PUMP TO	CARBURETOR	20	140-0594	1	Cover, Air Cleaner
	149-1025	1	Spec G Only - Metal	21	140-0584	1	Gasket, Air Cleaner
	149-1097	1	Spec H Only - Metal	22	GASKET, A	DAPTER 1	O CARBURETOR
	503-0669	1	Begin Spec J - Rubber		140-0585	1	Spec G Only
5	ELBOW, FUE	L PUMP			140-1302	1	Begin Spec H
	502-0313	2	Inlet and Outlet - Begin		140-1087	1	Begin Spec J - Key 1
			Spec J	23	520-0621	2	Stud. Air Cleaner
	502-0002	1	Outlet - Spec G and H	24	865-0020	2	Nut (1/4-20) Wing
	502-0020	1	Inlet - Spec G and H	25	526-0063	2	Washer (1/4")
6	CARBURETO	R, GASC	LINE - MANUAL CHOKE	26	123-0893	1	Tube, Adapter to Breather Hose
			sket (See Separate	27	526-0063	2	Washer, (Copper), Pump
	Groups for Co Parts Marked		ts) (Includes				Mounting - Used on Early Models
	141-0774	1	Spec G	28	868-0002	2	Nut (5/16-24) - Carburetor
	141-0878	1	Begin Spec H				Mounting
7	HOSE, BREAT	THER		29	854-0017	2	Washer, Shakeproof -
	503-0479	1	Spec G Only				Carburetor Mounting (5/16")
	503-0546	1	Begin Spec H	30	813-0108	2	Screw (10-32 x 1/2"), Round
7A	CLAMP, BRE.	ATHER H	IOSE				Head - Air Inlet to Carburetor
	503-0170	1	5/8"	31	526-0241	2	Washer (#10) - Flat Air Inlet
	503-0171	1	11/16"				Mounting
8	155-0916	2	Muffler, Exhaust	32	WASHER, L	OCK	
9	505-0086	2	Nipple (1 x 2-1/2"), Exhaust		850-0030	2	Air Inlet Mounting (#10)
10	141-0281	1	*Gasket, Carburetor Mounting	33	850-0050	2	Intake Manifold Mounting (3/8")
11	520-0526	2	Stud, Carburetor Mounting	34	800-0057	2	Screw (3/8-16 x 2-3/ 4") - Intake
12	154-1161	1	Manifold, Intake				Manifold Mounting
13	154-0013	2	Gasket, Intake Manifold to Cylinder Block	35	806-0009	2	Screw, Counterbore - Fuel Pump Mounting
14	149-0045	2	Spacer, Fuel Pump Mounting (Spec J - Use 1)		505-0008	2	†Plug (Not Shown)

^{* -} Parts Included in 141-0774/141-0878 Carburetor Kit.



^{† -} Parts Included in 149-1784/149-1792 Fuel Pump Kit.


SPARK ADVANCE MECHANISM - KEY 1



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	160-0791	1	Cam, Timing Control
2	516-0144	4	Pin, Roll (7/16")
3	WEIGHT AS	SEMBLY (I	ncludes Pins) -
	TIMING C	ONTROL	
	160-0789	2	Magneto Ignition (Spec G and H)
	160-1049	2	Begin Spec J
	1 60 -0790	2	Battery Ignition (Spec G and H)
	160-1198	2	Begin Spec J
4	PIN, GROON	/E-TIMING	CONTROL
	51 6 -0146	2	Spec G and H
	516-Q172	2	Begin Spec J

REF. NO.	PART NO.	QTY. U\$ED	PART DESCRIPTION
5	SPRING, TI	MING CONT	TROL
	160-0727	1	Spec G and ∰
	160-1051	1	Begin Spec J
6	160-0726	1	Retainer, Timing Control
			(Spec G and H)
7	RING, RETA	AINING - TIN	AING CONTROL
	518-0185	2	Spec G and H
	518-0129	2	Begin Spec J

FUEL PUMP PARTS




REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	PUMP, FUEL (Includes Mounting Gasket)				516-0113	1	Pin, Rocker Arm
	149-1792	1	Key 1	11		1	Body (Not Sold Separately)
	149-1784	1	Key 2	12	149-0710	1	Link and Arm. Rocker (Sold only as a set)
	149-0526	1	Kit, Fuel Pump Repair (Includes Parts Marked *)	14	LEVER, PRIN	MER 1	Key 1
	149-0003	1	*Gasket. Mounting		149-1042	1	Key 2
1		1	Body (Not Sold Separately)	15	509-0065	2	Şeat, "O" Ring
2	815-0148	4	Screw (#8-32 x 7/8")	16	SPRING PR	IMER LEV	ÈĦ
3	815-0147	2	Screw (#8-32 x 7/8")		149-1044	1	Key 1
			Phillips - Valve Retainer		149-0404	1	Key 2
4	149-0096	2	*Valve and Cage	17	149-0003	1	'Gasket, Pump Mounting
5	149-0095	2	*Gasket, Valve	18	518-0129	1	Ring, Retainer - Primer Lever
6	149-0582	1	*Diaphragm Assembly	10	149-0858	•	*Gasket, Diaphragm - Lower
7	149-0672	1	*Spring (Replaces 149-0093)	19	149-0656	'	Side
8	149-0539	1	Retainer, Valve Cage				Side
9	149-0675	1	*Spring (Replaces 149-0094)	• -	Parts Include	ed In 149-	0526 Repair Kit.



927-0404 (APRIL 1981)


CARBURETOR PARTS - GASOLINE - BEGIN SPEC H



REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	
		OR. GAS	OLINE (Includes	11	141-0701	1	£*Gasket, Bowl to Body
	Mounting Gaskets)			12	141-0700	1	Screw, Throttle Stop
	141-0878	1	Manual Choke	13	141-0711	1	Spring, Throttle Stop
	141-0747	1	Kit, Carburetor Repair	14	NEEDLE. AL	JUSTIN	G
			(Includes Parts Marked 1)		141-0713	1	Gasoline Units
	141-0748	1	Kit, Carburetor Gasket	15	SPRING, ID	LE NEED)LE
			(Includes Parts Marked £)	16	141-0077	1	£*Washer, Main Jet Assembly
	141-0281	1	£*Gasket Carburetor Flange	17	141-0712	1	Jet Assembly, Main (Adjustable)
1	141-0708	1	Bowl, Fuel	18	SHAFT, CH	OKE	
2	141-0741	1	Plate, Choke		141-0742	1	Manual Choke Units
3	141-0698	4	Screw & Washer, Choke and	19	141-0699	1	Washer
_	, , , , , , , , , , , , , , , , , , , ,		Throttle Plate Mounting	20	141-0697	1	£*Seal, Felt
4	141-0706	1	Plate, Throttle	21	141-0203	1	*Retainer, Felt Seal
5	141-0705	1	*Retainer, Seal	22	141-0709	1	Shaft and Lever, Throttle
6	141-0661	1	£*Seal. Rubber	23	141-0799	1	*Spring, Float
7	141-0830	1	*Valve Seat Assembly, Fuel				-
8	141-0811	1	£Washer, Fuel Valve Seat		Porte Includ	od 1/11-0	747 Carburetor Repair Kit.
9	141-0703	1	*Shaft, Float				747 Carburetor Nepair Kit. 748 Carburetor Gasket Kit.
10	141-0702	1	Float Assembly	L -	rails includ	60 141-0	, 40 Gardarotor Gaskot Mt.




CARBURETOR - GASOLINE - SPEC G ONLY




REF. NO.	PART NO.	QTY. USED		REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	CARBURET	OR, GAS	OLINE (Includes Mounting Gasket)	10	143-0105	1	Float and Lever
	141-0774	1	Manual Choke	11	143-0210	1	Bowl
	143-0332	1	Kit, Carburetor Repair (Includes	12	143-0077	1	*Gasket, Bowl Ring
			Parts Marked **)	13	141-0703	1	**Pin, Float Lever
	143-0201	1	**Kit, Carburetor Gasket (Includes	14	143-0341	1	**Valve, Fuel Inlet
			Parts Marked *)	15	143-0213	1	Screw, Idle Adjusting
	141-0281	1	*Gasket, Carburetor Flange	16	812-0014	4	**Screw (#3-48 x 3/16") - Choke
1	143-0202	1	Valve, Throttle				and Throttle Valve
3	143-0220	1	Valve, Choke - Manual Choke	17	143-0110	1	Plug, Expansion
4	143-0330	1	**Needle, Idle Jet and High Speed Adjusting	18	143-0214	1	Spring, Throttle Adjusting Screw
5	143-0329	1	"Nozzle	19	143-0112	1	Spring, Idle Adjusting Screw
6	143-0221	1	Shaft and Lever, Choke	22	854-0003	4	**Washer, Lock (IT #3)
7	143-0208	1	Screw and Gasket, Bowl				. ,
8	143-0015	1	*Gasket, Fuel Inlet Valve		Parts Includ	ad in 143	-0201 Carburetor Gasket Kit.
9	143-0209	1	*Gasket, Bowl Screw				-0332 Carburetor Repair Kit.



IGNITION SYSTEM (MAGNETO) - KEY 1






REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	PLUG, SPA	ЯK		5	160-0750	1	*Coil, Magneto Stator
	167-0241	2	Non-Resistor Type	6	160-0749	1	Pole Shoe, Magneto Stator
	167-0237	2	Resistor Type	7	526-0015	2	Washer, Flat (9/32" ID x
2	508-0095	2	Grommet, Rubber - Spark				9/16" OD x 1/16" THK)
			Plug Cables	8	526-0184	2	Washer, Flat (17/64" ID x
3	CABLE, SPA	ARK PLUG					5/8" OD x #10 Gauge)
			Key 1	9	815-0259	2	Screw Cap - Hex Head (1/4-20 x
	167-1404	1	Right Hand - Spec G and H				1-1/4" (g)
	167-1593	1	Right Hand - Begin Spec J	10	313-0018	1	Switch, Stop
	167-1403	1	Left Hand - Spec G and H	11	160-0257	1	Box Assembly, Breaker (See
	167-1594	1	Left Hand - Begin Spec J				Separate Group for Complete
			Key 1				Breakdown)
	167-1073	1	Right Hand - Spec G and H	12	167-0188	4	Clip, Spark Plug Cable
	167-1593	1	Right Hand - Begin Spec J	13	332-0273	1	Clip, Magneto Lead
	167-1330	1	Left Hand - Spec G and H	14	334-0028	1	Lead, (4' pieces of wire)
	167-1593	1	Left Hand - Begin Spec J	15	508-0002	1	Grommet, Magneto Lead
4	160-0752	1	Stator Assembly, Magneto (Includes Parts Marked *)	16	160-0043	1	Gasket, Ignition Breaker Box Mounting

^{* -} Parts Included in 160-0752 Magneto Stator Assembly.



IGNITION BREAKER BOX




REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART <u>D</u> ESCRIPTION
	160-0257	1	Box Assembly, Breaker -	7	312-0069	1	*Condenser, Ignition Points
			Complete (Includes Mounting	8	160-0043	1	*Gasket, Breaker Box Mounting
			Gasket, Washer and	10	160-0262	1	*Guide and Plunger, Ignition
			Screws) (Includes Parts	11	802-0034	2	*Screw, Cap - Socket Head
			Marked *)				(1/4-20 x 3/4" lg)
1	160-0930	1	*Cover, Breaker Box	12	850-0040	2	*Washer, Lock - Spring (1/4")
2	160-0150	1	*Gasket, Breaker Box Cover	13	850-0025	2	*Washer, Lock - Spring (#8)
3	160-0075	1	*Cam, Breaker Point Gap Adjusting	14	812-0077	2	*Screw, Machine - Round Head (#8-32 x 3/8" lg)
4	160-0002	1	*Point Set Breaker	15	518-0049	3	*Screw, Machine - Round Head
5	160-0349	1	*Block and Terminal Assembly				W/External Tooth -
6	160-0428	1	*Strap, Point Set to Terminal Block				(#8-32 x 1/4" lg)

^{* -} Parts Included in 160-0257 Breaker Box Assembly.



IGNITION SYSTEM (BATTERY) - KEY 2






IGNITION SYSTEM (BATTERY) - KEY 2

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	160-0257	1	Box, Breaker - Complete (See Separate Group for Complete	8	166-0402	1	Bracket, Coil Mounting - Spec G and H
			Breakdown of Components)	9	503-0514	1	Clamp, Coil - Spec G and H
2 3	160-0043 COIL, IGNIT	1 NON	Gasket, Breaker Box Mounting	10	160-0558	2	Nipple, Rubber Coil - Spec G and H
	166-0346	1	Spec G and H	11	304-0060	1	Resistor, Ignition - Spec G and H
4	166-0535 CABLE, SPA	1 ARK PLUG	Begin Spec J i	12	304-0610	1	Support, Resistor Terminal - Spec G and H
	167-1404 167-1073	1 1	Key 1 Spec G and H R/H Key 2 Spec G and H R/H	13	304-0014	2	Washer, Resistor Mounting Spec G and H
	167-1403 167-1330 167-1594	1 1 1	Key 1 Spec G and H L/H Key 2 Spec G and H L/H Key 1 Begin Spec J L/H	14	813-0112	1	Screw, Machine - Round Head Resistor Mounting Spec G and H (#10-32 x 2-1/2" lg)
	167-1595 167-1593 167-1596	1 1 1	Key 2 Begin Spec J (24") Key 1 Begin Spec J R/H Key 2 Begin Spec J (15")	15	526-0179	1	Washer, Flat - Resistor Mounting (Spec G and H) (7/32"ID x 5/8"OD x 1/16"Thk)
5	SPARK PLU	G, IGNITI		16	854-0010	1	Washer, Lock - Internal
	167-0241 167-0237	2 2	Non-Resistor Type Resistor Type				Shakeproof-Resistor Mounting Spec G and H (#10)
	166-0702	1	Kit, Lead Replacement (Includes Parts Marked *)	17	870-0053	1	Nut, Hex - Resistor Mounting Spec G and H (#10-32)
6	336-4414	1	*Lead Assembly, Coil to Breaker Box - Begin Spec J	18 19	166-0554 850-2005	1 1	*Nut, Hex (Special) *Washer, Lock (MS)
7	308-0002	1	Switch, Ignition On/Off	20	166-0604	2	Nut, Ignition Coil

^{* -} Parts Included in 166-0702 Lead Replacement Kit.



STARTER - SPEC G AND H




REF.	PART	QTY.	PART	REF.	PART	QTY.	PART
NO.	NO. USED DESCRIPTION		NO.	NO.	USED	DESCRIPTION	
1	191-0511	1	Starter Motor - (Includes Parts	9	191-0517	1	*Armature
	Marked *)		Marked *)	10	191-1017	1	*Coil Assembly Package, Field
2	191-0508	1	Flange, Starter Motor Mounting	11	191-0513	1	*Brush Set, Service
3	308-0028	1	Switch, Start	12	191-1018	1	*Head Assembly, Commutator
4	332-0570	1	Jumper, Starter to Switch				End Band, Cover (Not Sold
5	SCREW, CA	P-HEX HE	AD-STARTER MOTOR MOUNTING				Separately)
	800-0049	1	3/8-16 x 7/8" lg	13	191-1019	1	*Bearing Assembly, Intermediate
	800-0050	1	3/8-16 x 1" lg	14	191-0271	1	*Drive Assembly, Bendix
6	850-0050	2	Washer, Lock - Spring Starter	15	191-0735	1	*Bearing, Drive End
			Motor Mounting (3/8")	16	191-1020	1	*Spring, Brush (Set of 4)
7	102-0455	3	Screw, Cap - Hex Head - Starter	17	191-1021	1	*Washer, Armature Thrust (pkg.)
			Motor Flange Mounting				Use as required
8	850-0050	3	Washer, Lock - Spring - Starter	18	191-1022	1	*Stud. Terminal (pkg)
			Motor Flange Mounting (3/8")				

^{* -} Parts Included in 191-0511 Starter Motor



STARTER - BEGIN SPEC J




REF. NO.	PART NO.	QTY. USED	_	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	191-1052	1	Starter (Includes Parts Marked *)	10	191-1005	2	*Brush, Starter (Positive)
1	191-1011	1	*Screw & Washer Set	11	191-0997	1	*Insulating, Washer Set
2	191-0987	1	Solenoid Assembly	12	191-1088	1	*Armature, Starter
3	191-0988	2	*Bolt - Hex Washer Head	13	191-0984	1	*Plate & Spring Set
4	191-1009	1	*Bracket, Rear - Starter (Includes	14	191-0983	1	*Lever, Clutch
			Rear Sleeve Bearing)	15	191-1087	1	*Clutch & Pinion Gear
5	191-1010	1	*Bearing, Sleeve (Rear)	16	191-0991	1	*Stop Retaining Set - Pinion Gear
6	191-1006	1	*#Holder, Brush (Includes Negative Brush and Brush Springs)	17	191-1086	1	*Bracket, Front - Starter (Includes Front Sleeve Bearing)
			(Includes Parts Marked △)	18	191-0971	1	*Bearing, Sleeve (Front)
7	191-1008	1 #	‡∆*Brush, Starter (Negative)	19	191-1076	1	Seal, Air Begin Spec J
8	191-1007	3 ‡	#∆*Spring, Helical. Compression (Brush)	20	850-0050	2	Washer, Lock - Spring - Starter Mounting
9	191-1089	1	Yoke Assembly, (Includes Frame, Pole Shoes, Field Coil and Replaceable Positive Brushes)	21	800-0050	2	Screw, Cap - Hex Head - Starter Motor Mounting (3/8-16 x 1")

- # Early Brush Holder equipped with Two (2) Negative Brushes and Four (4) Brush Springs-Completely Interchangeable with Current Brush Holder.
- * Parts Included in 191-1052 Starter Motor
- $\Delta\,$ Parts Included in 191-1006 Brush Holder Assembly.




GOVERNOR

REF. NO.		QTY. USED	PART DESCRIPTION
1	150-0098	1	Spring, Governor
2	150-1023	1	Stud, Speed Adjustment
3	150-1262	1	Bracket, Speed Stud
4	870-0131	1	Nut, Speed Adjusting (#10-32)
5	JOINT, BALL		
	150-0974	2	Spec G Only
	150-0939	2	Begin Spec H through Serial #540766 During Spec H-Plastic
	150-0639	2	Begin Serial #540767 During Spec H - Metal
6	LINK, THROT	TLE	
	520-0187	1	Spec G and Begin Serial #540767 During Spec H
	520-0623	1	Begin Spec H through Serial #540766 During Spec H
7	870-0053	2	Palnut, Locking
8	870-0131	2	Nut, Keps - Locking Ball Joint (#10-32)
9	526-0196	2	Washer, Flat - Ball Joint (7/32"ID x 7/16"OD x 1/8"Thk)
10	821-0010	1	Screw, Self Lock - Hex Washer Head (1/4-20 x 1/2")



AIR HOUSING



REF. NO.	PART NO.	QTY. USED	PART Description				
1	HOUSING, B	LOWER					
		1	Key 1				
	134-1579	1	Spec G and H				
	134-2830	1	Begin Spec J				
			Key 2				
	134-1596	1	Spec G and H				
	134-2826	1	Begin Spec J				
2	134-0589	1	Housing, Cylinder Air - Left				
3	HOUSING, C	S, CYLINDER AIR (Right)					
	134-0588	1	Key 1				
		1	Key 2				
	134-0674	1	Spec G and H				
	134-2791	1	Begin Spec J				
4	134-0670	1	Baffle, Air - Key 2 Spec G and H				
5	CLIP, HOUSI	NG-CYLI	NDER AIR				
	134-0599	1	Right Side				
	134-2108	1	Left Side				
6	508-0095	2	Grommet, Blower Housing				
7	313-0018	1	Button Stop - Begin Spec J - Key 1				
8	815-0261	4	Screw, Cap - Hex Head (1/4-20 x 1/2")				

927-0404 (APRIL 1981)

CS-1069

SERVICE KITS AND MISCELLANEOUS

NOTE: For other kits, refer to the group for the part in question.

REF. NO.	PART NO.	QTY. USED	PART Description		
	98-1100	1	Decal Kit, Set		
	160-0836	1	Ignition Tune-up Kit		
	168-0103		Gasket Kit, Complete Engine		
	168-0095	1	Gasket Kit, Carbon Removal		
	ENGINE OV	VERHAUL KIT			
	522-0225	1	Spec G Only		
	522-0239	1	Begin Spec H		
	TOUCH-UP	PAINT (Pr	essurized Can)		
	525-0137	1	Metallic Green (13 oz.)		
	525-0305	1	Non-Metallic Green (13 oz.)		
	525-0454	1	Greige Enamel (13 oz).		




OPTIONAL EQUIPMENT SECTION

This section contains parts listing of factory installed options. NOTE: options may not be applicable to all models; for field installations, additional parts are usually required.




OPTION 1 ALTERNATOR (AUTOMOTIVE TYPE - LEFT SIDE MOUNTING)


REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	191-1233	1	*Alternator Assembly (Includes Parts Marked †) (35 Ampere.
			12 Voit)-Motorola #RA-12NON451
	191-1232	1	†Alternator, 35 Amp
2	191-1243	1 1	*Regulator, Voltage
3	191-0623	1	†Pulley, Alternator
4	BRACKET,	ALTERNA'	TOR MOUNTING
	191-0537	1	Pressure Cooled Engine
	191-0539	1	Vacu-Flo Cooled Engine
5	191-0535	1	Bracket, Alternator Adjusting
6	511-0051	1	Belt, Drive
7	191-0134	1	Pulley, Drive - Vacu-Flo Cooled Engine
8	191-0659	1	Brush and Holder Assembly (Part of 191-0573 Alternator)
9	191-0671	1	Diode Assembly, Isolation (Part of 191-0573 Alternator)
10	191-0662	1	Diode Assembly, Rectifier - Negative (Part of 191-0573
11	191-0661	1	Alternator) Diode Assembly, Rectifier - Positive (Part of 191-0573 Alternator)
٠ _	For compone	ents not lie	ted chark alternator nameniate



^{† -} Parts Included in 191-1233 Alternator Assembly.



OPTION 2 ALTERNATOR (AUTOMOTIVE TYPE - RIGHT SIDE MOUNTING)



REF. NO.	PART NO.	QTY. USED		REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	191-1233	1	*Alternator Assembly (Includes Parts Marked †) (35 Ampere,	8	191-0671	1	Diode Assembly, Isolation (Part of 191-0573 Alternator)
			12 Volt)-Motorola #RA-12NON451	9	191-0662	1	Diode Assembly, Rectifier - Negative (Part of 191-0573
	191-1232	1	†Alternator, 35 Amp				Alternator)
2	191-1243	1	†*Regulator, Voltage	10	191-0661	1	Diode Assembly, Rectifier -
3	191-0623	1	†Pulley, Alternator				Positive (Part of 191-0573
4	191-0575	1	Bracket, Alternator and Starter Mounting				Alternator)
5	191-0576	1	Bracket, Alternator Adjusting	• -	For compone	ents not lis	sted check alternator nameniate

Contribute Power Generation

511-0076

191-0659

Beft, Drive

Brush and Holder

(Part of 191-0573 Alternator)

and contact your nearest Motorola dealer.

† - Parts Included in 191-1233 Alternator Assembly.

OPTION 3 ALTERNATOR (AUTOMOTIVE TYPE - TOP MOUNTING) 5 BRACKET, ALTERNATOR ADJUSTING Pressure Cooled Engines -191-1168 Begin Serial Number 992673 **During Spec J** Pressure Cooled Engines -191-0637 Spec A through Serial Number 992673 During Spec J 191-0637 Vacu-Flo Cooled Engines BELT, DRIVE 511-0090 Pressure Cooled Engines -Begin Serial Number 992673 **During Spec J** Pressure Cooled Engines -511-0067 Spec A through Serial Number 992673 During Spec J Vacu-Flo Cooled Engines 511-0067 Spacer, Alternator Bracket 191-0640 191-0638 Bracket, Regulator Mounting 8 191-0659 Brush and Holder Assembly (Part of 191-0543 Alternator) 191-0663 Diode Assembly, Isolation 10 (Part of 191-0543 Alternator) 191-0662 Diode Assembly, Rectifier -11 Negative (Part of 191-0543 Alternator) Diode Assembly, Rectifier -12 191-0661 1 REF. PART QTY. PART Positive (Part of 191-0543 USED DESCRIPTION NO. NO. Alternator) Guard, Belt 13 191-0725 191-0543 *Alternator (35 Ampere, 12 Volt) 1 - Motorola #A12N-451

FLYWHEEL ALTERNATOR (20 AMP WICO) - KEY 2 SPEC G, H AND J 10 12 14 15 DOME PART REF. PART QTY. C\$-1070 USED DESCRIPTION NO. NO. Screw, Machine - Round Head 812-0156 Flywheel (Includes Ring Gear) 134-1895 (1/4-20 x 1-1/2") Gear, Ring - Flywheel 134-0673 850-0040 Washer, Lock - Spring (1/4")

14

15

16

18

19

800-0006

332-1358

813-0108

850-0030

321-0169

167-0188

332-0325

1

3

1

2

Parts Included in 191-0740 Stator Assembly

OPTION 4

* - For Components not listed, check alternator nameplate

and contact your nearest Motorola dealer.



3

5

6

8

٩

10

11

12

191-0642

191-0623

191-0636

191-0740

191-0400

305-0478

321-0165

321-0162

323-0759

323-0488

332-0556

191-0724

332-0529

3

*Regulator, Voltage

Pulley, Alternator

Bracket, Alternator Mounting

Stator Assembly (Includes

Regulator - Rectifier Assembly

*Connector, Socket Housing

Parts Marked *)

*Holder Assembly, Fuse

*Terminal, Faston - Male

*Fuse - 30 Amp.

*Stator Only

*Socket, Connector

*Connector, Faston

927-0404 (APRIL 1981)

Screw, Cap - Hex Head

Bracket, Connector Mounting

Screw, Machine - Round Head

Washer, Lock - Spring (#10)

(1/4-20 x 7/8")


(#10-32 x 1/2")

Clip, Fuse Holder


Clip, Stator Leads

Terminal (#10)

OPTION 5 <u>FLYWHE</u>EL ALTERNATOR (15 AMPERE PHELON) - KEY 2 - BEGIN SPEC J



	79	-	
REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	813-0143	3	Screw, Machine - Round Head Cross Recessed (#10-32 x 1-3/8")
2	850-0030	3	Washer, Lock - Spring (#10)
3	191-1256	1	Stator Assembly (Includes Parts Marked *)
4	821-0018	2	Screw, Cap-Hex Head - Self Locking (1/4-20 x 5/8")
5	191-0886	1	Regulator, Voltage
6	821-0012	2	Screw, Cap - Hex Head - Self Locking (1/4-20 x 1-1/8")



			CS-10
7	191-1107	1	Bracket, Regulator Mounting
8	134-2100	2	Spacer, Regulator Mounting
9	134-2621	1	Flywheel (Includes Ring Gear)
10	134-0673	1	Gear, Ring - Flywheel
11	323-0853	1	*Body, Connector
12	332-2073	3	*Terminal
13	167-0188	2	Clip, Stator Leads
14	191-1254	1	*Stator Only
15	323-1075	1	*Body, Connector

^{* -} Parts Included in 191-1256 Stator Assembly.

OPTION 6 FLYWHEEL ALTERNATOR (20 AMPERE SYNCRO) - KEY 2 - BEGIN SPEC J

11

12

13

15

16

323-0880

191-0937

850-0030 813-0108

323-0488


323-0496

167-0188

3


5

5



NO.	NO.	USED	DESCRIPTION
1	134-2642	1	Flywheel (Includes Ring Gear)
2	134-0673	1	Gear, Ring - Flywheel
3	821-0010	2	Screw, Cap - Hex Head Locking (1/4-20 x 1/2")
4	191-1107	1	Bracket, Regulator and Rectifier Mounting
5	815-0181	4	Screw, Cap - Hex Head W/ET Lockwasher (#10-32 x 5/16")
6	191-0938	1	Rectifier, Current
7	191-0939	1	Regulator, Voltage
8	323-0882	1	Plug, Connector (3 Female Contacts)
9	323-0881	1	Cap, Connector (3 Male
Citris	Power		Contacts)

Generation




Contacts)	
Plug, Connector (2 Female	
Contacts)	
Stator, Alternator	
Washer, Lock - Spring (#10)	
Screw, Machine - Round Hea	d
Cross Recessed	
(#10-32 x 1-1/4")	
Contact, Connecting - Femal	е
Contact, Connecting - Male	
Clip, Stator Leads	

Cap, Connector (2 Male

927-0404 (APRIL 1981)Redistribution or publication of this document by any means, is strictly prohibited.

OPTION 7 GENERATOR(AUTOMOTIVE TYPE)




REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	191-0277	1 -	Generator
2	191-0229	1	Pulley, Generator
3	511-0051	1	Belt, Generator Drive
4	BRACKET	GENERATO	RMOUNTING
	191-0279	1	Pressure Cooled
	191-0304	1	Vacu-flo Cooled
5	191-0280	1	Bracket, Generator Adjustin
6	191-0134	1	Pulley, Generator Drive - Vacu-flo Cooled
7	191-0305	1	Brace, Generator Mounting Bracket - Vacu flo Cooled

† - For components, check nameplate and contact your nearest Delco Remy Dealer.


OPTION 8 OIL FILTER

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	122-0321	1	Gasket
2	52 6-0065	2	Washer, Flat - Copper (21/64" ID x 9/16" OD x 1/16" Thk)
3	800-0028	2	Screw, Cap - Hex Head (5/16-18 x 1")
4	122-0320	1	Adapter, Filter
5	122-0323	1	Filter, Spin-On
6	122-0347	1	Seal, Air
7	122-0345	1	Tube, Oil Drain
8	505-0057	1	Plug, Adapter Outlet (1/8")






OPTION 9 READI-PULL STARTER - KEY 1



REF. NO.	PART NO.	QTY USE		REF. NO.	PART NO.	QTY. USEC	
	KIT.START	ER-CON	MPLETE	21	870-0110	4	†∆Nut, Speed Grip
	192-0325	1	Begin Spec E (Includes Parts Marked †)	22	526-0180	4	†ΔWasher, Flat (17/16" ID x 7/8" OD x 1/8" Thk)
	192-0215	1	Specs A through D (Includes Parts Marked Δ)	23	526-0130	4	†ΔWasher, Flat (17/64" ÎD x 1" OD x 1/16" Thk)
1	192-0045	1	†ΔRope and Grip Assembly	24	192-0309	1	†Wheel, Ratchet - Begin Spec E
			(Includes Parts Marked □)	25	516-0132	1	†ΔPin, Spiral - Brass
2	192-0043	1	†∆□Rope	26	526-0168	1	†∆Washer, Flat (1-15/32" ID x
3	192-0044	1	†∆□Grip				3" OD x .047" Thk)
4	517-0025		†Δ¤Plug, Grip	27	815-0137	4	†ΔScrew, Cap - Hex Head
5	526-0021	1	†∆□Washer, Fłat (17/64" ID x				(1/4-20 x 1-1/4")
			3/4" OD x 1/16" ™bk+	28	850-0050	1	†∆Washer, Lock - Spring (3/8")
6	192-0153		†ΔWheel, Cog	29	800-0007	4	†∆Screw, Cap - Hex Head
7	516-0138	1	†ΔPin, Roll				(1/4-20 x 1-1/4")
8	192-0039	1	†ΔSpring, Recoil	30	850-0040	8	†∆Washer, Lock - Spring (1/4")
9	526-0123	1	†ΔWasher, Thrust	31	815-0137	2	†∆Screw, Cap - Hex Head
10	192-0180	1	†ΔSheave, Rope (Includes Parts				(1/4-20 x 1-1/4")
		_	Marked *)	32	526-0158	4	†∆Washer, Flat (.261" ID x
11	192-0172		†∆*Pawl				1" OD x 1/8" Thk)
12	192-0165		†∆*Spring, Pawl	33	526-0015	2	†∆Washer, Flat (9/32" ID x
13	192-0168		†∆*Arm, Ratchet				9/16" OD x 1/16" Thk)
14	516-0110	4	†∆*Pin, Roll (2) Pawl (2) Ratchet Arm	34	192-0170	1	△Wheel, Ratchet - Specs A through D
15	192-0167	1	†∆*Clamp, Rope	35	192-0218	2	△Screw, Cap - Hex Head -
16	192-0163	1	†∆Bearing, Sheave Hub				Specs A through D
17	192-0323	1	†∆Screw, Cap - Socket Head				
			(Special)	† -	Parts Include	ed in 192-	-0325 Starter Kit.
18	862-0003	1	†∆Nut, Hex (3/8-16)				-0215 Starter Kit.
19	192-0152	1	†∆Cover. Starter				0045 Rope and Grip Assembly
20	192-0186	1	†∆Ring, Mounting	٠.	Parts Include	ed in 192-	-0180 Rope Sheave.
4.0	132-0100	'	raining, mounting				




OPTION 10 GEAR REDUCTION (3.3:1)



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	REDUCTION	N GEAR AS	SSEMBLY	14	800-0007	4	Screw, Cap - Hex Head
•	190-0444	1	Mounted Left Side				(1/4-20 x 1")
	.50 0111	•	Horizontal	15	515-0159	1	Key, Driven Gear
	190-0440	1	Mounted Right Side	16	518-0013	1	Ring, Retainer
			Horizontal	17	190-0202	1	Spacer, Bearing
2	190-0050	1	Housing - Includes Cover (Also	18	190-0192	1	Shaft, Take-Off
			Order 2 #516-0012 Pins)	19	515-0103	1	Key, Take-Off Shaft
3	516-0012	2	Pin, Dowel	20	510-0023	1	Cone, Roller Bearing
4	190-0020	1	Gasket, Housing to Engine	21	510-0024	1	Cup, Roller Bearing
5	190-0021	1	Gasket, Cover to Housing	22	850-0045	12	Washer, Lock - Spring (5/16")
6	190-0016	1	Plate, Bearing Retainer	23	505-0054	3	Plug, Pipe (1/4)
7	190-0115	1	Shim Set, End Play Adjustment	24	190-0306	2	Gasket, Bearing Plate to
8	509-0016	1	Seal, Oil				Housing
9	190-0195	1	Washer, Pinion Gear	25	800-0028	16	Screw, Cap - Hex Head
10	515-0142	1	Key, Pinion Gear				(5/16-18 x 1")
11	190-0447	1	Gear, Set (Pinion and Driven)	26	526-0063	4	Washer, Flat - Copper
12	510-0022	1	Cup, Roller Bearing				(17/64" ID x 7/16" OD x
13	510-0021	1	Cone, Roller Bearing				1/22" Thk)



OPTION 11 GEAR REDUCTION (4:1)




REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART	QTY.	PART
NO.	-			NO. 15	NO.	USED	DESCRIPTION
1	1 REDUCTION GEAR ASSEMBLY				515-0159	1	Key, Driven Gear
	190-0193	1	Mounted Left Side Horizontal	16	518-0013	1	Ring, Retainer
			(No Longer Available)	17	190-0202	1	Spacer, Bearing
	190-0299	1	Mounted Hight Side Horizontal	18	190-0192	1	Shaft, Take-Off
			(No Longer Available)	19	515-0103	1	Key, Take-Off Shaft
	FOR REPL	ACEMENT	ORDER:	20	510-0023	1	Cone, Roller Bearing
	190-0440	1	Reduction Gear Assembly,	21	510-0024	1	Cup, Roller Bearing
			Mounted Right Side Horizontal	22	850-0045	12	Washer, Lock - Spring (5/16")
	190-0447	1	Gear, Set (Pinion & Driver)	23	PLUG, PIPE	(1/4)	
	190-0195	1	Washer, Pinion Gear		505-0054	3	Mounted Left Side and Mounted
	515-0142	1	Key, Pinion Gear				Right Side Gear Box
	190-0410	1	Mounted Vertical Down		505-0054	2	Mounted Vertical Down Gear
2 190	190-0050	1	Housing - Includes Cover (No				Box
			Longer Available) (Also Order	24	190-0306	2	Gasket, Bearing Plate to Housing
		_	2 #516-0012 Pins)	25	800-0028	12	Screw, Cap - Hex Head
3		2	Pin, Dowel				(5/16-18 x 1")
4		1	Gasket, Housing to Engine	26	526-0063	4	Washer, Flat - Copper
5		1	Gasket, Cover to Housing				(17/64"IDx7/16"ODx1/32"Thk)
6		1	Plate, Bearing Retainer	27	800-0007	4	Screw, Cap - Hex Head
7	190-0115	1	Shim Set, End Play Adjustment				(1/4-20 x 1")
8	516-0057	1	Seal, Oil	28	505-0007	1	Bushing, Reducer - Mounted
9	190-0195	1	Washer, Pinion Gear				Vertical Down Gear Box
10	515-0142	1	Key, Pinion Gear	29	518-0172	1	Vent, Mounted Vertical Down
11	190-0191	1	Gear, Pinion (No Longer				Gear Box
			Available)	30	509-0016	1	Seal, Oil
12	510-0022	1	Cup, Roller Bearing				•
13	510-0021	1	Cone, Roller Bearing				
14	190-0190	1	Gear, Driven (No Longer				



927-0404 (APRIL 1981)

Available)


OPTION 12 CLUTCH (ROCKFORD)





For components, check Clutch nameplate and contact your nearest Rockford Clutch Dealer.

12

25










	<u></u>		
14	502-0002	1	Elbow, Inverted Male
15	193-0005	1	Gauge, Oil Pressure
16	302-1361	1	Ammeter (20-0-20) (Includes
			Parts Marked *)
17	334-0028	1	Lead (4 foot pieces of wire)
18	517-0009	1	Plug, Dot Button
19	308-0029	1	Switch, Start
20	308-0232	1	Switch, Stop
21	153-0328	1	Cable, Choke
22	301-2780	1	Bracket, Engine Control
23	150-1000	1	Extension, Governor Arm
24	815-0181	1	Screw, Cap - Hex Head W/ET
			(#10-32 x 1/2")
25	502-0020	1	Elbow, Pipe - Street Brass, 90°
			(1/8 NPT)
_	302-0270	1	'Hardware Mounting Package.

^{* -} Parts Included in 302-1361 Ammeter.

OPTION 14 AJR HOUSING - VACU-FLO COOLING (AND FLYWHEEL)







x 1/16" Thk)

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
10	800-0010	4	Screw, Cap - Hex Head (1/4-20 x 1-3/4")
11	850-0040	4	Washer, Lock - Spring (1/4")
12	104-0170	1	Screw, Cap - Hex Head (Special) - Flywheel Mounting
13	134-2956	1	†Guard, Scroll Outlet
14	815-0421	4	†Screw, Machine - Hex Head (#10-16 x 1/2")
15	405-1059	1	Anti-Vibration Package
16	812-0099	1	Screw, Round Head - Machine - Coil Mounting - Begin Spec J (10-24 x 7/16")
17	870-0177	1	Nut, Speed - Coil Mounting - Begin Spec J (#10)


* - Vacu-flo units with oil filter also see Oil Filter Group - Option 8.


† - Parts included in Air Discharge Scroll Assembly.





OPTION 15 FUEL SYSTEM (GASEOUS FUEL)





FS-1187


REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	148-0390	1	Repair Kit, Gas Regulator	8	505-0099	1	Nipple (1/4 x 7/8") -
1	148-0311	1	Regulator, Gas (Garretson				Regulator Outlet
			Manufacturer).	9	505-0038	1	Elbow (1/4") - Regulator
3	*CARBURET	OR, GAS-	GASOLINE (Includes Mounting				Outlet
	Gasket) (li	ncludes Pa	arts Marked †)	10	505-0017	1	Bushing (3/8 x 1/4") Regulator
	143-0338	1	Spec G Only (Manual Choke)				Outlet
	141-0887	1	Begin Spec H (Manual Choke)	11	148-0107	1	Vent, Regulator
	143-0339	1	Spec G Only (Electric Choke)	12	504-0007	1	Valve, Shut-Off - Fuel Pump
	141-0888	1	Begin Spec H (Electric Choke)				Inlet
3	*CARBURET	OR, GAS ((Includes Mounting Gasket)	13	141-0281	1	†Gasket, Carburetor Mounting
	(Includes I	Parts Mark	red †)	14	149-0136	1	Plate, Fuel Pump Hole
	141-0840	1	Spec G Only				Crankcase (Gas Fuel Sets)
	141-0892	1	Begin Spec H	15	143-0231	1	Wire, Choke Stop (Gas-
4	503-0315	1	Hose, Regulator to Carburetor				Gasoline Units)
			(1/2" ID x 2 FT)	16	526-0063	2	Washer, Flat, Copper
5	503-0032	2	Clamp, Hose		020 0000	_	(17/64" ID x 7/16 OD x
6	505-0302	1	Nipple (1/4 x 1-1/2"), Half				1/32" Thk)
7	505-0057	1	Plug (1/8") - Regulator	17	806-0009	2	Screw, Cap - Counterbore (1/4-20 x 1.1")

- * See Separate Group for Components and Gasket Kit. † Parts Included in 141-0840/141-0887/141-0888/141-0892 Carburetor Kit.




OPTION 16 RESERVOIR (DAY) TANK (ONE QUART)

REF.		QTY.	PART
NO.	NO.	USED	DESCRIPTION
	159-0591	1	Kit, Tank (Includes all parts in this group)
1	159-0041	1	Cap, Vent
2	415-0055	1	Bracket, Vent Cap
3	505-0028	1	Coupling, Pipe
4	505-0016	1	Bushing, Reducer (3/8 to 1/8")
5	502-0116	1	Connector, Compression
6	159-0345	1	Tubing, Copper (5/16 x 12")
7	502-0024	1	Elbow, Compression (90°)
8	159-0294	1	Tank, Reservoir
9	159-0556	1	Band, Reservoir Tank
10	159-0612	1	Bracket, Reservoir Tank
			Mounting
11	502-0020	1	Elbow, Street (90°)
12	501-0005	1	Line, Fuel - to Fuel Pump (18")
13	504-0086	1	Valve, Shut-off
14	501-0007	1	Line, Fuel - to Carburetor (24")
15	505-0057	1	Plug, Tank Drain
16	812-0156	1	Screw, Machine - Round Head (1/4-20 x 1-1/2")
17	850-0040	1	Washer, Lock - Spring (1/4")
18	862-0001	1	Nut, Hex (1/4-20)




OPTION 17 RESERVOIR (DAY) TANK (TWO QUART)



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	159-0942	1	Kit. Tank (Includes all parts in this group)
1	159-0041	1	Cap, Vent
2	415-0055	1	Bracket, Vent Cap
3	505-0028	1	Coupling, Pipe
4	505-0016	1	Bushing, Reducer (3/8 to 1/8")
5	502-0116	1	Connector, Compression
6	159-0345	1	Tubing, Copper (5/16 x 12")
7	502-0024	1	Elbow, Compression (90°)
8	159-0746	1	Tank, Reservoir
9	159-0936	1	Band, Reservoir Tank
10	159-0612	1	Bracket, Reservoir Tank
			Mounting
11	502-0020	1	Elbow, Street (90°)
12	501-0005	1	Line, Fuel - to Fuel Pump (18")
13	504-0086	1	Valve, Shut-off
14	501-0007	1	Line, Fuel - to Carburetor (24")
15	505-0057	1	Plug, Tank Drain
16	812-0156	1	Screw, Machine - Round Head (1/4-20 x 1-1/2")
17	850-0040	1	Washer, Lock - Spring (1/4")
18	862-0001	1	Nut. Hex (1/4-20)




OPTION 18 FUEL TANK (SIDE MOUNTED)




REF. NO.	PART NO.	QTY. USED		REF.		QTY USE	7 7
	159-0984	1	Kit, Fuel Tank with Gauge	7	504-0013	1 -	†"Valvo, Shut-off
	100 000		(Includes Parts Marked *)	8	505-0057	1	†*Plug, Tank Drain
	159-0597	1	Kit, Fuel Tank Without	9	502-0020	1	†*Elbow, Carburetor Inlet
			Gauge (Includes Parts Marked †)	10	813-0108	2	t*Screw, Machine - Round Head (#10-32 x 1-1/2")
1	159-0981	1	†*Tank, Fuel (Less Cap)	11	870-0053	2	†*Nut, Hex (#10-32)
2	159-0596	2	†*Strap, Fuel Tank	12	159-0020	1	†Cap, Fuel Tank (For 2-5/16"
3	159-0595	2	†*Bracket, Fuel Tank				Filler Neck) - Late Models
4	134-0599	ī	†*Clip, Fuel Line	13	159-0007	1	Cap, Fuel Tank (For 1-3/4"
5	501-0008	1	†*Line, Fuel				Filler Neck) - Early Models
6	193-0207	1	*Cap and Gauge, Fuel Tank (For 2-5/16" Filler Neck) - Late Models				-0597 Fuel Tank Kit. -0984 Fuel Tank Kit
							A07 A.B. (180.)



OPTION 19 BREAKER BOX (HIGH PROFILE)








REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	160-1135	1	Box Assembly, (includes Parts Marked *)
1	160-0931	1	*Guide, Plunger
2	160-0002	1	*Point Set
3	160-0349	1	*Terminal and Block Assembly
4	160-0075	1	*Cam, Point Adjusting
5	160-0428	1	*Strap, Point Set to Terminal
6	160-0150	1	*Gasket, Cover
7	160-0930	1	*Cover, Breaker Box
8	850-0025	2	*Washer, Lock - Spring (#8)
9	812-0077	2	*Screw, Machine - Round Head (#8-32 x 3/8")
10	312-0069	1	*Condenser (.3 Mfd)
11	802-0035	2	*Screw, Socket Head (1/4-20 x 7/8")
12	850-0040	2	*Washer, Lock - Spring (1/4")
13	526-0214	2	Washer, Flat (17/64 ID x 1/2 OD x 1/16 Thk)
14	BUSHING, (GUIDE	·
	160-1041	1	*Begin Spec J
	160-0929	1	Spec A through H
15	160-1040	1	*Gasket, Mounting - Begin Spec J
16	160-0043	1	Gasket, Spec A through H
17	160-0723	1	*Plunger, Breaker
18	160-0261	1	*Wick
19	815-0285	3	"Screw, Machine - Round Head W/ET Washer (#8-32 x 5/16")

- - Parts Included in 160-1135 Breaker Box Assembly.




OPTION 20 THERMO MAGNETIC CHOKE



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	153-0429	1	Replacement Kit (Includes	18	518-0129	1	Ring, Retainer
			Complete Choke - less leads)	. 19	332-0876	1	Terminal Ground
5	153-0385	1	Plate, Mounting	20	LEAD, CHOR	(E	
6	153-0386	1	Body		336-1550	1	Choke to Ground
7	153-0389	1	Cover		336-1549	1	Choke Solenoid Ground
8	153-0391	1	Core, Solenoid	21	815-0161	2	Screw (10-32 x 3/8")
9	153-0395	1	Armature	22	526-0008	1	Washer, Flat
10	307-1203	1	Coil, Solenoid Assembly	23	850-0030	1	Washer (#10), Lock
11	153-0392	1	Frame, Solenoid	24	813-0107	1	Screw (10-32 x 1-1/4")
12	153-0387	1	Spring	25	854-0007	2	Washer (#8), Lock
13	153-0390	1	Lever, Thermostat	26	812-0076	2	Screw (8-32 x 5/16")
14	526-0018	1	Washer	27	862-0015	1	Nut, Hex (5/16-18)
15	870-0134	1	Palnut (1/4-20)	28	854-0017	1	Washer, (5/16), Lock
16	153-0399	2	Insulator	29	526-0022	1	Washer, Flat
17	153-0400	1	Heater Assembly				



OPTION 21 STARTER (SOLENOID SHIFT) KEY 2




						•	\mathcal{D}
REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	
1	191-0790	1	Motor, Starter (Includes Parts	16	191-0749	1	*Lever Assembly
			Marked *)	17	191-0750	1	*Spring, Lever
2	191-0508	1	Flange, Starter Motor	18	191-0751	1	*Spring, Lever
3	850-0050	2	Washer, Lock - Spring (3/8")	19	191-0752	1	*Holder, Spring
4	800-0049	1	Screw, Cap - Hex Head	21	191-0754	1	*Washer, Plain
			(3/8-16 x 7/8")	22	191-0755	. 1	*Washer, Plain
5	800-0050	1	Screw, Cap - Hex Head	23	191-0756	1	*Washer, Insulation
			3/8-16 x 1")	24	191-0757	4	*∆Brush
6	850-0050	2	Washer, Lock - Spring (3/8")	25	191-0758	4	*Spring, Brush
7	102-0455	2	Screw, Cap - Hex Head (Special)	26	191-0759	2	*Bolt, Through
8	134-2131	1	Baffle, Air	27	191-0760	3	*Screw, Machine
9	191-0806	1	*Yoke Assembly (Frame) -	28	191-0761	1	*Switch Assembly, Solenoid
			(Includes Parts Marked △)	29	191-0762	1	*∆Coil Assembly, Field
10	191-0743	1	*Armature	30	191-0763	1	*Bearing, Front
11	191-0744	1	*Clutch	31	191-0764	1	*Bearing, Rear
12	191-0745	1	*Stop, Pinion	32	191-0765	4	*∆Pole Shoe
13	191-0746	1	*Ring	33	191-0766	4	*∆Screw
14	191-0747	1	*Washer, Plain				

- * Parts Included in 191-0790 Starter Motor. Δ Parts Included in 191-0806 Yoke Assembly.



OPTION 22 GOVERNOR CONTROL (VARIABLE SPEED)



FS-1203


REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	152-0085	i	Bracket and Control Arm Assembly Variable Speed - Complete (Includes Parts Marked *)
1	800-0005	1	*Screw, Cap - Hex Head (1/4-20 x 3/4")
2	526-0015	2	*Washer, Flat (9/32" ID x 9/16" OD x 1/16" Thk)
3	152-0083	1	*Lever, Control
4	815-0199	2	*Screw, Machine - Fillister Head (#10-32 c 5/16")
5	152-0086	1	*Bracket, Mounting
6	870-0131	2	*Nut, Hex with ET Lock Washer (#10-32)
8	152-0041	1	*Washer, Tension
9	870-0065	1	*Nut, Hex - Self Locking (1/4-20)
10	152-0090	1	Stud, Speed Adjusting
11	150-0621	1	Nut, Special - Speed Adjusting Stud
12	821-0008	2	Screw, Cap - Hex Head Locking (1/4-20 x 5/16")
13	150-1000	1	Extension, Governor Arm
14	815-0181	1	Screw, Cap - Hex Head with ET Lock Washer (#10-32 x 1/2")

Parts Included in 152-0085 Bracket and Arm Assembly.

OPTION 23 FUEL FILTER

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	149-0079	1	Bowl Assembly, Sediment - Complete (Includes Parts Marked *)
2	149-0150	1	*Bowl Only
3	149-0149	1	*Gasket, Bowl Mounting
4	149-0202	1	*Screen

* - Parts Included In 149-0079 Sediment Bowl Assembly.





OPTION 24 CARBURETOR PARTS (GASOLINE, ELECTRIC CHOKE) SPEC G ONLY)

REF.	PART NO.	QTY. USED		
	141-0792	1	Carburetor, Gasoline - Electric Choke (Includes Mounting Gasket)	₩.
	143-0332	1	Kit, Carburetor Repair (Includes Parts Marked **)	
	143-0201	1	**Kit, Carburetor Gasket (Includes Parts Marked *)	4 17 15
	141-0281	1	*Gasket, Carburetor Flange	30 🙀 💹 19 18→🛢
1	143-0202	1	Valve, Throttle	
3	143-0204	1	Valve, Choke - Electric Choke	16
4	143-0330	1	**Needle, Idle Jet and High Speed Adjusting	
5	143-0329	1	**Nozzle	
6	143-0315	1	Shaft, Choke - Electric Choke	6 3
7	143-0208	1	Screw and Gasket, Bowl	13 (1) -12
8	143-0015	1	*Gasket, Fuel Inlet Valve	
9	143-0209	1	*Gasket, Bowl Screw	8 4 4
10	143-0105	1	Float and Lever	
11	143-0210	1	Bowl	
12	143-0077	1	*Gasket, Bowl Ring	14 5
13	141-0703	1	**Pin, Float Lever	
14	143-0341	1	**Valve, Fuel Inlet	
15	143-0213	1	Screw, Idle Adjusting	10
16	812-0014	4	**Screw (#3-48 x 3/16) - Choke and Throttle Valve	
17	143-0110	1	Plug Expansion	-11
18	143-0214	1	Spring, Throttle Adjusting Screw	
19	143-0112	1	Spring, Idle Adjusting Screw	
29	143-0342	1	Diaphragm - Electric Choke	9 -9-7
30	854-0003	4	**Washer, Lock (It #3)	


- * Parts Included in 143-0201 Carburetor Gasket Kit.
- ** Parts Included in 143-0332 Carburetor Repair Kit.







OPTION 25 CARBURETOR PARTS (GAS-GASOLINE, MANUAL CHOKE) SPEC G ONLY

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	143-033B	1	Carburetor, Gas-Gasoline
			Manual Choke (Includes
			Mounting Gasket)
	143-0332	1	Kit, Carburetor Repair
			(Includes Parts Marked **)
	143-0201	1	**Kit, Carburetor Gasket
	444 6004		(Includes Parts Marked *)
	141-0281	1	*Gasket, Carburetor Flange
1 3	143-0202	1	Valve, Throttle
4	143-0220 143-0330	1	Valve, Choke - Manual Choke
4	143-0330	ľ	**Needle, Idle Jet and High
5	143-0329	1	Speed Adjusting **Nozzle
6	143-0329	1	Shaft and Lever, Choke -
O	143-0221	ļ	Manual Choke
7	143-0208	1	Screw and Gasket, Bowl
8	143-0015	1	*Gasket, Fuel Inlet Valve
9	143-0209	1	*Gasket, Bowl Screw
10	143-0105	į	Float and Lever
11	143-0210	i	Bowl
12	143-0077	1	*Gasket, Bowl Ring
13	141-0703		**Pin. Float Lever
14	143-0341		**Valve, Fuel Inlet
15	143-0213	2	Screw, Idle Adjusting
16	812-0014		**Screw (#3-48 x 3/16") - choke
			and Throttle Valve
17	143-0110	1	Plug. Expansion
18	143-0214	1	Spring, Throttle Adjusting
			Screw
19	143-0112	2	Spring, Idle Adjusting Screw
24	145-0308	1	Tube, Gas Inlet - Gas-Gasoline Only
27	854-0003	4	**Washer, Lock (It #3)










OPTION 26 CARBURETOR PARTS (GAS-GASOLINE, ELECTRIC CHOKE) SPEC G ONLY

REF.		QTY. USED	PART DESCRIPTION	The state of the s
	143-0339	1	Carburetor, Gas-Gasoline Electric Choke (Includes Mounting Gasket)	
	143-0332	1	Kit, Carburetor Repair (Includes Parts Marked **)	4 17 15
	143-0201	1	**Kit, Carburetor Gasket (Includes Parts Marked *)	4 - 17 - 15
	141-0281	1	*Gasket, Carburetor Flange	30 \$\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\
1	143-0202	1	Valve, Throttle	16
3	143-0204	1	Valve, Choke - Electric Choke	
4	143-0330	1	**Needle, Idle Jet and High Speed Adjusting	
5	143-0329	1	"Nozzle	
6	143-0315	1	Shaft, Choke - Electric Choke	6 3
7	143-0208	1	Screw and Gasket, Bowl	13' \(\)12
8	143-0015	1	*Gasket, Fuel Inlet Valve	
9	143-0209	1	*Gasket, Bowl Screw	8 → ♣
10	143-0105	1	Float and Lever	· 🐧 👖
11	143-0210	1	Bowl	14<
12	143-0077	1	*Gasket, Bowl Ring	
13	141-0703	1	"Pin, Float Lever	10.00m
14	143-0341	1	**Valve, Fuel Inlet	10
15	143-0213	2	Screw, Idle Adjusting	
16	812-0014	4	**Screw (#3-48 x 3/16") - choke and Throttle Valve	
17	143-0110	1	Plug, Expansion	+11
18	143-0214	1	Spring, Throttle Adjusting Screw	
19	143-0112	2	Spring, Idle Adjusting Screw	9 -9-7
24	145-0308	1	Tube, Gas Inlet	
29	143-0342	1	Diaphragm - Electric Choke	
30	854-0003	4	*Washer, Lock (It #3)	


- * Parts Included in 143-0201 Carburetor Gasket Kit.
- ** Parts Included in 143-0332 Carburetor Repair Kit.







OPTION 27 CARBURETOR PARTS (GAS) SPEC G ONLY


REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	141-0840	1	Carburetor, Gas (Includes Mounting Gasket)
	143-0332	1	Kit, Carburetor Repair (Includes Parts Marked **)
	143-0201	1	**Kit, Carburetor Gasket (Includes Parts Marked *)
	141-0281	1	*Gasket, Carburetor Flange
1	143-0202	1	Valve, Throttle
7	143-0208	1	Screw and Gasket, Bowl
9	143-0209	1	*Gasket, Bowl Screw
11	143-0210	1	Bowl
12	143-0077	1	*Gasket, Bowl Ring
15	143-0213	1	Screw, Idle Adjusting
16	812-0014	4	**Screw (#3-48 x 3/16") - Choke and Throttle Valve
17	143-0110	1	Plug, Expansion
18	143-0214	1	Spring, Throttle Adjusting Screw
19	143-0112	1	Spring, Idle Adjusting Screw
24	145-0308	1	Tube, Gas Inlet
28	505-0008	1	Plug (1/8")



^{** -} Parts Included in 143-0332 Carburetor Repair Kit.












OPTION 28 CARBURETOR PARTS (GASOLINE, ELECTRIC CHOKE) BEGIN SPEC H

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	
	141-0879	1	Carburetor, Gasoline - Electric Choke (Includes Mounting Gasket)	18
	141-0797	1	Kit, Carburetor Repair (Includes Parts Marked *)	
	141-0748	1	*Kit, Carburetor Gasket (Includes Parts Marked £)	
	141-0281	1	£*Gasket, Carburetor Flange	
1	141-0708	1	Bowl, Fuel	
2	141-0741	1	Plate, Choke	
3	141-0698	4	Screw & Washer, Choke and Throttle Plate Mounting	3
4	141-0706	1	Plate, Throttle	
5	141-0705	1	*Retainer, Seal	
6	141-0661	1 :	£*Seal, Rubber	
7	141-0830	1	*Valve Seat Assembly, Fuel	
8	141-0811	1	£Washer, Fuel Valve Seat	
9	141-0703	1	*Shaft, Float	
10	141-0702	1	Float Assembly	
11	141-0701	1 :	£*Gasket, Bowl to Body	
12	141-0700	1	Screw, Throttle Stop	
13	141-0711	1	Spring, Throttle Stop	
14	141-0713	1	Needle, Idle Adjusting	
15	141-0710	1	Spring, Idle Needle	
	141-0077	1 :	E*Washer, Main Jet Assembly	
17	141-0712	1	Jet Assembly, Main (Adjustable)	
	141-0679	1	Shaft, Choke	
22	141-0709	1	Shaft and Lever Throttle	
29	141-0799	1	*Spring, Float	




- * Parts Included in 141-0797 Carburetor Repair Kit. $\mathfrak L$ Parts Included in 141-0748 Carburetor Gasket Kit.





OPTION 29 CARBURETOR PARTS (GAS-GASOLINE, MANUAL CHOKE) BEGIN SPEC H

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION		
	141-0887	1	Carburetor, Gas-Gasoline		
			Manual Choke (Includes		
			Mounting Gasket)		
	141-0747	1	Kit, Carburetor Repair		
			(Includes Parts Marked *)		
	141-0748	1	*Kit, Carburetor Gasket		
			(Includes Parts Marked £)		
	141-0281	1	£*Gasket, Carburetor Flange		
1	141-0708	1	Bowl, Fuel		
2	141-0741	1	Plate, Choke		
3	141-0698	4	Screw & Washer, Choke and		
			Throttle Plate Mounting		
4	141-0706	1	Plate, Throttle		
5	141-0705	1	*Retainer, Seal		
6	141-0661	1	£*Seal, Rubber		
7	141-0830	1	"Valve Seat Assembly, Fuel		
8	141-0811	1	£Washer, Fuel Valve Seat		
9	141-0703	1	*Shaft, Float		
10	141-0702	1	Float Assembly		
11	141-0701	1	£*Gasket, Bowl to Body		
12	141-0700	1	Screw, Throttle Stop		
13	141-0711	1	Spring, Throttle Stop		
14	NEEDLE, IDLE ADJUSTING				
	141-0713	2	Gas-Gasoline Units		
15	SPRING, IDL	E NEED	ĻĒ		
	141-0710	2	Gas-Gasoline Units		
16	141-0077	1	£*Washer, Main Jet Assembly		
17	141-0712	1	Jet Assembly, Main (Adjustable)		
18	SHAFT, CHO				
	141-0742	1	Manual Choke Units		
19	141-0699	1	Washer		
20	141-0697	1	£*Seal, Felt		
21	141-0203	1	*Retainer, Felt Seal		
22	141-0709	1	Shaft and Lever, Throttle		
23	141-0733	1	Spring, Main Gas Needle		
24	141-0734	1	Needle, Main Gas Adjusting		
29	141-0799	1	*Spring, Float		



^{£ -} Parts Included in 141-0748 Carburetor Gasket Kit.






FS-1206





OPTION 30 CARBURETOR PARTS (GAS-GASOLINE, ELECTRIC CHOKE) BEGIN SPEC H

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION		
	141-0888	1	Carburetor, Gas-Gasoline		
			Electric Choke (Includes		
			Mounting Gasket)		
	141-0747	1	Kit, Carburetor Repair		
			(Includes Parts Marked *)		
	141-0748	1	*Kit, Carburetor Gasket		
			(Includes Parts Marked £)		
	141-0281	1	£ ⁻ Gasket, Carburetor Flange		
1	141-0708	1	Bowl, Fuel		
2	141-0741	1	Plate, Choke		
3	141-0698	4	Screw & Washer, Choke and		
			Throttle Plate Mounting		
4	141-0706	1	Plate, Throttle		
5	141-0705	1	*Retainer, Seal		
6	141-0661		£*Seal, Rubber		
7	141-0830	1	*Valve Seat Assembly, Fuel		
8	141-0811	1	£Washer. Fuel Valve Seat		
9	141-0703	1	*Shaft, Float		
10	141-0702	1	Float Assembly		
11	141-0701	1	£*Gasket, Bowl to Body		
12	141-0700	1	Screw, Throttle Stop		
13	141-0711	1	Spring, Throttle Stop		
14	NEEDLE, IDLE ADJUSTING				
	141-0713	2	Gas-Gasoline Units		
15	SPRING, ID	LE NEEDI			
	141-0710	2	Gas-Gasoline Units		
16	141-0077	1	£*Washer, Main Jet Assembly		
17	141-0712	1	Jet Assembly, Main (Adjustable)		
18	SHAFT, CH				
	141-0679	1	Electric Choke		
22	141-0709	1	Shaft and Lever, Throttle		
23	141-0733	1	Spring, Main Gas Needle Gas-Gasoline Units		
24	141-0734	1	Needle, Main Gas Adjusting - Gas-Gasoline Units		
29	141-0799	1	*Spring, Float		



^{£ -} Parts Included in 141-0748 Carburetor Gasket Kit.






FS-1205




OPTION 31 CARBURETOR PARTS (GAS) BEGIN SPEC H

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION		
	141-0892	1	Carburetor, Gas (Includes Mounting Gasket)		
	141-0747	1	Kit, Carburetor Repair (Includes Parts Marked *)		
	141-0748	1	*Kit, Carburetor Gasket (Includes Parts Marked £)		
	141-0281	1	£*Gasket, Carburetor Flange		
1	141-0708	1	Bowl, Fuel		
3	141-0698	2	Screw & Washer, Choke and Throttle Plate Mounting		
4	141-0706	1	Plate, Throttle		
5	141-0705	1	*Retainer, Seal		
6	141-0661	1	£*Seal, Rubber		
11	141-0701	1	£*Gasket, Bowl to Body		
12	141-0700	1	Screw, Throttle Stop		
13	141-0711	1	Spring, Throttle Stop		
14	·				
		1	Gas Only Units		
			(Not Available)		
15	5 SPRING, IDLE NEEDLE				
	141-0710	1	Gas Only Units		
16	141-0077	1	£*Washer, Main Jet Assembly		
22	141-0709	1	Shaft and Lever, Throttle		
23	141-0733	1	Spring, Main Gas Needle		
24	141-0734	1	Needle, Main Gas Adjusting		
25	141-0736	1	Nut, Bowl		
29	141-0799	1	*Spring, Float		
30	505-0008	1	Plug, Pipe (1/8")		
* - Parts Included in 141-0747 Carburetor Repair Kit.					


£ - Parts Included in 141-0748 Carburetor Gasket Kit.








MISCELLANEOUS OPTIONAL PARTS









MISCELLANEOUS OPTIONAL PARTS

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART Description
1	102-0558	1	Heater, Oil Base	15	193-0108	1	Sender, Oil Pressure
	ARM, GOVE	RNOR PU	LL - CONSTANT SPEED	16	502-0053	1	Elbow, Street (45°)
	GOVERNOR			17	153-0327	1	Bracket, Choke
2	150-0635	1	Rear Pull	18	518-0176	1	Clip, Choke Bracket
3	150-0755	1	Front Pull	19	134-1889	1	Guard, Flywheel - Rotating
4	150-0790	1	Left Pull	20	309-0237	1	Pressure Switch - Low Oil
5	150-0752	1	Right Pull				(8-10 PSI)
6	154-0973	2	Gasket, Exhaust Manifold	21	153-0464	1	Bracket, Choke Cable
7	154-0998	1	Manifold, Exhaust	22	153-0351	1	Cable, Choke Short
8	155-0906	1	Muffler, Exhaust	23	155-1660	2	Muffler (Ray Gun)
9	140-0645	1	Adapter, Air Cleaner	24	155-1239	2	Clamp, Muffler (1-5/8")
10	140-0500	1	Cleaner, Air	25	154-1757	2	Adapter Assembly, Manifold
11	140-0519	1	Band, Air Cleaner				
12	503-0365	2	Clamp, Air Cleaner Hose				
13	503-0444	1	Hose, Air Cleaner (2" ID 10 x 30" lg)				
14	505 -0 618	1	Cap, Pipe (1-1/2")				

